

# RS485 Index Command List.

*OM70 laser point / laser line –  
Distance sensors.*



## Contents

<b>1</b>	<b>Introduction .....</b>	<b>3</b>
1.1	UART Interface Settings .....	3
<b>2</b>	<b>Command Structure .....</b>	<b>3</b>
<b>3</b>	<b>Index Command List .....</b>	<b>4</b>
3.1	Application Errors .....	4
3.2	Device identification .....	4
3.3	Communication features .....	5
3.4	User interface features .....	5
3.5	Measurement features .....	6
3.6	Output configuration .....	7
3.7	Diagnosis features .....	8
3.8	Configuration storage features .....	9
<b>4</b>	<b>Appendix.....</b>	<b>14</b>
4.1	Dependencies .....	14
<b>5</b>	<b>History of changes .....</b>	<b>15</b>

# 1 Introduction


This manual supplements the manual "RS485 Protocol Structure" and is valid for the Baumer OM70 laser point / laser line sensors.

## 1.1 UART Interface Settings

Index Command	Value
Baud rate at power up	57600
Databits	8
Startbit	1
Stopbit	1
Parity	Even

# 2 Command Structure

An RS485 command is structured as follows (RS485 unlock):



The information to be transmitted is called PAYLOAD and has to be sent in a so-called frame so that the command can be recognized and processed.

This frame always has the same structure and contains a start, a device address, a PAYLOAD, a checksum and an end.

START	DEVICE ADDR	PAYLOAD	CHECKSUM	END
1 char	2 char	n char	4 char	2 char
:	01...99	Index Command List	****	\r\n

### 3 Index Command List

Values marked with \* are the Factory settings

<b>6</b> ( 0x6 )	RW		<b>Baudrate</b> Communication baud rate	Stored in configuration yes
	0	UINT8	0    38'400 1 *  57'600 2    115'200	

Annotations:

- Index: 6 (0x6)
- Read/Write: RW
- Content: Baudrate, Communication baud rate
- Can be stored: yes
- Empty: (empty cell)
- Offset: 0
- Data Type: UINT8
- Description: (here 0 stands für 38400....)

#### 3.1 Application Errors

<b>0</b> ( 0x0 )	R		<b>Application error</b> Contains the application error code of the last command. If an application error occurs, it is signalled using the underlying protocol. The error code has to be read immediately after the error is signalled. It will be overwritten by any other command.	Stored in configuration no
		UINT32	Application error 0    no error 1    value not accessible 99   argument out of range	

#### 3.2 Device identification

<b>1</b> ( 0x1 )	R		<b>Vendor info</b> Vendor information	Stored in configuration no
		UINT32	Vendor id 1    Baumer Electric AG	
		STRING 65	Vendor name  default: Baumer Electric AG	

<b>2</b> ( 0x2 )	R		<b>Device info</b> Device information	Stored in configuration no
		UINT32	Device id	
		UINT32	Product id Material number	
		STRING 65	Sensor type Eg. OXE7.E25T-MB3E.SIMD.A7	
		STRING 15	Serial number 1234567890AB	

### 3.3 Communication features

<b>5</b> ( 0x5 )	RW		<b>Bus address</b>	Stored in configuration yes
		UINT8	Bus address  Value range: 1 . . . 99	

<b>6</b> ( 0x6 )	RW		<b>Baudrate</b> Communication baud rate	Stored in configuration yes
		UINT8	Baudrate 0        38'400 1 *     57'600 2        115'200 3        230'400 4        460'800 5        921'600 6        1'500'000	

### 3.4 User interface features

<b>10</b> ( 0xA )	RW		<b>RS485 lock</b> Access lock for RS485. If the lock is activated, the sensor can be controlled using the touch buttons and all RS485 commands will be rejected (except access to this index). If the lock is deactivated, the sensor can be controlled using RS485. In this case, all physical outputs (analog, switching and alarm out) and the LEDs will be set to a fixed state. Writing into this index also automatically deactivates the diagnose mode (50), if it was previously enabled.	Stored in configuration no
		UINT8	RS485 lock 0        Lock deactivated 1 *     Lock activated	

<b>11</b> ( 0xB )	RW		<b>Output reactivation</b> If enabled, the physical outputs (analog, switching and alarm out) will be re-enabled. Be aware that using physical outputs and RS485 simultaneously may lead to interferences. When RS485 lock (10) is active, the outputs are also activated regardless of this index. This index is not accessible during RS485 streaming mode (44).	Stored in configuration yes
		UINT8	Output reactivation 0 *     Outputs deactivated 1        Outputs activated	

<b>15</b> ( 0xF )	RW		<b>Display language</b>	Stored in configuration yes
		UINT8	Display language 0 *     English 1        German 2        Italian 3        French	

<b>17</b> ( 0x11 )	RW		<b>Touch button lock</b>	Stored in configuration yes
		UINT8	Touch button lock 0 * Touch buttons not locked 1 Touch buttons locked	
<b>18</b> ( 0x12 )	RW		<b>Trigger mode</b>	Stored in configuration yes
		UINT8	Trigger mode This index defines how the sensor outputs will react on changes on the trigger/Sync line. When "Triggered free running measurement" is set, the sensor outputs will be continuously updated when the trigger/Sync line is low. When "Triggered single shot measurement" is set, the outputs are updated only with falling edge on the trigger/Sync line. Trigger mode cannot be changed during RS485 streaming mode (44) and during diagnose mode (50). 0 * Triggered free running measurement 1 Triggered single shot measurement	

### 3.5 Measurement features

<b>20</b> ( 0x14 )	R		<b>Measurement type selection</b>	Stored in configuration no
		UINT8	Measurement type selection Measurement type to use for outputs. 27 * Distance 34 Tolerance	
<b>21</b> ( 0x15 )	R		<b>Measurement value</b> Measurement value selected by the "Measurement type selection" index.	Stored in configuration no
		FLOAT32	Measurement value [mm]	
		UINT8	Quality Quality of the optical input signal and other additional information to measurement. 0 Valid 1 Low signal 4 No signal 6 Lost trigger 7 Poor quality and lost trigger 8 Poor quality 9 Invalid signal 10 Too much ambient light 11 Behind range 12 Before range 13 Warm-up	
<b>33</b> ( 0x21 )	RW		<b>Precision</b> Adjust the filtering of the measured values.	Stored in configuration yes
		UINT8	Precision 0 Standard 1 High 2 * Very high 3 Highest	

<b>34</b> ( 0x22 )	RW		<b>Laser off data hold</b> If activated, the measurement will be suspended and the laser is switched off. All outputs will hold the current value. If deactivated, the measurement will continue. This index will also be activated with the trigger line being high or trigger mode (18) being set to „Triggered single shot measurement“.	Stored in configuration no
		UINT8	Laser off data hold 0 * Measurement is running 1 Measurement is holding	

### 3.6 Output configuration

<b>40</b> ( 0x28 )	RW		<b>Digital output configuration</b> Settings of the digital output pin. The reply to configuring this index may take up to t_answer_extended (200ms).	Stored in configuration yes
		FLOAT32	Switch point 1 [mm]	
		FLOAT32	Switch point 2 [mm]	
		UINT8	Digital output type 0 Point 1 * Window	
		UINT8	Digital output polarity 0 * Active high 1 Active low	

<b>41</b> ( 0x29 )	RW		<b>Analog output configuration</b> The analog output can be set as current or voltage output.	Stored in configuration yes
		UINT8	Analog output type 0 * Current 1 Voltage	
		UINT8	Analog output slope Slope of the analog characteristic curve. Can be positive (minimum output at minimum measurement value, fullscale output at maximum measurement value) or negative (vice versa). 0 * Positive 1 Negative	

<b>42</b> ( 0x2A )	RW		<b>Analog output scaling</b> Points within the measuring range where the analog output value reaches its minimum/full scale value (depends on "Analog output slope" setting).	Stored in configuration yes
		FLOAT32	Analog scaling near point [mm]	
		FLOAT32	Analog scaling far point [mm]	

<b>43</b> ( 0x2B )	W		<b>Set analog out scale to MAX command</b> Sets the analog output scaling to its maximum values.	Stored in configuration no
		UINT8	Set analog out scale to MAX command 1 Set analog out scale to MAX.	

<b>44</b> ( 0x2C )	RW		<b>RS485 streaming mode</b> When enabled, measured data is pushed to the RS485 bus without request as soon as it is available (the used trigger mode (18) has to be considered). Data is sent in the format corresponding to index "measurement value" (21) with special message type - 'S' for human readable coding (instead of common 'A' for ACK), 0x08 for machine coding. During RS485 streaming mode it is only possible to configure the sensor while the trigger line is high. All other outputs (11) are deactivated when RS485 streaming mode is enabled. The reply to configuring this index may take up to t_answer_extended (200ms).	Stored in configuration no
		UINT8	Streaming mode 0 * RS485 streaming mode disabled 1 RS485 streaming mode enabled	
<b>45</b> ( 0x2D )	RW		<b>Digital out hysteresis configuration</b> Settings of the digital output hysteresis - its width and alignment. Values for Hysteresis 1 and Hysteresis 2 must be equal.	Stored in configuration yes
		FLOAT32	Hysteresis 1 Width of hysteresis 1 [mm] (for SP1)	
		FLOAT32	Hysteresis 2 Width of hysteresis 2 [mm] (for SP2)	
		UINT8	Hysteresis alignment 4 INNER ALIGNMENT 5 * OUTER ALIGNMENT	

### 3.7 Diagnosis features

<b>50</b> ( 0x32 )	RW		<b>Diagnose mode</b> If diagnose mode is activated, the diagnosis features (live monitor) can be used. To activate diagnose mode, following preconditions need to be met: trigger line signal is low, trigger mode (18) is configured to "Triggered free running measurement", the RS485 streaming mode (44) is disabled and the measurement is running (34). To deactivate diagnose mode or to read its state, no preconditions need to be met.	Stored in configuration no
		UINT8	Diagnose mode 0 * Deactivated 1 Activated	
<b>54</b> ( 0x36 )	R		<b>Live monitor</b> Live monitor values	Stored in configuration no
		FLOAT32	Measuring rate [Hz]	
		FLOAT32	Current distance [mm]	
		FLOAT32	Object reflectivity exposure reserve [-] (max possible exposure divided by current exposure)	



### 3.8 Configuration storage features

<b>200</b> ( 0xC8 )	W		<b>Load configuration command</b> Loads the selected configuration to ram (current configuration). For permanent storage of the loaded values, the "Store configuration command" has to be used. This command is not accessible during RS485 streaming mode (44) and during diagnose mode (50).	Stored in configuration no
		UINT8	Configuration number 0 Active config 1 Config 1 2 Config 2 3 Config 3	
<b>201</b> ( 0xC9 )	W		<b>Store configuration command</b> Permanently stores the current configuration. This command is not accessible during the RS485 streaming mode (44).	Stored in configuration no
		UINT8	Configuration number 0 Active config      Current configuration will be stored to the active configuration. 1 Config 1            Current configuration will be stored to Config 1. 2 Config 2            Current configuration will be stored to Config 2. 3 Config 3            Current configuration will be stored to Config 3.	
<b>202</b> ( 0xCA )	W		<b>Reset to factory settings command</b> All configurations will be reset to factory settings. The sensor will reboot after execution of this command.	Stored in configuration no
		UINT8	Reset to factory settings command 0 Reset to factory settings	
<b>207</b> ( 0xCF )	R		<b>Configuration 1</b> Values stored in configuration 1.	Stored in configuration no
		UINT32	Product id Material number	
		UINT8	Measurement type selection Measurement type to use for outputs. 27 * Distance 34 Tolerance	
		UINT8	Precision 0 Standard 1 High 2 * Very high 3 Highest	
		UINT8	Trigger mode This index defines how the sensor outputs will react on changes on the trigger/Sync line. When "Triggered free running measurement" is set, the sensor outputs will be continuously updated when the trigger/Sync line is low. When "Triggered single shot measurement" is set, the outputs are updated only with falling edge on the trigger/Sync line. Trigger mode cannot be changed during RS485 streaming mode (44) and during diagnose mode (50). 0 * Triggered free running measurement 1 Triggered single shot measurement	
		UINT8	Analog output type 0 * Current 1 Voltage	
		UINT8	Analog output slope Slope of the analog characteristic curve. Can be positive (minimum output at minimum measurement value, fullscale output at maximum measurement value) or negative (vice	

			versa). 0 * Positive 1 Negative
		UINT8	Digital output type 0 Point 1 * Window
		UINT8	Digital output polarity 0 * Active high 1 Active low
		UINT8	Hysteresis alignment 4 INNER ALIGNMENT 5 * OUTER ALIGNMENT
		FLOAT32	Analog scaling near point [mm]
		FLOAT32	Analog scaling far point [mm]
		FLOAT32	Switch point 1 [mm]
		FLOAT32	Switch point 2 [mm]
		FLOAT32	Hysteresis 1 Width of hysteresis 1 [mm] (for SP1)
		FLOAT32	Hysteresis 2 Width of hysteresis 2 [mm] (for SP2)

<b>208</b> ( 0xD0 )	R		<b>Configuration 2</b> Values stored in configuration 2.	Stored in configuration no
		UINT32	Product id Material number	
		UINT8	Measurement type selection Measurement type to use for outputs. 27 * Distance 34 Tolerance	
		UINT8	Precision 0 Standard 1 High 2 * Very high 3 Highest	
		UINT8	Trigger mode This index defines how the sensor outputs will react on changes on the trigger/Sync line. When "Triggered free running measurement" is set, the sensor outputs will be continuously updated when the trigger/Sync line is low. When "Triggered single shot measurement" is set, the outputs are updated only with falling edge on the trigger/Sync line. Trigger mode cannot be changed during RS485 streaming mode (44) and during diagnose mode (50). 0 * Triggered free running measurement 1 Triggered single shot measurement	
		UINT8	Analog output type 0 * Current 1 Voltage	
		UINT8	Analog output slope Slope of the analog characteristic curve. Can be positive (minimum output at minimum measurement value, fullscale output at maximum measurement value) or negative (vice versa). 0 * Positive 1 Negative	

		UINT8	Digital output type 0 Point 1 * Window
		UINT8	Digital output polarity 0 * Active high 1 Active low
		UINT8	Hysteresis alignment 4 INNER ALIGNMENT 5 * OUTER ALIGNMENT
		FLOAT32	Analog scaling near point [mm]
		FLOAT32	Analog scaling far point [mm]
		FLOAT32	Switch point 1 [mm]
		FLOAT32	Switch point 2 [mm]
		FLOAT32	Hysteresis 1 Width of hysteresis 1 [mm] (for SP1)
		FLOAT32	Hysteresis 2 Width of hysteresis 2 [mm] (for SP2)

<b>209</b> ( 0xD1 )	R		<b>Configuration 3</b> Values stored in configuration 3.	Stored in configuration no
		UINT32	Product id Material number	
		UINT8	Measurement type selection Measurement type to use for outputs. 27 * Distance 34 Tolerance	
		UINT8	Precision 0 Standard 1 High 2 * Very high 3 Highest	
		UINT8	Trigger mode This index defines how the sensor outputs will react on changes on the trigger/Sync line. When "Triggered free running measurement" is set, the sensor outputs will be continuously updated when the trigger/Sync line is low. When "Triggered single shot measurement" is set, the outputs are updated only with falling edge on the trigger/Sync line. Trigger mode cannot be changed during RS485 streaming mode (44) and during diagnose mode (50). 0 * Triggered free running measurement 1 Triggered single shot measurement	
		UINT8	Analog output type 0 * Current 1 Voltage	
		UINT8	Analog output slope Slope of the analog characteristic curve. Can be positive (minimum output at minimum measurement value, fullscale output at maximum measurement value) or negative (vice versa). 0 * Positive 1 Negative	
		UINT8	Digital output type 0 Point 1 * Window	

		UINT8	Digital output polarity 0 * Active high 1 Active low
		UINT8	Hysteresis alignment 4 INNER ALIGNMENT 5 * OUTER ALIGNMENT
		FLOAT32	Analog scaling near point [mm]
		FLOAT32	Analog scaling far point [mm]
		FLOAT32	Switch point 1 [mm]
		FLOAT32	Switch point 2 [mm]
		FLOAT32	Hysteresis 1 Width of hysteresis 1 [mm] (for SP1)
		FLOAT32	Hysteresis 2 Width of hysteresis 2 [mm] (for SP2)

<b>210</b> ( 0xD2 )	R		<b>Active configuration</b> Values stored in active configuration.	Stored in configuration no
		UINT32	Product id Material number	
		UINT8	Measurement type selection Measurement type to use for outputs. 27 * Distance 34 Tolerance	
		UINT8	Precision 0 Standard 1 High 2 * Very high 3 Highest	
		UINT8	Trigger mode This index defines how the sensor outputs will react on changes on the trigger/Sync line. When "Triggered free running measurement" is set, the sensor outputs will be continuously updated when the trigger/Sync line is low. When "Triggered single shot measurement" is set, the outputs are updated only with falling edge on the trigger/Sync line. Trigger mode cannot be changed during RS485 streaming mode (44) and during diagnose mode (50). 0 * Triggered free running measurement 1 Triggered single shot measurement	
		UINT8	Analog output type 0 * Current 1 Voltage	
		UINT8	Analog output slope Slope of the analog characteristic curve. Can be positive (minimum output at minimum measurement value, fullscale output at maximum measurement value) or negative (vice versa). 0 * Positive 1 Negative	
		UINT8	Digital output type 0 Point 1 * Window	
		UINT8	Digital output polarity 0 * Active high 1 Active low	

		UINT8	Hysteresis alignment 4 INNER ALIGNMENT 5 * OUTER ALIGNMENT
		FLOAT32	Analog scaling near point [mm]
		FLOAT32	Analog scaling far point [mm]
		FLOAT32	Switch point 1 [mm]
		FLOAT32	Switch point 2 [mm]
		FLOAT32	Hysteresis 1 Width of hysteresis 1 [mm] (for SP1)
		FLOAT32	Hysteresis 2 Width of hysteresis 2 [mm] (for SP2)



## 5 History of changes

Date	Version	Description
10.11.2017	1.0	Document created



Passion for Sensors

**Baumer Group**  
International Sales  
P.O. Box · Hummelstrasse 17 · CH-8501 Frauenfeld  
Phone +41 (0)52 728 1122 · Fax +41 (0)52 728 1144  
sales@baumer.com · www.baumer.com