

This operation manual is intended for users with basic knowledge of electricity and electric devices.

* LSLV-G100 is the official name for G100.

Safety Information

Read and follow all safety instructions in this manual precisely to avoid unsafe operating conditions, property damage, personal injury, or even death.

Safety Symbols in This Manual

Danger

Indicates an imminently hazardous situation which, if not avoided, will result in severe injury or even death.

Warning

Indicates a potentially hazardous situation which, if not avoided, could result in injury or even death.

Caution

Indicates a potentially hazardous situation which, if not avoided, could result in minor injury or property damage.

Safety Information

Danger

- Never remove the product cover or touch the internal printed circuit board (PCB) or any contact points when the power is on. Also, do not start the product when the cover is open. This may cause an electrical shock due to the exposure of high voltage terminals or live parts.
- Even if the power is off, do not open the cover unless it is absolutely necessary like for the wiring operation or for regular inspection. Opening the cover may still cause an electrical shock even after the power is blocked because the product has been charged for a long period of time.
- Wait at least 10 minutes before opening the covers and exposing the terminal connections. Before starting work on the inverter, test the connections to ensure all DC voltage has been fully discharged. Otherwise it may cause an electrical shock and result in personal injury or even death.

 Warning

- Make sure to install ground connection between the equipment and the motor for safe use. Otherwise it may cause an electrical shock and result in personal injury or even death.
- Do not turn on the power if the product is damaged or faulty. If you find that the product is faulty, disconnect the power supply and have the product professionally repaired.
- The inverter becomes hot during operation. Avoid touching the inverter until it has cooled to avoid burns. Avoid touching the inverter until it has cooled to avoid burns.
- Do not allow foreign objects, such as screws, metal chips, debris, water, or oil to get inside the inverter. Allowing foreign objects inside the inverter may cause the inverter to malfunction or result in a fire.
- Do not operate the switch with wet hands. Otherwise it may cause an electrical shock and result in personal injury or even death.
- Check the information about the protection level for the circuits and devices.

The connection terminals and parts below have electrical protection class 0. This means that the protection class of the circuit depends on basic insulation and there is a danger of electric shock if the basic insulation is not working properly. Therefore, take the same protective measures as handling the power line when connecting wires to the terminals or the device below, or when installing or using the devices.

- Multi-function Input: P1-P5, CM
 - Analog Input/Output: VR, V1, I2, AO
 - Digital Output: 24, A1/B1/C1, A2/C2
 - Communication: S+/ S-
 - Fan
- The protection level of this equipment (inverter) is electrical protective class 1.

 Caution

- Do not change the inside of the product at your own discretion. This may result in injury or damage to the product due to failure or malfunction. Also, products changed at your own discretion will be excluded from the product warranty.
- Do not use the inverter for single phase motor operation as it has been designed for three phase motor operation. Using a single phase motor may damage the motor.
- Do not place heavy objects on top of electric cables. Heavy objects may damage the cable and result in electric shock.

Note

Maximum allowed prospective short-circuit current at the input power connection is defined in IEC 60439-1 as 100 kA. Depending on the selected MCCB, the LSLV-G100 Series is suitable for use in circuits capable of delivering a maximum of 100 kA RMS symmetrical amperes at the drive's maximum rated voltage. The following table shows the recommended MCCB for RMS symmetrical amperes.

Remarque

Le courant maximum de court-circuit présumé autorisé au connecteur d'alimentation électrique est défini dans la norme IEC 60439-1 comme égal à 100 kA. Selon le MCCB sélectionné, la série LSLV-G100 peut être utilisée sur des circuits pouvant fournir un courant RMS symétrique de 100 kA maximum en ampères à la tension nominale maximale du variateur. Le tableau suivant indique le MCCB recommandé selon le courant RMS symétrique en ampères.

Working Voltage	UTE100E	UTE100H	UTS150H
240V(50/60Hz)	50 kA	100 kA	100 kA
480V(50/60Hz)	25 kA	65 kA	65 kA

Quick Reference Table

The table below is a summary of situations that users encounter frequently while using the product. For faster and easier information searching, see the table below.

Situation	Ref.
I want to run a slightly higher rated motor than the inverter's rated capacity.	p.169
I want to configure the inverter to start operating as soon as the power source is applied.	p.75
I want to configure the motor's parameters.	p.126
I want to set up sensorless vector control.	p.129
Something seems to be wrong with the inverter or the motor.	p.186 , p.266
What is auto tuning?	p.126
What are the recommended wiring lengths?	p.27
The motor is too noisy.	p.144
I want to apply PID control on my system.	p.118
What are the factory default settings for P1-P5 multi-function terminals?	p.24
I want to review recent fault trip and warning histories.	p.257
I want to change the inverter's operation frequency using a potentiometer.	p.49
I want to install a frequency meter using an analog terminal.	p.25
I want to display the supply current to motor.	p.53
I want to operate the inverter using a multi-step speed configuration.	p.70
The motor runs too hot.	p.167
The inverter is too hot.	p.176
The cooling fan does not work.	p.148
I want to change the items that are monitored on the keypad.	p.276

Table of Contents

1	Preparing the Installation	1
1.1	Product Identification.....	1
1.2	Part Names.....	3
1.3	Installation Considerations.....	5
1.4	Selecting the Installation Site	6
1.5	Cable Selection.....	10
2	Installing the Inverter	11
2.1	Mounting the Inverter	13
2.2	Wiring.....	16
2.3	Post-Installation Checklist.....	32
2.4	Test Run	34
3	Learning to Perform Basic Operations	37
3.1	About the Keypad	37
3.1.1	About the Display.....	38
3.1.2	Operation Keys.....	39
3.1.3	Control Menu	40
3.2	Learning to Use the Keypad	40
3.2.1	Group and Code Selection.....	41
3.2.2	Navigating Directly to Different Codes	42
3.2.3	Setting Parameter Values	43
3.3	Actual Application Examples	44
3.3.1	Acceleration Time Configuration	44
3.3.2	Frequency Reference Configuration	45
3.3.3	Jog Frequency Configuration	46
3.3.4	Parameter Initialization.....	47
3.3.5	Frequency Setting (Keypad) and Operation (via Terminal Input).....	48
3.3.6	Frequency Setting (Potentiometer) and Operation (Terminal Input)	49
3.3.7	Frequency Setting (Potentiometer) and Operation (Keypad).....	51
3.4	Monitoring the Operation.....	53

3.4.1	Output Current Monitoring.....	53
3.4.2	Trip Condition Monitor.....	54
4	Learning Basic Features.....	57
4.1	Setting Frequency Reference.....	60
4.1.1	Keypad as the Source (KeyPad-1 Setting).....	60
4.1.2	Keypad as the Source (KeyPad-2 Setting).....	61
4.1.3	V1 Terminal as the Source.....	61
4.1.4	Built-in Volume Input (V0) as the Source.....	67
4.1.5	Setting a Reference Frequency using Input Current (I2).....	67
4.1.6	Frequency Reference Source Configuration for RS-485 Communication	69
4.2	Frequency Hold by Analog Input.....	69
4.3	Setting Multi-step Frequency.....	70
4.4	Command Source Configuration.....	72
4.4.1	The Keypad as a Command Input Device.....	72
4.4.2	Terminal Block as a Command Input Device (Fwd/Rev Run Commands)	72
4.4.3	Terminal Block as a Command Input Device (Run and Rotation Direction Commands).....	73
4.4.4	RS-485 Communication as a Command Input Device.....	74
4.5	Forward or Reverse Run Prevention.....	74
4.6	Power-on Run.....	75
4.7	Reset and Restart.....	76
4.8	Setting Acceleration and Deceleration Times.....	77
4.8.1	Acc/Dec Time Based on Maximum Frequency.....	77
4.8.2	Acc/Dec Time Based on Operation Frequency.....	78
4.8.3	Multi-step Acc/Dec Time Configuration.....	79
4.8.4	Acc/Dec Time Switch Frequency.....	81
4.9	Acc/Dec Pattern Configuration.....	82
4.10	Stopping the Acc/Dec Operation.....	84
4.11	V/F Control.....	84
4.11.1	Linear V/F Pattern Operation.....	84
4.11.2	Square Reduction V/F Pattern Operation.....	85
4.11.3	User V/F Pattern Operation.....	86

Table of Contents

4.12	Torque Boost.....	88
4.12.1	Manual Torque Boost.....	88
4.12.2	Auto Torque Boost.....	89
4.13	Motor Output Voltage Adjustment	90
4.14	Start Mode Setting.....	90
4.14.1	Accelerating Start.....	90
4.14.2	DC Braking After Start.....	91
4.14.3	Initial Excitation of Stop Status (Pre-excite).....	92
4.15	Stop Mode Setting.....	92
4.15.1	Deceleration Stop.....	92
4.15.2	DC Braking After Stop.....	93
4.15.3	Free Run Stop.....	94
4.15.4	Power Braking.....	94
4.16	Frequency Limit.....	95
4.16.1	Frequency Limit Using Maximum Frequency and Start Frequency.....	95
4.16.2	Frequency Limit Using Upper and Lower Limit Frequency Values.....	96
4.16.3	Frequency Jump.....	97
4.17	2 nd Operation Mode.....	98
4.18	Multi-Function Input Terminal Control.....	99
4.19	Fire Mode Operation.....	100
5	Learning Advanced Features	103
5.1	Operating with Auxiliary References.....	105
5.2	Jog Operation.....	109
5.2.1	Jog Operation 1-Forward	109
5.2.2	Jog Operation 2-Fwd/Rev Jog by Multi-Function Terminal.....	110
5.3	Up-down Operation.....	111
5.4	3-Wire Operation.....	113
5.5	Safe Operation mode.....	114
5.6	Dwell Operation.....	115
5.7	Slip Compensation Operation.....	117
5.8	PID Control.....	118
5.8.1	Basic PID Operation.....	119

5.8.2	Pre-PID Operation.....	124
5.8.3	PID Operation Sleep mode	124
5.8.4	PID Switching (PID Openloop).....	125
5.9	Auto-tuning.....	126
5.10	Sensorless Vector Control for Induction Motors.....	129
5.10.1	Sensorless Vector Control Operation Setting for Induction Motors.....	130
5.10.2	Sensorless Vector Control Operation Guide for Induction Motors.....	133
5.11	Energy Buffering Operation (Kinetic Energy Buffering)	135
5.12	Energy Saving Operation.....	138
5.12.1	Manual Energy Saving Operation.....	138
5.12.2	Automatic Energy Saving Operation.....	138
5.13	Speed Search Operation.....	139
5.14	Auto Restart Settings	143
5.15	Operational Noise Settings (Change of Carrier Frequency Settings)	144
5.16	2 nd Motor Operation.....	146
5.17	Commercial Power Source Transition.....	147
5.18	Cooling Fan Control	148
5.19	Input Power Frequency and Voltage Settings.....	149
5.20	Parameter Initialization.....	150
5.21	Parameter Lock	151
5.22	Changed Parameter Display.....	152
5.23	Timer Settings.....	152
5.24	Brake Control	153
5.25	Multi-Function Output On/Off Control	154
5.26	Press Regeneration Prevention.....	155
5.27	Analog Output.....	157
5.27.1	Current Analog Output.....	157
5.28	Digital Output.....	159
5.28.1	Multi-Function Relay Settings.....	159
5.28.2	Trip Output to Multi-Function Relay	163
5.28.3	Multi-Function Relay Terminal Delay Time Settings.....	164

5.29	Base Block.....	165
6	Learning Protection Features	167
6.1	Motor Protection.....	167
6.1.1	Electronic Thermal Motor Overheating Prevention (ETH).....	167
6.1.2	Overload Early Warning and Trip.....	169
6.1.3	Stall Prevention and Flux Braking.....	171
6.2	Inverter and Sequence Protection	174
6.2.1	Input/output Open-phase Protection.....	174
6.2.2	External Trip Signal.....	175
6.2.3	Inverter Overload Protection	176
6.2.4	Speed Command Loss.....	177
6.2.5	Dynamic Braking (DB) Resistor Configuration.....	179
6.3	Under load Fault Trip and Warning	181
6.3.1	Fan Fault Detection	182
6.3.2	Lifetime Diagnosis of Components	183
6.3.3	Low Voltage Fault Trip.....	183
6.3.4	Output Block by Multi-Function Terminal.....	184
6.3.5	Trip Status Reset	184
6.3.6	Inverter Diagnosis State.....	185
6.3.7	Operation Mode on Option Card Trip.....	185
6.3.8	No Motor Trip.....	186
6.3.9	Low Voltage Trip 2	186
6.3.10	Inverter Pre-overheat Warning.....	187
6.3.11	Torque Detection Protection Action	188
6.4	Fault/Warning List.....	190
7	RS-485 Communication Features	193
7.1	Communication Standards.....	193
7.2	Communication System Configuration.....	195
7.2.1	Communication Line Connection	195
7.2.2	Setting Communication Parameters.....	196
7.2.3	Setting Operation Command and Frequency	197
7.2.4	Command Loss Protective Operation.....	198
7.2.5	Setting Virtual Multi-Function Input	198
7.2.6	Saving Parameters Defined by Communication.....	199

7.2.7	Total Memory Map for Communication.....	199
7.2.8	Parameter Group for Data Transmission.....	200
7.3	Communication Protocol.....	200
7.3.1	LS INV 485 Protocol.....	200
7.3.2	Modbus-RTU Protocol.....	206
7.4	Compatible Common Area Parameter.....	209
7.5	G100 Expansion Common Area Parameter.....	212
7.5.1	Monitoring Area Parameter (Read Only).....	212
7.5.2	Control Area Parameter (Read/ Write).....	217
7.5.3	Memory Control Area Parameter (Read and Write).....	219
8	Table of Functions.....	221
8.1	Operation Group.....	221
8.2	Drive Group (PAR→dr).....	222
8.3	Basic Function Group (PAR→bA).....	225
8.4	Expanded Function Group (PAR→Ad).....	229
8.5	Control Function Group (PAR→Cn).....	235
8.6	Input Terminal Block Function Group (PAR→In).....	239
8.7	Output Terminal Block Function Group (PAR→OU).....	243
8.8	Communication Function Group (PAR→CM).....	246
8.9	Application Function Group (PAR→AP).....	250
8.10	Protection Function Group (PAR→Pr).....	253
8.11	2nd Motor Function Group (PAR→M2).....	258
9	Troubleshooting.....	261
9.1	Trip and Warning.....	261
9.1.1	Fault Trips.....	261
9.1.2	Warning Messages.....	265
9.2	Troubleshooting Fault Trips.....	266

9.3	Other Faults.....	268
10	Maintenance.....	273
10.1	Regular Inspection Lists.....	273
10.1.1	Daily Inspections.....	273
10.1.2	Annual Inspections.....	274
10.1.3	Bi-annual Inspections.....	276
10.2	Storage and Disposal.....	276
10.2.1	Storage.....	276
10.2.2	Disposal.....	277
11	Technical Specification.....	279
11.1	Input and Output Specification.....	279
11.2	Product Specification Details.....	281
11.3	External Dimensions.....	283
11.4	Peripheral Devices.....	287
11.5	Fuse and Reactor Specifications.....	288
11.6	Terminal Screw Specification.....	289
11.7	Braking Resistor Specification.....	290
11.8	Continuous Rated Current Derating.....	291
11.9	Heat Emission.....	293
11.10	Remote Keypad Option.....	294
	Product Warranty.....	296
	Index.....	300

1 Preparing the Installation

This chapter provides details on product identification, part names, correct installation and cable specifications. To install the inverter correctly and safely, carefully read and follow the instructions.

1.1 Product Identification

The G100 Inverter is manufactured in a range of product groups based on drive capacity and power source specifications. Product name and specifications are detailed on the rating plate. Check the rating plate before installing the product and make sure that the product meets your requirements. For more detailed product specifications, refer to **11.1 input and Output Specification** on page **279**.

Note

Check the product name, open the packaging, and then confirm that the product is free from defects. Contact your supplier if you have any issues or questions about your product.

LSLV0022G100-2E0FNS

INPUT 200-240V 3 Phase 50/60Hz
 HD: 11.8A ND: 13.1A
 OUTPUT 0-Input V 3 Phase 0.01~400Hz
 HD: 11A ND: 12A
 4.2kVA IP20
 Ser. No 5501406001F
 Inspected by D. K. YU
 KCC-REM-LSR-XXXXXXX

LSLV 0022 G100 - 2E0FNS

Motor capacity _____

0001 - 0.1kW
 0002 - 0.2kW
 0004 - 0.4kW
 0008 - 0.75kW
 0015 - 1.5kW
 0022 - 2.2kW

Series name _____

Input voltage _____

2 - 3-phase 200V - 240V

Keypad _____

E - LED Keypad

UL Type _____

O - UL Open Type

EMC filter _____


F - Built-in EMC filter(C2)

Reactor _____

N - Non-Reactor

I/O _____


S - Standard
 A - Advanced




1.2 Part Names

The illustration below displays part names. Details may vary between product groups.

0.4–4.0 kW (3-Phase)



5.5–7.5 kW (3-Phase)




1.3 Installation Considerations

Inverters are composed of various precision, electronic devices, and therefore the installation environment can significantly impact the lifespan and reliability of the product. The table below details the ideal operation and installation conditions for the inverter.

Items	Description
Ambient temperature*	Heavy load: -10–50°C, Normal load: -10–40°C
Ambient humidity	Less than 95% relative humidity (no condensation)
Storage temperature	-20 - 65°C
Environmental factors	An environment free from corrosive or flammable gases, oil residue, or dust
Operation altitude/oscillation	Lower than 3,280 ft (1,000 m) above sea level, less than 1G (9.8 m/sec ²)
Air Pressure	70–106 kPa

* The ambient temperature is the temperature measured at a point 2" (5 cm) from the surface of the inverter.




⚠ Caution

Do not allow the ambient temperature to exceed the allowable range while operating the inverter.


1.4 Selecting the Installation Site

When selecting an installation location consider the following points:

- The location must be free from vibration, and the inverter must be installed on a wall that can support the inverter's weight.
- The inverter can become very hot during operation. Install the inverter on a surface that is fire-resistant or flame-retardant and with sufficient clearance around the inverter to allow air to circulate. The illustrations below detail the required installation clearances.




- Make sure that sufficient air circulation is provided around the product. When installing the product inside the panel, carefully consider the position of the product's cooling fan and the ventilation louver. The product must be placed for the cooling fan to discharge heat satisfactorily during the operation.




Preparing the Installation

- If you are installing multiple inverters in one location, arrange them side-by-side and remove the top covers. The top covers **MUST** be removed for side-by-side installations. Use a flat head screwdriver to remove the top covers.



- If you are installing multiple inverters, of different ratings, provide sufficient clearance to meet the clearance specifications of the larger inverter.



1.5 Cable Selection

When you install power and signal cables in the terminal blocks, only use cables that meet the required specification for the safe and reliable operation of the product. Refer to the following information to assist you with cable selection.

⚠ Caution

- Wherever possible use cables with the largest cross-sectional area for mains power wiring, to ensure that voltage drop does not exceed 2%.
- Use copper cables rated for 600V, 75°C for power terminal wiring.
- Use copper cables rated for 300V, 75°C for control terminal wiring.

Ground Cable and Power Cable Specification

Capacity (kW)	Ground		Power Terminal Wiring				Terminal Size	
	mm ²	AWG	mm ²		AWG			
			R/S/T	U/V/W	R/S/T	U/V/W		
3-Phase 200V	0.4	4	12	1.5	1.5	16	16	M3
	0.75							
	1.5	4	12	4	2.5	12	14	M4
	2.2							
	4	6	10	6	6	10	10	M4
	5.5	6	10	16	10	6	8	M4
7.5								
3-Phase 400V	0.4	2.5	14	1.5	1.5	16	16	M3.5
	0.75							
	1.5							
	2.2	6	10	2.5	2.5	14	14	M4
	4							
	5.5							
7.5	6	10	10	6	8	10	M4	

Signal (Control) Cable Specifications


Terminals	Control Terminal Wiring			
	Without Crimp Terminal Connectors (Bare wire)		With Crimp Terminal Connectors (Bootlace Ferrule)	
	mm ²	AWG	mm ²	AWG
24/P1, P2-P5, CM	0.8	18	0.5	20
A1/B1/C1/A2/C2, VR/V1/I2/AO/CM, S+/S-				

2 Installing the Inverter

This chapter describes the physical and electrical installation methods, including mounting and wiring of the product. Refer to the flowchart and basic configuration diagram provided below to understand the procedures and installation methods to be followed to install the product correctly.


Installation Flowchart

The flowchart lists the sequence to be followed during installation. The steps cover equipment installation and testing of the product. More information on each step is referenced in the steps.



Basic Configuration Diagram

The diagram below shows the basic system configuration. Use the diagram for reference when configuring the system by connecting the product with peripheral devices. Ensure that all of the required peripherals and optional devices (resistor brakes, contactors, noise filters, etc.) are available. For more details on peripheral devices, see to **11.4 Peripheral Devices** on page **287**.



⚠ Caution


- Note that the illustration on this user manual may represent the product with the cover open or the circuit breaker removed for explanation. When operating the inverter, make sure to follow the instructions of user manual after fully installing the necessary parts, such as the cover and circuit breaker.
- Do not start or stop the inverter with a magnetic contactor. This may cause damage to the inverter.
- If the inverter is damaged and loses control, the machine may cause a dangerous situation. Install an additional safety device such as an emergency brake to prevent these situations.
- High levels of current draw during power-on can affect the system. Ensure that correctly rated circuit breakers are installed to operate safely during power-on situations.
- Reactors can be installed to improve the power factor. Note that reactors may be installed within 30 ft (9.14 m) from the power source if the input power exceeds 10 times of inverter capacity. Refer to **11.5 Fuse and Reactor Specifications** on page **288** and carefully select a reactor that meets the requirements.

2.1 Mounting the Inverter


Mount the inverter on a wall or inside a panel following the procedures provided below. Before installation, ensure that there is sufficient space to meet the clearance specifications, and that there are no obstacles impeding the cooling fan's air flow.

Select a wall or panel suitable to support the installation. Refer to **11.3 External dimensions** on page **283** and check the inverter's mounting bracket dimensions.

- 1 Use a level to draw a horizontal line on the mounting surface, and then carefully mark the fixing points.
- 2 Drill the two upper mounting bolt holes, and then install the mounting bolts. Do not fully tighten the bolts at this time. Fully tighten the mounting bolts after the inverter has been mounted.



- 3 Mount the inverter on a wall or inside a panel using two mounting bolts. Fully tighten the upper mounting bolts, then install two lower mounting bolts and tighten fully to mount the inverter. Ensure that the inverter is placed flat on the mounting surface, and that the installation surface can securely support the weight of the inverter.




Note

The quantity and dimensions of the mounting brackets vary based on the frame size. Refer to **11.3 External dimensions** on page **283** for detailed information about your model.

⚠ Caution

- Do not transport the inverter by lifting with the inverter's covers or plastic surfaces. The inverter may tip over if covers break, causing injuries or damage to the product. Always support the inverter using the metal frames when moving it.
- Use a transport method that is suitable for the weight of the product. Some high capacity inverters can be too heavy for one person to carry. Use an adequate number of people and transport tool to safely move the product.
- Do not install the inverter on the floor or mount it sideways against a wall. The inverter must be installed vertically, on a wall or inside a panel, with its rear flat on the mounting surface.



2.2 Wiring

Open the front cover, remove the cable guides and control terminal cover, and then install the ground connection as specified. Complete the cable connections by connecting an appropriately rated cable to the terminals on the power and control terminal blocks. Read the following information carefully before carrying out wiring connections to the inverter. All warning instructions must be followed.


ⓘ Caution

- Install the inverter before carrying out wiring connections.
- Ensure that no small metal debris, such as wire cut-offs, remain inside the inverter. Metal debris in the inverter may cause inverter failure.
- Tighten terminal screws to their specified torque. Loose terminal block screws may allow the cables to disconnect and cause short circuit or inverter failure. Refer to **11.6 Terminal Screw Specification** on page **289** for torque specifications.
- Do not place heavy objects on top of electric cables. Heavy objects may damage the cable and result in electric shock.
- The power supply system for this equipment (inverter) is a grounded system. Only use a grounded power supply system for this equipment (inverter). Do not use a TT, TN, IT, or corner grounded system with the inverter.
- The equipment may generate direct current in the protective ground wire. When installing the residual current device (RCD) or residual current monitoring (RCM), only Type B RCDs and RCMs can be used.
- Use cables with the largest cross-sectional area, appropriate for power terminal wiring, to ensure that voltage drop does not exceed 2%.
- Use copper cables rated at 600V, 75°C for power terminal wiring.
- Use copper cables rated at 300V, 75°C for control terminal wiring.
- Separate control circuit wires from the main circuits and other high voltage circuits (200 V relay sequence circuit).
- Check for short circuits or wiring failure in the control circuit. They could cause system failure or device malfunction.
- Use shielded cables for control terminal wiring. Failure to do so may cause malfunction due to interference. When grounding is needed, use shielded twisted pair (STP) cables.
- If you need to re-wire the terminals due to wiring-related faults, ensure that the inverter keypad display is turned off and the charge lamp under the front cover is off before working on wiring connections. The inverter may hold a high voltage electric charge long after the power supply has been turned off.

Step1 Front Cover, Control Terminal Cover

For power terminal and control terminal wiring, the front cover and the control terminal cover must be disassembled in order. Note that the disassembling procedure of front cover and control terminal cover may vary depending on the product group. Disassemble each cover in the following order:

- 1 Loosen the bolt that secures the front cover (right side). Push and hold the latch on the right side of the cover. Then remove the cover by lifting it from the bottom and moving it away from the front of the inverter.




Note

If you have installed the remote keypad, remove the plastic cover under the lower-right part of the control terminal cover, and then connect the remote keypad signal to the RJ-45 connector.

Step2 Ground Connection

Remove the front cover(s) and the control terminal cover. Then follow the instructions below to install the ground connection for the inverter.

- 1 Locate the ground terminal and connect an appropriately rated ground cable to the terminals. Refer to **1.5 Cable Selection** on page **10** to find the appropriate cable specification for your installation.



- 2 Connect the other ends of the ground cables to the supply earth (ground) terminal.

Note

- 200 V products require Class 3 grounding. Resistance to ground must be $< 100\Omega$.
- 400 V products require Special Class 3 grounding. Resistance to ground must be $< 10\Omega$.

⚠ Warning

Make sure to install ground connection between the equipment and the motor for safe use. Otherwise it may cause an electrical shock and result in personal injury or even death.

Step3 Power Terminal Wiring

The following illustration shows the terminal layout on the power terminal block. Refer to the detailed descriptions to understand the function and location of each terminal before making wiring connections. Ensure that the cables selected meet or exceed the specifications in **1.5 Cable Selection** on page **10** before installing them.

ⓘ Caution


- Apply rated torques to the terminal screws. Loose screws may cause short circuits and malfunctions. Tightening the screw too much may damage the terminals and cause short circuits and malfunctions.
- Use copper wires only with 600V, 75°C rating for the power terminal wiring, and 300V, 75°C rating for the control terminal wiring.
- Do not connect two wires to one terminal when wiring the power.
- Power supply wirings must be connected to the R, S, and T terminals. Connecting them to the U, V, W terminals causes internal damages to the inverter. Motor should be connected to the U, V, and W Terminals. Arrangement of the phase sequence is not necessary.

ⓘ Attention


- Appliquer des couples de marche aux vis des bornes. Des vis desserrées peuvent provoquer des courts-circuits et des dysfonctionnements. Ne pas trop serrer la vis, car cela risqué d'endommager les bornes et de provoquer des courts-circuits et des dysfonctionnements. Utiliser uniquement des fils de cuivre avec une valeur nominale de 600 V, 75 °C pour le câblage de la borne d'alimentation, et une valeur nominale de 300 V, 75 °C pour le câblage de la borne de commande.
- Ne jamais connecter deux câbles à une borne lors du câblage de l'alimentation.
- Les câblages de l'alimentation électrique doivent être connectés aux bornes R, S et T. Leur connexion aux bornes U, V et W provoque des dommages internes à l'onduleur. Le moteur doit être raccordé aux bornes U, V et W. L'arrangement de l'ordre de phase n'est pas nécessaire.

Installing the Inverter


0.4–0.8kW




1.5–2.2kW




4.0kW



5.5–7.5kW



Power Terminal Labels and Descriptions

Terminal Labels	Name	Description
	Ground Terminal	Connect earth grounding.
R(L1)/S(L2)/T(L3)	AC power input terminal	Mains supply AC power connections.
B1/B2	Brake resistor terminals	Brake resistor wiring connection.
U/V/W	Motor output terminals	3-phase induction motor wiring connections.

Note

- Do not use 3 core cables to connect a remotely located motor with the inverter.
- When you operating Brake resistor, the motor may vibrate under the Flux braking operation. In this case, please turn off the Flux braking (Pr.50).
- Make sure that the total cable length does not exceed 665 ft (202 m). For inverters ≤ 4.0 kW capacity, ensure that the total cable length does not exceed 165 ft (50 m).
- Long cable runs can cause reduced motor torque in low frequency applications due to voltage drop. Long cable runs also increase a circuit's susceptibility to stray capacitance and may trigger over-current protection devices or result in malfunction of equipment connected to the inverter. Voltage drop is calculated by using the following formula:
Voltage Drop (V) = $[\sqrt{3} \times \text{cable resistance (m}\Omega\text{/m)} \times \text{cable length (m)} \times \text{current (A)}] / 1000$
- Use cables with the largest possible cross-sectional area to ensure that voltage drop is minimized over long cable runs. Lowering the carrier frequency and installing a micro surge filter may also help to reduce voltage drop.

Distance	< 330 ft (50 m)	< 330 ft (100 m)	> 330 ft (100 m)
Allowed Carrier Frequency	< 15 kHz	< 5 kHz	< 2.5 kHz

Warning


Do not connect power to the inverter until installation has been fully completed and the inverter is ready to be operated. Otherwise it may cause an electrical shock and result in personal injury or even death.

Caution

- Power supply cables must be connected to the R, S, and T terminals. Connecting power cables to other terminals will damage the inverter.
- Use insulated ring lugs when connecting cables to R/S/T and U/V/W terminals.
- The inverter's power terminal connections can cause harmonics that may interfere with other communication devices located near to the inverter. To reduce interference the installation of noise filters or line filters may be required.
- Are advanced-phase capacitors, surge protection and electromagnetic interference filters installed correctly?
- To avoid circuit interruption or damaging connected equipment, do not install magnetic contactors on the output side of the inverter. Metal debris in the inverter may cause inverter failure.

Step 4 Control Terminal Wiring

The illustrations below show the detailed layout of control wiring terminals, and control board switches. Ensure that the cables selected meet or exceed the specifications in **1.5 Cable Selection** on page **10** before installing them.




Control Board Switches

Switch	Description
SW1	NPN/PNP mode selection switch
SW2	Terminating Resistor selection switch

Connector

Name	Description
RJ-45 Connector	Connect to Remote I/O or smart copier, connect with RS-485 communication.



Input Terminal Labels and Descriptions

Category	Terminal Labels	Name	Description
Multi-function terminal configuration	P1-P5	Multi-function Input 1-5	Configurable for multi-function input terminals. Factory default terminals and setup are as follows: <ul style="list-style-type: none"> • P1: Fx • P2: Rx • P3: BX • P4: RST • P5: Speed-L
	CM	Sequence common terminal	Common terminal for analog terminal inputs and outputs.
Analog input	VR	Potentiometer frequency reference input	Used to setup or modify a frequency reference via analog voltage or current input. <ul style="list-style-type: none"> • Maximum Voltage Output: 12 V • Maximum Current Output: 100mA • Potentiometer: 1/5 kΩ


Category	Terminal Labels	Name	Description
	V1	Voltage input for frequency reference input	Used to setup or modify a frequency reference via analog voltage input terminal. <ul style="list-style-type: none"> • Unipolar: 0–10V (12V Max.) • Bipolar: -10–10V (±12V Max.)
	I2	Current input for frequency reference input Terminal	Used to setup or modify a frequency reference via current input terminal. <ul style="list-style-type: none"> • Input current: 4-20 mA • Maximum Input current: 24mA • Input resistance: 249 Ω

Output/Communication Terminal Labels and Descriptions

Category	Terminal Labels	Name	Description
Analog output	AO	Voltage output terminal	Used to send inverter output information to external devices: output frequency, output current, output voltage, or a DC voltage. <ul style="list-style-type: none"> • Output Voltage: 0–10 V • Maximum output voltage/current: 12 V, 10 mA • Factory default output: Frequency
Digital Output	24	External 24V power source	Maximum Current Output: 100mA
	A1/C1/B1	Fault signal output 1	Sends out alarm signals when the inverter's safety features are activated (AC 250V <1A, DC 30V < 1A). <ul style="list-style-type: none"> • Fault condition: A1 and C1 contacts are connected (B1 and C1 open connection) • Normal operation: B1 and C1 contacts are connected (A1 and C1 open connection)
	A2/C2	Fault signal output 2	Sends out alarm signals when the inverter's safety features are activated (AC 250V <1A, DC 30V < 1A). <ul style="list-style-type: none"> • Fault condition: A1 and C1 contacts are open connection • Normal operation: A1 and C1 contacts are connected
RS-485 Communication	S+/S-	RS-485 signal line	Used to send or receive RS-485 signals. Refer to 7 RS-485 Communication Features on page 193 for more details.

Pre-insulated Crimp Terminal


Use pre-insulated crimp terminal connectors to increase reliability of the control terminal wiring. Refer to the specifications below to determine the crimp terminals to fit various cable sizes.



P/N	Cable Spec.		Dimensions (inches/mm)				Manufacturer
	AWG	mm ²	L*	P	d1	D	
CE005006	22	0.50	12.0	6.0	1.3	3.2	JEONO (Jeono Electric, http://www.jeono.com/)
CE007506	20	0.75	12.0	6.0	1.5	3.4	
CE010006	18	1.0	12.0	6.0	1.7	3.6	


* If the length (L) of the crimp terminals exceeds 0.5" (12.7mm) after wiring, the control terminal cover may not close fully.

To connect cables to the control terminals without using crimp terminals, refer to the following illustration detailing the correct length of exposed conductor at the end of the control cable.



Note

- While making wiring connections at the control terminals, ensure that the total cable length does not exceed 165 ft (50 m).
- Ensure that the length of any safety related wiring does not exceed 100ft (30m).
- Use ferrite material to protect signal cables from electro-magnetic interference.
- Take care when supporting cables using cable ties, to apply the cable ties no closer than 6 inches from the inverter. This provides sufficient access to fully close the front cover.
- When making control terminal cable connections, use a small flat-tip screw driver (0.1 in wide (2.5 mm) and 0.015 in thick (0.4 mm) at the tip).




Step 5 PNP/NPN Mode Selection

The G100 inverter supports both PNP (Source) and NPN (Sink) modes for sequence inputs at the terminal. Select an appropriate mode to suit requirements using the PNP/NPN selection switch (SW1) on the control board. Refer to the following information for detailed applications.


PNP Mode (Source)

Select PNP using the PNP/NPN selection switch (SW1). CM is the common ground terminal for all analog inputs at the terminal, and P24 is 24 V internal source. If you are using an external 24 V source, build a circuit that connects the external source (-) and the CM terminal.







NPN Mode (Sink)

Select NPN using the PNP/NPN selection switch (SW1). CM is the common ground terminal for all analog inputs at the terminal, and P24 is 24 V internal source. Note that the factory default setting is NPN mode.



Step 6 Disabling the EMC Filter for Power Sources with Asymmetrical Grounding



G100, 400 V products do not have built-in EMC filters. An EMC filter prevents electromagnetic interference by reducing radio emissions from the inverter. EMC filter feature is set to On by factory default. Current leakage increases when the EMC filter feature is used.


Asymmetrical Grounding Connection			
One phase of a delta connection is grounded		Intermediate grounding point on one phase of a delta connection	
End of a single phase is grounded		A 3-phase connection without grounding	

⚠ Danger

- Do not activate the EMC filter if the inverter uses a power source with an asymmetrical grounding structure, for example a grounded delta connection. Otherwise it may cause an electrical shock and result in personal injury or even death.
- Wait at least 10 minutes before opening the covers and exposing the terminal connections. Before starting work on the inverter, test the connections to ensure all DC voltage has been fully discharged. Otherwise it may cause an electrical shock and result in personal injury or even death.

Before using the inverter, confirm the power supply's grounding system. Disable the EMC filter if the power source has an asymmetrical grounding connection. Check the location of the EMC filter on/off screw and attach the plastic washer to the screw under the control terminal block.

Steel bolt	Steel bolt + Plastic washer
	
EMC ON	EMC OFF



Re-assembling the Covers and Routing Bracket

After completing the wiring and basic configurations, re-assemble the control terminal cover, front cover respectively. Note that the assembly procedure may vary according to the product group or frame size of the product.

2.3 Post-Installation Checklist

After completing the installation, check the items in the following table to make sure that the inverter has been safely and correctly installed.

Items	Description	Ref.	Result
Installation Location/Power I/O Verification	Is the installation location appropriate?	p.5	
	Does the environment meet the inverter's operating conditions?	p.6	
	Does the power source match the inverter's rated input?	p.279	
	Is the inverter's rated output sufficient to supply the equipment? (Derating is applied in specific conditions. Refer to 11.8 Continuous Rated Current Derating on page 291 for more details.)	p.279	
Power Terminal Wiring	Is a circuit breaker installed on the input side of the inverter?	p.12	
	Is the circuit breaker correctly rated?	p.287	
	Are the power source cables correctly connected to the R/S/T terminals of the inverter? (Caution: connecting the power source to the U/V/W terminals may damage the inverter.)	p.19	
	Are the motor output cables connected in the correct phase rotation (U/V/W)? (Caution: motors will rotate in reverse direction if three phase cables are not wired in the correct rotation.)	p.19	
	Are the cables used in the power terminal connections correctly rated?	p.10	
	Is the inverter grounded correctly?	p.18	
	Are the power terminal screws and the ground terminal screws tightened to their specified torques?	p.19	
	Are the overload protection circuits installed correctly on the motors (if multiple motors are run using one inverter)?	-	
	Is the inverter separated from the power source by a magnetic contactor (if a braking resistor is in use)?	p.12	
	Are advanced-phase capacitors, surge protection and electromagnetic interference filters installed correctly? (These devices MUST not be installed on the output side of the inverter.)	p.19	

Items	Description	Ref.	Result
Control Terminal Wiring	Are shielded twisted pair (STP) cables used for control terminal wiring?	-	
	Is the shielding of the STP wiring properly grounded?	-	
	If 3-wire operation is required, are the multi-function input terminals defined prior to the installation of the control wiring connections?	p.23	
	Are the control cables properly wired?	p.23	
	Are the control terminal screws tightened to their specified torques?	p.14	
	Is the total cable length of all control wiring < 165 ft (50 m)?	p.27	
	Is the total length of safety wiring < 100 ft (30 m)?	p.27	
Miscellaneous	Are optional cards connected correctly?	-	
	Is there any debris left inside the inverter?	p.14	
	Are any cables contacting adjacent terminals, creating a potential short circuit risk?	-	
	Are the control terminal connections separated from the power terminal connections?	-	
	Have the capacitors been replaced if they have been in use for > 2 years?	-	
	Have the fans been replaced if they have been in use for > 3 years?	-	
	Has a fuse been installed for the power source?	p.288	
Are the connections to the motor separated from other connections?	-		

Note

Shielded twisted pair (STP) cable has a highly conductive, shielded screen around twisted cable pairs. STP cables protect conductors from electromagnetic interference.

2.4 Test Run

After the post-installation checklist has been completed, follow the instructions below to test the inverter.

- 1 Turn on the power supply to the inverter. Ensure that the keypad display light is on.
- 2 Select the command source.
- 3 Set a frequency reference, and then check the following:
 - If V1 is selected as the frequency reference source, does the reference change according to the input voltage at VR?
 - If I2 is selected as the frequency reference source, does the reference change according to the input current?
- 4 Set the acceleration and deceleration time.
- 5 Start the motor and check the following:
 - Ensure that the motor rotates in the correct direction. If the motor is rotating in the reverse direction, refer to the details below.
 - Ensure that the motor accelerates and decelerates according to the set times, and that the motor speed reaches the frequency reference.

Note

If the forward command (Fx) is on, the motor should rotate counterclockwise when viewed from the load side of the motor. If the motor rotates in the reverse direction, switch the cables at the U and V terminals.


Remarque

Si la commande avant (Fx) est activée, le moteur doit tourner dans le sens anti-horaire si on le regarde côté charge du moteur. Si le moteur tourne dans le sens inverse, inverser les câbles aux bornes U et V.

Verifying the Motor Rotation

- 1 On the keypad, set the drv (Frequency reference source) code in the Operation group to 0 (Keypad).

- 2 Set a frequency reference.
- 3 Press the [RUN] key. Motor starts forward operation.
- 4 Observe the motor's rotation from the load side and ensure that the motor rotates counterclockwise (forward).



ⓘ Caution


- Check the parameter settings before running the inverter. Parameter settings may have to be adjusted depending on the load.
- Do not supply the inverter with an input voltage that exceeds the rated voltage for the equipment. This may cause damage to the inverter.
- Before running the motor at maximum speed, confirm the motor's rated capacity. As inverters can be used to easily increase motor speed, take caution to ensure that motor speeds do not accidentally exceed the motor's rated capacity.

3 Learning to Perform Basic Operations

This chapter describes the keypad layout, functions, and the operation method as well as the function groups used for the inverter operation and the basic operation method using the keypad. Become familiar with the correct basic operation method before advancing to more complex uses by setting the various features of the inverter and giving an operation command by changing the frequency or input voltage.

3.1 About the Keypad

The keypad is composed of two main components – the display and the operation (input) keys. Refer to the following illustration to identify part names and functions.



3.1.1 About the Display

The following table lists display part names and their functions.







No.	Name	Function
①	7-Segment Display	Displays current operational status and parameter information.
②	SET Indicator	LED flashes during parameter configuration and when the ESC key operates as the multi-function key.
③	RUN Indicator	LED turns on (steady) during an operation, and flashes during acceleration or deceleration.
④	FWD Indicator	LED turns on (steady) during forward operation.
⑤	REV Indicator	LED turns on (steady) during reverse operation.

The table below lists the way that the keypad displays characters (letters and numbers).

Display	Number/ character	Display	Number/ character	Display	Number/ character	Display	Number/ character
0	0	A	A	K	K	U	U
1	1	b	B	L	L	V	V
2	2	c	C	M	M	W	W
3	3	d	D	N	N	X	X
4	4	E	E	O	O	Y	Y
5	5	F	F	P	P	Z	Z
6	6	G	G	Q	Q		
7	7	H	H	R	R		
8	8	I	I	S	S		
9	9	J	J	T	T		

3.1.2 Operation Keys

The following table lists the names and functions of the keypad's operation keys.

Key	Name	Function
	[RUN] key	Used to run the inverter (inputs a RUN command).
	[STOP/RESET] key	STOP: Stops the inverter. RESET: Resets the inverter if a fault or failure occurs.
	[▲] key, [▼] key	Switches between codes, or increases or decreases parameter values.
	[MODE/SHIFT] key	Moves between groups or moves to the digit on the left when setting the parameter. Press the MODE/SHIFT key once again on the maximum number of digits to move to the minimum number of digits.
	[ENTER] key	Switches from the selected state of parameter to the input state. Edits parameter and apply change. Accesses the operation information screen during failure on the failure screen.
	[Volume]	Used to set the operation frequency.

⚠ Caution

Install a separate emergency stop switch in the circuit. The [STOP/RESET] key on the keypad works only when the inverter has been configured to accept an input from the keypad.

3.1.3 Control Menu

The following table lists the functions groups under Parameter mode.

Group	Keypad Display	Description
Operation	-	Configures basic parameters for inverter operation.
Drive	<i>dr</i>	Configures parameters for basic operations. These include jog operation, motor capacity evaluation, torque boost, and other keypad related parameters.
Basic	<i>bA</i>	Configures basic operation parameters. These parameters include motor parameters and multi-step frequency parameters.
Advanced	<i>Ad</i>	Configures acceleration or deceleration patterns, frequency limits, etc.
Control	<i>Ln</i>	Configures sensorless vector-related features.
Input Terminal	<i>ln</i>	Configures input terminal-related features, including digital multi-functional inputs and analog inputs.
Output Terminal	<i>ou</i>	Configures output terminal-related features such as relays and analog outputs.
Communication	<i>CA</i>	Configures communication features for RS-485 or other communication options.
Application	<i>AP</i>	Configures functions related to PID control.
Protection	<i>Pr</i>	Configures motor and inverter protection features
Motor 2 (Secondary motor)	<i>M2</i>	Configures secondary motor related features. The secondary motor (M2) group appears on the keypad only when one of the multi-function input terminals (In.65–In.69) has been set to 26 (Secondary motor).



3.2 Learning to Use the Keypad

The keypad enables movement between groups and codes. It also enables users to select and configure functions. At code level, you can set parameter values to turn on or off specific functions, or decide how the functions will be used. Refer to **8 Table of Functions** on page **221** to find the functions you need.

Confirm the correct values (or the correct range of the values), and then follow the examples below to configure the inverter with the keypad.

3.2.1 Group and Code Selection

Follow the examples below to learn how to switch between groups and codes.

Step	Instruction	Keypad Display
1	Move to the group you want using the [MODE] keys. Press the [MODE] key for longer than 1 second to move in the opposite direction.	
2	Move up and down through the codes using the [▲] and [▼] keys until you locate the code that you require.	
3	Press the [ENT] key to save the change.	-


Note

When moving up and down through the codes using the [▲] and [▼] keys in each group, there are cases where the code number does not increase or decrease. This is because the number was left blank in the inverter program by expecting additional features or the program was set up to not display the unused features.

Example) If Ad.24 (frequency limit) code is set to 0 (No), Ad.25 (frequency lower limit value) and Ad.26 (frequency upper limit value) codes will not be displayed. Ad.24 (frequency limit) code must be set to 1 (Yes) to display Ad.25 (frequency lower limit value) and Ad.26 (frequency upper limit value) codes.

3.2.2 Navigating Directly to Different Codes







The following example details navigating to code dr. 95, from the initial code in the Drive group (dr. 0). This example applies to all groups whenever you would like to navigate to a specific code number.



Step	Instruction	Keypad Display
1	Ensure that you are currently at the first code of the Drive group (dr.0).	
2	Press the [ENT] key. Number "9" will flash.	
3	Press the [▼] key and change the ones' place of the code "95" to "5."	
4	Press the [MODE] to move to the tens' place. The cursor will move to the left and "05" will be displayed. At this time, the number "0" will be flashing.	
5	Press the [▲] key to change the tens' place number from "0" to "9," so the designated code is "95."	
6	Press the [ENT] key. Code dr.95 is displayed.	

3.2.3 Setting Parameter Values

Enable or disable features by setting or modifying parameter values for different codes. Directly enter setting values, such as frequency references, supply voltages, and motor speeds. Follow the instructions below to learn to set or modify parameter values.

Step	Instruction	Keypad Display
1	Select the group and code to setup or modify parameter settings, and then press the [ENT] key. The first number on the right side of the display will flash.	
2	Move to the place value to edit using the Mode key, change the value using the [▲] and [▼] keys, and then press the [ENT] key. Press the [MODE] key for longer than 1 second to move to the left place value. The selected value will flash on the display.	    
3	Press the [ENT] key again to save the changes.	-


Note

- A flashing number on the display indicates that the keypad is waiting for an input from the user. Changes will be saved when the [ENT] key is pressed while the number is flashing. The setting change will be canceled if you press any other key.
- Each code's parameter values have default features and ranges specified. Refer to **8 Table of Functions** on page **221** for information about the features and ranges before setting or modifying parameter values.

3.3 Actual Application Examples

3.3.1 Acceleration Time Configuration


The following is an example demonstrating how to modify the Acceleration time (ACC) code value (from 5.0 to 16.0) from the Operation group.



Step	Instruction	Keypad Display
1	Ensure that the first code of the Operation group is selected, and code 0.00 (Command Frequency) is displayed.	
2	Press the [▲] key. The display will change to the second code in the Operation group, the acceleration time (ACC) code.	
3	Press the [ENT] key. The number "5.0" will be displayed, with "0" flashing. This indicates that the current acceleration time is set to 5.0 seconds. The flashing value is ready to be modified by using the keypad.	
4	Press the [MODE] key to change the place value. "5" in the ones' place from "5.0" will flash. This indicates the flashing value, "5" is ready to be modified.	
5	To make the target value "16", press the [▲] key to change the ones' place value "5" to "6".	
6	Press the [MODE] key to move to the tens' place value. "0" in the tens' place from "06.0" will flash.	
7	To make the target value "16", press the [▲] key to change the tens' place value "0" to "1", and then press the [ENT] key. The selected value will flash on the display.	
8	Press the [ENT] key again to save the changes. "ACC" will be displayed. The change to the acceleration time setup has been completed.	

3.3.2 Frequency Reference Configuration

The following is an example to demonstrate configuring a frequency reference of 30.05 (Hz) from the first code in the Operation group (0.00).




Step	Instruction	Keypad Display
1	Ensure that the first code of the Operation group is selected, and code 0.00 (Command Frequency) is displayed.	
2	Press the [ENT] key. The default value "0.00" will be displayed and "0" in the second decimal place will flash.	
3	Press the [MODE] key 3 times to move to the tens' place value. "0" in the tens' place will flash.	
4	To make the target value "30.05", press the [▲] key to change the tens' place value "0" to "3"	
5	Press the [MODE] key 2 times. The "0" in the second decimal place will flash.	
6	To make the target value "30.05", press the [▲] key to change the second decimal place value "0" to "5", and then press the [ENT] key. The selected value will flash on the display.	
7	Press the [ENT] key again to save the changes. Flashing stops. The frequency reference has been configured to 30.05 Hz.	

Note

- A flashing number on the display indicates that the keypad is waiting for an input from the user. Changes will be saved when the [ENT] key is pressed while the number is flashing. The setting change will be canceled if you press any other key.
- The G100 inverter keypad display can display up to 4 digits. However, 5-digit figures can be used and are accessed by pressing the [MODE] key, to allow keypad input.

3.3.3 Jog Frequency Configuration


The following example demonstrates how to configure Jog Frequency by modifying code 11 in the Drive group (Jog Frequency) from 10.00 Hz to 20.00 Hz. You can configure the parameters for different codes in any other group in exactly the same way.



Step	Instruction	Keypad Display
1	Go to code 11 (Jog Frequency) in the Drive group.	dr.11
2	Press the [ENT] key. The current Jog Frequency value (10.00) for code dr.11 is displayed.	10.00
3	Press the [MODE] key 3 times to move to the tens' place value. "1" in the tens' place will flash.	10.00
4	To make the target value "20.00", press the [▲] key to change the tens' place value "1" to "2", and then press the [ENT] key. The selected value will flash on the display.	20.00
5	Press the [ENT] key again to save the changes. Code dr.11 will be displayed. The parameter change has been completed.	dr.11

3.3.4 Parameter Initialization

The following example demonstrates parameter initialization using code dr.93 (Parameter Initialization) in the Drive group. Once executed, parameter initialization will delete all modified values for all codes and groups.










Step	Instruction	Keypad Display
1	Go to code 0 (Jog Frequency) in the Drive group.	
2	Press the [ENT] key. The current parameter value "9" will be displayed.	
3	To make the target value "93", press the [▼] key to change the ones' place value "9" to "3".	
4	Press the [MODE] key to move to the tens' place value.	
5	To make the target value "93", press the [▲] or [▼] key to change the tens' place value "0" to "9".	
6	Press the [ENT] key. Code dr.93 will be displayed.	
7	Press the [ENT] key once again. The current parameter value for code dr.93 is set to 0 (Do not initialize).	
8	Press the [▲] key to change the value to 1 (All Grp), and then press the [ENT] key. The parameter value will flash.	
9	Press the [ENT] key once again. Parameter initialization begins. Parameter initialization is complete when code dr.93 reappears on the display.	

Note


Following parameter initialization, all parameters are reset to factory default values. Ensure that parameters are reconfigured before running the inverter again after an initialization.

3.3.5 Frequency Setting (Keypad) and Operation (via Terminal Input)

Step	Instruction	Keypad Display
1	Turn on the inverter.	-
2	Ensure that the first code of the Operation group is selected, and code 0.00 (Command Frequency) is displayed, then press the [ENT] key. The first number on the right side of the display will flash.	
3	Press the [MODE] key 3 times to move to the tens' place value. "0" in the tens' place will flash.	
4	Press the [▲] key to change it to 1, and then press the [ENT] key. The selected value will flash on the display.	
5	Press the [ENT] key again to save the changes. A change of reference frequency to 10.00 Hz has been completed.	
6	Refer to the wiring diagram at the bottom of the table, and close the switch between the P1 (FX) and CM terminals. The RUN indicator light flashes and the FWD indicator light comes on steady. The current acceleration frequency is displayed.	
7	When the frequency reference is reached (10 Hz), open the switch between the P1 (FX) and CM terminals. The RUN indicator light flashes again and the current deceleration frequency is displayed. When the frequency reaches 0 Hz, the RUN and FWD indicator lights turn off, and the frequency reference (10.00 Hz) is displayed again.	



[Wiring Diagram]





[Operation Pattern]


Note

The instructions in the table are based on the factory default parameter settings. The inverter may not work correctly if the default parameter settings are changed after the inverter is purchased. In such cases, initialize all parameters to reset the values to the factory default parameter settings before following the instructions in the table (refer to **5.20 Parameter initialization** on page 150).


3.3.6 Frequency Setting (Potentiometer) and Operation (Terminal Input)

Step	Instruction	Keypad Display
1	Turn on the inverter.	-
2	Ensure that the first code of the Operation group is selected, and code 0.00 (Command Frequency) is displayed.	0.00
3	Press the [▲] key 4 times. Move to the Frq (Frequency reference source) code.	Frq
4	Press the [ENT] key. The Frq code in the Operation group is currently set to 0 (keypad).	0
5	Press the [▲] key to change the parameter value to 2 (Potentiometer), and then press the [ENT] key. The parameter value will flash.	2
6	Press the [ENT] key once again. The Frq code will be displayed again. The frequency input has been configured for the potentiometer.	Frq
7	Press the [▼] key 4 times. Move to the first code of the Operation group (0.00). From here frequency setting values can be monitored	0.00

Step	Instruction	Keypad Display
8	Adjust the potentiometer to increase or decrease the frequency reference to 10 Hz.	-
9	Refer to the wiring diagram at the bottom of the table, and close the switch between the P1 (FX) and CM terminals. The RUN indicator light flashes and the FWD indicator light comes on steady. The current acceleration frequency is displayed.	
10	When the frequency reference is reached (10 Hz), open the switch between the P1 (FX) and CM terminals. The RUN indicator light flashes again and the current deceleration frequency is displayed. When the frequency reaches 0 Hz, the RUN and FWD indicator lights turn off, and the frequency reference (10.00 Hz) is displayed again.	



[Wiring Diagram]




[Operation Pattern]

Note


The instructions in the table are based on the factory default parameter settings. The inverter may not work correctly if the default parameter settings are changed after the inverter is purchased. In such cases, initialize all parameters to reset the values to factory default parameter settings before following the instructions in the table (refer to **5.20 Parameter initialization** on page 150).

3.3.7 Frequency Setting (Potentiometer) and Operation (Keypad)

Step	Instruction	Keypad Display
1	Turn on the inverter.	-
2	Ensure that the first code of the Operation group is selected, and code 0.00 (Command Frequency) is displayed.	
3	Press the [▲] key 3 times. Move to the operation group drv (command source) code.	
4	Press the [ENT] key. The drv code in the Operation group is currently set to 1 (Analog Terminal).	
5	Press the [▼] key to change the parameter value to 0 (Keypad), and then press the [ENT] key. The parameter value will flash.	
6	Press the [ENT] key once again. The drv code is displayed again. The frequency input has been configured for the keypad.	
7	Press the [▲] key 1 times. Move to the Frq (Frequency reference source) code.	
8	Press the [ENT] key. The Frq code in the Operation group is currently set to 0 (keypad).	
9	Press the [▲] key to change the parameter value to 2 (Potentiometer), and then press the [ENT] key. The parameter value will flash.	
10	Press the [ENT] key once again. The Frq code will be displayed again. The frequency input has been configured for the potentiometer.	
11	Press the [▼] key 4 times. Move to the first code of the Operation group (0.00). From here frequency setting values can be monitored	
12	Adjust the potentiometer to increase or decrease the frequency reference to 10 Hz.	-
13	Press the [RUN] key. The RUN indicator light flashes and the FWD indicator light comes on steady. The current acceleration frequency is displayed.	
14	When the frequency reaches the reference (10Hz), press the [STOP/RESET] key on the keypad. The RUN indicator light flashes again and the current deceleration frequency is displayed. When the frequency reaches 0 Hz, the RUN and FWD indicator lights turn off, and the frequency reference (10.00 Hz) is displayed again.	



[Wiring Diagram]



[Operation Pattern]


Note

The instructions in the table are based on the factory default parameter settings. The inverter may not work correctly if the default parameter settings are changed after the inverter is purchased. In such cases, initialize all parameters to reset the values to factory default parameter settings before following the instructions in the table (refer to [5.20 Parameter initialization](#) on page 150).

3.4 Monitoring the Operation

3.4.1 Output Current Monitoring

The following example demonstrates how to monitor the output current in the Operation group using the keypad.




Step	Instruction	Keypad Display
1	Ensure that the first code of the Operation group is selected, and code 0.00 (Command Frequency) is displayed.	0.00
2	Press the [▲] or [▼] key to move to the Cur code.	Cur
3	Press the [ENT] key. The output current (5.0A) is displayed.	5.0
4	Press the [ENT] key once again. Returns to the Cur code.	Cur

Note

You can use the dCL (DC link voltage monitor) and vOL (output voltage monitor) codes in the Operation group in exactly the same way as shown in the example above, to monitor each function's relevant values.

3.4.2 Trip Condition Monitor


The following example demonstrates how to monitor fault trip conditions in the Operation group using the keypad.



Step	Instruction	Keypad Display
1	Refer to the example keypad display. An over current trip fault has occurred.	
2	Press the [ENT] key, and then the [▲] key. The operation frequency at the time of the fault (30.00Hz) is displayed.	
3	Press the [▲] key. The output current at the time of the fault (5.0A) is displayed.	
4	Press the [▲] key. The operation status at the time of the fault is displayed. ACC on the display indicates that the fault occurred during acceleration.	
5	Press the [STOP/RESET] key. The inverter resets and the fault condition is cleared. The frequency reference is displayed on the keypad.	

Note

- If multiple fault trips occur at the same time, a maximum of 3 fault trip records can be retrieved as shown in the following example.



- If a warning situation occurs while operating with the entered frequency, a `Warn` display and the current screen will flash in 1 second intervals. Refer to **6.3 Under load Fault Trip and Warning** on page **181** for more details.

4 Learning Basic Features

This chapter describes the basic features of the G100 inverter. Check the reference page in the table to see the detailed description for each of the advanced features.

Basic Tasks	Description	Ref.
Frequency reference source configuration for the keypad	Configures the inverter to allow you to setup or modify frequency reference using the Keypad.	p.60
Frequency reference source configuration for the terminal block (input voltage)	Configures the inverter to allow input voltages at the terminal block (V1, V2) and to setup or modify a frequency reference.	p.61
Frequency reference source configuration for the terminal block (input current)	Configures the inverter to allow input currents at the terminal block (I2) and to setup or modify a frequency reference.	p.67
Frequency reference source configuration for RS-485 communication	Configures the inverter to allow communication signals from upper level controllers, such as PLCs or PCs, and to setup or modify a frequency reference.	p.69
Frequency Hold by Analog Input	Enables the user to hold a frequency using analog inputs at terminals.	p.69
Multi-step speed (frequency) configuration	Configures multi-step frequency operations by receiving an input at the terminals defined for each step frequency.	p.70
The Keypad as a Command Input Device	Configures the inverter to allow the manual operation of the [FWD], [REV] and [Stop] keys.	p.72
Command source configuration for terminal block inputs	Configures the inverter to accept inputs at the FX/RX terminals.	p.72
RS-485 Communication as a Command Input Device	Configures the inverter to allow communication signals from upper level controllers, such as PLCs or PCs, and to set up an operation command using S+ and S- terminals or the RJ45 connector.	p.74
Forward or Reverse Run Prevention	Configures the inverter to limit a motor's rotation direction.	p.74
start at power-on	Configures to accelerate instantly if the operation command is on when inverter power is supplied.	p.75
Automatic restart after reset of a fault trip condition	Configures the inverter to start operating when the inverter is reset following a fault trip. In this configuration, the inverter starts to run and the motor accelerates as soon as the inverter is reset following a fault trip condition.	p.76

Basic Tasks	Description	Ref.
	For automatic start-up configuration to work, the operation command terminals at the terminal block must be turned on.	
Acc/Dec Time Based on Maximum Frequency	Configures the acceleration and deceleration times for a motor based on a defined maximum frequency.	p.77
Acc/Dec Time Based on Operation Frequency	Configures acceleration and deceleration times for a motor based on a defined frequency reference.	p.78
Multi-step Acc/Dec Time Configuration	Configures multi-stage acceleration and deceleration times for a motor based on defined parameters for the multi-function terminals.	p.79
Acc/Dec time switch frequency	Enables modification of acceleration and deceleration gradients without configuring the multi-functional terminals.	p.81
Acc/Dec pattern configuration	Enables modification of the acceleration and deceleration gradient patterns. Basic patterns to choose from include linear and S-curve patterns.	p.82
Acc/Dec stop command	Stops the current acceleration or deceleration and controls motor operation at a constant speed. Multi-function terminals must be configured for this command.	p.84
Linear V/F pattern operation	Used for loads that require constant torque regardless of the frequency.	p.84
Square reduction V/F pattern operation	Configures the inverter to run the motor at a square reduction V/F pattern. Fans and pumps are appropriate loads for square reduction V/F operation.	p.85
User V/F pattern Operation	Enables the user to configure a V/F pattern to match the characteristics of a motor. This configuration is for special-purpose motor applications to achieve optimal performance.	p.86
manual torque boost	Manual configuration of the inverter to produce a momentary torque boost. This configuration is for loads that require a large amount of starting torque, such as elevators or lifts.	p.88
Auto torque boost	Automatic configuration of the inverter that provides "auto tuning" that produces a momentary torque boost. This configuration is for loads that require a large amount of starting torque, such as elevators or lifts.	p.89
Motor output voltage adjustment	Adjusts the output voltage to the motor when the power supply to the inverter differs from the motor's rated input voltage.	p.89
Accelerating start	Acceleration start is a general acceleration mode. If there are no extra settings applied, the motor accelerates directly to the frequency reference when the command is input.	p.90

Basic Tasks	Description	Ref.
DC braking after start	Configures the inverter to perform DC braking before the motor starts rotating again. This configuration is used when the motor will be rotating before the voltage is supplied from the inverter.	<u>p.91</u>
Deceleration stop	Deceleration stop is the typical method used to stop a motor. The motor decelerates to 0Hz and stops on a stop command, however there may be other stop or deceleration conditions defined.	<u>p.92</u>
DC braking after stop	Configures the inverter to apply DC braking during motor deceleration. The frequency at which DC braking occurs must be defined and during deceleration, when the motor reaches the defined frequency, DC braking is applied.	<u>p.93</u>
Free-run stop	When the Operation command is off, the inverter output turns off, and the load stops due to residual inertia.	<u>p.94</u>
Power braking	Configures the inverter to provide optimal, motor deceleration, without tripping over-voltage protection.	<u>p.94</u>
Start/maximum frequency configuration	Configures the frequency reference limits by defining a start frequency and a maximum frequency.	<u>p.95</u>
Frequency Limit Using Upper and Lower Limit Frequency Values	Configures the frequency reference limits by defining an upper limit and a lower limit.	<u>p.96</u>
Frequency jump	Configures the inverter to avoid running a motor in mechanically resonating frequencies.	<u>p.97</u>
2 nd Operation Configuration	Used to configure the 2 nd operation mode and switch between the operation modes according to your requirements.	<u>p.98</u>
Multi-function Input Terminal Control	Enables the user to improve the responsiveness of the multi-function input terminals.	<u>p.99</u>

4.1 Setting Frequency Reference

The G100 inverter provides several methods to setup and modify a frequency reference for an operation. The keypad, analog inputs [for example voltage (V1) and current (I2) signals], or RS-485 (digital signals from higher-level controllers, such as PC or PLC) can be used.

Group	Code	Name	Setting		Setting Range	Unit
Run	Frq	Frequency reference source	0	KeyPad-1	0~8	-
			1	KeyPad-2		
			2	V1		
			4	Volume		
			5	I2		
			6	Int 485		
			8	Fieldbus		

4.1.1 Keypad as the Source (KeyPad-1 Setting)

You can modify frequency reference by using the keypad and apply changes by pressing the [ENT] key. To use the keypad as a frequency reference input source, go to the Frq (Frequency reference source) code in the Operation group and change the parameter value to 0 (Keypad-1). Input the frequency reference for an operation at the 0.00 (Command Frequency) code in the Operation group.

Group	Code	Name	Setting		Setting Range	Unit
Run	Frq	Frequency reference source	0	KeyPad-1	0~8	-
	0.00	Target frequency	0.00		Min to Max Frq*	Hz

* You cannot set a frequency reference that exceeds the Max. Frequency, as configured with dr.20.

4.1.2 Keypad as the Source (KeyPad-2 Setting)

You can use the [▲] and [▼] keys to modify a frequency reference. To use this as a second option, set the keypad as the source of the frequency reference, by going to the Frq (Frequency reference source) code in the Operation group and change the parameter value to 1 (Keypad-2). This allows frequency reference values to be increased or decreased by pressing the [▲] and [▼] keys.

Group	Code	Name	Setting	Setting Range	Unit	
Run	Frq	Frequency reference source	1	Keypad-2	0~8	-
	0.00	Target frequency	0.00		Min to Max Frq*	Hz


* You cannot set a frequency reference that exceeds the Max. Frequency, as configured with dr.20.

4.1.3 V1 Terminal as the Source


You can set and modify a frequency reference by setting voltage inputs when using the V1 terminal. Use voltage inputs ranging from 0 to 10 V (unipolar) for forward only operation. Use voltage inputs ranging from -10 to +10 V (bipolar) for both directions, where negative voltage inputs are used reverse operations.

4.1.3.1 Setting a Frequency Reference for 0–10 V Input

Set the Frq (Frequency reference source) code in the Operation group to 2 (V1), and then set code 06 (V1 Polarity) to 0 (unipolar) in the Input Terminal group (IN). Use the voltage output of the external controller or use the VR terminal (frequency setting power terminal) of the control terminal to input voltage in the V1 terminal as the volume resistance.



[Connecting to external power source]






[Connecting to internal power source]


Group	Code	Name	Setting		Setting Range	Unit
Run	Frq	Frequency reference source	2	V1	0~8	-
In	01	Frequency for maximum analog input	Maximum frequency		0.00–Max. Frequency	Hz
	05	V1 input voltage display	0.00		0.00~12.00	V
	06	V1 input polarity selection	0	Unipolar	0~1	-
	07	Time constant of V1 input filter	100		0~10000	ms
	08	V1 Minimum input voltage	0.00		0.00~10.00	V
	09	V1 output at Minimum voltage (%)	0.00		0.00~100.00	%
	10	V1 Maximum input voltage	10.00		0.00–12.00	V
	11	V1 output at Maximum voltage (%)	100.00		0~100	%
	16	Rotation direction options	0	No	0~1	-
	17	V1 quantization level	0.04		0.00*, 0.04–10.00	%

* Quantizing is disabled if "0" is selected.

0–10V Input Voltage Setting Details


Code	Description
In.01 Freq at 100%	<p>Configures the frequency reference at the maximum input voltage when a potentiometer is connected to the control terminal block. A frequency set with code In.01 becomes the maximum frequency only if the value set in code In.11 (or In.15) is 100%.</p> <ul style="list-style-type: none"> Set code In.01 to 40.00 and use default values for codes In.02–In.16. Motor will run at 40.00Hz when a 10V input is provided at V1. Set code In.11 to 50.00 and use default values for codes In.01–In.16. Motor will run at 30.00Hz (50% of the default maximum frequency–60Hz) when a 10V input is provided at V1.
In.05 V1 Monitor[V]	Configures the inverter to monitor the input voltage at V1.
In.07 V1 Filter	<p>As a low-pass filter, use if there is significant variation of frequency parameter setting value due to high noise level. When used, it filters the analog signal to pass only the clean input signals. The higher the number of time constant filter, the lower the variation in frequency. However this slows down the time t and thus affects the response time.</p> <p>The value t (time) indicates the time required for the frequency to reach 63% of the reference, when external input voltages are provided in multiple steps.</p>

Code	Description
	<p>V1 input from external source </p> 
In.08 V1 volt x1– In.11 V1 Perc y2	<p>These parameters are used to configure the gradient level and offset values of the Output Frequency, based on the Input Voltage.</p> 
In.16 V1 Inverting	<p>Inverts the direction of rotation. Set this code to 1 (Yes) if you need the motor to run in the opposite direction from the current rotation.</p>
In.17 V1 Quantizing (Quantizing)	<p>Quantizing may be used when the noise level is high in the analog input (V1 terminal) signal. The frequency is output by measuring (quantizing) the height (value) of the input signal in a consistent interval. This means that the delicate control on the output frequency (power resolution) is low, but the noise is reduced, so it is suitable for systems that are sensitive to noise.</p> <p>Parameter values for quantizing refer to a percentage based on the maximum input. Therefore, if the value is set to 1% of the analog maximum input (60Hz), the output frequency will increase or decrease by 0.6Hz per 0.1V difference.</p> <p>To reduce the effect of the input signal changes (runout of height) on the operation frequency, the output frequency during increase or decrease of input signal value (height) is applied differently. When the input signal value increases, the output frequency starts changing if the height becomes equivalent to 3/4 of the quantizing value. From then on, the output</p>


Code	Description
	<p>frequency increases according to the quantizing value. On the other hand, when the input signal decrease, the output frequency starts decreasing if the height becomes equivalent to 1/4 of the quantizing value.</p> <p>Although the noise can be reduced using the low-pass filter (In.07), the response on the input signal takes long as the set value gets higher. Since it becomes difficult to control the frequency if the input signal is delayed, a period of long pulse (ripple) may occur on the output frequency.</p> 

4.1.3.2 Setting a Frequency Reference for -10~10 V Input

Set the Frq (Frequency reference source) code in the Operation group to 2 (V1), and then set code 06 (V1 Polarity) to 1 (bipolar) in the Input Terminal group (IN). Use the output voltage from an external source to provide input to V1.



[Setting voltage of -10 ~+10V on a V1 terminal]



Bipolar input voltage and output frequency

Group	Code	Name	Setting	Setting Range	Unit
Run	Frq	Frequency reference source	2 V1	0~8	-
In	01	Frequency for maximum analog input	60.00	0–Max Frequency	Hz
	05	V1 input voltage display	0.00	0.00–12.00 V	V
	06	V1 input polarity selection	1 Bipolar	0~1	-
	12	V1 Minimum input voltage	0.00	10.00–0.00 V	V
	13	V1 output at Minimum voltage (%)	0.00	-100.00–0.00 %	%

Group	Code	Name	Setting	Setting Range	Unit
	14	V1 Maximum input voltage	-10.00	-12.00–0.00 V	V
	15	V1 output at Maximum voltage (%)	-100.00	-100.00–0.00 %	%

Rotational Directions for Different Voltage Inputs

Operation command	Input voltage	
	0–10 V	-10–0 V
FWD	Fwd	Rev
REV	Rev	Fwd

-10–10V Voltage Input Setting Details

Code	Description
In.12 V1- volt x1– In.15 V1- Perc y2	<p>Sets the gradient level and off-set value of the output frequency in relation to the input voltage. These codes are displayed only when In.06 is set to 1 (bipolar).</p> <p>As an example, if the minimum input voltage (at V1) is set to -2 (V) with 10% output ratio, and the maximum voltage is set to -8 (V) with 80% output ratio respectively, the output frequency will vary within the range of 6 - 48 Hz.</p> <p>For details about the 0–+10V analog inputs, refer to the code descriptions In.08 V1 volt x1–In.11 V1 Perc y2 on page 63.</p>

4.1.4 Built-in Volume Input (V0) as the Source

You can modify the frequency reference by using the built-in volume dial. Go to the Frq (Frequency reference source) code in the Operation group and change the parameter value to 4, and then rotate the built-in volume dial. You can monitor the parameter setting of the frequency reference at the 0.00 (command frequency) code in the Operation group.

Group	Code	Name	Setting		Setting Range	Unit
Run	Frq	Frequency reference source	4	V0	0~8	-
In	01	Frequency for maximum analog input	60.00		0–Max Frequency	Hz
	35	V0 input voltage display	0.00		0.00~5.00	V
	37	Time constant of V0 input filter	100		0~10000	ms
	38	V0 Minimum input voltage	0.00		0.00~5.00	V
	39	V0 output at minimum current (%)	0.00		0~100	%
	40	V0 Maximum input voltage	5.00		0.00~5.00	V
	41	V0 output at Maximum current (%)	100.00		0.00~100.00	%
	46	Changing rotation direction of V0	0	No	0~1	-
47	V0 quantization level	0.04		0.00*, 0.04–10.00	%	

4.1.5 Setting a Reference Frequency using Input Current (I2)

Input voltage to the I2 terminal of the control terminal block to set the frequency. Set the Frq (Frequency reference source) code in the Operation group to 5 (I2) and apply 4–20 mA input current to I2.

Group	Code	Name	Setting		Setting Range	Unit
Run	Frq	Frequency reference source	5	I2	0~8	-
In	01	Frequency for maximum analog input	60.00		0–Max Frequency	Hz
	50	I2 input voltage display	0.00		0.00~24.00	mA
	52	Time constant of I2 input filter	100		0~10000	ms
	53	I2 minimum input current	4.00		0.00~20.00	mA
	54	I2 output at minimum current (%)	0.00		0~100	%
	55	I2 maximum input current	20.00		0.00~24.00	mA

Group	Code	Name	Setting	Setting Range	Unit
	56	I2 output at Maximum current (%)	100.00	0.00~100.00	%
	61	Changing rotation direction of I2	0 No	0~1	-
	62	I2 quantization level	0.04	0.00*, 0.04~10.00	%

* Quantizing is disabled if "0" is selected.

Input Current (I2) Setting Details

Code	Description
In.01 Freq at 100%	<p>Configures the frequency reference for operation at the maximum current (when In.56 is set to 100%).</p> <ul style="list-style-type: none"> If In.01 is set to 40.00 Hz, and default settings are used for In.53~56, 20 mA input current (max) to I2 will produce a frequency reference of 40.00 Hz. If In.56 is set to 50.00 (%), and default settings are used for In.01 (60 Hz) and In.53~55, 20 mA input current (max) to I2 will produce a frequency reference of 30.00 Hz (50% of 60 Hz).
In.50 I2 Monitor	Used to monitor input current at I2.
In.52 I2 Filter	Configures the time for the operation frequency to reach 63 % of target frequency based on the input current at I2.
In.53 I2 Curr x1– In.56 I2 Perc y2	<p>Configures the gradient level and off-set value of the output frequency.</p>

4.1.6 Frequency Reference Source Configuration for RS-485 Communication


Control the inverter with upper-level controllers, such as PCs or PLCs, via RS-485 communication. Set the Frq (Frequency reference source) code in the Operation group to 6 (Int 485) and use the RS-485 signal input terminals (S+/S-) for communication. Refer to [7 RS-485 Communication Features](#) on page [193](#) for more details.

Group	Code	Name	Setting		Setting Range	Unit
Run	Frq	Frequency reference source	6	Int 485	0~8	-
CM	01	Built-in communication inverter ID	-	1	1~250	-
			0	ModBus RTU		
	02	Built-in communication protocol	1	Reserved	0~2	-
			2	LS Inv 485		
			3	9600 bps		
	03	Built-in communication speed	0	D8/PN/S1	0~3	-
			1	D8/PN/S2		
			2	D8/PE/S1		
3			D8/PO/S1			

4.2 Frequency Hold by Analog Input

If you set a frequency reference via analog input at the control terminal block, you can hold the operation frequency of the inverter by assigning a multi-function input as the analog frequency hold terminal. The operation frequency will be fixed upon an analog input signal.

Group	Code	Name	Setting		Setting Range	Unit
Run	Frq	Frequency reference source	0	Keypad-1	0~8	-
			1	Keypad-2		
			2	V1		
			4	V0		
			5	I2		
			6	Int 485		
			8	Fieldbus		
			In	65~69		




4.3 Setting Multi-step Frequency

Multi-step operations can be carried out by assigning different speeds (or frequencies) to the Px terminals. Step 0 uses the frequency reference source set with the Frq code in the Operation group. Px terminal parameter values 7 (Speed-L), 8 (Speed-M) and 9 (Speed-H) are recognized as binary commands and work in combination with Fx or Rx run commands. The inverter operates according to the frequencies set with St.1–3 (multi-step frequency 1–3), bA.53–56 (multi-step frequency 4–7) and the binary command combinations.

Group	Code	Name	Setting	Setting Range	Unit	
Run	St1~St3	Multi-step frequency 1-3	-	0–Max Frequency	Hz	
bA	53~56	Multi-step frequency 4-7	-	0–Max Frequency	Hz	
In	65~69	Px terminal setting options	7	Speed-L	0~52	-
			8	Speed-M		-
			9	Speed-H		-
	89	Multi-step command delay time	1	1~5000	ms	

Multi-step Frequency Setting Details

Code	Description
Operation group St1–St3	Configure multi-step frequency 1–3.
bA.53–56 Step Freq - 4–7	Configure multi-step frequency 4–7.

Code	Description																																													
In.65–69 Px Define	<p>Choose the terminals to setup as multi-step inputs, and then set the relevant codes (In.65–69) to 7 (Speed-L), 8 (Speed-M), or 9 (Speed-H). Provided that terminals P3, P4 and P5 have been set to Speed-L, Speed-M and Speed-H respectively, the following multi-step operation will be available.</p>  <p>An example of a multi-step operation</p> <table border="1" data-bbox="363 1101 1227 1458"> <thead> <tr> <th>Speed</th> <th>Fx/Rx</th> <th>P5</th> <th>P4</th> <th>P3</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>✓</td> <td>-</td> <td>-</td> <td>-</td> </tr> <tr> <td>1</td> <td>✓</td> <td>-</td> <td>-</td> <td>✓</td> </tr> <tr> <td>2</td> <td>✓</td> <td>-</td> <td>✓</td> <td>-</td> </tr> <tr> <td>3</td> <td>✓</td> <td>-</td> <td>✓</td> <td>✓</td> </tr> <tr> <td>4</td> <td>✓</td> <td>✓</td> <td>-</td> <td>-</td> </tr> <tr> <td>5</td> <td>✓</td> <td>✓</td> <td>-</td> <td>✓</td> </tr> <tr> <td>6</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>-</td> </tr> <tr> <td>7</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> </tr> </tbody> </table> <p>An example of a multi-step speed</p>	Speed	Fx/Rx	P5	P4	P3	0	✓	-	-	-	1	✓	-	-	✓	2	✓	-	✓	-	3	✓	-	✓	✓	4	✓	✓	-	-	5	✓	✓	-	✓	6	✓	✓	✓	-	7	✓	✓	✓	✓
Speed	Fx/Rx	P5	P4	P3																																										
0	✓	-	-	-																																										
1	✓	-	-	✓																																										
2	✓	-	✓	-																																										
3	✓	-	✓	✓																																										
4	✓	✓	-	-																																										
5	✓	✓	-	✓																																										
6	✓	✓	✓	-																																										
7	✓	✓	✓	✓																																										
In.89 InCheck Time	<p>Set the time for the inverter to check for other terminal block inputs. After adjusting In.89 to 100 ms and an input signal is received at P5, the inverter will search for inputs at other terminals for 100 ms, before proceeding to accelerate or decelerate based on P5's configuration.</p>																																													

4.4 Command Source Configuration

Various devices can be selected as command input devices for the G100 inverter. Input devices available to select include keypad, multi-function input terminal, RS-485 communication and field bus adapter.

Group	Code	Name	Setting		Setting Range	Unit
Run	drv	Command Source	0	Keypad	0~4	-
			1	Fx/Rx-1		
			2	Fx/Rx-2		
			3	Int 485		
			4	Fieldbus		

4.4.1 The Keypad as a Command Input Device

The keypad can be selected as a command input device to send command signals to the inverter. This is configured by setting the drv (command source) code to 0 (Keypad). Press the [RUN] key on the keypad to start an operation, and the [STOP/RESET] key to end it.

Group	Code	Name	Setting		Setting Range	Unit
Run	drv	Command Source	0	Keypad	0~4	-


4.4.2 Terminal Block as a Command Input Device (Fwd/Rev Run Commands)

Multi-function terminals can be selected as a command input device. This is configured by setting the drv (command source) code in the Operation group to 1 (Fx/Rx). Select 2 terminals for the forward and reverse operations, and then set the relevant codes (2 of the 5 multi-function terminal codes, In.65–69 for P1–P7) to 1 (Fx) and 2 (Rx) respectively. This application enables both terminals to be turned on or off at the same time, constituting a stop command that will cause the inverter to stop operation.

Group	Code	Name	Setting		Setting Range	Unit
Run	drv	Command Source	1	Fx/Rx-1	0~4	-
In	65~69	Px terminal setting options	1	Fx	0~52	-
			2	Rx		

Fwd/Rev Command by Multi-function Terminal – Setting Details

Code	Description
Operation group drv- Cmd Source	Set to 1(Fx/Rx-1).
In.65–69 Px Define	Assign a terminal for forward (Fx) operation. Assign a terminal for reverse (Rx) operation.




4.4.3 Terminal Block as a Command Input Device (Run and Rotation Direction Commands)

Multi-function terminals can be selected as a command input device. This is configured by setting the drv (command source) code in the Operation group to 2(Fx/Rx-2). Select 2 terminals for run and rotation direction commands, and then select the relevant codes (2 of the 5 multi-function terminal codes, In.65–69 for P1–P7) to 1(Fx) and 2(Rx) respectively. This application uses an Fx input as a run command, and an Rx input to change a motor’s rotation direction (On-Rx, Off-Fx).

Group	Code	Name	Setting	Setting Range	Unit	
Run	drv	Command Source	2	Fx/Rx-2	0~4	-
In	65~69	Px terminal setting options	1	Fx	0~52	-
			2	Rx		

Run Command and Fwd/Rev Change Command Using Multi-function Terminal – Setting Details

Code	Description
Operation group drv- Cmd Source	Set to 2(Fx/Rx-2).
In.65–69 Px Define	Assign a terminal for run command (Fx). Assign a terminal for changing rotation direction (Rx).



4.4.4 RS-485 Communication as a Command Input Device

Internal RS-485 communication can be selected as a command input device by setting the drv (command source) code in the Operation group to 3(Int 485). This configuration uses upper level controllers such as PCs or PLCs to control the inverter by transmitting and receiving signals via the S+, S- terminals at the terminal block. Refer to **7 RS-485 Communication Features** on page **193** for more details.

Group	Code	Name	Setting		Setting Range	Unit
Run	drv	Command Source	3	Int 485	0~4	-
CM	01	Built-in communication inverter ID	1		1~250	-
	02	Built-in communication protocol	0	ModBus RTU	0~2	-
	03	Built-in communication speed	3	9600 bps	0~7	-
	04	Built-in communication frame setting	0	D8/PN/S1	0~3	-

4.5 Forward or Reverse Run Prevention

The rotation direction of motors can be configured to prevent motors to only run in one direction.

Group	Code	Name	Setting		Setting Range	Unit
Ad	09	Run prevention options	0	None	0~2	-
			1	Forward Prev		
			2	Reverse Prev		


Forward/Reverse Run Prevention Setting Details

Code	Description		
Ad.09 Run Prevent	Choose a direction to prevent.		
	Configuration		Function
	0	None	Do not set run prevention.
	1	Forward Prev	Set forward run prevention.
2	Reverse Prev	Set reverse run prevention.	

4.6 Power-on Run

A power-on command can be setup to start an inverter operation after powering up, based on terminal block operation commands (if they have been configured). To enable power-on run set the drv (command source) code to 1 (Fx/Rx-1) or 2 (Fx/Rx-2) in the Operation group.

Group	Code	Name	Setting		Setting Range	Unit
Run	drv	Command Source	1, 2	Fx/Rx-1 or Fx/Rx-2	0~4	-
Ad	10	Starting with power on	1	Yes	0~1	-



Note

- A fault trip may be triggered if the inverter starts operation while a motor's load (fan-type load) is in free-run state. To prevent this from happening, set bit4 to 1 in Cn. 71 (speed search options) of the Control group. The inverter will perform a speed search at the beginning of the operation.
- If the speed search is not enabled, the inverter will begin its operation in a normal V/F pattern and accelerate the motor. If the inverter has been turned on without power-on run enabled, the terminal block command must first be turned off, and then turned on again to begin the inverter's operation.


⚠ Caution

Use caution when operating the inverter with Power-on Run enabled as the motor will begin rotating when the inverter starts up.

4.7 Reset and Restart

Reset and restart operations can be setup for inverter operation following a fault trip, based on the terminal block operation command (if it is configured). When a fault trip occurs, the inverter cuts off the output and the motor will free-run. Another fault trip may be triggered if the inverter begins its operation while motor load is in a free-run state.

Group	Code	Name	Setting	Setting Range	Unit
Run	drv	Command Source	1 2	Fx/Rx-1 or Fx/Rx-2	0~4 -
Pr	08	Selection of startup on trip reset	1	Yes	0~1
	09	Number of automatic restarts	0		0~10
	10	Auto restart delay time	1.0		0~60 sec



Note

- To prevent a repeat fault trip from occurring, set Cn.71 (speed search options) bit 2 equal to 1. The inverter will perform a speed search at the beginning of the operation.
- If the speed search is not enabled, the inverter will start its operation in a normal V/F pattern and accelerate the motor. If the inverter has been turned on without 'Reset and Restart' enabled, trips must be reset, then turn the terminal block command off and on to begin the inverter's operation.

⚠ Caution

Use caution when operating the inverter with Power-on Run enabled as the motor will begin rotating when the inverter starts up.

4.8 Setting Acceleration and Deceleration Times

4.8.1 Acc/Dec Time Based on Maximum Frequency

Acc/Dec time values can be set based on maximum frequency, not on inverter operation frequency. To set Acc/Dec time values based on maximum frequency, set bA. 08 (Acc/Dec reference) in the Basic group to 0 (Max Freq).

Acceleration time set at the ACC (Acceleration time) code in the Operation group (dr.03 in an LCD keypad) refers to the time required for the inverter to reach the maximum frequency from a stopped (0Hz) state. Likewise, the value set at the DEC (deceleration time) code in the Operation group (dr.04 in an LCD keypad) refers to the time required to return to a stopped state (0Hz) from the maximum frequency.

Group	Code	Name	Setting		Setting Range	Unit
Run	ACC	Acceleration time	20.0		0.0~600.0	sec
	DEC	Deceleration time	30.0		0.0~600.0	sec
dr	20	Maximum frequency	60.00		40.00~400.00	Hz
bA	08	Acc/Dec reference frequency	0	Max Freq	0~1	-
	09	Time scale setting	1	0.1sec	0~2	-

Acc/Dec Time Based on Maximum Frequency – Setting Details

Code	Description									
bA.08 Ramp T Mode	Set the parameter value to 0 (Max Freq) to setup Acc/Dec time based on maximum frequency.									
	<table border="1"> <thead> <tr> <th colspan="2">Configuration</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Max Freq</td> <td>Set the Acc/Dec time based on maximum frequency.</td> </tr> <tr> <td>1</td> <td>Delta Freq</td> <td>Set the Acc/Dec time based on operating frequency.</td> </tr> </tbody> </table>	Configuration		Function	0	Max Freq	Set the Acc/Dec time based on maximum frequency.	1	Delta Freq	Set the Acc/Dec time based on operating frequency.
	Configuration		Function							
	0	Max Freq	Set the Acc/Dec time based on maximum frequency.							
1	Delta Freq	Set the Acc/Dec time based on operating frequency.								
If, for example, maximum frequency is 60.00 Hz, the Acc/Dec times are set to 5 seconds, and the frequency reference for operation is set at 30 Hz (half of 60 Hz), the time required to reach 30 Hz therefore is 2.5 seconds (half of 5 seconds).										

Code	Description												
bA.09 Time scale	<p>Use the time scale for all time-related values. It is particularly useful when a more accurate Acc/Dec times are required because of load characteristics, or when the maximum time range needs to be extended.</p> <table border="1"> <thead> <tr> <th colspan="2">Configuration</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0.01sec</td> <td>Sets 0.01 second as the minimum unit.</td> </tr> <tr> <td>1</td> <td>0.1sec</td> <td>Sets 0.1 second as the minimum unit.</td> </tr> <tr> <td>2</td> <td>1sec</td> <td>Sets 1 second as the minimum unit.</td> </tr> </tbody> </table>	Configuration		Function	0	0.01sec	Sets 0.01 second as the minimum unit.	1	0.1sec	Sets 0.1 second as the minimum unit.	2	1sec	Sets 1 second as the minimum unit.
Configuration		Function											
0	0.01sec	Sets 0.01 second as the minimum unit.											
1	0.1sec	Sets 0.1 second as the minimum unit.											
2	1sec	Sets 1 second as the minimum unit.											

ⓘ Caution

Note that the range of maximum time values may change automatically when the units are changed. If for example, the acceleration time is set at 6000 seconds, a time scale change from 1 second to 0.01 second will result in a modified acceleration time of 60.00 seconds.

4.8.2 Acc/Dec Time Based on Operation Frequency

Acc/Dec times can be set based on the time required to reach the next step frequency from the existing operation frequency. To set the Acc/Dec time values based on the existing operation frequency, set bA. 08 (acc/dec reference) in the Basic group to 1 (Delta Freq).

Group	Code	Name	Setting	Setting Range	Unit
Run	ACC	Acceleration time	20.0	0.0~600.0	sec
	DEC	Deceleration time	30.0	0.0~600.0	sec
bA	08	Acc/Dec reference frequency	1 Delta Freq	0~1	-

Acc/Dec Time Based on Operation Frequency – Setting Details

Code	Description										
bA.08 Ramp T Mode	Set the parameter value to 1 (Delta Freq) to set Acc/Dec times based on Maximum frequency.										
	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="background-color: #e0e0e0;">Configuration</th> <th style="background-color: #e0e0e0;">Function</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td style="text-align: center;">Max Freq</td> <td>Set the Acc/Dec time based on maximum frequency.</td> </tr> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">Delta Freq</td> <td>Set the Acc/Dec time based on operating frequency.</td> </tr> </tbody> </table>		Configuration		Function	0	Max Freq	Set the Acc/Dec time based on maximum frequency.	1	Delta Freq	Set the Acc/Dec time based on operating frequency.
	Configuration		Function								
	0	Max Freq	Set the Acc/Dec time based on maximum frequency.								
1	Delta Freq	Set the Acc/Dec time based on operating frequency.									
If Acc/Dec times are set to 5 seconds, and multiple frequency references are used in the operation in 2 steps, at 10Hz and 30 Hz, each acceleration stage will take 5 seconds (refer to the graph below).											

4.8.3 Multi-step Acc/Dec Time Configuration

Acc/Dec times can be configured via a multi-function terminal by setting the ACC (acceleration time) and DEC (deceleration time) codes in the Operation group.

Group	Code	Name	Setting	Setting Range	Unit	
Run	ACC	Acceleration time	20.0	0.0~600.0	sec	
	DEC	Deceleration time	30.0	0.0~600.0	sec	
bA	70~82	Multi-step acceleration time 1-7	0.0	0.0~600.0	sec	
	71~83	Multi-step deceleration time 1-7	0.0	0.0~600.0	sec	
In	65~69	Px terminal setting options	11	XCEL-L	0~52	-
			12	XCEL-M		
			49	XCEL-H		
	89	Multi-step command delay time	1	1~5000	ms	

Acc/Dec Time Setup via Multi-function Terminals – Setting Details

Code	Description
bA. 70~82 Acc Time 1~7	Set multi-step acceleration time 1~7.
bA.71~83 Dec Time 1~7	Set multi-step deceleration time 1~7.

Choose and configure the terminals to use for multi-step Acc/Dec time inputs.

Configuration		Function
11	XCEL-L	Acc/Dec command-L
12	XCEL-M	Acc/Dec command-M
49	XCEL-H	Acc/Dec command-H

Acc/Dec commands are recognized as binary code inputs and will control the acceleration and deceleration based on parameter values set with bA.70~83.

If, for example, the P4 and P5 terminals are set as XCEL-L and XCEL respectively, the following operation will be available.

In.65~69
Px Define
(P1~P5)

Acc/Dec time	P5	P4
0	-	-
1	-	✓
2	✓	-
3	✓	✓

[Configuration of multi-function terminals P4 and P5]

In.89 In Check Time	Set the time for the inverter to check for other terminal block inputs. In.89 is set to 100 ms and a signal is supplied to the P4 terminal, the inverter searches for other inputs over the next 100 ms. When the time expires, the Acc/Dec time will be set based on the input received at P4.
---------------------	---


4.8.4 Acc/Dec Time Switch Frequency

You can switch between two different sets of Acc/Dec times (Acc/Dec gradients) by configuring the switch frequency without configuring the multi-function terminals.

Group	Code	Name	Setting	Setting Range	Unit
Run	ACC	Acceleration time	10.0	0.0~600.0	sec
	DEC	Deceleration time	10.0	0.0~600.0	sec
bA	70	Multi-step acceleration time 1	20.0	0.0~600.0	sec
	71	Multi-step deceleration time 1	20.0	0.0~600.0	sec
Ad	60	Acc/Dec time transition frequency	30.00	0~Max Frequency	Hz

Acc/Dec Time Switch Frequency Setting Details

Code	Description
Ad.60 Xcel Change Fr	<p>After the Acc/Dec switch frequency has been set, Acc/Dec gradients configured at bA.70 and 71 will be used when the inverter's operation frequency is at or below the switch frequency.</p> <p>If the operation frequency exceeds the switch frequency, the configured gradient level, configured for the ACC and DEC codes, will be used.</p> <p>If you configure the P1–P5 multi-function input terminals for multi-step Acc/Dec gradients (XCEL-L, XCEL-M, XCEL-H), the inverter will operate based on the Acc/Dec inputs at the terminals instead of the Acc/Dec switch frequency configurations.</p>



4.9 Acc/Dec Pattern Configuration


Acc/Dec gradient level patterns can be configured to enhance and smooth the inverter's acceleration and deceleration curves. Linear pattern features a linear increase or decrease to the output frequency, at a fixed rate. For an S-curve pattern a smoother and more gradual increase or decrease of output frequency, ideal for lift-type loads or elevator doors, etc. S-curve gradient level can be adjusted using codes Ad. 03–06 in the Advanced group.

Group	Code	Name	Setting	Setting Range	Unit
bA	08	Acc/Dec reference	0 Max Freq	0~1	-
Ad	01	Acceleration pattern	0 Linear	0~1	-
	02	Deceleration pattern	1 S-curve		-
	03	S-curve acceleration start point gradient	40	1~100	%
	04	S-curve acceleration end point gradient	40	1~100	%
	05	S-curve deceleration start point gradient	40	1~100	%
	06	S-curve deceleration end point gradient	40	1~100	%



Acc/Dec Pattern Setting Details

Code	Description
Ad.03 Acc S Start	<p>If the acc/dec pattern is set as the S-curve, set the gradient level (slant) for the acceleration start time. Gradient level is the ratio which gradient acceleration takes up in the section under 1/2 frequency based on the 1/2 frequency of target frequency.</p> <p>If the frequency reference and maximum frequency are set at 60 Hz and Ad.03 is set to 50 %, Ad. 03 configures acceleration up to 30 Hz (half of 60 Hz).The inverter will operate S-curve acceleration in the 0-15 Hz frequency range (50% of 30 Hz). Linear acceleration will be applied to the remaining acceleration within the 15–30 Hz frequency range.</p>
Ad.04 Acc S End	<p>Set the gradient level for when the operation frequency reaches the target frequency.</p> <p>If the frequency reference and the maximum frequency are set at 60 Hz and Ad.04 is set to 50 %, setting Ad. 04 configures acceleration to increase from 30 Hz (half of 60 Hz) to 60 Hz (end of acceleration). Linear acceleration will be applied within the 30-45 Hz frequency range. The inverter will perform an S-curve acceleration for the remaining acceleration in the 45–60 Hz frequency range.</p> <p>If the frequency reference and the maximum frequency are set at 60 Hz and Ad.04 is set to 50 %, setting Ad. 04 configures acceleration to increase from 30 Hz (half of 60 Hz) to 60 Hz (end of acceleration). Linear acceleration will be applied within the 30-45 Hz frequency range. The inverter will perform an S-curve acceleration for the remaining acceleration in the 45–60 Hz frequency range.</p>

Code	Description
Ad.05 Dec S Start – Ad.06 Dec S End	Sets the rate of S-curve deceleration. The setup method is the same as the ratio during acceleration.



[Acceleration / deceleration pattern configuration]



[Acceleration / deceleration S-curve pattern configuration]

Note

The Actual Acc/Dec time during an S-curve application

Actual acceleration time = user-configured acceleration time + user-configured acceleration time x starting gradient level/2 + user-configured acceleration time x ending gradient level/2.
 Actual deceleration time = user-configured deceleration time + user-configured deceleration time x starting gradient level/2 + user-configured deceleration time x ending gradient level/2.


⚠ Caution

Note that actual Acc/Dec times become greater than user defined Acc/Dec times when S-curve Acc/Dec patterns are in use.

4.10 Stopping the Acc/Dec Operation

Configure the multi-function input terminals to stop acceleration or deceleration and operate the inverter at a fixed frequency.

Group	Code	Name	Setting	Setting Range	Unit	
In	65—69	Px terminal setting options	25	XCEL Stop	0~52	-



4.11 V/F Control

Configure the inverter’s output voltages, gradient levels and output patterns to achieve a target output frequency with V/F control. The amount of torque boost used during low frequency operations can also be adjusted.

4.11.1 Linear V/F Pattern Operation

A linear V/F pattern configures the inverter to increase or decrease the output voltage at a fixed rate for different operation frequencies based on V/F characteristics. Used for loads that require constant torque regardless of the frequency.

Group	Code	Name	Setting	Setting Range	Unit	
dr	09	Control mode	0	V/F	0~4	-
	18	Base frequency	60.00		30.00~400.00	Hz
	19	Start frequency	0.50		0.01~10.00	Hz
bA	07	V/F pattern	0	Linear	0~3	-

Linear V/F Pattern Setting Details

Code	Description
dr.18 Base Freq	Sets the base frequency. A base frequency is the inverter's output frequency when running at its rated voltage. Refer to the motor's rating plate to set this parameter value.
dr.19 Start Freq	<p>Sets the start frequency. A start frequency is a frequency at which the inverter starts voltage output.</p> <p>The inverter does not produce output voltage while the frequency reference is lower than the set frequency. However, if a deceleration stop is made while operating above the start frequency, output voltage will continue until the operation frequency reaches a full-stop (0 Hz).</p>


4.11.2 Square Reduction V/F Pattern Operation

Square reduction V/F pattern is ideal for loads such as fans and pumps. It provides non-linear acceleration and deceleration patterns to sustain torque throughout the whole frequency range.

Group	Code	Name	Setting	Setting Range	Unit	
bA	07	V/F pattern	1	Square	0~3	-
			3	Square2		

Square Reduction V/F Pattern Operation - Setting Details

Code	Description	
bA.07 V/F Pattern	Sets the parameter value to 1 (Square) or 3 (Square2) according to the load's start characteristics.	
	Configuration	Function
	1	Square The inverter produces output voltage proportional to 1.5 square of the operation frequency.
3	Square2 The inverter produces output voltage proportional to 2 square of the operation frequency. This setup is ideal for variable torque loads such as fans or pumps.	



4.11.3 User V/F Pattern Operation


The G100 inverter allows the configuration of user-defined V/F patterns to suit the load characteristics of special motors.

Group	Code	Name	Setting	Setting Range	Unit
bA	07	V/F pattern	2 User V/F	0~3	-
	41	User Frequency 1	15.00	0~Max Frequency	Hz
	42	User Voltage 1	25	0~100	%
	43	User Frequency 2	30.00	0~Max Frequency	Hz
	44	User Voltage 2	50	0~100	%
	45	User Frequency 3	45.00	0~Max Frequency	Hz
	46	User Voltage 3	75	0~100	%
	47	User Frequency 4	Maximum frequency	0~Max Frequency	Hz
	48	User Voltage 4	100	0~100 %	%

User V/F Pattern Setting Details

Code	Description
bA.41 User Freq 1 – bA.48 User Volt 4	Set the parameter values to assign arbitrary frequencies (User Freq 1–4) for start and maximum frequencies. Voltages can also be set to correspond with each frequency, and for each user voltage (User Volt 1–4).

The 100% output voltage in the figure below is based on the parameter settings of bA.15 (motor rated voltage). If bA.15 is set to 0 it will be based on the input voltage.



⚠ Caution

- When a normal induction motor is in use, care must be taken not to configure the output pattern away from a linear V/F pattern. Non-linear V/F patterns may cause insufficient motor torque or motor overheating due to over-excitation.
- When a user V/F pattern is in use, forward torque boost (dr.16) and reverse torque boost (dr.17) do not operate.

4.12 Torque Boost


4.12.1 Manual Torque Boost

Manual torque boost enables users to adjust output voltage during low speed operation or motor start. Increase low speed torque or improve motor starting properties by manually increasing output voltage. Configure manual torque boost while running loads that require high starting torque, such as lift-type loads.

Group	Code	Name	Setting		Setting Range	Unit
dr	15	Torque boost mode	0	Manual	0~1	-
	16	Forward Torque boost	2.0		0.0~15.0	%
	17	Reverse torque boost	2.0		0.0~15.0	%

Manual Torque Boost Setting Details

Code	Description
dr.16 Fwd Boost	Set torque boost for forward operation.
dr.17 Rev Boost	Set torque boost for reverse operation.



⚠ Caution

Excessive torque boost will result in over-excitation and motor overheating.

4.12.2 Auto Torque Boost

In V/F operation, this adjusts the output voltage if operation is unavailable due to a low output voltage. It is used when operation is unavailable, due to a lack of starting torque, by providing a voltage boost to the output voltage via the torque current.

Group	Code	Name	Setting		Setting Range	Unit
dr	15	Torque boost mode	1	Auto	0~1	-
dr	26	Auto torque boost filter gain	2		1~1000	-
dr	27	Auto torque boost motoring voltage gain	50.0		0.0~300.0	%
dr	28	Auto torque boost regeneration voltage gain	50.0		0.0~300.0	%

You can use the parameter value displayed on the motor's rating plate without motor parameter tuning. Use after entering the value recorded on the motor's rating plate in dr18 (base frequency), bA12 (motor's rated slip frequency), bA13 (motor's rated current), and bA14 (motor's no load current). If you do not use the value displayed on the motor's rating plate, each parameter value is set to the initial value and some features may be limited.


In V/F operation, this adjusts the output voltage if operation is unavailable due to a low output voltage. Use when it cannot be started due to the lack of the starting torque as a method to output voltage by adding the voltage boost quantity calculated by using torque current on the manual torque boost quantity (dr16, dr17). If the run direction is forward, dr16 forward torque boost quantity is applied. If the direction is reverse, dr17 reverse torque boost quantity is applied. As the values to adjust the amount of compensation according to the load, dr27 and dr28 automatic torque boost voltage gain can be adjusted and used when there is a lack of starting torque or when excessive current is flowing.

If number 1 (automatic torque boost) is selected from the dr15 code of drive (dr) group, dr26, dr27, and dr28 parameters can be corrected and the inverter outputs voltage according to the torque boost quantity.

4.13 Motor Output Voltage Adjustment

Output voltage settings are required when a motor's rated voltage differs from the input voltage to the inverter. Set bA.15 to configure the motor's rated operating voltage. The set voltage becomes the output voltage of the inverter's base frequency. If bA.15 (motor rated voltage) is set to 0, the inverter corrects the output voltage based on the input voltage in the stopped condition. If the frequency is higher than the base frequency, when the input voltage is lower than the parameter setting, the input voltage will be the inverter output voltage.

Group	Code	Name	Setting	Setting Range	Unit
bA	15	Motor rated voltage	0	0, 170–480	V



4.14 Start Mode Setting

Select the start mode to use when the operation command is input with the motor in the stopped condition.

4.14.1 Accelerating Start


Acceleration start is a general acceleration mode. If there are no extra settings applied, the motor accelerates directly to the frequency reference when the command is input.

Group	Code	Name	Setting	Setting Range	Unit
Ad	07	Start Mode	0 Acc	0~1	-

4.14.2 DC Braking After Start

This start mode supplies a DC voltage for a set amount of time to provide DC braking before an inverter starts to accelerate a motor. If the motor continues to rotate due to its inertia, DC braking will stop the motor, allowing the motor to accelerate from a stopped condition. DC braking can also be used with a mechanical brake connected to a motor shaft when a constant torque load is applied, if a constant torque is required after the mechanical brake is released. The function to start after DC braking will not operate if the control mode is set to IM Sensorless.

Group	Code	Name	Setting	Setting Range	Unit
Ad	07	Start Mode	1 Dc-Start	0~1	-
	12	Start DC braking time	0.00	0.00~60.00	sec
	13	Amount of applied DC	50	0–inverter rated current	%



⚠ Caution

The amount of DC braking required is based on the motor's rated current. Do not use DC braking resistance values that can cause current draw to exceed the rated current of the inverter. If the DC braking resistance is too high or brake time is too long, the motor may overheat or be damaged. The maximum value of the amount of applied DC is limited to the inverter rated current.

4.14.3 Initial Excitation of Stop Status (Pre-excite)

Use to apply the exciting current to the motor under a stop status. If you enter the multi-function input signal set with the initial excitation signal, DC voltage will be supplied to the motor.

Group	Code	Name	Setting		Setting Range	Unit
Ad	13	Amount of applied DC	50		0~200	%
In	65~69	Px terminal setting options	34	Pre excite	-	-

⚠ Caution

The amount of DC braking required is based on the motor's rated current. Do not use DC braking resistance values that can cause current draw to exceed the rated current of the inverter. If the DC braking resistance is too high or brake time is too long, the motor may overheat or be damaged. The maximum value of the amount of applied DC is limited to the inverter rated current.


4.15 Stop Mode Setting

Select a stop mode to stop the inverter operation.

4.15.1 Deceleration Stop

Deceleration stop is a general stop mode. If there are no extra settings applied, the motor decelerates down to 0 Hz and stops, as shown in the figure below.

Group	Code	Name	Setting		Setting Range	Unit
Ad	08	Stop Mode	0	Dec	0~4	-




4.15.2 DC Braking After Stop

When the operation frequency reaches the set value during deceleration (DC braking frequency), the inverter stops the motor by supplying DC power to the motor. With a stop command input, the inverter begins decelerating the motor. When the frequency reaches the DC braking frequency set at Ad.17, the inverter supplies DC voltage to the motor and stops it.

Group	Code	Name	Setting	Setting Range	Unit
Ad	08	Stop Mode	0 Dec	0~4	-
	14	Output block time before braking	0.10	0.00~60.00	sec
	15	DC braking time	1.00	0~60	sec
	16	DC braking rate	50	0–inverter rated current	%
	17	DC braking frequency	5.00	0.00~60.00	Hz

DC Braking After Stop Setting Details

Code	Description
Ad.14 Dc-Block Time	Set the time to block the inverter output before DC braking. If the inertia of the load is great, or if DC braking frequency (Ad.17) is set too high, a fault trip may occur due to overcurrent conditions when the inverter supplies DC voltage to the motor. Prevent overcurrent fault trips by adjusting the output block time before DC braking.
Ad.15 Dc-Brake Time	Set the time duration for the DC voltage supply to the motor.
Ad.16 Dc-Brake Level	Set the amount of DC braking to apply. The parameter setting is based on the rated current of the motor. The maximum value of the DC braking rate is limited as an inverter rated current.
Ad.17 Dc-Brake Freq	Set the frequency to start DC braking. When the frequency is reached, the inverter starts deceleration. If the dwell frequency is set lower than the DC braking frequency, dwell operation will not work and DC braking will start instead.




⚠ Caution

- Note that the motor can overheat or be damaged if excessive amount of DC braking is applied to the motor, or DC braking time is set too long.
- DC braking is configured based on the motor's rated current. To prevent overheating or damaging motors, do not set the current value higher than the inverter's rated current. The maximum value of the DC braking rate is limited as an inverter rated current.

4.15.3 Free Run Stop

When the Operation command is off, the inverter output turns off, and the load stops due to residual inertia.

Group	Code	Name	Setting	Setting Range	Unit
Ad	08	Stop Mode	2	Free-Run	-



⚠ Caution

Note that when there is high inertia on the output side and the motor is operating at high speed, the load's inertia will cause the motor to continue rotating even if the inverter output is blocked.

4.15.4 Power Braking

When the inverter's DC voltage rises above a specified level due to motor regenerated energy, a control is made to either adjust the deceleration gradient level or reaccelerate the motor in order to reduce the regenerated energy. Power braking can be used when short deceleration times are needed without brake resistors, or when optimum deceleration is needed without causing an over voltage fault trip.

Group	Code	Name	Setting	Setting Range	Unit
Ad	08	Stop Mode	4	Power Braking	-

⚠ Caution

- To prevent overheating or damaging the motor, do not apply power braking to the loads that require frequent deceleration.
- Stall prevention and power braking only operate during deceleration, and power braking takes priority over stall prevention. In other words, when both Pr.50 (stall prevention and flux braking) and Ad.08 (power braking) are set, power braking will take precedence and operate.
- Note that if deceleration time is too short or inertia of the load is too great, an overvoltage fault trip may occur.
- Note that if a free run stop is used, the actual deceleration time can be longer than the pre-set deceleration time.

4.16 Frequency Limit

Operation frequency can be limited by setting maximum frequency, start frequency, upper limit frequency and lower limit frequency.

4.16.1 Frequency Limit Using Maximum Frequency and Start Frequency

Group	Code	Name	Setting	Setting Range	Unit
dr	19	Start frequency	0.50	0.01~10.00	Hz
	20	Maximum frequency	60.00	40.00~400.00	Hz

Frequency Limit Using Maximum Frequency and Start Frequency - Setting Details


Code	Description
dr.19 Start Freq	Set the lower limit value for speed unit parameters that are expressed in Hz or rpm. If an input frequency is lower than the start frequency, the parameter value will be 0.00.
dr.20 Max Freq	Set upper and lower frequency limits. All frequency selections are restricted to frequencies from within the upper and lower limits. This restriction also applies when you in input a frequency reference using the keypad.

4.16.2 Frequency Limit Using Upper and Lower Limit Frequency Values

Group	Code	Name	Setting	Setting Range	Unit
Ad	24	Frequency limit	0 No	0~1	-
	25	Frequency lower limit value	0.50	0.0–maximum frequency	Hz
	26	Frequency upper limit value	Maximum frequency	Lower limit–maximum frequency	Hz

Frequency Limit Using Upper and Lower Limit Frequencies - Setting Details

Code	Description
Ad.24 Freq Limit	The initial setting is 0 (No). When the setting is changed to 1 (Yes), the frequency can be set only between the lower limit frequency (Ad.25) and the upper limit frequency (Ad.26). When the setting is 0 (No), codes Ad.25 and Ad.26 are not visible.
Ad.25 Freq Limit Lo, Ad.26 Freq Limit Hi	Set an upper limit frequency to all speed unit parameters that are expressed in Hz or rpm, except for the base frequency (dr.18). Frequency cannot be set higher than the upper limit frequency.




4.16.3 Frequency Jump

Use frequency jump to avoid mechanical resonance frequencies. Jump through frequency bands when a motor accelerates and decelerates. Operation frequencies cannot be set within the pre-set frequency jump band.

When a frequency setting is increased, while the frequency parameter setting value (voltage, current, RS-485 communication, keypad setting, etc.) is within a jump frequency band, the frequency will be maintained at the lower limit value of the frequency band. Then, the frequency will increase when the frequency parameter setting exceeds the range of frequencies used by the frequency jump band.

Group	Code	Name	Setting	Setting Range	Unit
Ad	27	Frequency jump	0 No	0~1	-
	28	Jump frequency lower limit 1	10.00	0.00–Jump frequency upper limit 1	Hz
	29	Jump frequency upper limit 1	15.00	Jump frequency lower limit 1–Maximum frequency	Hz
	30	Jump frequency lower limit 2	20.00	0.00–Jump frequency upper limit 2	Hz
	31	Jump frequency upper limit 2	25.00	Jump frequency lower limit 2–Maximum frequency	Hz
	32	Jump frequency lower limit 3	30.00	0.00–Jump frequency upper limit 3	Hz
	33	Jump frequency upper limit 3	35.00	Jump frequency lower limit 3–Maximum frequency	Hz



4.17 2nd Operation Mode

Apply two types of operation modes and switch between them as required. For both the first and second command source, set the frequency after shifting operation commands to the multi-function input terminal. Mode switching can be used to stop remote control during an operation using the communication option and to switch operation mode to operate via the local panel, or to operate the inverter from another remote control location.

Select one of the multi-function terminals from codes In. 65–69 and set the parameter value to 15 (2nd Source).

Group	Code	Name	Setting	Setting Range	Unit	
Run	drv	Command Source	1	Fx/Rx-1	0~4	-
	Frq	Frequency reference source	2	V1	0~8	-
bA	04	2nd command source	0	Keypad	0~4	-
	05	2nd frequency source	0	KeyPad-1	0~8	-
In	65~69	Px terminal setting options	15	2nd Source	0~52	-

2nd Operation Mode Setting Details

Code	Description
bA.04 Cmd 2nd Src bA.05 Freq 2nd Src	If signals are provided to the multi-function terminal set as the 2nd command source (2nd Source), the operation can be performed using the set values from bA.04-05 instead of the set values from the drv and Frq codes in the Operation group. The 2nd command source settings cannot be changed while operating with the 1st command source (Main Source).

⚠ Caution

- When setting the multi-function terminal to the 2nd command source (2nd Source) and input (On) the signal, operation state is changed because the frequency setting and the Operation command will be changed to the 2nd command. Before shifting input to the multi-function terminal, ensure that the 2nd command is correctly set. Note that if the deceleration time is too short or inertia of the load is too high, an overvoltage fault trip may occur.
- Depending on the parameter settings, the inverter may stop operating when you switch the command modes.













4.18 Multi-Function Input Terminal Control



Filter time constants and the type of multi-function input terminals can be configured to improve the response of input terminals.

Group	Code	Name	Setting	Setting Range	Unit
In	85	Multi-function input terminal On filter	10	0~10000	ms
	86	Multi-function input terminal Off filter	3	0~10000	ms
	87	Multi-function input terminal selection	0 0000*	-	-
	88	NO/NC selection of operation command	0	0~1	-
	90	Multi-function input terminal status	0 0000*	-	-

* Displayed as  on the keypad.

Multi-Function Input Terminal Control Setting Details

Code	Description						
In.84 DI Delay Sel	Select whether or not to activate the time values set at In.85 and In.86. If deactivated, the time values are set to the default values at In.85 and In.86. If activated, the set time values at In.85 and In.86 are set to the corresponding terminals.						
	<table border="1"> <thead> <tr> <th>Items</th> <th>B terminal status (Normally Closed)</th> <th>A terminal status (Normally Open)</th> </tr> </thead> <tbody> <tr> <td>Keypad</td> <td></td> <td></td> </tr> </tbody> </table>	Items	B terminal status (Normally Closed)	A terminal status (Normally Open)	Keypad		
	Items	B terminal status (Normally Closed)	A terminal status (Normally Open)				
Keypad							
In.85 DI On Delay, In.86 DI Off Delay	If the input terminal's state is not changed during the set time, when the terminal receives an input, it is recognized as On or Off.						
In.87 DI NC/NO Sel	Select terminal contact types for each input terminal. The position of the indicator light corresponds to the segment that is on as shown in the table below. With the bottom segment on, it indicates that the terminal is configured as an A terminal (Normally Open) contact. With the top segment on, it indicates that the terminal is configured as a B terminal (Normally Closed) contact. Terminals are numbered P1–P5, from right to left.						
	<table border="1"> <thead> <tr> <th>Items</th> <th>B terminal status (Normally Closed)</th> <th>A terminal status (Normally Open)</th> </tr> </thead> <tbody> <tr> <td>Keypad</td> <td></td> <td></td> </tr> </tbody> </table>	Items	B terminal status (Normally Closed)	A terminal status (Normally Open)	Keypad		
	Items	B terminal status (Normally Closed)	A terminal status (Normally Open)				
Keypad							

Code	Description		
In.88 Fx/Rx NO/NC Sel	Select whether to use the terminal set to Fx/Rx as NO (Normal Open) only or to use as NO (Normal Open) and NC(Normal Close). If set to 1:NO only, the terminal in which the functions are set to Fx/Rx cannot be set as NC. If set to 0:NO/NC, terminals set as Fx/Rx can also be set as NC.		
In.90 DI Status	Display the configuration of each contact. When a segment is configured as A terminal using dr.87, the On condition is indicated by the top segment turning on. The Off condition is indicated when the bottom segment is turned on. When contacts are configured as B terminals, the segment lights behave conversely. Terminals are numbered P1–P5, from right to left.		
	Items	A terminal setting (On)	A terminal setting (Off)
	Keypad		

4.19 Fire Mode Operation

This function is used to allow the inverter to ignore minor faults during emergency situations, such as fire, and provides continuous operation to fire pumps.

When turned on, Fire mode forces the inverter to ignore all minor fault trips and repeat a Reset and Restart for major fault trips, regardless of the restart trial count limit. The retry delay time set at PR. 10 (Retry Delay) still applies while the inverter performs a Reset and Restart.

Fire Mode Parameter Settings

Group	Code	Name	Setting		Setting Range	Unit
Ad	80	Fire Mode selection	1	Fire Mode	0~2	-
	81	Fire Mode frequency	0~60		0~60	
	82	Fire Mode run direction	0~1		0~1	
	83	Fire Mode operation count	Not configurable		-	-
In	65~69	Px terminal setting options	51	Fire Mode	0~52	-

Ad 80. If Fire Mode Sel parameter is selected as Fire Mode and the terminal selected as 51:Fire Mode in In. 65-69 Px terminal feature setup parameter is entered as On state, the inverter will operate as Fire Mode and Ad 83. Fire Mode Count will be increased by 1.

ⓘ Caution

Fire mode operation may result in inverter malfunction. Note that if AD 83 Fire mode count is not "0m" the warranty is voided.

Code	Description	Details
Ad.81 Fire Mode frequency	Fire mode frequency reference	The frequency set at Ad. 81 (Fire mode frequency) is used for the inverter operation in Fire mode. The Fire mode frequency takes priority over the Jog frequency, Multi-step frequencies, and the keypad input frequency.
Dr.03 Acc Time / Dr.04 Dec Time	Fire mode Acc/Dec times	During Fire Mode operation, the inverter accelerates for the time set in Dr 03. Acc Time. If the Px terminal input set as Fire Mode input becomes Off status, the inverter decelerates for the time set in Dr 0.4. Dec Time until the operation is ended.
PR.10 Retry Delay	Fault trip process	<p>Some fault trips are ignored during Fire mode operation. The fault trip history is saved, but trip outputs are disabled even when they are configured at the multi-function output terminals.</p> <p>Fault trips that are ignored in Fire mode BX, External Trip, Low Voltage Trip, Inverter Overheat, Inverter Overload, Overload, Electrical Thermal Trip, Input/Output Open Phase, Motor Overload, Fan Trip, No Motor Trips, and other minor fault trips.</p>
		<p>For the following fault trips, the inverter performs a Reset and Restart until the trip conditions are released. The retry delay time set at PR. 10 (Retry Delay) applies while the inverter performs a Reset and Restart.</p> <p>Fault trips that force a Reset Restart in Fire mode Over Voltage, Over Current1(OC1), Ground Fault Trip</p>
		<p>The inverter stops operating when the following fault trips occur:</p> <p>Fault trips that stop inverter operation in Fire mode H/W Diag, Over Current 2 (Arm-Short)</p>

5 Learning Advanced Features

This chapter describes the advanced features of the G100 inverter. Check the reference page in the table to see the detailed description for each of the advanced features.

Advanced Tasks	Description	Ref.
Auxiliary frequency operation	Use the main and auxiliary frequencies in the predefined formulas to create various operating conditions. Auxiliary frequency operation is ideal for Draw Operation* as this feature enables fine-tuning of operation speeds.	<u>p.105</u>
Jog operation	Jog operation is a kind of a manual operation. The inverter operates to a set of parameter settings predefined for Jog operation, while the Jog command button is pressed.	<u>p.109</u>
Up-down operation	Uses the upper and lower limit value switch output signals (i.e. signals from a flow meter) as Acc/Dec commands to motors.	<u>p.111</u>
3-wire operation	3-wire operation is used to latch an input signal. This configuration is used to operate the inverter by a push button.	<u>p.113</u>
Safe Operation mode	This safety feature allows the inverter's operation only after a signal is input to the multi-function terminal designated for the safety operation mode. This feature is useful when extra care is needed in operating the inverter using the multi-purpose terminals.	<u>p.114</u>
Dwell operation	Use this feature for the lift-type loads such as elevators, when the torque needs to be maintained while the brakes are applied or released.	<u>p.115</u>
Slip compensation	This feature ensures that the motor rotates at a constant speed, by compensating for the motor slip as a load increases.	<u>p.117</u>
PID Control	PID control provides constant automated control of flow, pressure, and temperature by adjusting the output frequency of the inverter.	<u>p.118</u>
Auto tuning	Used to automatically measure the motor control parameters to optimize the inverter's control mode performance.	<u>p.126</u>
sensorless vector control	An efficient mode to control magnetic flux and torque without special sensors. Efficiency is achieved through the high torque characteristics at low current when compared with the V/F control mode.	<u>p.129</u>
Energy buffering	Used to maintain the DC link voltage for as long as possible by controlling the inverter output frequency during power interruptions, thus to delay a low voltage fault trip.	<u>p.135</u>
Energy saving operation	Used to save energy by reducing the voltage supplied to motors during low-load and no-load conditions.	<u>p.138</u>
Speed search operation	Used to prevent fault trips when the inverter voltage is output while the motor is idling or free-running.	<u>p.139</u>

Advanced Tasks	Description	Ref.
Auto restart operation	Auto restart configuration is used to automatically restart the inverter when a trip condition is released, after the inverter stops operating due to activation of protective devices (fault trips).	<u>p.143</u>
2 nd Motor Operation	Used to switch equipment operation by connecting two motors to one inverter. Configure and operate the second motor using the terminal input defined for the second motor operation.	<u>p.146</u>
commercial power source transition	Used to switch the power source to the motor from the inverter output to a commercial power source, or vice versa.	<u>p.147</u>
Cooling fan control	Used to control the cooling fan of the inverter.	<u>p.148</u>
Timer settings	Set the timer value and control the On/Off state of the multi-function output and relay.	<u>p.152</u>
brake control	Used to control the On/Off operation of the load's electronic braking system.	<u>p.153</u>
Multi-function output On/Off control	Set standard values and turn On/Off the output relays or multi-function output terminals according to the analog input value.	<u>p.154</u>
press regeneration prevention	Used during a press operation to avoid motor regeneration, by increasing the motor operation speed.	<u>p.155</u>

* Draw operation is an openloop tension control. This feature allows a constant tension to be applied to the material that is drawn by a motor-driven device, by fine-tuning the motor speed using operation frequencies that are proportional to a ratio of the main frequency reference.

5.1 Operating with Auxiliary References

Frequency references can be configured with various calculated conditions that use the main and auxiliary frequency references simultaneously. The main frequency reference is used as the operating frequency, while auxiliary references are used to modify and fine-tune the main reference.


Group	Code	Name	Setting		Setting Range	Unit
Run	Frq	Frequency reference source	0	Keypad-1	0~8	-
bA	01	Auxiliary reference source	1	V1	0~4	-
	02	Auxiliary command calculation type	0	M+(G*A)	0~7	-
	03	Auxiliary frequency reference gain	0.0		-200.0~200.0	%
In	65~ 71	Px terminal setting options	40	dis Aux Ref	0~52	-

The table above lists the available calculated conditions for the main and auxiliary frequency references. Refer to the table to see how the calculations apply to an example where the Frq code has been set to 0(Keypad-1), and the inverter is operating at a main reference frequency of 30.00 Hz. Signals at -10 – +10 V are received at terminal V1, with the reference gain set at 5 %. In this example, the resulting frequency reference is fine-tuned within the range of 27.00–33.00 Hz [Codes In.01–16 must be set to the default values, and In.06 (V1 Polarity), set to 1 (Bipolar)].

Auxiliary Reference Setting Details

Code	Description		
bA.01 Aux Ref Src	Set the input type to be used for the auxiliary frequency reference.		
	Configuration		Function
	0	None	Auxiliary frequency reference is disabled.
	1	V1	Sets the V1 (voltage) terminal at the control terminal block as the source of auxiliary frequency reference.
	3	V0	Select the volume dial of keypad as auxiliary command.
4	I2	Sets the I2 (current) terminal at the control terminal block as the source of auxiliary frequency reference.	

bA.02 Aux Calc Type	Set the auxiliary reference gain with bA.03 (Aux Ref Gain) to configure the auxiliary reference and set the percentage to be reflected when calculating the main reference. Note that items 4–7 below may result in either plus (+) or minus (-) references (forward or reverse operation) even when unipolar analog inputs are used.		
	Configuration	Calculating final command frequency	
	0	$M+(G^*A)$	Main reference+(bA.03xbA.01xln.01)
	1	$M*(G^*A)$	Main referencex(bA.03xbA.01)
	2	$M/(G^*A)$	Main reference/(bA.03xbA.01)
	3	$M+\{M*(G^*A)\}$	Main reference+{Main referencex(bA.03xbA.01)}
	4	$M+G^2*(A-50)$	Main reference+bA.03x2x(bA.01-50)xln.01
	5	$M*\{G^2*(A-50)\}$	Main referencex{bA.03x2x(bA.01-50)}
6	$M/\{G^2*(A-50)\}$	Main reference/{bA.03x2x(bA.01-50)}	
7	$M+M*G^2*(A-50)$	Main reference+Main referencexbA.03x2x(bA.01-50)	
M: Main frequency reference (Hz or rpm) G: Auxiliary reference gain (%) A: Auxiliary frequency reference (Hz or rpm) or gain (%)			
bA.03 Aux Ref Gain	Adjust the size of the input (bA.01 Aux Ref Src) configured for auxiliary frequency.		
In.65–69 Px Define	Set one of the multi-function input terminals to 40(dis Aux Ref) and turn it on to disable the auxiliary frequency reference. The inverter will operate using the main frequency reference only.		



Auxiliary Reference Operation Ex #1

Keypad Frequency Setting is Main Frequency and V1 Analog Voltage is Auxiliary Frequency

- Main frequency: Keypad (operation frequency 30 Hz)
- Maximum frequency setting (dr.20): 400 Hz
- Auxiliary frequency setting (bA.01): V1[Display by percentage(%) or auxiliary frequency (Hz) depending on the operation setting condition]
- Auxiliary reference gain setting (bA.03): 50 %
- In.01-32: Factory default output

Example: an input voltage of 6V is supplied to V1, and the frequency corresponding to 10 V is 60 Hz. The table below shows the auxiliary frequency A as 36 Hz[=60 Hz X (6 V/10 V)] or 60 % [= 100 % X (6 V/10 V)].

	Setting*	Calculating final command frequency
0	$M[z] + (G[\%] * A[\text{Hz}])$	$30\text{Hz}(M) + (50\%(G) \times 36\text{Hz}(A)) = 48\text{Hz}$
1	$M[\text{Hz}] * (G[\%] * A[\%])$	$30\text{Hz}(M) \times (50\%(G) \times 60\%(A)) = 9\text{Hz}$
2	$M[\text{Hz}] / (G[\%] * A[\%])$	$30\text{Hz}(M) / (50\%(G) \times 60\%(A)) = 100\text{Hz}$
3	$M[\text{Hz}] + \{M[\text{Hz}] * (G[\%] * A[\%])\}$	$30\text{Hz}(M) + \{30[\text{Hz}] \times (50\%(G) \times 60\%(A))\} = 39\text{Hz}$
4	$M[\text{Hz}] + G[\%] * 2 * (A[\%] - 50[\%])[\text{Hz}]$	$30\text{Hz}(M) + 50\%(G) \times 2 \times (60\%(A) - 50\%) \times 60\text{Hz} = 36\text{Hz}$
5	$M[\text{Hz}] * \{G[\%] * 2 * (A[\%] - 50[\%])\}$	$30\text{Hz}(M) \times \{50\%(G) \times 2 \times (60\%(A) - 50\%)\} = 3\text{Hz}$
6	$M[\text{Hz}] / \{G[\%] * 2 * (A[\%] - 50[\%])\}$	$30\text{Hz}(M) / \{50\%(G) \times 2 \times (60\% - 50\%)\} = 300\text{Hz}$
7	$M[\text{Hz}] + M[\text{Hz}] * G[\%] * 2 * (A[\%] - 50[\%])$	$30\text{Hz}(M) + 30\text{Hz}(M) \times 50\%(G) \times 2 \times (60\%(A) - 50\%) = 33\text{Hz}$

*M: Main frequency reference/ G: Auxiliary reference gain (%) / A: Auxiliary frequency reference (Hz or rpm) or gain (%)

Auxiliary Reference Operation Ex #2

Keypad Frequency Setting is Main Frequency and I2 Analog Voltage is Auxiliary Frequency

- Main frequency: Keypad (operation frequency 30 Hz)
- Maximum frequency setting (dr.20): 400 Hz
- Auxiliary frequency setting (bA.01): I2[Display by percentage(%) or auxiliary frequency (Hz) depending on the operation setting condition]
- Auxiliary reference gain setting (bA.03): 50 %
- In.01-32: Factory default output

Example: an input current of 10.4mA is applied to I2, with the frequency corresponding to 20mA of 60Hz. The table below shows auxiliary frequency A as 24Hz[=60[Hz] X {(10.4[mA]-4[mA])/(20[mA] - 4[mA])}] or 40% [=100[%] X {(10.4[mA] - 4[mA])/(20[mA] - 4[mA])}].

Setting*	Calculating final command frequency
0	$M[\text{Hz}] + (G[\%] \times A[\text{Hz}])$ 30Hz(M)+(50%(G)x24Hz(A))=42Hz
1	$M[\text{Hz}] \times (G[\%] \times A[\%])$ 30Hz(M)x(50%(G)x40%(A))=6Hz
2	$M[\text{Hz}] / (G[\%] \times A[\%])$ 30Hz(M)/(50%(G)x40%(A))=150Hz
3	$M[\text{Hz}] + \{M[\text{Hz}] \times (G[\%] \times A[\%])\}$ 30Hz(M)+{30[Hz]x(50%(G)x40%(A))}=36Hz
4	$M[\text{Hz}] + G[\%] \times 2 \times (A[\%] - 50[\%])[\text{Hz}]$ 30Hz(M)+50%(G)x2x(40%(A)-50%)x60Hz=24Hz
5	$M[\text{Hz}] \times \{G[\%] \times 2 \times (A[\%] - 50[\%])\}$ 30Hz(M)x{50%(G)x2x(40%(A)-50%)} = -3Hz(Reverse)
6	$M[\text{Hz}] / \{G[\%] \times 2 \times (A[\%] - 50[\%])\}$ 30Hz(M)/{50%(G)x2x(60%-40%)} = -300Hz(Reverse)
7	$M[\text{Hz}] + M[\text{Hz}] \times G[\%] \times 2 \times (A[\%] - 50[\%])$ 30Hz(M)+30Hz(M)x50%(G)x2x(40%(A)-50%)=27Hz

* M: Main frequency reference/ G: Auxiliary reference gain (%) / A: Auxiliary frequency reference (Hz or rpm) or gain (%)

Auxiliary Reference Operation Ex #3

V1 is Main Frequency and I2 is Auxiliary Frequency

- Main frequency: V1 (frequency command setting to 5 V and is set to 30 Hz)
- Maximum frequency setting (dr.20): 400 Hz
- Auxiliary frequency (bA.01): I2[Display by percentage (%) or auxiliary frequency (Hz) depending on the operation setting condition]
- Auxiliary reference gain (bA.03): 50 %
- In.01-32: Factory default output

Example: an input current of 10.4mA is applied to I2, with the frequency corresponding to 20mA of 60Hz. The table below shows auxiliary frequency Aas 24Hz(=60[Hz]x{(10.4[mA]-4[mA])/(20[mA]-4[mA])}) or 40%(=100[%] x {(10.4[mA] - 4[mA]) / (20 [mA] - 4[mA])}).

Setting*	Calculating final command frequency
0	$M[\text{Hz}] + (G[\%] \times A[\text{Hz}])$ 30Hz(M)+(50%(G)x24Hz(A))=42Hz
1	$M[\text{Hz}] \times (G[\%] \times A[\%])$ 30Hz(M)x(50%(G)x40%(A))=6Hz
2	$M[\text{Hz}] / (G[\%] \times A[\%])$ 30Hz(M)/(50%(G)x40%(A))=150Hz
3	$M[\text{Hz}] + \{M[\text{Hz}] \times (G[\%] \times A[\%])\}$ 30Hz(M)+{30[Hz]x(50%(G)x40%(A))}=36Hz
4	$M[\text{Hz}] + G[\%] \times 2 \times (A[\%] - 50[\%])[\text{Hz}]$ 30Hz(M)+50%(G)x2x(40%(A)-50%)x60Hz=24Hz
5	$M[\text{Hz}] \times \{G[\%] \times 2 \times (A[\%] - 50[\%])\}$ 30Hz(M)x{50%(G)x2x(40%(A)-50%)}=-3Hz(Reverse)
6	$M[\text{Hz}] / \{G[\%] \times 2 \times (A[\%] - 50[\%])\}$ 30Hz(M)/{50%(G)x2x(60%-40%)}=-300Hz(Reverse)
7	$M[\text{Hz}] + M[\text{Hz}] \times G[\%] \times 2 \times (A[\%] - 50[\%])$ 30Hz(M)+30Hz(M)x50%(G)x2x(40%(A)-50%)=27Hz

* M: Main frequency reference/ G: Auxiliary reference gain (%) / A: Auxiliary frequency reference (Hz or rpm) or gain (%)

Note

When the maximum frequency value is high, output frequency deviation may result due to analog input variation and deviations in the calculations.

5.2 Jog Operation

The jog operation allows for a temporary control of the inverter. You can enter a jog operation command using the multi-function terminals.


The jog operation is the second highest priority operation, after the dwell operation. If a jog operation is requested while operating the multi-step, up-down, or 3-wire operation modes, the jog operation overrides all other operation modes.

5.2.1 Jog Operation 1-Forward

The jog operation is available in either forward or reverse direction, using the keypad or multi-function terminal inputs. The table below lists parameter setting for a forward jog operation using the multi-function terminal inputs.


Group	Code	Name	Setting	Setting Range	Unit
dr	11	Jog frequency	10.00	0.50–Max Frequency	Hz
	12	Jog run acceleration time	20.00	0.00~600.00	sec
	13	Jog run deceleration time	30.00	0.00~600.00	sec
In	65~69	Px terminal setting options	6 JOG	0~52	-

Forward Jog Description Details

Code	Description
In.65–69 Px Define	<p>Select the jog frequency from P1- P5 and then select 6. Jog from In.65-69.</p>  <p>[Terminal settings for jog operation]</p>

Code	Description
dr.11 JOG Frequency	Set the operation frequency.
dr.12 JOG Acc Time	Set the acceleration speed.
dr.13 JOG Dec Time	Set the deceleration speed.


If a signal is entered at the jog terminal while an FX operation command is on, the operation frequency changes to the jog frequency and the jog operation begins.



5.2.2 Jog Operation 2-Fwd/Rev Jog by Multi-Function Terminal

For jog operation 1, an operation command must be entered to start operation, but while using jog operation 2, a terminal that is set for a forward or reverse jog also starts an operation. The priorities for frequency, Acc/Dec time and terminal block input during operation in relation to other operating modes (Dwell, 3-wire, up/down, etc.) are identical to jog operation 1. If a different operation command is entered during a jog operation, it is ignored and the operation maintains the jog frequency.

Group	Code	Name	Setting	Setting Range	Unit
dr	11	Jog Frequency	10.00	0.50-Maximum frequency	Hz
	12	Jog run acceleration time	20.00	0.00~600.00	sec
	13	Jog run deceleration time	30.00	0.00~600.00	sec
In	65~69	Px terminal setting options	46 FWD JOG 47 REV JOG	0~52	-



5.3 Up-down Operation

The Acc/Dec time can be controlled through input at the multi-function terminal block. Similar to a flowmeter, the up-down operation can be applied easily to a system that uses the upper-lower limit switch signals for Acc/Dec commands.



Advanced Features

Group	Code	Name	Setting		Setting Range	Unit
Ad	65	Up-down operation frequency save	1	Yes	0~1	-
In	65~69	Px terminal setting options	17	Up	0~52	-
			18	Down		
			20	U/D Clear		
			27	U/D Enable		

The up-down operation will operate only when the multi-function terminal set to U/D Enable is entered. For example, even if up-down signal is entered for the up-down operation while operating according to the analog voltage input V1, the inverter will operate according to the analog voltage input V1. If the up-down switchover (U/D Enable) signal is entered, the operation will follow the up-down operation terminal input and the analog voltage input V1 will not be used for the inverter operation until the up-down switchover (U/D Enable) signal is disabled.

Up-down Operation Setting Details

Code	Description
In.65-69 Px Define	Select three terminals for up-down operation and set them to 17 (Up), 18 (Down) and 27(U/D Enable), respectively. If the up-down switchover (U/D Enable) command is not entered, acceleration/deceleration will follow the operation command set in drv. If the up-down switchover (U/D Enable) command is entered during acceleration/deceleration,


Code	Description
	<p>acceleration/deceleration will stop to wait for Up and Down commands. When the operation command and up-down activation command is entered, the operation will be accelerated if the Up terminal signal turns On, and the acceleration will stop to operate as a constant speed if the signal turns Off.</p> <p>During operation, deceleration begins when the Down signal is on. Deceleration stops and constant speed operation begins when both Up and Down signals are entered at the same time.</p> 
<p>Ad.65 U/D Save Mode</p>	<p>During a constant speed operation, the operating frequency is saved automatically in the following conditions: the operation command (Fx or Rx) is off, a fault trip occurs, or the power is off.</p> <p>When the operation command is turned on again, or when the inverter regains the power source or resumes to a normal operation from a fault trip, it resumes operation at the saved frequency. To delete the saved frequency, use the multi-function terminal block. Set one of the multi-function terminals to 20 (U/D Clear) and apply signals to it during constant speed operation. The saved frequency and the up-down operation configuration will be deleted.</p> 

5.4 3-Wire Operation


The 3-wire operation latches the signal input (the signal stays on after the button is released), and is used when operating the inverter with a push button.

Group	Code	Name	Setting	Setting Range	Unit
Run	drv	Command Source	1	Fx/Rx - 1	-
In	65~69	Px terminal setting options	14	3-Wire	0~52

To enable the 3-wire operation, the following circuit sequence is necessary. The minimum input time (t) for 3-wire operation is 1ms, and the operation stops when both forward and reverse operation commands are entered at the same time.



[Terminal connections for 3-wire operation]



[3-wire operation]


5.5 Safe Operation mode

When the multi-function terminals are configured to operate in safe mode, operation commands can be entered in the Safe operation mode only. Safe operation mode is used to safely and carefully control the inverter through the multi-function terminals.

Group	Code	Name	Setting		Setting Range	Unit
Ad	70	Safe operation selection	1	DI Dependent	-	
	71	Safe operation stop options	0	Free-Run	0~2	-
	72	Safe operation deceleration time	5.0		0.0~600.0	sec
In	65~69	Px terminal setting options	13	RUN Enable	0~52	-

Safe Operation Mode Setting Details

Code	Description												
In.65–69 Px Define	From the multi-function terminals, select a terminal to operate in safe operation mode and set it to 13 (RUN Enable).												
Ad.70 Run En Mode	<table border="1"> <thead> <tr> <th colspan="2">Configuration</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Always Enable</td> <td>Enables safe operation mode.</td> </tr> <tr> <td>1</td> <td>DI Dependent</td> <td>Recognizes the operation command from a multi-function input terminal.</td> </tr> </tbody> </table>	Configuration		Function	0	Always Enable	Enables safe operation mode.	1	DI Dependent	Recognizes the operation command from a multi-function input terminal.			
	Configuration		Function										
	0	Always Enable	Enables safe operation mode.										
1	DI Dependent	Recognizes the operation command from a multi-function input terminal.											
Ad.71 Run Dis Stop	Set the operation of the inverter when the multi-function input terminal in safe operation mode is off.												
	<table border="1"> <thead> <tr> <th colspan="2">Configuration</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Free-Run</td> <td>Blocks the inverter output when the multi-function terminal is off.</td> </tr> <tr> <td>2</td> <td>Q-Stop</td> <td>The deceleration time (Q-Stop Time) used in safe operation mode. Once stopped, the operation command must be entered again to restart the operation even if the multi-function terminal is turned On.</td> </tr> <tr> <td>3</td> <td>Q-Stop Resume</td> <td>The inverter decelerates to the deceleration time (Q-Stop Time) in safe operation mode and stops. Once stopped, a normal operation will be continued if the multi-function terminal is entered again when the operation command is turned On.</td> </tr> </tbody> </table>	Configuration		Function	1	Free-Run	Blocks the inverter output when the multi-function terminal is off.	2	Q-Stop	The deceleration time (Q-Stop Time) used in safe operation mode. Once stopped, the operation command must be entered again to restart the operation even if the multi-function terminal is turned On.	3	Q-Stop Resume	The inverter decelerates to the deceleration time (Q-Stop Time) in safe operation mode and stops. Once stopped, a normal operation will be continued if the multi-function terminal is entered again when the operation command is turned On.
	Configuration		Function										
1	Free-Run	Blocks the inverter output when the multi-function terminal is off.											
2	Q-Stop	The deceleration time (Q-Stop Time) used in safe operation mode. Once stopped, the operation command must be entered again to restart the operation even if the multi-function terminal is turned On.											
3	Q-Stop Resume	The inverter decelerates to the deceleration time (Q-Stop Time) in safe operation mode and stops. Once stopped, a normal operation will be continued if the multi-function terminal is entered again when the operation command is turned On.											
Ad.72 Q-Stop Time	Sets the deceleration time when Ad.71 (Run Dis Stop) is set to 1 (Q-Stop) or 2 (Q-Stop Resume).												




5.6 Dwell Operation

The dwell operation is used to maintain torque during the application and release of the brakes on lift-type loads. Inverter dwell operation is based on the Acc/Dec dwell frequency and the dwell time set by the user. The following points also affect dwell operation:

- **Acceleration Dwell Operation:** When an operation command runs, acceleration continues until the acceleration dwell frequency and constant speed is reached within the acceleration dwell operation time (Acc Dwell Time). After the Acc Dwell Time has passed, acceleration is carried out based on the acceleration time and the operation speed that was originally set.
- **Deceleration Dwell Operation:** When a stop command is run, deceleration continues until the deceleration dwell frequency and constant speed is reached within the deceleration dwell operation time (Dec Dwell Freq). After the set time has passed, deceleration is carried out based on the deceleration time that was originally set, then the operation stops.

When dr.09 (Control Mode) is set to 0 (V/F), the inverter can be used for operations with dwell frequency before opening the mechanical brake of lift-type loads, such as an elevator.


Group	Code	Name	Setting	Setting Range	Unit
Ad	20	Dwell frequency on acceleration	5.00	Start frequency – Maximum frequency	Hz
	21	Operation time during acceleration	0.0	0.0~10.0	sec
	22	Dwell frequency during deceleration	5.00	Start frequency – Maximum frequency	Hz
	23	Operation time during deceleration	0.0	0.0–60.0	sec



Note


Dwell operation does not work when:

- Dwell operation time is set to 0 sec or dwell frequency is set to 0 Hz.
- Re-acceleration is attempted from stop or during deceleration, as only the first acceleration dwell operation command is valid.



[Acceleration dwell operation]

- Although deceleration dwell operation is carried out whenever stop commands are entered and the deceleration dwell frequency is passed through, it does not work during a deceleration by simple frequency change (which is not a deceleration due to a stop operation), or during external brake control applications.



[Deceleration dwell operation]

⚠ Caution

When a dwell operation is carried out for a lift - type load before its mechanical brake is released, motors can be damaged or their lifecycle reduced due to overflow current in the motor.

5.7 Slip Compensation Operation


Slip refers to the variation between the setting frequency (synchronous speed) and motor rotation speed. As the load increases there can be variations between the setting frequency and motor rotation speed. Slip compensation is used for loads that require compensation of these speed variations.

Group	Code	Name	Setting	Setting Range	Unit
dr	09	Control mode	2 Slip Compen	-	-
	14	Motor capacity	2 0.75 kW (0.75kW based)	0~15	-
bA	11	Number of motor poles	4	2~48	-
	12	Rated slip speed	90(0.75 kW based)	0~3000	Rpm
	13	Rated motor current	3.6(0.75 kW based)	1.0~1000.0	A
	14	Motor no-load current	1.6(0.75 kW based)	0.5~1000.0	A
	16	Motor efficiency	72(0.75 kW based)	64~100	%
	17	Load inertia rate	0(0.75 kW based)	0~8	-

Slip Compensation Operation Setting Details

Code	Description	
dr.09 Control Mode	Set dr.09 to 2 (Slip Compen) to carry out the slip compensation operation.	
dr.14 Motor Capacity	Set the capacity of the motor connected to the inverter.	
bA.11 Pole Number	Enter the number of poles from the motor rating plate.	
bA.12 Rated Slip	Enter the number of rated rotations from the motor rating plate.	
bA.13 Rated Curr	Enter the rated current from the motor rating plate.	
bA.14 Noload Curr	Enter the measured current when the load on the motor axis is removed and when the motor is operated at the rated frequency. If no-load current is difficult to measure, enter a current equivalent to 30-50 % of the rated motor current.	
bA.16 Efficiency	Enter the efficiency from the motor rating place.	
bA.17 Inertia Rate	Select load inertia based on motor inertia.	
	Configuration	Function
	0	Less than 10 times motor inertia
	1	10 times motor inertia
	2~8	More than 10 times motor inertia

Code	Description
	$f_s = f_r - \frac{Rpm \times P}{120}$ f_s =Rated slip frequency f_r =Rated frequency Rpm =Number of the rated motor rotations P =Number of motor poles



5.8 PID Control

Pid control is one of the most common auto-control methods. It uses a combination of proportional, integral, and differential (PID) control that provides more effective control for automated systems.

The functions of PID control that can be applied to the inverter operation are as follows:

Code	Function
Speed control	Controls speed by using feedback about the existing speed level of the equipment or machinery to be controlled. Control maintains consistent speed or operates at the target speed.
Pressure Control	Controls pressure by using feedback about the existing pressure level of the equipment or machinery to be controlled. Control maintains consistent pressure or operates at the target pressure.
Flow Control	Controls flow by using feedback about the amount of existing flow in the equipment or machinery to be controlled. Control maintains consistent flow or operates at a target flow.
Temperature Control	Controls temperature by using feedback about the existing temperature level of the equipment or machinery to be controlled. Control maintains a consistent temperature or operates at a target temperature.

5.8.1 Basic PID Operation

PID operates by controlling the output frequency of the inverter, through automated system process control to maintain speed, pressure, flow, temperature and tension.

Group	Code	Name	Setting	Setting Range	Unit
AP	01	Application function selection	2 Proc PID	0~2	-
	16	PID output monitor	-	-	-
	17	PID reference monitor	-	-	-
	18	PID feedback monitor	-	-	-
	19	PID reference setting	50.00	-100.00~100.00	%
	20	PID reference source	0 Keypad	0~7	-
	21	PID feedback source	0 V1	0~6	-
	22	PID controller proportional gain	50.0	0.0~1000.0	%
	23	PID controller integral time	10.0	0.0~200.0	sec
	24	PID controller differential time	0	0~1000	ms
	25	PID controller feed-forward compensation gain	0.0	0~1000	%
	26	Proportional gain scale	100.0	0.0~100.0	%
	27	PID output filter	0	0~10000	ms
	29	PID upper limit frequency	60.00	-300.00~300.00	Hz
	30	PID lower limit frequency	0.5	-300.00~300.00	Hz
	32	PID output scale	100.0	0.1~1000.0	%
	33	PID output inverse	0 No	0~1	-
	34	PID controller motion frequency	0.00	0–Max Frequency	Hz
	35	PID controller motion level	0.0	0.0~100.0	%
	36	PID controller motion delay time	600	0~9999	sec
	37	PID sleep mode delay time	60.0	0~999.9	sec
	38	PID sleep mode frequency	0.00	0–Max Frequency	Hz
	39	PID wake-up level	35	0~100	%
	40	PID wake-up mode selection	0 Below Level	0~2	-
	42	PID controller unit selection	0 %	0~12	-
43	PID unit gain	100.0	0~300	%	
44	PID unit scale	2 x 1	0~4	-	
45	PID 2 nd proportional gain	100.00	0~1000	%	
In	65~69	Px terminal setting options	22 I-Term Clear	0~52	-
			23 PID Openloop		
			24 P Gain2		

Note


When the PID switch operation (switching from PID operation to general operation) enters the multi-function input, [%] values are converted to [Hz] values. The normal PID output, PID OUT, is unipolar, and is limited by AP.29 (PID Limit Hi) and AP.30 (PID Limit Lo). A calculation of 100.0% is based on the dr.20 (Max Freq) parameter setting.

PID Basic Operation Setting Details

Code	Description														
AP.01 App Mode	Set the code to 2 (Proc PID) to select functions for the process PID.														
AP.16 PID Output	Displays the existing output value of the PID controller. The unit, gain, and scale that were set at AP. 42-44 are applied on the display.														
AP.17 PID Ref Value	Displays the existing reference value set for the PID controller. The unit, gain, and scale that were set at AP. 42-44 are applied on the display.														
AP.18 PID Fdb Value	Displays the input value of the PID controller that is included in the latest feedback. The unit, gain, and scale that were set at AP. 42-44 are applied on the display.														
AP.19 PID Ref Set	When AP.20 (PID control reference source) is set to 0 (Keypad), the reference value can be entered. If the reference source is set to any other value, the setting values for AP.19 are void.														
AP.20 PID Ref Source	Selects the reference input for the PID control. If the V1 terminal is set to PID feedback source (PID F/B Source), the V1 terminal cannot be set to the PID reference source (PID Ref Source). To set V1 as a reference source, change the feedback source.														
	<table border="1"> <thead> <tr> <th>Configuration</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Keypad</td> </tr> <tr> <td>1</td> <td>V1</td> </tr> <tr> <td>3</td> <td>V0</td> </tr> <tr> <td>4</td> <td>I2</td> </tr> <tr> <td>5</td> <td>Int. 485</td> </tr> <tr> <td>7</td> <td>FieldBus</td> </tr> </tbody> </table>	Configuration	Function	0	Keypad	1	V1	3	V0	4	I2	5	Int. 485	7	FieldBus
	Configuration	Function													
	0	Keypad													
	1	V1													
	3	V0													
	4	I2													
5	Int. 485														
7	FieldBus														
	When using the keypad, the PID reference setting can be displayed at AP.17.														
AP.21 PID F/B Source	Selects feedback input for PID control. Items can be selected as reference input, except the keypad input (Keypad-1 and Keypad-2). Feedback cannot be set to an input item that is identical to the item selected as the reference.														
	For example, when Ap.20 (Ref Source) is set to 1 (V1), for AP. 21 (PID F/B Source), an input other than the V1 terminal must be selected.														

Code	Description
AP.22 PID P-Gain, AP.26 P Gain Scale	Sets the output ratio for differences (errors) between reference and feedback. If the P-gain is set to 50 %, then 50 % of the error is output. The setting range for P-gain is 0.0-1,000 %. For ratios below 0.1 %, use AP.26 (P Gain Scale).
AP.23 PID I- Time	Sets the time to output accumulated errors. When the error is 100%, the time taken for 100% output is set. When the integral time (PID I-Time) is set to 1 second, 100 % output occurs after 1 second of the error remaining at 100 %. Differences in a normal state can be reduced by PID I Time. When the multi-function terminal block is set to 21 (I-Term Clear) and is turned on, all of the accumulated errors are deleted.
AP.24 PID D-Time	Sets the output volume for the rate of change in errors. If the differential time (PID D-Time) is set to 1 ms and the rate of change in errors per sec is 100 %, output occurs at 1 % per 10 ms.
AP.25 PID F-Gain	Sets the ratio that adds the target to the PID output. Adjusting this value leads to a faster response.
AP.27 PID Out LPF	Used when the output of the PID controller changes too fast or the entire system is unstable, due to severe oscillation. In general, a lower value (default value=0) is used to speed up response time, but in some cases a higher value increases stability. The higher the value, the more stable the PID controller output is, but the slower the response time.
AP.29 PID Limit Hi, AP.30 PID Limit Lo	Limits the output of the controller.
AP.32 PID Out Scale	Adjusts the volume of the controller output.

Code	Description		
AP.42 PID Unit Sel	Sets the unit of the control variable.		
	Configuration	Function	
	0	%	Displays a percentage without a physical quantity given.
	1	Bar	Various units of pressure can be selected.
	2	mBar	
	3	Pa	
	4	kPa	
	5	Hz	Displays the inverter output frequency or the motor rotation speed.
	6	Rpm	
	7	V	Displays in voltage/current/power/horsepower.
	8	I	
	9	kW	
	10	HP	
	11	°C	Displays in Celsius or Fahrenheit.
12	°F		
AP.43 PID Unit Gain, AP.44 PID Unit Scale	Adjusts the size to fit the unit selected at AP.41 PID Unit Sel.		
AP.45 PID P2-Gain	The PID controller's gain can be adjusted using the multi-function terminal. When a terminal is selected from In.65-69 and set to 24 (P Gain2), and if the selected terminal is entered, the gain set in AP.22 and AP.23 can be switched to the gain set in AP.45.		




[PID control block diagram]

5.8.2 Pre-PID Operation

When an operation command is entered that does not include PID control, general acceleration occurs until the set frequency is reached. When the controlled variables increase to a particular point, the PID operation begins.

Pre-PID Operation Setting Details

Code	Description
AP.34 Pre-PID Freq	When general acceleration is required, the frequency up to general acceleration is entered. If Pre-PID Freq is set to 30Hz, the general operation continues until the control variable (PID feedback variable) set at AP. 35 is exceeded.
AP.35 Pre-PID Exit, AP.36 Pre-PID Delay	When the feedback variable of the PID controller is higher than the value set at AP. 35, the PID control operation begins. However, when a value is set for AP.36 (Pre-PID Delay) and a feedback variable less than the value set at AP.35 is maintained for a set amount of time, the “pre-PID Fail” fault trip will occur and the output will be blocked.




5.8.3 PID Operation Sleep mode

If the operation continues at a frequency lower than the set condition for PID operation, the PID operation sleep mode starts. When PID operation sleep mode starts, the operation will stop until the feedback exceeds the parameter value set at AP.39 (PID WakeUp Lev).


PID Operation Sleep Mode Setting Details

Code	Description
AP.37 PID Sleep DT, AP.38 PID Sleep Freq	If an operation frequency lower than the value set at AP.38 is maintained for the time set at AP.37, the operation stops and the PID operation sleep mode starts.
AP.39 PID WakeUp Lev, AP.40 PID WakeUp Mod	Starts the PID operation when in PID operation sleep mode. If AP. 40 is set to 0 (Below Level), the PID operation starts when the feedback variable is less than the value set as the AP. 39 parameter setting. If AP. 40 is set to 1 (Above Level), the operation starts when the feedback variable is higher than the value set at AP. 39. If AP. 40 is set to 2 (Beyond Level), the operation starts when the difference between the reference value and the feedback variable is greater than the value set at AP. 39.



5.8.4 PID Switching (PID Openloop)

When one of the multi-function terminals (In. 65-69) is set to 23 (PID Openloop) and is turned on, the PID operation stops and is switched to general operation. When the terminal turns off, the PID operation starts again.



5.9 Auto-tuning

The motor parameters can be measured automatically and can be used for auto torque boost or sensorless vector control.

Example - Auto Tuning Based on 0.75kW, 200V Motor

Group	Code	Name	Setting	Setting Range	Unit
dr	14	Motor capacity	1 0.75 kW	0~15	-
bA	11	Number of motor poles	4	2~48	-
	12	Rated slip speed	40	0~3000	Rpm
	13	Motor rated current	3.6	1.0~1000.0	A
	14	Motor noload current	1.6	0.5~1000.0	A
	15	Motor rated voltage	220	170~480	V
	16	Motor efficiency	72	64~100	%
	20	Auto tuning	0 None	-	-
	21	Stator resistance	26.00	Depends on the motor setting	Ω
	22	Leakage inductance	179.4	Depends on the motor setting	mH
	23	Stator inductance	1544	Depends on the motor setting	mH
24	Rotor time constant	145	25~5000	ms	

Default Motor Parameter Settings

Motor capacity (kW)	Rated current [3-Phase input] (A)	No-load Current (A)	Rated Slip Frequency (Hz)	Stator resistance (Ω)	Leakage Inductance (mH)	
200 V	0.2	1.1	0.8	3.33	14.0	40.4
	0.4	2.4	1.4	3.33	6.70	26.9
	0.75	3.4	1.7	3.00	2.600	17.94
	1.5	6.4	2.6	2.67	1.170	9.29
	2.2	8.6	3.3	2.33	0.840	6.63
	3.7	13.8	5.0	2.33	0.500	4.48
	5.5	21.0	7.1	1.50	0.314	3.19
	7.5	28.2	9.3	1.33	0.169	2.844
400 V	0.2	0.7	0.5	3.33	28.00	121.2
	0.4	1.4	0.8	3.33	14.0	80.8
	0.75	2.0	1.0	3.00	7.81	53.9
	1.5	3.7	1.5	2.67	3.52	27.9
	2.2	5.0	1.9	2.33	2.520	19.95
	3.7	8.0	2.9	2.33	1.500	13.45
	5.5	12.1	4.1	1.50	0.940	9.62
	7.5	16.3	5.4	1.33	0.520	8.53

Auto Tuning Parameter Setting Details

Code	Description	
bA.20 Auto Tuning	Select an auto tuning type and run it. Select one of the options and then press the [ENT] key to run the auto tuning.	
	Configuration	Function
	0	None
1	All (Rotation type)	Measures all motor parameters, including stator resistance (R_s), stator inductance (L_{σ}), no-load current (Noload Curr), rotor time constant (T_r), etc., while the motor is rotating. As the motor is rotating while the parameters are being measured, if the load is connected to the motor spindle, the parameters may not be measured accurately. For accurate measurements, remove the load attached to the motor spindle. However, note that the rotor time constant (T_r) must be measured in a stopped position.

Code	Description	
	2	<p>All (static)</p> <p>Measures all parameters while the motor is in the stopped position. Measures stator resistance (Rs), stator inductance (Lsigma), no-load current (Noload Curr), rotor time constant (Tr), etc., while the motor is in the stopped position.</p> <p>As the motor is not rotating while the parameters are measured, the measurements are not affected when the load is connected to the motor spindle. However, when measuring parameters, do not rotate the motor spindle on the load side.</p>
	3	<p>Rs+Lsigma (rotating type)</p> <p>Measures parameters while the motor is rotating. The measured motor parameters are used for auto torque boost or sensorless vector control.</p>
	6	<p>Tr (Static type)</p> <p>Measures the rotor time constant (Tr) with the motor in the stopped position and Control Mode (dr.09) is set to IM Sensorless.</p>
bA.14 Noload Curr, bA.21 Rs-bA.24 Tr	<p>Displays motor parameters measured by auto tuning.</p> <p>For parameters that are not included in the auto tuning measurement list, the default setting will be displayed.</p>	

⚠ Caution

- Perform auto tuning ONLY after the motor has completely stopped running.
- Before you run auto tuning, check the motor pole number, rated slip, rated current, rated voltage and efficiency on the motor's rating plate and enter the data. The default parameter setting is used for values that are not entered.
- When measuring all parameters after selecting 2 (All - static type) at bA20: compared with rotation type auto tuning where parameters are measured while the motor is rotating, parameter values measured with static auto tuning may be less accurate. Inaccuracy of the measured parameters may degrade the performance of sensorless operation. Therefore, run static type auto tuning by selecting 2 (All) only when the motor cannot be rotated (when gearing and belts cannot be separated easily, or when the motor cannot be separated mechanically from the load).

5.10 Sensorless Vector Control for Induction Motors

Sensorless vector control is an operation to carry out vector control without the rotation speed feedback from the motor but with an estimation of the motor rotation speed calculated by the inverter. Compared to V/F control, sensorless vector control can generate greater torque at a lower level of current.

Group	Code	Name	Setting		Setting Range	Unit
dr	09	Control mode	4	IM Sensorless	-	-
	14	Motor capacity	Varies by Motor capacity		0~15	-
	18	Base frequency	60		30~400	Hz
bA	11	Number of motor poles	4		2~48	-
	12	Rated slip speed	Varies by Motor capacity		0~3000	Hz
	13	Motor rated current	Varies by Motor capacity		1~1000	A
	14	Motor no-load current	Varies by Motor capacity		0.5~1000	A
	15	Motor rated voltage	220/380/440/480		170~480	V
	16	Motor efficiency	Varies by Motor capacity		64~100	%
	20	Auto tuning	1	All	-	-
Cn	09	Initial excitation time	1.0		0.0~60.0	sec
	10	Initial excitation amount	100.0		100.0~300.0	%
	20	Sensorless second gain display setting	1	Yes	0~1	-
	21	Stator resistance scale	Varies by Motor capacity		50~300	%
	22	Stator leakage inductance scale	Varies by Motor capacity		50~300	%
	23	Stator inductance scale	Varies by Motor capacity		50~300	%
	24	Rotor time constant scale	Varies by Motor capacity		50~300	%
	25	No-load current scale	Varies by Motor capacity		50~300	%
	26*	Speed controller bandwidth	4.0		1.0~10.0	Hz
	27*	PLL BandWidth	20.0		5.0~50.0	Hz
	28*	Speed low-pass filter bandwidth	20.0		5.0~50.0	Hz
	29*	Flux controller extreme point weight	1.06		0.50~2.00	-
	30*	Speed controller adjustment gain	4.0		2.0~10.0	-
	31*	Current controller bandwidth	70		50~400	Hz
	53	Torque limit setting	0	Keypad-1	0~12	-

Group	Code	Name	Setting	Setting Range	Unit
	54	Forward direction retrograde torque limit	180.0	0.0~200.0	%
	55	Forward direction regenerative torque limit	180.0	0.0~200.0	%
	56	Reverse direction regenerative torque limit	180.0	0.0~200.0	%
	57	Reverse direction retrograde torque limit	180.0	0.0~200.0	%

*Cn.23-32 and Cn.85-95 can be displayed only when Cn.20 is set to 1 (Yes).

⚠ Caution

For high-performance operation, the parameters of the motor connected to the inverter output must be measured. Use auto tuning (bA.20 Auto Tuning) to measure the parameters before you run sensorless vector operation. To run high-performance sensorless vector control, the inverter and the motor must have the same capacity. If the motor capacity is smaller than the inverter capacity by more than two levels, control may be inaccurate. In that case, change the control mode to V/F control. When operating with sensorless vector control, do not connect multiple motors to the inverter output.

5.10.1 Sensorless Vector Control Operation Setting for Induction Motors

To run sensorless vector control operation, set dr.09 (Control Mode) to 4 (IM sensorless), select the capacity of the motor you will use at dr.14 (Motor Capacity), and select the appropriate codes to enter the rating plate information of the motor.

Code	Input (Motor Rating Plate Information)
dr.18 Base Freq	Base frequency
bA.11 Pole Number	Number of motor poles
bA.12 Rated Slip	Rated slip
bA.13 Rated Curr	Rated current
bA.15 Rated Volt	Rated voltage
bA.16 Efficiency	Efficiency (when no information is on the rating plate, default values are used.)


After setting each code, set bA.20 (Auto tuning) to 1 (All - rotation type) or 2 (All - static type) and run auto tuning. Because rotation type auto tuning is more accurate than static type auto tuning, select 1 (All - rotation type) and run auto tuning if you can rotate the motor.


Note

Excitation Current

A motor can be operated only after magnetic flux is generated by current flowing through a coil. The power supply used to generate the magnetic flux is called the excitation current. The stator coil that is used with the inverter does not have a permanent magnetic flux, so the magnetic flux must be generated by supplying an excitation current to the coil before operating the motor.

Sensorless Vector Control Operation Setting Details for Induction Motors

Code	Description							
Cn.20 SL Gain View Sel	<table border="1"> <thead> <tr> <th data-bbox="417 658 614 697">Configuration</th> <th data-bbox="614 658 1241 697">Function</th> </tr> </thead> <tbody> <tr> <td data-bbox="417 697 614 765">0</td> <td data-bbox="614 697 1241 765">No Does not display sensorless vector control gain code.</td> </tr> <tr> <td data-bbox="417 765 614 832">1</td> <td data-bbox="614 765 1241 832">Yes Allow users to set the controller gain value related to the sensorless vector control.</td> </tr> </tbody> </table>		Configuration	Function	0	No Does not display sensorless vector control gain code.	1	Yes Allow users to set the controller gain value related to the sensorless vector control.
	Configuration	Function						
	0	No Does not display sensorless vector control gain code.						
1	Yes Allow users to set the controller gain value related to the sensorless vector control.							
Codes available when setting to 1 (Yes): Cn.26–31								
Cn.09 PreExTime	Sets pre-excitation time. Pre-excitation is used to start the operation after performing excitation up to the motor’s rated flux.							
Cn.10 Flux Force	<p>Allows for the reduction of the pre-excitation time. The motor flux increases up to the rated flux with the time constant as shown in the following figure.</p> <p>To reduce the time taken to reach the rated flux, a higher motor flux base value than the rated flux must be provided. When the magnetic flux reaches the rated flux, the provided motor flux base value is reduced.</p>							
								

Code	Description											
Cn.11 Hold Time	<p>Sets the zero-speed control time (hold time) in the stopped position. The output is blocked after zero-speed operation for a set period when the motor decelerates and is stopped by a stop command.</p> 											
Cn.21 Rs Scale	<p>Stator resistance scale value has effect mainly on the low speed operation. Refer to 133 on page 5.10.2 Sensorless Vector Control Operation Guide for Induction Motors for more details.</p>											
Cn.22 sigmaLs Scale	<p>Stator leakage inductance scale value is related to the torque load quantity that can be mainly produced by the inverter. Refer to 133 on page 5.10.2 Sensorless Vector Control Operation Guide for Induction Motors for more details.</p>											
Cn.23 Ls Scale	<p>Stator resistance scale value has effect mainly on the motor speed. Refer to 133 on page 5.10.2 Sensorless Vector Control Operation Guide for Induction Motors for more details.</p>											
Cn.24 Tr Scale	<p>Rotor time constant scale value has effect mainly on the motor speed. Refer to 133 on page 5.10.2 Sensorless Vector Control Operation Guide for Induction Motors for more details.</p>											
Cn.29 KWnFactor	<p>The value of the flux controller extreme point weight has effect on the error level of the estimated frequency during no load for the most part. Refer to 133 on page 5.10.2 Sensorless Vector Control Operation Guide for Induction Motors for more details.</p>											
Cn.30 Ksc	<p>Speed controller adjustment gain value is the value that is changed mainly according to the load inertia. Refer to 133 on page 5.10.2 Sensorless Vector Control Operation Guide for Induction Motors for more details.</p>											
Cn.53 Torque Lmt Src	<p>Select a type of torque limit setting, using the keypad, terminal block analog input (V1 and I2) or communication power. When setting torque limit, adjust the torque size by limiting the speed controller output. Set the retrograde and regenerative limits for forward and reverse operation.</p> <table border="1" data-bbox="422 1566 1234 1760"> <thead> <tr> <th colspan="2">Configuration</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>KeyPad-1</td> <td rowspan="2">Sets the torque limit with the keypad.</td> </tr> <tr> <td>1</td> <td>KeyPad-2</td> </tr> <tr> <td>2</td> <td>V1</td> <td>Sets the torque limit with the V1 input terminal of the terminal block.</td> </tr> </tbody> </table>	Configuration		Function	0	KeyPad-1	Sets the torque limit with the keypad.	1	KeyPad-2	2	V1	Sets the torque limit with the V1 input terminal of the terminal block.
Configuration		Function										
0	KeyPad-1	Sets the torque limit with the keypad.										
1	KeyPad-2											
2	V1	Sets the torque limit with the V1 input terminal of the terminal block.										

Code	Description		
	4	V0	Sets the torque limit with the volume dial of keypad.
	5	I2	Sets the torque limit with the I2 input terminal of the terminal block.
	6	Int 485	Sets the torque limit with the communication terminal of the terminal block.
	8	FieldBus	Sets the torque limit with the Fieldbus communication option.
The torque limit can be set up to 200% of the rated motor torque.			
Cn.54 FWD +Trq Lmt	Sets the torque limit for forward retrograde (motoring) operation.		
Cn.55 FWD -Trq Lmt	Sets the torque limit for forward regenerative operation.		
Cn.56 REV +Trq Lmt	Sets the torque limit for reverse regenerative operation.		
Cn.57 REV -Trq Lmt	Sets the torque limit for reverse retrograde (motoring) operation.		
In.02 Torque at 100%	Sets the maximum torque. For example, if In.02 is set to 200% and an input voltage (V1) is used, the torque limit is 200 % when 10V is entered.		

⚠ Caution



Scale value can be adjusted according to the load characteristics. However, use with caution because conditions, such as motor overheating and unstable system may occur depending on the scale value settings.

Note

Speed controller gain can improve the speed control waveform while monitoring the changes in speed. If speed deviation does not decrease quickly, increase the speed controller P gain or decrease I gain (time in ms). However, if the P gain is increased too high or I gain is decreased too low, severe vibration may occur. If oscillation occurs in the speed waveform, try to increase I gain (ms) or reduce P gain to adjust the waveform.

5.10.2 Sensorless Vector Control Operation Guide for Induction Motors

Problem	Relevant function code	Troubleshooting
If the number of motor rotations drops due to the lack of torque	Cn.22 sigmaLs Scale	If there is a severe drop in the motor rotation to 100 RPM or more, increase the Cn.22 sigmaLs Scale value in 10% units.

Problem	Relevant function code	Troubleshooting
<p>If the motor rotation count error factor is 18 RPM or greater even though there is a sufficient amount of torque.</p>	<p>Cn.23 Ls Scale Cn.24 Tr Scale</p>	<p>Change the Cn.23 Ls Scale value in 5% units. Refer to the load-rotation count gradient according to the Ls Scale value below. Example: The gradient slants clockwise as Ls Scale value increases.</p>  <p>Change the Cn.23 Tr Scale value in 5% units. Refer to the load-rotation count gradient according to the Tr Scale value below. Example: The gradient slants counterclockwise as the Tr Scale value increases.</p> 
<p>If torque is lacking due to a load increase in low speed (5Hz or less)</p>	<p>Cn.21 Rs Scale</p>	<p>If torque is lacking under low speed, increase the Cn.21 value in 5% units.</p>
<p>If rotating in reverse direction due to a load increase in low speed (5Hz or less)</p>	<p>Cn.21 Rs Scale</p>	<p>If rotating in reverse direction due to a load increase in low speed, decrease the Cn.21 value 5% at a time.</p>

Problem	Relevant function code	Troubleshooting
If low speed (3Hz or less) out-of-phase occurs because the inertia of load is high.	Cn.30 Ksc	Sometimes control is not possible under a low speed due to high load inertia. In this case, increase the parameter Ksc related to inertia by 1 at a time.
If motor rotation count error margin occurs during no load	Cn.25 If Scale Cn.29 KWnFactor	If over 10rpm of motor rotation count error occurs under no load operation, increase the Cn.25 value in 5% units. Additionally, adjust the Cn.29 value to adjust the error rate of the motor rotation count.


5.11 Energy Buffering Operation (Kinetic Energy Buffering)

When the input power supply is disconnected, the inverter's DC link voltage decreases, and a low voltage trip occurs blocking the output. A kinetic energy buffering operation uses regenerative energy generated by the motor during the blackout to maintain the DC link voltage. This extends the time for a low voltage trip to occur, after an instantaneous power interruption. For the KEB feature to operate properly, bA-19 input power voltage parameter must be set to match the voltage of input power.

Group	Code	Name	Setting	Setting Range	Unit	
bA	19	Input power voltage settings	220/380	170~480	V	
Cn	77	Energy buffering selection	0	None	0~2	-
			1	KEB-1		
			2	KEB-2		
	78	Energy buffering start level	125.0	110.0~200.0	%	
	79	Energy buffering stop level	130.0	Cn-78~210.0	%	
	80	Energy buffering P gain	1000	1~20000	-	
	81	Energy buffering I gain	500	0~20000	-	
	82	Energy buffering Slip gain	30.0	0~2000.0	%	
In	65 ~69	Pn terminal function setting	52	KEB-1 Select	-	-

Kinetic Energy Buffering Operation Setting Details

Code	Description	
Cn.77 KEB Select	Select the kinetic energy buffering operation when the input power is disconnected. If 1 or 2 is selected, it controls the inverter's output frequency and charges the DC link (inverter's DC part) with energy generated from the motor. Also, this function can be set using a terminal input. From the Pn terminal function settings, select KEB-1 Select, and then turn on the terminal block to run the KEB-1 function. (If KEB-1 Select is selected, KEB-1 or KEB-2 cannot be set in Cn-77.)	
	Configuration	Function
	0	None General deceleration is carried out until a low voltage trip occurs.
	1	KEB-1 When the input power is blocked, it charges the DC link with regenerated energy. When the input power is restored, it restores normal operation from the energy buffering operation to the frequency reference operation. KEB Acc Time in Cn-89 is applied as the operation frequency acceleration time when restoring to the normal operation.
2	KEB-2 When the input power is blocked, it charges the DC link with regenerated energy. When the input power is restored, it changes from the energy buffering operation to the deceleration stop operation. The Dec Time in dr-04 is applied as the operation frequency deceleration time during the deceleration stop operation.	
<p>[KEB-1]</p> <p>The diagram illustrates the KEB-1 operation sequence. It consists of three vertically aligned waveforms: DC Link voltage, Output frequency, and Px(FX). 1. Initial State: DC Link voltage is constant at a high level. Output frequency is constant at a 'Start frequency'. Px(FX) is low. 2. Power Disconnection: Px(FX) goes high, initiating KEB control. The DC Link voltage begins to rise, and the Output frequency begins to decelerate. 3. KEB Control: The DC Link voltage continues to rise until it reaches a peak labeled 'CON-78'. Simultaneously, the Output frequency decelerates to zero. This period is labeled 'KEB control'. 4. Power Restoration: Px(FX) goes low, ending KEB control. The DC Link voltage begins to fall, reaching a level labeled 'CON-79'. The Output frequency begins to accelerate back to the 'Start frequency'. This period is labeled 'Operation restore (CON-89)'. 5. Final State: DC Link voltage is constant at a lower level. Output frequency is constant at the 'Start frequency'. Px(FX) is low.</p>		

Code	Description
	<p>[KEB-2]</p>  <p>The diagram illustrates the KEB (Kinetic Energy Buffering) operation. It shows three waveforms over time: DC Link voltage, Output frequency, and Px(FX). The DC Link voltage starts at a high level, then drops during the KEB control period. The Output frequency starts at a level defined by CON-78, remains constant for a short duration, then decelerates to a level defined by CON-79. The Px(FX) signal is active during the KEB control period. The deceleration stop is labeled as DRV-04.</p>
Cn.78 KEB Start Lev, Cn.79 KEB Stop Lev	Sets the start and stop points of the kinetic energy buffering operation. The set values must be based on the low voltage trip level as 100% and the stop level (Cn. 79) must be set higher than the start level (Cn.78).
Cn.80 KEB P Gain	The controller P Gain is for maintaining the voltage of the DC power section during the kinetic energy buffering operation. Change the setting value when a low voltage trip occurs right after a power failure.
Cn.81 KEB I Gain	The controller I Gain is for maintaining the voltage of the DC power section during the kinetic energy buffering operation. Sets the gain value to maintain the frequency during the kinetic energy buffering operation until the inverter stops.
Cn.82 KEB Slip Gain	The slip gain is for preventing a low voltage trip due to load when the kinetic energy buffering operation start from blackout.
Cn.83 KEB Acc Time	Set the acceleration time of operation frequency when it restores normal operation from the kinetic energy buffering operation under the input power is restored.

⚠ Caution


Depending on the duration of Instantaneous power interruptions and the amount of load inertia, a low voltage trip may occur even during a kinetic energy buffering operation. Motors may vibrate during kinetic energy buffering operation for some loads except variable torque load (for example, fan or pump loads).

5.12 Energy Saving Operation

5.12.1 Manual Energy Saving Operation

If the inverter output current is lower than the current which is set at bA.14 (Noload Curr), the output voltage must be reduced as low as the level set at Ad.51 (Energy Save). The voltage before the energy saving operation starts will become the base value of the percentage. Manual energy saving operation will not be carried out during acceleration and deceleration.

Group	Code	Name	Setting		Setting Range	Unit
Ad	50	Energy saving operation	1	Manual	-	-
	51	Energy saving amount	30		0~30	%



5.12.2 Automatic Energy Saving Operation

The amount of energy saving can be automatically calculated based on the rated motor current (bA.13) and the no-load current (bA.14). From the calculations, the output voltage can be adjusted.

Group	Code	Name	Setting		Setting Range	Unit
Ad	50	Energy saving operation	2	Auto	-	-


⚠ Caution

If operation frequency is changed or acceleration and /deceleration is carried out by a stop command during the energy saving operation, the actual Acc/Dec time may take longer than the set Acc/Dec time due to the time required to return to the general operation from the energy saving operation.

5.13 Speed Search Operation

This operation is used to prevent fault trips that can occur while the inverter output voltage is disconnected and the motor is idling. Because this feature estimates the motor rotation speed based on the inverter output current, it does not give the exact speed.

Group	Code	Name	Setting	Setting Range	Unit	
Cn	70	Speed search mode selection	0	Flying Start-1	-	-
			1	Flying Start-2		
	71	Speed search operation selection	0000*		-	bit
	72	Speed search reference current	-	Below 75 kW	80~200	%
	73	Speed search proportional gain	100		0~9999	-
	74	Speed search integral gain	200		0~9999	-
OU	75	Output block time before speed search	1.0		0~60	sec
	31	Multi-function relay 1 item	1 9	Speed Search	-	-
	33	Multi-function relay 2 item				

*Displayed as  on the Keypad.



Speed Search Operation Setting Details

Code	Description	
Cn.70 SS Mode	Select a speed search type.	
	Configuration	Function
	0	Flying Start-1

The speed search is carried out as it controls the inverter output current during idling below the Cn.72 (SS Sup-Current) parameter setting. If the direction of the idling motor and the direction of operation command at restart are the same, a stable speed search function can be performed at about 10 Hz or lower. However, if the direction of the idling motor and the direction of operation command at restart are different, the speed search does not produce a satisfactory result because the direction of idling cannot be established.

Code	Description		
1	Flying Start-2	The speed search is carried out as it PI controls the ripple current which is generated by the counter electromotive force during no-load rotation. Because this mode establishes the direction of the idling motor (forward/reverse), the speed search function is stable regardless of the direction of the idling motor and direction of operation command. However because the ripple current is used which is generated by the counter electromotive force at idle (the counter electromotive force is proportional to the idle speed), the idle frequency is not determined accurately and re-acceleration may start from zero speed when the speed search is performed for the idling motor at low speed (about 10 - 15 Hz, though it depends on motor characteristics).	


Speed search can be selected from the following 4 options. If the top display segment is on it is enabled (On), and if the bottom segment is on it is disabled (Off).

Items	Bit Setting On Status	Bit setting Off Status
Keypad		

Type and Functions of Speed Search Setting

Configuration				Function
bit4	bit3	bit2	bit1	
			✓	Speed search for general acceleration
		✓		Initialization after a fault trip
	✓			Restart after instantaneous power interruption
✓				Starting with power-on

- Speed search for general acceleration:** If bit 1 is set to 1 and the inverter operation command runs, acceleration starts with speed search operation. When the motor is rotating under load, a fault trip may occur if the operation command is run for the inverter to provide output voltage. The speed search function prevents such fault trip from occurring.

Code	Description
	<ul style="list-style-type: none"> • Initialization after a fault trip: If Bit 2 is set to 1 and Pr.08 (RST Restart) is set to 1 (Yes), the speed search operation automatically accelerates the motor to the operation frequency used before the fault trip, when the [Reset] key is pressed (or the terminal block is initialized) after a fault trip. • Automatic restart after reset of a fault trip: If bit 3 is set to 1, and if a low voltage trip occurs due to a power interruption but the power is restored before the internal power shuts down, the speed search operation accelerates the motor back to its frequency reference before the low voltage trip. <p>If an instantaneous power interruption occurs and the input power is disconnected, the inverter generates a low voltage trip and blocks the output. When the input power returns, the operation frequency before the low voltage trip and the voltage is increased by the inverter's inner PI control</p> <p>If the current increases above the value set at Cn.72, the voltage stops increasing and the frequency decreases (t1 zone). If the current decreases below the value set at Cn.27, the voltage increases again and the frequency stops decelerating (t2 zone). When the normal frequency and voltage are resumed, the speed search operation accelerates the motor back to its frequency reference before the fault trip.</p>  <ul style="list-style-type: none"> • Starting with power-on: Set bit 4 to 1 and Ad.10 (Power-on Run) to 1 (Yes). If inverter input power is supplied while the inverter operation command is on, the speed search operation will accelerate the motor up to the frequency reference.

Code	Description
Cn.72 SS Sup-Current	The amount of current flow is controlled during speed search operation based on the motor's rated current. If Cn.70 (SS mode) is set to 1 (Flying Start-2), this code is not visible.
Cn.73 SS P/I-Gain, Cn.75 SS Block Time	The P/I gain of the speed search controller can be adjusted. If Cn.70 (SS Mode) is set to 1 (Flying Start-2), different factory defaults based on motor capacity are used and defined in dr.14 (Motor Capacity).

Note

- If operated within the rated output, the G100 series inverter is designed to withstand instantaneous power interruptions within 15 ms and maintain normal operation. Based on the rated heavy load current, safe operation during an instantaneous power interruption is guaranteed for 200 V and 400 V inverters (whose rated input voltages are 200-230 VAC and 380-460 VAC respectively).
- The DC voltage inside the inverter may vary depending on the output load. If the power interruption time is longer than 15 ms, a low voltage trip may occur.


⚠ Caution

When operating in sensorless II mode while the starting load is in free-run, the speed search function (for general acceleration) must be set for smooth operation. If the speed search function is not set, an overcurrent trip or overload trip may occur.

5.14 Auto Restart Settings


When inverter operation stops due to a fault and a fault trip is activated, the inverter automatically restarts based on the parameter settings.

Group	Code	Name	Setting	Setting Range	Unit
Pr	08	Selection of startup on trip reset	0 No	0~1	-
	09	Number of automatic restarts	0	0~10	-
	10	Auto restart delay time	1.0	0.0~60.0	sec
Cn	71	Speed search operation selection	-	0000*~1111	bit
	72	Speed search reference current	150	80~200	%
	73	Speed search proportional gain	100	0~9999	
	74	Speed search integral gain	200	0~9999	
	75	Output block time before speed search	1.0	0.0~60.0	sec

*Displayed as  on the Keypad.

Auto Restart Setting Details

Code	Description
Pr.08 RST Restart, Pr.09 Retry Number, Pr.10 Retry Delay	<p>Only operates when Pr.08 (RST Restart) is set to 1(Yes). The number of attempts to try the auto restart is set at Pr.09 (Auto Restart Count). If a fault trip occurs during operation, the inverter automatically restarts after the set time programmed at Pr.10 (Retry Delay). At each restart, the inverter counts the number of tries and subtracts it from the number set at Pr.09 until the retry number count reaches 0. After an auto restart, if a fault trip does not occur within 60 sec, it will increase the restart count number. The maximum count number is limited by the number set at Pr.09 (Auto Restart Count).</p> <p>If the inverter stops due to low voltage, emergency stop (Bx), inverter overheating, or hardware diagnosis, an auto restart is not activated. At auto restart, the acceleration options are identical to those of speed search operation. Codes Cn.72–75 can be set based on the load. Information about the speed search function can be found at 5.13 Speed Search Operation on page 139.</p>



[Example of auto restart with a setting of 2]

⚠ Caution

If the auto restart number is set, be careful when the inverter resets from a fault trip. The motor may automatically start to rotate.

5.15 Operational Noise Settings (Change of Carrier Frequency Settings)

Group	Code	Name	Setting Range	Unit
Cn	04	Carrier Frequency	1.0~15.0	kHz

* PWM: Pulse width modulation

Operational Noise Setting Details

Code	Description
Cn.04 Carrier Freq	Adjust motor operational noise by changing carrier frequency settings. Power transistors (IGBT) in the inverter generate and supply high frequency switching voltage to the motor. The switching speed in this process refers to the carrier frequency. If the carrier frequency is set high, it reduces operational noise from the motor, and if the carrier frequency is set low, it increases operational noise from the motor.

Note


Factory default carrier frequency (0.4-7.5kW)

- Normal Duty: 2 kHz(Max 5 kHz)
- Heavy load: 3kHz(Max 15kHz)

G100 Series Inverter Derating Standard

- G100 inverter is designed to respond to two types of load rates. Heavy load (heavy duty) and normal load (normal duty). The overload rate represents an acceptable load amount that exceeds rated load, and is expressed in a ratio based on the rated load and the duration. The overload capacity on the S100 series inverter is 150%/1min for heavy loads, and 120%/1min for normal loads. The current rating differs from the load rating, as it also has an ambient temperature limit. For derating specifications, refer to **11.8 Continuous Rated Current Derating** on page **291**.

- Current rating for ambient temperature at normal load operation.



- Below shows the carrier frequency rated current guaranteed area according to the load.

Inverter capacity	Normal load	Heavy load
0.4-7.5kW	2kHz	6 kHz

5.16 2nd Motor Operation

The 2nd motor operation is used when a single inverter switch operates two motors. Using the 2nd motor operation, a parameter for the 2nd motor is set. The 2nd motor is operated when a multi-function terminal input defined as a 2nd motor function is turned on.

Group	Code	Name	Setting		Setting Range	Unit
In	65~69	Px terminal setting options	26	2nd Motor	0~52	-

2nd Motor Operation Setting Details

Code	Description
In.65–69 Px Define	<p>Set one of the multi-function input terminals (P1–P5) to 26 (2nd Motor) to display M2 (2nd motor group) group. An input signal to a multi-function terminal set to 2nd motor will operate the motor according to the code settings listed below. However, if the inverter is in operation, input signals to the multi-function terminals will not read as a 2nd motor parameter.</p> <p>Pr.50 (Stall Prevent) must be set first, before M2.28 (M2-Stall Lev) settings can be used. Also, Pr.40 (ETH Trip Sel) must be set first, before M2.29 (M2-ETH 1min) and M2.30 (M2.ETH Cont) settings.</p>


Parameter Setting at Multi-function Terminal Input on a 2nd Motor

Code	Description	Code	Description
M2.04 Acc Time	Acceleration time	M2.16 Inertia Rt	Load inertia rate
M2.05 Dec Time	Deceleration time	M2.17 Rs	Stator resistance
M2.06 Capacity	Motor capacity	M2.18 Lsigma	Leakage inductance
M2.07 Base Freq	Motor base frequency	M2.19 Ls	Stator inductance
M2.08 Ctrl Mode	Control mode	M2.20 Tr	Rotor time constant
M2.10 Pole Num	Pole number	M2.25 V/F Patt	V/F pattern
M2.11 Rate Slip	Rated slip	M2.26 Fwd Boost	Forward Torque boost
M2.12 Rated Curr	Rated current	M2.27 Rev Boost	Reverse torque boost
M2.13 Noload Curr	No-load Current	M2.28 Stall Lev	Stall prevention level
M2.14 Rated Volt	Motor rated voltage	M2.29 ETH 1min	Electronic thermal 1 minute rating
M2.15 Efficiency	Motor efficiency	M2.30 ETH Cont	Electronic thermal continuous rating

Example - 2nd Motor Operation

Use the 2nd motor operation when switching operation between a 7.5 kW motor and a secondary 3.7 kW motor connected to terminal P3. Refer to the following settings.

Group	Code	Name	Setting	Setting Range	Unit
In	67	P3 terminal function setting	26	2nd Motor	-
M2	06	Motor capacity	-	3.7kW	-
	08	Control mode	0	V/F	-



5.17 Commercial Power Source Transition

Supply power transition is used to switch the power source for the motor connected to the inverter from the inverter output power to the main supply power source (commercial power source), or vice versa.

Group	Code	Name	Setting	Setting Range	Unit
In	65~69	Px terminal setting options	16	Exchange	0~52
OU	31	Multi-function relay 1 item	17	Inverter Line	-
	33	Multi-function relay 2 item	18	Comm Line	-

Supply Power Transition Setting Details

Code	Description
In.65-69 Px Define	When the motor power source changes from inverter output to main supply power, select a terminal to use and set the code value to 16 (Exchange). Power will be switched when the selected terminal is on. To reverse the transition, switch off the terminal.

Code	Description
OU.31 Relay 1 Define, OU.33 Q1 Define	<p>This function sets the multi-function relay to the no. 17 inverter line and no. 18 comm line. Relay operation sequence is as follows.</p>

5.18 Cooling Fan Control

This function turns the inverter’s heat-sink cooling fan on and off. It is used in situations where the load stops and starts frequently, or noise free environment is required. The correct use of cooling fan control can extend the cooling fan’s life.

Group	Code	Name	Setting	Setting Range	Unit	
Ad	64	Cooling fan control	0	During Run	0~2	-

Cooling Fan Control Detail Settings

Code	Function	
Ad.64 Fan Control	Configuration	Function
	0	During Run
<p>Cooling fan runs when the power is supplied to the inverter and the operation command is on. The cooling fan stops when the power is supplied to the inverter and the operation command is off. When the inverter heat sink temperature is higher than its set value, the cooling fan operates automatically regardless of its operation status.</p>		

Code	Function		
	1	Always On	Cooling fan runs constantly if the power is supplied to the inverter.
	2	Temp Control	With power connected and the run operation command on, if the setting is in Temp Control, the cooling fan will not operate unless the temperature in the heat sink reaches the set temperature.

Note

Despite setting Ad.64 to 0(During Run), if the heat sink temperature reaches a set level by current input harmonic wave or noise, the cooling fan may run as a protection function. Also, the cooling fan operates regardless of the cooling fan control settings to protect the internal circuit when the input voltage is 480 VAC or higher for 400V products.

5.19 Input Power Frequency and Voltage Settings

Select the frequency for inverter input power. If the frequency changes from 60 Hz to 50 Hz, all other frequency (or RPM) settings including the maximum frequency, base frequency etc., will change to 50 Hz. Likewise, changing the input power frequency setting from 50 Hz to 60Hz will change all related function item settings from 50 Hz to 60 Hz.

Group	Code	Name	Setting		Setting Range	Unit
bA	10	input power frequency	0	60Hz	0~1	-

Set Inverter input power voltage at bA.19. Low voltage fault trip level changes automatically to the set voltage standard.

Group	Code	Name	Setting		Setting Range	Unit
bA	19	Input power voltage	220V	220	170~240	V
			400V	380	320~480	

5.20 Parameter Initialization

The parameter changed by the user can be initialized to the factory default settings. Initialize the data of all groups or initialize data by selecting specific groups. However, during a fault trip situation or operation, parameters cannot be initialized.

Group	Code	Name	Setting		Setting Range	Unit
dr	93	Parameter initialization	0	No	0~14	-

Parameter Initialization Setting Details

Code		Description	
dr.93 Parameter Init	Configuration		Function
	0	No	-
	1	Initialize all groups	Initialize all data. Select 1(All Grp) and press [PROG/ENT] key to start initialization. On completion, 0(No) will be displayed.
	2	Initialize dr group	Initialize data by groups. Select initialize group and press [PROG/ENT] key to start initialization. On completion, 0(No) will be displayed.
	3	Initialize bA group	
	4	Initialize Ad group	
	5	Initialize Cn group	
	6	Initialize In group	
	7	Initialize OU group	
	8	Initialize CM group	
	9	Initialize AP group	
	11	Initialize AO group	
	12	Initialize Pr group	
	13	Initialize M2 group	
	14	Initialize Operation Group	

5.21 Parameter Lock

Use parameter view lock to hide parameters after registering and entering a user password.

Group	Code	Name	Setting	Setting Range	Unit
dr	94	Password registration	-	0~9999	-
	95	Parameter lock settings	-	0~9999	-

Parameter Lock Setting Details

Code	Description												
dr-94	Register a password to prohibit parameter modifications. Follow the procedures below to register a password.												
	<table border="1"> <thead> <tr> <th>Step</th> <th>Procedures</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Press the [PROG/ENT] key on dr-94 code and the saved password input window will be displayed. If password registration is being made for the first time, enter 0. It is the factory default.</td> </tr> <tr> <td>2</td> <td>If a saved password has been set, enter the saved password.</td> </tr> <tr> <td>3</td> <td>If the entered password matches the saved password, then a new window to enter a new password will be displayed. (The process will not move to next stage until the user enters a valid password).</td> </tr> <tr> <td>4</td> <td>Register a new password.</td> </tr> <tr> <td>5</td> <td>After registration, Code dr-94 will be displayed.</td> </tr> </tbody> </table>	Step	Procedures	1	Press the [PROG/ENT] key on dr-94 code and the saved password input window will be displayed. If password registration is being made for the first time, enter 0. It is the factory default.	2	If a saved password has been set, enter the saved password.	3	If the entered password matches the saved password, then a new window to enter a new password will be displayed. (The process will not move to next stage until the user enters a valid password).	4	Register a new password.	5	After registration, Code dr-94 will be displayed.
	Step	Procedures											
	1	Press the [PROG/ENT] key on dr-94 code and the saved password input window will be displayed. If password registration is being made for the first time, enter 0. It is the factory default.											
	2	If a saved password has been set, enter the saved password.											
	3	If the entered password matches the saved password, then a new window to enter a new password will be displayed. (The process will not move to next stage until the user enters a valid password).											
4	Register a new password.												
5	After registration, Code dr-94 will be displayed.												
dr-95	Press the [ENT] key when the change prevention feature is disabled, and UL (Unlocked) is displayed.. Press the [ENT] key again a field to input password is shown. Enter the password and the Locked display is shown. Even if you press [ENT] key from the function code to change the changing the parameter, this will not be changed to edit mode. Enter password again to display UL (Unlocked). The change prevention feature is disabled.												

⚠ Caution

If parameter view lock and parameter lock functions are enabled, no inverter operation related function changes can be made. It is very important that you memorize the password.

5.22 Changed Parameter Display

This feature displays all the parameters that are different from the factory defaults. Use this feature to track changed parameters.

Group	Code	Name	Setting		Setting Range	Unit
dr	89	Changed parameter display	0	View All	-	-

Changed Parameter Display Setting Details

Code	Description		
dr-89 Changed Para	Configuration		Function
	0	View All	Display all parameters
	1	View Changed	Display changed parameters only

5.23 Timer Settings


Set a multi-function input terminal to a timer and On/Off control the multi-function output and relay according to the timer settings.

Group	Code	Name	Setting		Setting Range	Unit
In	65~69	Px terminal setting options	38	Timer In	0~52	-
OU	31	Multi-function relay 1 item	28	Timer Out	-	-
	33	Multi-function relay 2 item				
	55	Timer On delay	3.00		0.00~100	sec
	56	Timer Off delay	1.00		0.00~100	sec

Timer Setting Details

Code	Description
In.65-69 Px Define	Choose one of the multi-function input terminals and change it to a timer terminal by setting it to 38 (Timer In).

Code	Description
OU.31 Relay1, OU.33 Relay 2	Set multi-function output terminal or relay to be used as a timer to 28 (Timer out).
OU.55 TimerOn Delay, OU.56 TimerOff Delay	Input a signal (On) to the timer terminal to operate a timer output (Timer out) after the time set at OU.55 has passed. When the multi-function input terminal is off, multi-function output or relay turns off after the time set at OU.56.



5.24 Brake Control


This feature controls the On/Off operation of the load's electronic braking system.

Group	Code	Name	Setting	Setting Range	Unit
dr	09	Control mode	0	V/F	-
Ad	41	Brake release current	50.0	0.0~180 %	%
	42	Brake release delay time	1.00	0.0~10.0	sec
	44	Brake release Forward frequency	1.00	0~Max Frequency	Hz
	45	Brake release Reverse frequency	1.00	0~Max Frequency	Hz
	46	Brake engage delay time	1.00	0.00~10.00	sec
	47	Brake engage frequency	2.00	0~Max Frequency	Hz
OU	31	Multi-function relay 1 item	35	BR Control:	-
	33	Multi-function relay 2 item			

When brake control is activated, DC braking (Ad.12) at inverter start and dwell operation (Ad.20~23) do not operate.

- Brake release sequence:** During motor stop state, if an operation command is entered, the inverter accelerates up to brake release frequency (Ad.44– 45) in forward or in reverse direction. After reaching brake release frequency, if motor current reaches brake release current (BR Rls Curr), the output relay or multi-function output terminal for brake control sends a release signal. Once the signal has been sent, acceleration will begin after maintaining frequency for brake release delay time (BR Rls Dly).

- Brake engage sequence:** If a stop command is sent during operation, the motor decelerates. Once the output frequency reaches brake engage frequency (BR Eng Fr), the motor stops deceleration and sends out a brake engage signal to a preset output terminal. Frequency is maintained for the brake engage delay time (BR Eng Dly) and will become 0 afterwards. If DC braking time (Ad.15) and DC braking resistance (Ad.16) are set, inverter output is blocked after DC braking. For DC braking, refer to **4.15.2 DC Braking After Stop** on page **93**.




5.25 Multi-Function Output On/Off Control

Set reference values (on/off level) for analog input and control output relay or multi-function output terminal on/off status accordingly.

Group	Code	Name	Setting		Setting Range	Unit
Ad	66	Output terminal on/off control mode	1	V1	-	-
	67	Output contact On level	90.00		Output contact off level–100.00 %	%
	68	Output contact Off level	10.00		0.00–Output terminal on level	%
OU	31	Multi-function relay 1 item	34	On/Off	-	-
	33	Multi-function relay 2 item				

Multi-function Output On/Off Control Setting Details

Code	Description
Ad.66 On/Off Ctrl Src	Select analog input On/Off control.
Ad.67 On-C Level , Ad.68 Off-C Level	Set On/Off level at the output terminal.



5.26 Press Regeneration Prevention


Press regeneration prevention is used during press operations to prevent braking during the regeneration process. If motor regeneration occurs during a press operation, motor operation speed automatically goes up to avoid the regeneration zone.

Group	Code	Name	Setting	Setting Range	Unit
Ad	74	Selection of regeneration evasion function for press	0 No	0~1	-
	75	Voltage level of regeneration evasion motion for press	350V	200 V 300~400 V	V
			700V	400 V 600~800 V	
	76	Compensation frequency limit of regeneration evasion for press	1.00 (Hz)	0.00~10.00 Hz	Hz
	77	Regeneration evasion for press P gain	50.0 (%)	0~100 %	%
78	Regeneration evasion for press I gain	500 (ms)	20~30000 ms	ms	

Press Regeneration Prevention Setting Details

Code	Description
Ad.74 RegenAvd Sel	Frequent regeneration voltage from a press load during constant speed motor operation may force excessive work on the brake unit which may damage or shorten the brake life. To prevent this situation, select Ad.74 (RegenAvd Sel) to control DC link voltage and disable the brake unit operation.

Code	Description
Ad.75 RegenAvd Level	Set brake operation prevention level voltage when the DC link voltage goes up due to regeneration.
Ad.76 CompFreq Limit	Set alternative frequency width that can replace actual operation frequency during regeneration prevention.
Ad.77 RegenAvd Pgain, Ad.78 RegenAvd Igain	To prevent regeneration zone, set P gain/I gain in the DC link voltage suppress PI controller.



Note

Press regeneration prevention does not operate during accelerations or decelerations, but it only operates during constant speed motor operation. When regeneration prevention is activated, output frequency may change within the range set at Ad.76 (CompFreq Limit).

5.27 Analog Output

An analog output terminal provides output of 0–10 V voltage and 4–20 mA current.

5.27.1 Current Analog Output

An output size can be adjusted by selecting an output option at AO (Analog Output) terminal.

Group	Code	Name	Setting	Setting Range	Unit	
OU	01	Analog output 1 item	0	Frequency	0~15	-
	02	Analog output 1 gain	100.0		-1000.0~1000.0	%
	03	Analog output 1 bias	0.0		-100.0~100.0	%
	04	Analog output 1 filter	5		0~10000	ms
	05	Analog constant output1	0.0		0.0~100.0	%
	06	Analog output1 monitor	0.0		0.0~1000.0	%

Voltage and Current Analog Output Setting Details

Code	Description															
OU.01 AO1 Mode	Select a constant value for output.															
	<table border="1"> <thead> <tr> <th>Configuration</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Frequency</td> </tr> <tr> <td>1</td> <td>Output Current</td> </tr> <tr> <td>2</td> <td>Output Voltage</td> </tr> <tr> <td>3</td> <td>DC Link Volt</td> </tr> <tr> <td>4</td> <td>Torque</td> </tr> <tr> <td>5</td> <td>Output Power</td> </tr> </tbody> </table>		Configuration	Function	0	Frequency	1	Output Current	2	Output Voltage	3	DC Link Volt	4	Torque	5	Output Power
	Configuration	Function														
	0	Frequency														
	1	Output Current														
	2	Output Voltage														
	3	DC Link Volt														
4	Torque															
5	Output Power															
0	Frequency	Outputs operation frequency as a standard. 10V output is made from the frequency set at dr.20 (Max Freq).														
1	Output Current	10 V output is made from 200 % of inverter rated current (heavy load).														
2	Output Voltage	Sets the outputs based on the inverter output voltage. 10 V output is made from a set voltage in bA.15 (Rated V). If 0 V is set in bA.15, 200V/240V/400V models output 10 V based on the actual input voltage (480V).														
3	DC Link Volt	Outputs inverter DC link voltage as a standard. Outputs 10V when the DC link voltage is 410 Vdc for 200 V models, and 820 Vdc for 400 V models.														
4	Torque	Outputs the generated torque as a standard. Outputs 10V at 250% of motor rated torque.														
5	Output Power	Monitors output wattage. 200 % of rated output is the maximum display voltage (10 V).														

Code	Description		
	6	Idse	Outputs the maximum voltage at 200 % of no load current.
	7	Iqse	Outputs the maximum voltage at 250 % of rated torque current. rated torque current = $\sqrt{\text{rated current}^2 - \text{no load current}^2}$
	8	Target Freq	Outputs set frequency as a standard. Outputs 10 V at the maximum frequency (dr.20).
	9	Ramp Freq	Outputs frequency calculated with Acc/Dec function as a standard. May vary with actual output frequency. Outputs 10V.
	12	PID Ref Value	Outputs command value of a PID controller as a standard. Outputs approximately 6.6 V at 100 %.
	13	PID Fdk Value	Outputs feedback volume of a PID controller as a standard. Outputs approximately 6.6 V at 100 %.
	14	PID Output	Outputs output value of a PID controller as a standard. Outputs approximately 10 V at 100 %.
	15	Constant	Outputs OU.05 (AO1 Const %) value as a standard.
OU.02 AO1 Gain, OU.03 AO1 Bias	<p>Adjusts output value and offset. If frequency is selected as an output item, it will operate as shown below.</p> $AO1 = \frac{\text{Frequency}}{\text{MaxFreq}} \times AO1 \text{ Gain} + AO1 \text{ Bias}$ <p>The graph below illustrates the analog voltage output (AO1) changes depend on OU.02 (AO1 Gain) and OU.3 (AO1 Bias) values. Y-axis is analog output voltage (0–10V), and X-axis is % value of the output item.</p> <p>Example, if the maximum frequency set at dr.20 (Max Freq) is 60 Hz and the present output frequency is 30 Hz, then the x-axis value on the next graph is 50 %.</p>		

Code	Description
	<div style="text-align: center;"> <p>The figure shows four graphs arranged in a 2x2 grid. The top row is labeled 'OU.02 AO1 Gain' and the bottom row is labeled 'OU.03 AO1 Bias'. The left column shows '0.0% Factory default' and '20.0%' bias settings. The right column shows '80.0%' and '100.0% (Factory default)' gain settings. Each graph plots Voltage (V) on the y-axis (0V to 10V) against Percentage (%) on the x-axis (0% to 100%).</p> <ul style="list-style-type: none"> 0.0% Factory default: Linear relationship from (0, 0) to (100, 10). 20.0%: Linear relationship from (0, 2) to (80, 10), then constant at 10V until 100%. 80.0%: Linear relationship from (0, 0) to (80, 8), then constant at 8V until 100%. 100.0% (Factory default): Linear relationship from (0, 0) to (100, 10). </div>
OU.04 AO1 Filter	Set filter time constant on analog output.
OU.05 AO1 Const %	If analog output at OU.01 (AO1 Mode) is set to 15(Constant), the analog voltage output is dependent on the set parameter values (0–100 %).
OU.06 AO1 Monitor	Monitors analog output value. Displays the maximum output voltage as a percentage (%) with 10 V as the standard.

5.28 Digital Output

5.28.1 Multi-Function Relay Settings


Group	Code	Name	Setting	Setting Range	Unit
OU	30	Fault output item	010*	-	bit
	31	Multi-function relay 1 item	29	Trip	-
	33	Multi-function relay 2 item	14	Run	-
	41	Multi-function output monitor	-	00~ 11	bit
	57	Detection frequency	30.00	0.00–Max Frequency	Hz
58	Detection frequency band	10.00			
In	65~69	Px terminal setting options	16	Exchange	-

* Displayed as on the keypad.

Multi-Function Relay Setting Details

Code	Description	
OU.31 Relay1	Set the Relay 1 output item.	
OU.33 Relay 2	Set the Relay 2 output item.	
OU.41 DO Status	Set output terminal and relay functions according to OU.57 FDT (Frequency), OU.58 (FDT Band) settings and fault trip conditions.	
	Configuration	Function
	0	None
1	FDT-1	<p>Detects inverter output frequency reaching the user set frequency. Outputs signal when the conditions below are satisfied.</p> <p>Absolute value(set frequency–output frequency) < detected frequency width/2</p> <p>When detected frequency width is 10Hz, FDT-1 output is as shown in the graph below.</p>
2	FDT-2	<p>Outputs a signal when the user set frequency and detected frequency (FDT Frequency) are equal, and fulfills FDT-1 condition at the same time.</p> <p>[Absolute value (set frequency-detected frequency) < detected frequency width/2]&[FDT-1]</p> <p>Detected frequency width is 10Hz. When the detected frequency is set to 30Hz, FDT-2 output is as shown in the graph below.</p>

Code		Description
3	FDT-3	<p>Outputs signal when the operation frequency below meets the conditions.</p> <p>Absolute value(output frequency–operation frequency) < detected frequency width/2</p> <p>Detected frequency width is 10Hz. When the detected frequency is set to 30Hz, FDT-3 output is as shown in the graph below.</p>
4	FDT-4	<p>Output signal can be separately set for acceleration and deceleration conditions.</p> <ul style="list-style-type: none"> • In acceleration: Operation frequency \geq Detected frequency • In deceleration: Operation frequency > (Detected frequency–Detected frequency width/2) <p>Detected frequency width is 10Hz. When the detected frequency is set to 30Hz, FDT-4 output is as shown in the graph below.</p>
5	Over Load (Overload)	Outputs a signal at motor overload.
6	IOL	Outputs a signal when a fault is triggered from a protective function operation by inverter overload inverse proportion.
7	Under Load (Underload)	Outputs a signal at load fault warning.
8	Fan Warning (Fan Warning)	Outputs a signal at fan fault warning.

Code		Description
9	Stall (motor stall)	Outputs a signal when a motor is overloaded and stalled.
10	Over Voltage (Over Voltage)	Outputs a signal when the inverter DC link voltage rises above the protective operation voltage.
11	Low Voltage (Low Voltage)	Outputs a signal when the inverter DC link voltage drops below the low voltage protective level.
12	Over Heat (Over Heat)	Outputs signal when the inverter overheats.
13	Lost Command (Lost Command)	Outputs a signal when there is a loss of analog input terminal and RS-485 communication command at the terminal block. Outputs a signal when communication power and expansion an I/O power card is installed, and also outputs a signal when losing analog input and communication power commands.
14	RUN	<p>Outputs a signal when operation command is entered and the inverter outputs voltage. No signal output during DC braking.</p> 
15	Stop	Outputs a signal at operation command off, and when there is no inverter output voltage.
16	Steady (Steady)	Outputs a signal in steady operation.
17	Inverter Line (Inverter Line)	Outputs a signal while the motor is driven by the inverter line.
18	Comm Line (Comm Line)	Outputs a signal while the motor is driven by a commercial power source. For details, refer to 5.17 Commercial Power Source Transition on page 147 .
19	Speed Search (Speed Search)	Outputs a signal during inverter speed search operation. For details, refer to 5.13 Speed Search Operation on page 139 .
21	Regeneration (Regeneration)	Outputs signal if the motor is operating under regeneration mode. Braking resistance is activated when the inverter DC voltage is higher than the voltage set in Ad-79 and this feature operates only when the inverter is operating.







Code		Description
22	Ready (Ready)	Outputs signal when the inverter is in stand by operation and ready to receive an external operation command.
23	FDT-5(Zspd)	Outputs signal that is lower than the frequency set in iOU-57 and OU-58.
28	Timer Out	This is a feature to activate the contact output after a certain period of time using the multi-function terminal block. For details, refer to 5.23 Timer Settings on page 152 .
29	Trip	Outputs a signal after a fault trip. Refer to 5.25 Multi-Function Output On/Off Control on page 154 for more details.
31	DB Warn %ED	Refer to 6.2.5 Dynamic Braking (DB) Resistor Configuration on page 179 .
34	On/Off Control	Outputs a signal using an analog input value as a standard. Refer to 5.25 Multi-Function Output On/Off Control on page 154 for more details.
35	BR Control	Outputs a brake release signal. Refer to 5.24 Brake Control on page 153 for more details.
40	KEB Operating	This outputs when the energy buffering operation is started because of low voltage of the inverter's DC power section due to a power failure on the input power. (This outputs in the energy buffering state before the input power restoration regardless of KEB-1 and KEB-2 mode settings.)
42	Minor Fault	Outputs signal when inverter is under warning status.

5.28.2 Trip Output to Multi-Function Relay

Using multi-function relays 1 and 2, you can output the trip status of inverter.

Group	Code	Name	Setting	Setting Range	Unit
OU	30	Fault output item	010	-	bit
	31	Multi-function relay 1 item	29	Trip	-
	33	Multi-function relay 2 item	14	Run	-
	53	Fault output On delay	0.00	0.00~100.00	sec
	54	Fault output Off delay	0.00	0.00~100.00	Sec


Trip Setting Details to Multi-Function Relay

Code	Description																		
OU.30 Trip Out Mode	Fault trip relay operates based on the fault trip output settings.																		
	<table border="1"> <thead> <tr> <th>Items</th> <th>Bit Setting On Status</th> <th>Bit setting Off Status</th> </tr> </thead> <tbody> <tr> <td>Keypad</td> <td></td> <td></td> </tr> </tbody> </table>	Items	Bit Setting On Status	Bit setting Off Status	Keypad														
	Items	Bit Setting On Status	Bit setting Off Status																
	Keypad																		
	After selecting the multi-function relay to use as the trip output, select 29 (Trip Mode) in OU.31, 33. If the trip occurs from the inverter, the applicable multi-function relay will be activated. Activation status of multi-function relay can be set up as below depending on the trip type.																		
	<table border="1"> <thead> <tr> <th colspan="3">Configuration</th> <th rowspan="2">Function</th> </tr> <tr> <th>bit3</th> <th>bit2</th> <th>bit1</th> </tr> </thead> <tbody> <tr> <td></td> <td></td> <td>✓</td> <td>Operates when low voltage fault trips occur</td> </tr> <tr> <td></td> <td>✓</td> <td></td> <td>Operates when fault trips other than low voltage occur</td> </tr> <tr> <td>✓</td> <td></td> <td></td> <td>Operates when auto restart fails (Pr. 08–09)</td> </tr> </tbody> </table>	Configuration			Function	bit3	bit2	bit1			✓	Operates when low voltage fault trips occur		✓		Operates when fault trips other than low voltage occur	✓		
Configuration			Function																
bit3	bit2	bit1																	
		✓	Operates when low voltage fault trips occur																
	✓		Operates when fault trips other than low voltage occur																
✓			Operates when auto restart fails (Pr. 08–09)																
OU.31 Relay1	Set the Relay 1 output item.																		
OU.33 Relay 2	Set the Relay 2 output item.																		
OU.53 TripOut On Dly, OU.54 TripOut OffDly	If a trip occurs, multi-function relay 1 or multi-function relay 2 will be activated after the time set in multi-function. Terminal is off with the input initialized after the time delay set in OU.54.																		



5.28.3 Multi-Function Relay Terminal Delay Time Settings


Set On delay time and Off delay time specifically to adjust the multi-function relay operation time of the terminal. The delay time set in OU.50-51 will be applied to both Relay 1 and Relay 2 except for when the multi-function relay feature is under trip mode.

Group	Code	Name	Setting	Setting Range	Unit
OU	50	Multi-function output On delay	0.00	0.00~ 100.00	sec
	51	Multi-function output Off delay	0.00	0.00~ 100.00	sec
	52	Multi-function output contact selection	00*	00~11	bit

*Displayed as  on the Keypad.

Output Terminal Delay Time Setting Details

Code	Description		
OU.52 DO NC/NO Sel	Select the contact type of relay 1 and relay 2. By setting the relevant bit to 0, it will operate A terminal (Normally Open), and setting it to 1 will operate B terminal (Normally Closed). Shown below in the table are Relay 1 and Relay 2 settings starting from the right bit.		
	Items	Bit Setting On Status	Bit setting Off Status
	Keypad		



5.29 Base Block

This feature is used when output is blocked while operating the inverter or when the multi-function relay must maintain the operating status by blocking output while stopping. If the multi-function signal set as base block is entered during operation, the motor will run freely. If the base block signal is disabled, speed search operation will start with the value set in Cn-72-75 even if the Cn-71 speed search operation selection parameter is not activated. The output being blocked by the base block feature does not have effect on the multi-function relay and will be recognized as being in operation even if there is no inverter output.

Group	Code	Name	Setting	Setting Range	Unit	
In	65-69	Px terminal setting options	33	Base Block	1-52	-
OU	31	Multi-function relay 1 item	14	Run	1-44	-
	33	Multi-function relay 2 item				

Base Block Operation Setting Details

Code	Description
In 65-69 Px define	Select the multi-function input terminal to receive the base block signal and set the applicable terminal to 33 (Base Block).
OU31 Relay 1 OU33 Relay 2 Define	Set the multi-function relay terminal to 14 (Run). If the operation command is given, the inverter will accelerate up to the command frequency. If the base block signal is entered during acceleration or constant speed operation, the inverter will block the output immediately and start free-run. If the base block signal is disabled, the inverter will accelerate as a speed search operation until it reaches the command frequency, without receiving a specific reset command. "bb" will be displayed on the keypad during the base block operation. Disabling the base block will reset the inverter automatically and the base block will not be recorded in the trip history.

6 Learning Protection Features

Protection features provided by the G100 series inverter are categorized into two types: protection from overheating damage to the motor, and protection against the inverter malfunction.

6.1 Motor Protection


6.1.1 Electronic Thermal Motor Overheating Prevention (ETH)



ETH is a protective function that uses the output current of the inverter without a separate temperature sensor, to predict a rise in motor temperature to protect the motor based on its heat characteristics.

Group	Code	Name	Setting		Setting Range	Unit
Pr	40	Electronic thermal prevention fault trip selection	0	None	0~2	-
	41	Motor cooling fan type	0	Self-cool	-	-
	42	Electronic thermal 1 minute rating	150		120~200	%
	43	Electronic thermal continuous rating	120		50~150	%

Electronic Thermal (ETH) Prevention Function Setting Details

Code	Description									
Pr.40 ETH Trip Sel	ETH can be selected to provide motor thermal protection.									
	<table border="1"> <thead> <tr> <th>Configuration</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>None</td> </tr> <tr> <td>1</td> <td>Free-Run</td> </tr> <tr> <td>2</td> <td>Dec</td> </tr> </tbody> </table>		Configuration	Function	0	None	1	Free-Run	2	Dec
	Configuration	Function								
	0	None								
1	Free-Run									
2	Dec									
0	None	The ETH function is not activated.								
1	Free-Run	The inverter output is blocked. The motor coasts to a halt (free-run).								
2	Dec	The inverter decelerates the motor to a stop.								

Code	Description								
Pr.41 Motor Cooling	Select the drive mode of the cooling fan, attached to the motor.								
	<table border="1"> <thead> <tr> <th data-bbox="381 301 436 330">Configuration</th> <th data-bbox="436 301 600 330"></th> <th data-bbox="600 301 1251 330">Function</th> </tr> </thead> <tbody> <tr> <td data-bbox="381 330 436 436">0</td> <td data-bbox="436 330 600 436">Self-cool</td> <td data-bbox="600 330 1251 436">As the cooling fan is connected to the motor axis, the cooling effect varies, based on motor speed. Most universal induction motors have this design.</td> </tr> <tr> <td data-bbox="381 436 436 571">1</td> <td data-bbox="436 436 600 571">Forced-cool</td> <td data-bbox="600 436 1251 571">Additional power is supplied to operate the cooling fan. This provides extended operation at low speeds. Motors designed for inverters typically have this design.</td> </tr> </tbody> </table>	Configuration		Function	0	Self-cool	As the cooling fan is connected to the motor axis, the cooling effect varies, based on motor speed. Most universal induction motors have this design.	1	Forced-cool
Configuration		Function							
0	Self-cool	As the cooling fan is connected to the motor axis, the cooling effect varies, based on motor speed. Most universal induction motors have this design.							
1	Forced-cool	Additional power is supplied to operate the cooling fan. This provides extended operation at low speeds. Motors designed for inverters typically have this design.							
Pr.42 ETH 1min	The amount of input current that can be continuously supplied to the motor for 1 minute, based on the motor-rated current (bA.13).								
Pr.43 ETH Cont	<p>Sets the amount of current with the ETH function activated. The range below details the set values that can be used during continuous operation without the protection function.</p> 								



6.1.2 Overload Early Warning and Trip


A warning or fault 'trip' (cutoff) occurs when the motor reaches an overload state, based on the motor's rated current. The amount of current for warnings and trips can be set separately.

Group	Code	Name	Setting		Setting Range	Unit
Pr	04	Load level setting	1	Heavy Duty	-	-
	17	Overload warning selection	1	Yes	0~1	-
	18	Overload warning level	150		30~180	%
	19	Overload warning time	10.0		0~30	sec
	20	Motion at overload fault	1	Free-Run	-	-
	21	Overload fault level	180		30~200	%
	22	Overload fault time	60.0		0~60.0	sec
OU	31	Multi-function relay 1 item	5	Over Load	-	-
	33	Multi-function relay 2 item				

Overload Early Warning and Trip Setting Details

Code	Description						
Pr.04 Load Duty	Select the load level.						
	<table border="1"> <thead> <tr> <th>Configuration</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>0 Normal Duty</td> <td>Used in underloads, like fans and pumps (overload tolerance: 120% of rated underload current for 1 minute).</td> </tr> <tr> <td>1 Heavy Duty</td> <td>Used in heavy loads, like hoists, cranes, and parking devices (overload tolerance: 150% of rated heavy load current for 1 minute).</td> </tr> </tbody> </table>	Configuration	Function	0 Normal Duty	Used in underloads, like fans and pumps (overload tolerance: 120% of rated underload current for 1 minute).	1 Heavy Duty	Used in heavy loads, like hoists, cranes, and parking devices (overload tolerance: 150% of rated heavy load current for 1 minute).
	Configuration	Function					
0 Normal Duty	Used in underloads, like fans and pumps (overload tolerance: 120% of rated underload current for 1 minute).						
1 Heavy Duty	Used in heavy loads, like hoists, cranes, and parking devices (overload tolerance: 150% of rated heavy load current for 1 minute).						
Pr.17 OL Warn Select	If the overload reaches the warning level, the terminal block multi-function output terminal and relay are used to output a warning signal. If 1 (Yes) is selected, it will operate. If 0 (No) is selected, it will not operate.						
Pr.18 OL Warn Level, Pr.19 OL Warn Time	When the input current to the motor is greater than the overload warning level (OL Warn Level) and continues at that level during the overload warning time (OL Warn Time), the multi-function output (Relay 1, Relay 1) sends a warning signal. Multi-function relay terminal and relay outputs signal if OU.31 and OU.33 codes are set to 5 (Over load). The signal output does not block the inverter output.						

Code	Description		
Pr.20 OL Trip Select	Select the inverter protective action in the event of an overload fault trip.		
	Configuration	Function	
	0	None	No protective action is taken.
	1	Free-Run	In the event of an overload fault, inverter output is blocked and the motor will free-run due to inertia.
3	Dec	If a fault trip occurs, the motor decelerates and stops.	
Pr.21 OL Trip Level, Pr.22 OL Trip Time	When the current supplied to the motor is greater than the preset value at the overload trip level (OL Trip Level) and continues to be supplied during the overload trip time (OL Trip Time), the inverter output is either blocked according to the preset mode from Pr. 17 or slows to a stop after deceleration.		



Note


Overload warnings warn of an overload before an overload fault trip occurs. The overload warning signal may not work in an overload fault trip situation, if the overload warn level (OL Warn Level) and the overload warn time (OL Warn Time) are set higher than the overload trip level (OL Trip Level) and overload trip time (OL Trip Time).

6.1.3 Stall Prevention and Flux Braking



The stall prevention function is a protective function that prevents motor stall caused by overloads. If a motor stall occurs due to an overload, the inverter operation frequency is adjusted automatically. When stall is caused by overload, high currents are induced in the motor may cause motor overheat or damage the motor and interrupt operation of the motor-driven devices.

Flux braking is used to gain the optimum deceleration time without the braking resistance. If the deceleration time is too short, over voltage trip may occur due to the regeneration energy from the motor. When using flux braking, ideal deceleration time may be gained without over voltage trip because regenerative energy is expended at the motor. Flux braking stops operating when the control mode is IM Sensorless.



Group	Code	Name	Setting	Setting Range	Unit
Pr	50	Stall prevention motion and flux braking	0000*	-	bit
	51	Stall frequency 1	60.00	Start frequency–Stall Freq 1	Hz
	52	Stall level 1	180	30~250	%
	53	Stall frequency 2	60.00	Stall Freq 1–Stall Freq 3	Hz
	54	Stall level 2	180	30~250	%
	55	Stall frequency 3	60.00	Stall Freq 2–Stall Freq 4	Hz
	56	Stall level 3	180	30~250	%
	57	Stall frequency 4	60.00	Stall Freq 3–Maximum frequency	Hz
OU	31	Multi-function relay 1 item	9	Stall	-
	33	Multi-function relay 2 item			

* Displayed as  on the Keypad.

Stall Prevention Function and Flux Braking Setting Details

Code	Description		
Pr.50 Stall Prevent	Stall prevention can be configured for acceleration, deceleration, or while operating a motor at constant speed. When the top LCD segment is on, the corresponding bit is set. When the bottom LCD segment is on, the corresponding bit is off.		
	Items	Bit Setting On Status	Bit setting Off Status
	Keypad		

Code	Description				
	Configuration				Function
	bit4	bit3	bit2	bit1	
				✓	Stall protection during acceleration
			✓		Stall protection while operating at a constant speed
		✓			Stall protection during deceleration
	✓				Flux braking during deceleration
	Configuration		Function		
	0001	Stall protection during acceleration	If inverter output current exceeds the preset stall level (Pr. 52, 54, 56, 58) during acceleration, the motor stops accelerating and starts decelerating. If current level stays above the stall level, the motor decelerates to the start frequency (dr.19). If the current level causes deceleration below the preset level while operating the stall protection function, the motor resumes acceleration.		
	0010	Stall protection while operating at constant speed	Similar to stall protection function during acceleration, the output frequency automatically decelerates when the current level exceeds the preset stall level while operating at constant speed. When the load current decelerates below the preset level, it resumes acceleration. During acceleration, the operation will follow the stall protection settings for acceleration.		
	0100	Stall protection during deceleration	The inverter decelerates and keeps the DC link voltage below a certain level to prevent an over voltage fault trip during deceleration. As a result, deceleration times can be longer than the set time depending on the load.		
1000	Flux braking during deceleration	When using flux braking, deceleration time may be reduced because regenerative energy is expended at the motor.			
1100	Stall protection and flux braking during deceleration	Stall protection and flux braking operate together during deceleration to achieve the shortest and most stable deceleration performance.			

Code	Description
	
<p>Pr.51 Stall Freq 1 - Pr.58 Stall Level I4</p>	<p>Additional stall protection levels can be configured for different frequencies, based on the load type. As shown in the graph below, the stall level can be set above the base frequency. The lower and upper limits are set using numbers that correspond in ascending order. For example, the range for Stall Frequency 2 (Stall Freq 2) becomes the lower limit for Stall Frequency 1 (Stall Freq 1) and the upper limit for Stall Frequency 3 (Stall Freq 3).</p> 

Note

Stall protection and flux braking operate together only during deceleration. Turn on the third and fourth bits of Pr.50 (Stall Prevention) to achieve the shortest and most stable deceleration performance without triggering an overvoltage fault trip for loads with high inertia and short deceleration times. Do not use this function when frequent deceleration of the load is required, as the motor can overheat and may be damaged easily.

When you operating Brake resistor, the motor may vibrate under the Flux braking operation. In this case, please turn off the Flux braking (Pr.50).

⚠ Caution

- Use caution when decelerating while using stall protection as depending on the load, the deceleration time can take longer than the time set. Acceleration stops when stall protection operates during acceleration.
- When the motor is operating, Stall Level 1 applies and determines the operation of stall protection.

6.2 Inverter and Sequence Protection



6.2.1 Input/output Open-phase Protection

Open-phase protection is used to prevent overcurrent levels induced at the inverter inputs due to an open-phase within the input power supply. Open-phase output protection is also available. An open-phase at the connection between the motor and the inverter output may cause the motor to stall, due to a lack of torque.

Group	Code	Name	Setting	Setting Range	Unit
Pr	05	Input/output open-phase protection	00*	-	bit
	06	Input voltage range during open-phase	15	1–100 V	V


*Displayed as  on the Keypad.

Input and Output Open-phase Protection Setting Details

Code	Description		
Pr.05 Phase Loss Chk, Pr.06 IPO V Band	When open-phase protection is operating, input and output configurations are displayed differently. When the top LCD segment is on, the corresponding bit is set. When the bottom LCD segment is on, the corresponding bit is off.		
	Items	Bit Setting On Status	Bit setting Off Status
	Keypad		
	Configuration		Function
	bit2	bit1	
		✓	Output open-phase protection
	✓		Input open-phase protection
	Initial values by each product on input voltage range during open-phase are shown as below.		
	Items	Initial Value	Unit
	0.4 kW-2.2 kW (200 V/400 V)	15	V
4.0kW-7.5kW (200 V/400 V)	13	V	


6.2.2 External Trip Signal

Set one of the multi-function input terminals to 4 (External Trip) to allow the inverter to stop operation by using external signals.

Group	Code	Name	Setting		Setting Range	Unit
In	65~69	Px terminal setting options	4	External Trip	-	-
	87	Multi-function input terminal selection			-	bit

External Trip Signal Setting Details

Code	Description												
In.87 DI NC/NO Sel	<p>Selects the type of input contact. If the mark of the switch is at the bottom (0), it operates as an A contact (Normally Open). If the mark is at the top (1), it operates as a B contact (Normally Closed). The corresponding terminals for each bit are as follows:</p> <table border="1"> <thead> <tr> <th>Bit</th> <th>5</th> <th>4</th> <th>3</th> <th>2</th> <th>1</th> </tr> </thead> <tbody> <tr> <td>Terminals</td> <td>P5</td> <td>P4</td> <td>P3</td> <td>P2</td> <td>P1</td> </tr> </tbody> </table>	Bit	5	4	3	2	1	Terminals	P5	P4	P3	P2	P1
Bit	5	4	3	2	1								
Terminals	P5	P4	P3	P2	P1								



6.2.3 Inverter Overload Protection

When the inverter input current exceeds the rated current, a protective function is activated to prevent damages to the inverter based on inverse proportional characteristics.

Group	Code	Name	Setting	Setting Range	Unit
OU	31	Multi-function relay 1 item	6	IOL	-
	33	Multi-function relay 2 item			

Note

A warning signal output can be provided in advance by the multi-function output terminal before the inverter overload protection function (IOLT) operates. When the overcurrent time reaches 60 of the allowed overcurrent (150 %, 1 min), a warning signal output is provided (signal output at 150 %, 36 sec).

6.2.4 Speed Command Loss

When setting operation speed using an analog input at the terminal block, communication options, or the keypad, speed command loss setting can be used to select the inverter operation for situations when the speed command is lost due to the disconnection of signal cables.


Group	Code	Name	Setting		Setting Range	Unit
Pr	12	Motion at speed command loss	1	Free-Run	-	-
	13	Time to determine speed command loss	1.0		0.1–120	sec
	14	Operation frequency at speed command loss	0.00		Start frequency–Max. frequency	Hz
	15	Analog input loss decision level	0	Half of x1		-
OU	31	Multi-function relay 1 item	13	Lost Command	-	-
	33	Multi-function relay 2 item				

Speed Command Loss Setting Details

Code	Description		
Pr.12 Lost Cmd Mode	In situations when speed commands are lost, the inverter can be configured to operate in a specific mode:		
	Configuration	Function	
	0	None	The speed command immediately becomes the operation frequency without any protection function.
	1	Free-Run	The inverter blocks output. The motor performs in free-run condition.
	2	Dec	The motor decelerates and then stops at the time set at Pr.07 (Trip Dec Time).
	3	Hold Input	The inverter calculates the average input value for 10 seconds before the loss of the speed command and uses it as the speed reference.
	4	Hold Output	The inverter calculates the average output value for 10 seconds before the loss of the speed command and uses it as the speed reference.
	5	Lost Preset	The inverter operates at the frequency set at Pr. 14 (Lost Preset F).

Code	Description	
Pr.15 AI Lost Level, Pr.13 Lst Cmd Time	Configure the voltage and decision time for speed command loss when using analog input.	
	Configuration	Function
	0	Half of x1
1	Below of x1	The protective operation starts when the signal becomes smaller than the initial value of the analog input set by the speed command and it continues for the speed loss decision time set at Pr.13 (Lost Cmd Time). Codes In.08 and In.12 are used to set the standard values.
Pr.14 Lost Preset F	In situations where speed commands are lost, set the operation mode (Pr.12 Lost Cmd Mode) to 5 (Lost Preset). This operates the protection function and sets the frequency so that the operation can continue.	

Set Pr.15 (AI Lost Level) to 1 (Below x 1), Pr.12 (Lost Cmd Mode) to 2 (Dec), and Pr.13 (Lost Cmd Time) to 5 sec. Then it operates as follows:



Note

If speed command is lost while using communication options or the integrated RS-485 communication, the protection function operates after the command loss decision time set at Pr.13 (Lost Cmd Time) is passed.


6.2.5 Dynamic Braking (DB) Resistor Configuration

For G100 series, the braking resistor circuit is integrated inside the inverter.

Group	Code	Name	Setting	Setting Range	Unit
Pr	66	DB resistor warning level	10	0~30	%
OU	31	Multi-function relay 1 item	31	DB Warn %ED	-
	33	Multi-function relay 2 item			

Dynamic Braking Resistor Setting Details

Code	Description
Pr.66 DB Warn %ED	<p>Set the amount of braking resistor (%ED: Duty cycle) for use. Braking resistor configuration sets the rate at which the braking resistor operates for one operation cycle. The maximum time for continuous braking is 15 sec and the braking resistor signal is not output from the inverter after the 15 sec period has expired. The time until braking resistance is available again after continuous use of braking resistance for 15 seconds is calculated as below.</p> $T = \frac{(100\% - \%ED) \times 15}{\%ED} [s]$ <p>If the braking resistor usage rate is set to 0%, braking resistance can be used without usage rate restriction. However, precaution is necessary since there is risk of fire if the braking resistance usage is higher than the power consumption of braking resistance.</p> <p>An example of braking resistor set up is as follows:</p> $\%ED = \frac{T_{dec}}{T_{acc} + T_{steady} + T_{dec} + T_{stop}} \times 100\%$ <p>[Example 1]</p>

Code	Description
	$\%ED = \frac{T_{dec}}{T_{dec} + T_{steady1} + T_{acc} + T_{steady2}} \times 100\%$  <p>[Example 2]</p> <ul style="list-style-type: none"> • T_{acc}: Acceleration time to set frequency • T_{steady}: Constant speed operation time at set frequency • T_{dec}: Deceleration time to a frequency lower than constant speed operation or the stop time from constant speed operation frequency • T_{stop}: Stop time until operation resumes


⚠ Caution

Do not set the braking resistor to exceed the resistor’s power rating. If overloaded, it can overheat and cause a fire. When using a resistor with a heat sensor, the sensor output can be used as an external trip signal for the inverter’s multi-function input.

6.3 Under load Fault Trip and Warning

Group	Code	Name	Setting		Setting Range	Unit
Pr	04	Load level setting	0	Normal Duty	-	-
	25	Under load warning selection	1	Yes	0~1	-
	26	Under load warning time	10.0		0~600	sec
	27	Under load fault selection	1	Free-Run	-	-
	28	Under load fault time	30.0		0~600	sec
	29	Under load lower limit level	30		10~100	%
	30	Under load upper limit level	30		10~100	%

Under Load Trip and Warning Setting Details

Code	Description
Pr.27 UL Trip Sel	Sets the underload fault trip occurs. If set to 0 (None), does not detect the underload fault trip. If set to 1 (Free-Run), the output is blocked in an underload fault trip situation. If set to 2 (Dec), the motor decelerates and stops when an underload trip occurs.
Pr.25 UL Warn Sel	Sets the underload warning options. Set to 1 (Yes) and set the multi-function output terminals (at OU-31 and 33) to 7 (Underload). The warning signals are output when an underload condition arises.
Pr.26 UL Warn Time, Pr.28 UL Trip Time	The protection function operates when the underload level condition explained above is maintained for a set warning time or fault trip time. This function does not operate if energy-saving operation is activated at Ad-50 (E-Save Mode).
Pr.29 UL LF Level, Pr.30 UL BF Level	<ul style="list-style-type: none"> Setting Heavy Duty - Do not support Pr.29. - At Pr.30, the underload level is decided based on the motor's rated current. 

Code	Description
	<ul style="list-style-type: none"> Setting Normal Duty - At Pr.29, the under load rate is decided based on twice the operation frequency of the motor's rated slip speed (bA.12 Rated Slip). - At Pr.30, the under load rate is decided based on the base frequency set at dr.18 (Base Freq). An upper limit and lower limit is based on the inverter's rated current. <div style="text-align: center;"> <p>The graph plots Output current on the y-axis against Output frequency on the x-axis. A curve starts at a point labeled Pr.29 on the x-axis, which is also labeled 'Rated slip × 2'. The curve rises and levels off at a point labeled Pr.30 on the y-axis, which is also labeled 'Base frequency' on the x-axis. Dashed lines indicate the coordinates for Pr.29 and Pr.30.</p> </div>

6.3.1 Fan Fault Detection

Group	Code	Name	Setting	Setting Range	Unit
Pr	79	Cooling fan fault selection	0	Trip	
OU	31	Multi-function relay 1 item	8	FAN Warning	-
OU	33	Multi-function relay 2 item			

Fan Fault Detection Setting Details

Code	Description									
Pr.79 FAN Trip Mode	Set the cooling fan fault mode.									
	<table border="1" style="width: 100%;"> <thead> <tr> <th colspan="2">Configuration</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td style="text-align: center;">Trip</td> <td>The inverter output is blocked and the fan trip is displayed when a cooling fan error is detected.</td> </tr> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">Warning</td> <td>When OU.33 (Relay 2) and OU.31 (Relay 1) are set to 8 (FAN Warning), the fan error signal is output and the operation continues.</td> </tr> </tbody> </table>	Configuration		Function	0	Trip	The inverter output is blocked and the fan trip is displayed when a cooling fan error is detected.	1	Warning	When OU.33 (Relay 2) and OU.31 (Relay 1) are set to 8 (FAN Warning), the fan error signal is output and the operation continues.
	Configuration		Function							
0	Trip	The inverter output is blocked and the fan trip is displayed when a cooling fan error is detected.								
1	Warning	When OU.33 (Relay 2) and OU.31 (Relay 1) are set to 8 (FAN Warning), the fan error signal is output and the operation continues.								
OU.31 Relay 1, OU.33 Relay 2	When the code value is set to 8 (FAN Warning), the fan error signal is output and operation continues. However, when the inverter inside temperature rises above a certain level, output is blocked due to activation of overheat protection.									

6.3.2 Lifetime Diagnosis of Components

Lifetime Diagnosis for Fans

Enter the Pr-87(Fan exchange warning level) code (%). After the selected usage (%) is reached (out of 50,000 hours), the fan exchange warning message will appear in the multi-functional output or keypad.

The total fan usage level (%) appears at Pr-86. When exchanging fans, you may initialize the accumulated value to 0 by setting the CNF-75 (Initializing accumulated time for cooling fans) to 1.

Group	Code	Name	Setting	Setting Range	Unit
Pr	86	Accumulated percent of fan usage	0.0	0.0–6553.5	%
	87	Fan exchange warning Level	90.0	0.0–100.0	%
OU	31	Multi-function relay 1 item	38 FAN Exchange	-	-
	33	Multi-function relay 2 item			

6.3.3 Low Voltage Fault Trip

When inverter input power is lost and the internal DC link voltage drops below a certain voltage level, the inverter stops output and a low voltage trip occurs.

Group	Code	Name	Setting	Setting Range	Unit
Pr	81	Low voltage trip decision delay time	0.0	0~60	sec
OU	31	Multi-function relay 1 item	11 Low Voltage	-	-
	33	Multi-function relay 2 item			

Low Voltage Fault Trip Setting Details

Code	Description
Pr.81 LVT Delay	If the code value is set to 11 (Low Voltage), the inverter output is blocked first when the low voltage trip occurs and the trip is handled after a set time. You can generate a warning signal on the low voltage trip using the multi-function relay. The LVT Delay time is not applied on the warning signal.

6.3.4 Output Block by Multi-Function Terminal

When the multi-function input terminal is set as the output block signal terminal and the signal is input to the terminal, then the operation stops.

Group	Code	Name	Setting		Setting Range	Unit
In	65~69	Px terminal setting options	5	BX	-	-

Output Block by Multi-Function Terminal Setting Details

Code	Description
In.65-69 Px Define	When the operation of the multi-function input terminal is set to 5 (BX) and is turned on during operation, the inverter blocks the output and 'BX' is displayed on the keypad display. While 'BX' is displayed on the keypad screen, the inverter's operation information including the operation frequency and current at the time of BX signal can be monitored. The inverter resumes operation when the BX terminal turns off and operation command is input.

6.3.5 Trip Status Reset

Restart the inverter using the keypad or analog input terminal, to reset the trip status.


Group	Code	Name	Setting		Setting Range	Unit
In	65~69	Px terminal setting options	3	RST	-	-

Trip Status Reset Setting Details

Code	Description
In.65-69 Px Define	Press [Stop/Reset] key on the keypad or use the multi-function input terminal to restart the inverter. Set the multi-function input terminal to 3 (RST) and turn on the terminal to reset the trip status.

6.3.6 Inverter Diagnosis State

Check the diagnosis of components or devices for inverter to check if they need to be replaced.

Group	Code	Name	Setting	Setting Range		Unit
Pr	89	FAN replacement warning		Bit	00-01	Bit
				00	-	
				01	FAN Warning	

6.3.7 Operation Mode on Option Card Trip

Option card trips may occur when an option card is used with the inverter. Set the operation mode for the inverter when a communication error occurs between the option card and the inverter body, or when the option card is detached during operation.

Group	Code	Name	Setting	Setting Range	Unit	
Pr	80	Motion selection at option trip	0	None	0~3	-
			1	Free-Run		
			2	Dec		

Operation Mode on Option Trip Setting Details

Code	Description		
Pr.80 Opt Trip Mode	Configuration		
	Function		
	0	None	No operation.
	1	Free-Run	The inverter output is blocked and fault trip information is shown on the keypad.
2	Dec	The motor decelerates to the value set at Pr.07 (Trip Dec Time).	

6.3.8 No Motor Trip

If an operation command is run when the motor is disconnected from the inverter output terminal, a 'no motor trip' occurs and a protective operation is performed by the system.

Group	Code	Name	Setting	Setting Range	Unit	
Pr	31	No motor motion at detection	0	None	0~1	-
			1	Free-run		
	32	No motor detection current level	5		1~100	%
	33	No motor detection time	3.0		0.1~10	sec

No Motor Trip Setting Details

Code	Description
Pr.32 No Motor Level, Pr.33 No Motor Time	If the output current value [based on the rated current (bA.13)] is lower than the value set at Pr.32 (No Motor Level), and if this continues for the time set at Pr.33 (No Motor Time), a 'no motor trip' occurs.

⚠ Caution

If bA.07 (V/F Pattern) is set to 1 (Square), set Pr.32 (No Motor Level) to a value lower than the factory default. Otherwise, 'no motor trip' due to a lack of output current will result when the 'no motor trip' operation is set.

6.3.9 Low Voltage Trip 2

If you set the Pr-82(LV2 Selection) code to Yes (1), the trip notification is displayed when a low voltage trip occurs. . In this case, even if the voltage of the DC Link condenser is higher than the trip level, the LV2 trip will not be retrieved. To retrieve the trip, reset the inverter. The trip history will not be saved.

Group	Code	Name	Setting	Setting Range	Unit
Pr	82	LV2 Selection	Yes(1)	0/1	-

6.3.10 Inverter Pre-overheat Warning

This feature outputs a warning if the inverter temperature exceeds the temperature set by the user in Pr-77. The user can set up the operation for when the warning is generated before four types of overheating and output warning with the multi-function relay.

Group	Code	Name	Setting	Setting Range	Unit	
Pr	77	Pre-overheat warning temperature	90	10-110	°C	
	78	Pre-overheat warning operation setting	0:None	0	None	-
				1	Warning	
				2	Free-Run	
3	Dec					
OU	31, 33	Multi-function relay 1 item Multi-function relay 2 item	41:Pre Over Heat	0-44	-	

Pre-overheat Warning Operation Setting Details

Code	Description
Pr.77 Pre-overheat warning temperature	Set the pre-overheat warning temperature. Setting Range: 10-110[°C]
Pr.78 Pre-overheat warning operation setting	0: None → No pre-overheat warning operation 1: Warning → If the pre-overheat warning temperature is exceeded, warning message is displayed on the keypad and inverter will operate normally. 2: Free-Run → If the pre-overheat warning temperature is exceeded, a pre-overheat trip occurs and free-run will stop. 3: Dec → If the pre-overheat warning temperature is exceeded, a pre-overheat trip occurs and deceleration will stop.
OU.31, 33 multi-function relay 1, 2	38: Pre-overheat warning → Signal is output if a pre-overheat warning or trip occurs.

6.3.11 Torque Detection Protection Action

This feature outputs torque status to the multi-function relay if a motor overload or sudden underload occurs. This feature is activated when the multi-function relay (OU31, 33) is set to 43, 44.


Group	Code	Name	Setting		Setting Range	Unit
OU	31, 33	Multi-function relay 1 item	42	Prt Trq Det 1	0-43	-
		Multi-function relay 2 item	43	Prt Trq Det 2		
	67*	Torque detection 1 operation setting	0:None		0~8	-
	68*	Torque detection 1 level	100		0~200.0	%
	69*	Torque detection 1 delay time	0.1		0.0~10.0	sec
	70**	Torque detection 2 operation setting	0:None		0~8	-
	71**	Torque detection 2 level	100		0~200.0	%
72**	Torque detection 2 delay time	0.1		0.0~10.0	sec	

*Visible only when the multi-function relay (OU.31, 33) is set to 42 (Prt Trq Det 1).


**Visible only when the multi-function relay (OU.31, 33) is set to 43 (Prt Trq Det 2).

The over and under torque detection action operates as shown in the figure by having a hysteresis level of 10% compared to the motor's rated current.

Over Torque Detection Action



Under Torque Detection Action



The over and under torque detection level set as OU68, 71 parameters are set as the ratio on motor's rated current.

Torque Detection Operation Setting Details

Code	Description
OU67, 70 Torque detection operation setting	0: None → Torque detection is not operating. 1: OT CmdSpd Warn → Detects over torque and outputs warning only when the inverter output frequency is the same as the command frequency. 2: OT Warning → Detects over torque during the operation and outputs warning. 3: OT CmdSpdTrip → Detects over torque and generates a trip only when the inverter output frequency is the same as the command frequency. 4: OT Trip → Detects over torque during operation and generates a trip. 5: UT CmdSpd Warn → Detects under torque and outputs warning only when the inverter output frequency is the same as the command frequency. 6: OT Warning → Detects under torque during the operation and outputs warning. 7: UT CmdSpd Trip → Detects under torque and generates a trip only when the inverter output frequency is the same as the command frequency. 8: UT Trip → Detects under torque during operation and generates a trip.
OU.68, 71 Torque detection level	Sets the torque detection level of torque detection 1, 2. The set value is a % of the motor's rated current. The detection level must be higher than Ba.14 no load current value.
OU.69, 72 Torque detection delay time	Sets the delay time on torque detection 1, 2. When over or under torque is detected, a warning or trip is output after the torque detection delay time.

6.4 Fault/Warning List

The following list shows the types of faults and warnings that can occur while using the G100 inverter. Please refer to **6 Learning Protection Features** on page **167** for details about faults and warnings.

Category		Description
Major fault	Latch	Over current trip
		Over voltage trip
		External signal trip
		Temperature sensor trip
		ARM short current fault trip
		Option fault trip*
		Over heat fault trip
		Output open-phase fault trip
		Input open-phase fault trip
		Inverter overload trip
		Ground fault trip**
		Fan trip
		Motor over heat trip
		Pre-PID operation failure
		I/O board link trip
		External brake trip
		No motor trip
		Low voltage trip during operation
		Inverter pre-overheat trip
		Over torque 1 trip
		Under torque 1 trip
		Over torque 2 trip
		Under torque 2 trip
	Level type	Low voltage fault trip
		Emergency stop trip
		Command loss trip
	Fatal	External memory error
		Analog input error
		CPU Watch Dog fault trip

Category	Description
Minor fault	Motor overload trip
	Motor light load trip
Warning	Command loss fault trip warning
	Overload warning
	Under load warning
	Inverter overload warning
	Fan operation warning
	Braking resistor braking rate warning
	Rotor time constant tuning error
	Fan replacement warning
	Inverter pre-overheat warning
	Over torque 1 warning
	Under torque 1 warning
	Over torque 2 warning
	Under torque 2 warning

*Appears only when using the option board.

**Ground detection feature is provided only in 5.5-7.5kW products. 0.4-4.0kW products protect inverter with OVT/OCT/OC2 trip when grounding occurs.

7 RS-485 Communication Features


This section in the user manual explains how to control the inverter with a PLC or a computer over a long distance using the RS-485 communication features. To use the RS-485 communication features, connect the communication cables and set the communication parameters on the inverter. Refer to the communication protocols and parameters to configure and use the RS-485 communication features.

7.1 Communication Standards

Following the RS-485 communication standards, G100 products exchange data with a PLC and computer. The RS-485 communication standards support the Multi-drop Link System and offer an interface that is strongly resistant to noise. Please refer to the following table for details about the communication standards.

Items	Standard
Communication method/ Transmission type	RS-485/Bus type, Multi-drop Link System
Inverter type name	G100
Number of connected inverters/ Transmission distance	Maximum of 16 inverters / Maximum 1,200 m (recommended distance: within 700 m)
Recommended cable size	0.75mm ² , (18AWG), Shielded Type Twisted-Pair (STP) Wire
Installation type	Dedicated terminals (S+/S-) on the control terminal block Connected to the RJ-45 connector (no 1 pin S+, no 8 pin S-)
Power supply	Supplied by the inverter - insulated power source from the inverter's internal circuit
Communication speed	1,200/2,400/9,600/19,200/38,400/57,600/115,200 bps
Control procedure	Asynchronous communications system
Communication system	Half duplex system
Character system	Modbus-RTU: Binary / LS Bus: ASCII
Stop bit length	1-bit/2-bit
Frame error check	2 bytes
Parity check	None/Even/Odd

Connect the communication lines by referring to the illustration below.



Use 2Pair STP (Shielded twisted Pair) cable (using only no.1 pin S+, no.8 pin S-/ no.1 and no.8 pins are twisted types) and a RJ45 STP plug. Use a RJ45 coupler for connection between products and cable extension (Y type LAN coupler where STP can be mounted). (Use LAN standardized products for cables, plugs, and couplers: CAT5, CAT5e, CAT6.)


Note

- Communication cables must be installed by separating from the power cable.
- Use the RS-485 communication by selecting one from S+ or S- of the terminal block and S+ or S- of the RJ45 plug.

7.2 Communication System Configuration

In an RS-485 communication system, the PLC or computer is the master device and the inverter is the slave device. When using a computer as the master, the RS-232 converter must be integrated with the computer, so that it can communicate with the inverter through the RS-232/RS-485 converter. Specifications and performance of converters may vary depending on the manufacturer, but the basic functions are identical. Please refer to the converter manufacturer's user manual for details about features and specifications.

Connect the wires and configure the communication parameters on the inverter by referring to the following illustration of the communication system configuration.



7.2.1 Communication Line Connection

After checking that the power of the inverter is fully blocked, connect the RS-485 communication line to S+ or S-terminal of the control terminal or RJ45 connector (no.1 pin S+, no.8 pin S-) of the I/O board. The maximum number of inverters you can connect is 16. For communication lines, use shielded twisted pair (STP) cables.

The maximum length of the communication line is 1,200 meters, but it is recommended to use no more than 700 meters of communication line to ensure stable communication. Please use a repeater to enhance the communication speed when using a communication line longer than 1,200 meters or when using a large number of devices. A repeater is effective when smooth communication is not available due to noise interference.

7.2.2 Setting Communication Parameters

Before proceeding with setting communication configurations, make sure that the communication lines are connected properly. Turn on the inverter and set the communication parameters.

Group	Code	Name	Setting	Setting Range	Unit
CM	01	Built-in communication inverter ID	1	1~250	-
	02	Built-in communication protocol	0 ModBus RTU	0, 2	-
	03	Built-in communication speed	3 9600 bps	0~7	-
	04	Built-in communication frame setting	0 D8/PN/S1	0~3	-
	05	Transmission delay after reception	5	0~1000	ms

Communication Parameters Setting Details

Code	Description																		
CM.01 Int485 St ID	Set the inverter station ID between 1 and 250.																		
CM.02 Int485 Proto	Select one of the two built-in protocols: Modbus-RTU or LS INV 485.																		
	<table border="1"> <thead> <tr> <th>Configuration</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>0 Modbus-RTU</td> <td>Modbus-RTU compatible protocol</td> </tr> <tr> <td>2 LS INV 485</td> <td>Dedicated protocol for the LS inverter</td> </tr> </tbody> </table>	Configuration	Function	0 Modbus-RTU	Modbus-RTU compatible protocol	2 LS INV 485	Dedicated protocol for the LS inverter												
	Configuration	Function																	
0 Modbus-RTU	Modbus-RTU compatible protocol																		
2 LS INV 485	Dedicated protocol for the LS inverter																		
CM.03 Int485 BaudR	Set a communication setting speed up to 115,200 bps.																		
CM.03 Int485 BaudR	<table border="1"> <thead> <tr> <th>Configuration</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1200bps</td> </tr> <tr> <td>1</td> <td>2400bps</td> </tr> <tr> <td>2</td> <td>4800bps</td> </tr> <tr> <td>3</td> <td>9600bps</td> </tr> <tr> <td>4</td> <td>19200bps</td> </tr> <tr> <td>5</td> <td>38400bps</td> </tr> <tr> <td>6</td> <td>56Kbps</td> </tr> <tr> <td>7</td> <td>115 Kbps(115,200 bps)</td> </tr> </tbody> </table>	Configuration	Function	0	1200bps	1	2400bps	2	4800bps	3	9600bps	4	19200bps	5	38400bps	6	56Kbps	7	115 Kbps(115,200 bps)
	Configuration	Function																	
	0	1200bps																	
	1	2400bps																	
	2	4800bps																	
	3	9600bps																	
	4	19200bps																	
	5	38400bps																	
	6	56Kbps																	
7	115 Kbps(115,200 bps)																		

Code	Description																
CM.04 Int485 Mode	Set a communication configuration. Set the data length, parity check method, and the number of stop bits.																
	<table border="1"> <thead> <tr> <th colspan="2">Configuration</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>D8/PN/S1</td> <td>8-bit data / no parity check / 1 stop bit</td> </tr> <tr> <td>1</td> <td>D8/PN/S2</td> <td>8-bit data / no parity check / 2 stop bit</td> </tr> <tr> <td>2</td> <td>D8/PE/S1</td> <td>8-bit data / even parity / 1 stop bit</td> </tr> <tr> <td>3</td> <td>D8/PO/S1</td> <td>8-bit data / odd parity / 1 stop bit</td> </tr> </tbody> </table>		Configuration		Function	0	D8/PN/S1	8-bit data / no parity check / 1 stop bit	1	D8/PN/S2	8-bit data / no parity check / 2 stop bit	2	D8/PE/S1	8-bit data / even parity / 1 stop bit	3	D8/PO/S1	8-bit data / odd parity / 1 stop bit
	Configuration		Function														
	0	D8/PN/S1	8-bit data / no parity check / 1 stop bit														
	1	D8/PN/S2	8-bit data / no parity check / 2 stop bit														
2	D8/PE/S1	8-bit data / even parity / 1 stop bit															
3	D8/PO/S1	8-bit data / odd parity / 1 stop bit															
CM.05 Resp Delay	Set the response time for the slave (inverter) to react to the request from the master. Response time is used in a system where the slave device response is too fast for the master device to process. Set this code to an appropriate value for smooth master-slave communication.																
	<p>The diagram illustrates the timing between a Master and a Slave. The Master sends two 'Request' pulses. For each request, the Slave sends a 'Response' pulse. A horizontal double-headed arrow labeled 'CM.5 Resp Delay' indicates the time interval between the rising edge of the 'Request' pulse and the rising edge of the 'Response' pulse. This delay is shown for both communication cycles.</p>																

7.2.3 Setting Operation Command and Frequency

To select the built-in RS-485 communication as the source of command, set the Frq code to 6 (Int485) on the keypad (basic keypad with 7-segment display). On an LCD keypad, set the DRV code to 3 (Int485). Then, set common area parameters for the operation command and frequency via communication.

Group	Code	Name	Setting	Setting Range	Unit	
Run	drv	Command Source	3	Int 485	0~4	-
	Frq	Frequency reference source	6	Int 485	0~8	-

7.2.4 Command Loss Protective Operation

Configure the command loss decision standards and protective operations run when a communication problem lasts for a specified period of time.

Command Loss Protective Operation Setting Details

Code	Description															
Pr.12 Lost Cmd Mode, Pr.13 Lost Cmd Time	Select the operation to run when a communication error has occurred and lasted exceeding the time set at Pr. 13.															
	<table border="1"> <thead> <tr> <th>Configuration</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>None</td> </tr> <tr> <td>1</td> <td>Free-Run</td> </tr> <tr> <td>2</td> <td>Dec</td> </tr> <tr> <td>3</td> <td>Hold Input</td> </tr> <tr> <td>4</td> <td>Hold Output</td> </tr> <tr> <td>5</td> <td>Lost Preset</td> </tr> </tbody> </table>		Configuration	Function	0	None	1	Free-Run	2	Dec	3	Hold Input	4	Hold Output	5	Lost Preset
	Configuration	Function														
	0	None														
	1	Free-Run														
	2	Dec														
	3	Hold Input														
4	Hold Output															
5	Lost Preset															
0	None	The speed command immediately becomes the operation frequency without any protection function.														
1	Free-Run	The inverter blocks output. The motor performs in free-run condition.														
2	Dec	The motor decelerates and then stops at the time set at Pr.07 (Trip Dec Time).														
3	Hold Input	The inverter calculates the average input value for 10 seconds before the loss of the speed command and uses it as the speed reference.														
4	Hold Output	The inverter calculates the average output value for 10 seconds before the loss of the speed command and uses it as the speed reference.														
5	Lost Preset	The inverter operates at the frequency set at Pr. 14 (Lost Preset F).														

7.2.5 Setting Virtual Multi-Function Input

Multi-function input can be controlled using a communication address (0h0385). Set codes CM.70–77 to the functions to operate, and then set the BIT relevant to the function to 1 at 0h0322 to operate it. Virtual multi-function operates independently from In.65–69 analog multi-function inputs and cannot be set redundantly. Virtual multi-function input can be monitored using CM.86 (Virt DI Status). Before you configure the virtual multi-function inputs, set the DRV code according to the command source.

Group	Code	Name	Setting		Setting Range	Unit
CM	70–77	Communication multi-function input x	0	None	0–49	-
	86	Communication multi-function input monitoring	-	-	-	-

Example: When sending an Fx command by controlling virtual multi-function input in the common area via Int485, set CM.70 to FX and set address 0h0322 to 0h0001. Then, assign a 0h0001 value to the communication address 0h0322 to operate the forward direction operation (Fx) feature.

Note

The following are values and functions that are applied to address 0h0322:

Setting	Function
0h0001	Forward operation (Fx)
0h0003	Reverse operation (Rx)
0h0000	Stop

7.2.6 Saving Parameters Defined by Communication

If you turn off the inverter after setting the common area parameters or keypad parameters via communication and operate the inverter, the changes are lost and the values changed via communication revert to the previous setting values when you turn on the inverter.

Setting address 0h03E0 to 0 and then setting it again to 1 via communication allows the existing parameter settings to be saved. However, setting address 0h03E0 to 1 and then setting it to 0 does not carry out the same function.

7.2.7 Total Memory Map for Communication

Communication Area	Memory Map	Description
Communication common compatible area	0h0000~0h00FF	iS5, iP5A, iV5, iG5A compatible area
Parameter registration type area	0h0100~0h01FF	Areas registered at CM.31–38 and CM.51–58
G100 communication common area	0h0300~0h037F	Inverter monitoring area
	0h0380~0h03DF	Inverter control area
	0h03E0~0h03FF	Inverter memory control area
	0h0400~0h0FFF	Reserved
	0h1100	dr Group
	0h1200	bA Group
	0h1300	Ad Group
	0h1400	Cn Group
	0h1500	In Group
	0h1600	OU Group
	0h1700	CM Group
	0h1800	AP Group
	0h1B00	Pr Group
0h1C00	M2 Group	

7.2.8 Parameter Group for Data Transmission

By defining a parameter group for data transmission, the communication addresses registered in the communication function group (CM) can be used in communication. Parameter group for data transmission may be defined to transmit multiple parameters at once, into the communication frame.

Group	Code	Name	Setting	Setting Range	Unit
CM	31-38	Output communication address x	-	0000-FFFF	Hex
	51-58	Input communication address x	-	0000-FFFF	Hex

Currently Registered CM Group Parameter

Comm. Address	parameter	Assigned Content by Bit
0h0100~0h0107	Status Parameter-1 – Status Parameter-8	Parameter communication code value registered at CM.31-38 (Read-only)
0h0110~0h0117	Control Parameter-1 – Control Parameter-8	Parameter communication code value registered at CM.51-58 (Read/Write access)

Note

When registering control parameters, register the operation speed (0h0005, 0h0380, 0h0381) and operation command (0h0006, 0h0382) parameters at the end of a parameter control frame. The operation speed and operation command must be registered to the highest number of the parameter control-h (Para Control-h).

For example, when the parameter control frame has 5 parameter control items (Para Control - x), register the operation speed at Para Control-4 and the operation command to Para Control-5.

7.3 Communication Protocol

The built-in RS-485 communication supports LS INV 485 and Modbus-RTU protocols.

7.3.1 LS INV 485 Protocol

The slave device (inverter) responds to read and write requests from the master device (PLC or PC). The basic types of protocol are as below.

Request

ENQ	Station ID	CMD	Data	SUM	EOT
1 byte	2 bytes	1 byte	n bytes	2 bytes	1 byte

Normal Response

ACK	Station ID	CMD	Data	SUM	EOT
1 byte	2 bytes	1 byte	n x 4 bytes	2 bytes	1 byte

Error Response

NAK	Station ID	CMD	error code	SUM	EOT
1 byte	2 bytes	1 byte	2 bytes	2 bytes	1 byte

- A request starts with ENQ and ends with EOT.
- A normal response starts with ACK and ends with EOT.
- An error response starts with NAK and ends with EOT.
- A station ID indicates the inverter number and is displayed as a two-byte ASCII-HEX string that uses characters 0-9 and A-F. ASCII-HEX is a hexadecimal notation composed of numbers between 0-9 and letters between A-F.
- CMD: Uses uppercase characters (returns an IF error if lowercase characters are encountered)—please refer to the following table.

Character	ASCII-HEX	Command
'R'	52h	Read
'W'	57h	Write
'X'	58h	Request monitor registration
'Y'	59h	Perform monitor registration

- Data will be displayed as ASCII-HEX. (For example, if data value is 3000: 3000 → '0"B"B"8'h → 30h 42h 42h 38h).
- Error code: ASCII-HEX (refer to **7.3.1.4 Error Code** on page **204**)
- Transmission/reception buffer size: Transmission=39 bytes, Reception=44 bytes
- Monitor registration buffer: 8 Words
- SUM: Checks communication errors via sum.
SUM=a total of the lower 8 bits values for station ID, command and data (Station ID+CMD+Data) in ASCII-HEX.

For example, a command to read 1 address from address 3000:

SUM='0'+ '1'+ 'R'+ '3'+ '0'+ '0'+ '0'+ '1' = 30h+31h+52h+33h+30h+30h+30h+31h = 1A7h
(the control value is not included: ENQ, ACK, NAK, etc.).

ENQ	Station ID	CMD	Address	Number of Addresses	SUM	EOT
05h	'01'	'R'	'3000'	'1'	'A7'	04h
1 byte	2 bytes	1 byte	4 bytes	1 byte	2 bytes	1 byte

Note

Broadcasting

Broadcasting sends commands to all inverters connected to the network simultaneously. When commands are sent from station ID 255, each inverter acts on the command regardless of the station ID. However, no response is issued for commands transmitted by broadcasting.

7.3.1.1 Detailed Read Protocol

Read Request: Reads successive n words from address XXXX.

ENQ	Station ID	CMD	Address	Number of Addresses	SUM	EOT
05h	'01'-'FA'	'R'	'XXXX'	'1'-'8' = n	'XX'	04h
1 byte	2 bytes	1 byte	4 bytes	1 byte	2 bytes	1 byte

Total bytes=12. Characters are displayed inside single quotation marks(').

Read Normal Response

ACK	Station ID	CMD	Data	SUM	EOT
06h	'01'-'FA'	'R'	'XXXX'	'XX'	04h
1 byte	2 bytes	1 byte	n x 4 bytes	2 bytes	1 byte

Total bytes= (7 x n x 4): a maximum of 39

Read Error Response

NAK	Station ID	CMD	error code	SUM	EOT
15h	'01'-'FA'	'R'	'**'	'XX'	04h
1 byte	2 bytes	1 byte	2 bytes	2 bytes	1 byte

Total bytes=9

7.3.1.2 Detailed Write Protocol

Write Request

ENQ	Station ID	CMD	Address	Number of Addresses	Data	SUM	EOT
05h	'01'-'FA'	'W'	'XXXX'	'1'-'8' = n	'XXXX...'	'XX'	04h
1 byte	2 bytes	1 byte	4 bytes	1 byte	n x 4 bytes	2 bytes	1 byte

Total bytes= (12 x n x 4): a maximum of 44

Write Normal Response

ACK	Station ID	CMD	Data	SUM	EOT
06h	'01'-'FA'	'W'	'XXXX...'	'XX'	04h
1 byte	2 bytes	1 byte	n x 4 bytes	2 bytes	1 byte

Total bytes= (7 x n x 4): a maximum of 39

Write Error Response

NAK	Station ID	CMD	error code	SUM	EOT
15h	'01'-'FA'	'W'	'**'	'XX'	04h
1 byte	2 bytes	1 byte	2 bytes	2 bytes	1 byte

Total bytes=9

7.3.1.3 Monitor Registration Detailed Protocol

Monitor registration request is made to designate the type of data that requires continuous monitoring and periodic updating.

Monitor Registration Request: Registration requests for n addresses (where n refers to the number of addresses. The addresses do not have to be contiguous.)

ENQ	Station ID	CMD	Number of Addresses	Address	SUM	EOT
05h	'01'-'FA'	'X'	'1'-'8'=n	'XXXX...'	'XX'	04h
1 byte	2 bytes	1 byte	1 byte	n x 4 bytes	2 bytes	1 byte

Total bytes= (8 x n x 4): a maximum of 40

Monitor Registration Normal Response

ACK	Station ID	CMD	SUM	EOT
06h	'01'-'FA'	'X'	'XX'	04h
1 byte	2 bytes	1 byte	2 bytes	1 byte

Total bytes=7

Monitor Registration Error Response

NAK	Station ID	CMD	error code	SUM	EOT
15h	'01'-'FA'	'X'	'**'	'XX'	04h
1 byte	2 bytes	1 byte	2 bytes	2 bytes	1 byte

Total bytes=9

Monitor Registration Perform Request: A data read request for a registered address, received from a monitor registration request

ENQ	Station ID	CMD	SUM	EOT
05h	'01'-'FA'	'Y'	'XX'	04h
1 byte	2 bytes	1 byte	2 bytes	1 byte

Total bytes=7

Monitor Registration Execution Normal Response

ACK	Station ID	CMD	Data	SUM	EOT
06h	'01'-'FA'	'Y'	'XXXX...'	'XX'	04h
1 byte	2 bytes	1 byte	n x 4 bytes	2 bytes	1 byte

Total bytes= (7 x n x 4): a maximum of 39

Monitor Registration Execution Error Response

NAK	Station ID	CMD	error code	SUM	EOT
15h	'01'-'FA'	'Y'	'**'	'XX'	04h
1 byte	2 bytes	1 byte	2 bytes	2 bytes	1 byte

Total bytes=9

7.3.1.4 Error Code

Items	Abbreviation	Description
ILLEGAL FUNCTION	IF	The requested function cannot be performed by a slave The corresponding function does not exist.
ILLEGAL DATA ADDRESS	IA	The received parameter address is invalid at the slave.
ILLEGAL DATA VALUE	ID	The received parameter data is invalid at the slave.
WRITE MODE ERROR	WM	Tried writing (W) to a parameter that does not allow writing (read-only parameters, or when writing is prohibited during operation)
FRAME ERROR	FE	The frame size does not match.

7.3.1.5 ASCII Code

Character	Hex	Character	Hex	Character	Hex
A	41	q	71	@	40
B	42	r	72	[5B
C	43	s	73	\	5C
D	44	t	74]	5D
E	45	u	75		5E
F	46	v	76		5F
G	47	w	77		60
H	48	x	78	{	7B
I	49	y	79		7C
J	4A	z	7A	}	7D
K	4B	0	30	-	7E
L	4C	1	31	BEL	07
M	4D	2	32	BS	08
N	4E	3	33	CAN	18
O	4F	4	34	CR	0D
P	50	5	35	DC1	11
Q	51	6	36	DC2	12
R	52	7	37	DC3	13
S	53	8	38	DC4	14
T	54	9	39	DEL	7F
U	55	space	20	DLE	10
V	56	!	21	EM	19
W	57	"	22	ACK	06
X	58	#	23	ENQ	05
Y	59	\$	24	EOT	04
Z	5A	%	25	ESC	1B
a	61	&	26	ETB	17
b	62	'	27	ETX	03
c	63	(28	FF	0C
d	64)	29	FS	1C
e	65	*	2A	GS	1D
f	66	+	2B	HT	09
g	67	,	2C	LF	0A
h	68	-	2D	NAK	15
i	69	.	2E	NUL	00
j	6A	/	2F	RS	1E
k	6B	:	3A	S1	0F
l	6C	;	3B	SO	0E
m	6D	<	3C	SOH	01
n	6E	=	3D	STX	02
o	6F	>	3E	SUB	1A
p	70	?	3F	SYN	16
				US	1F
				VT	0B

7.3.2 Modbus-RTU Protocol

7.3.2.1 Function Code and Protocol (Unit: byte)

In the following section, station ID is the value set at CM.01 (Int485 St ID), and starting address is the communication address. (starting address size is in bytes). For more information about communication addresses, refer to **7.4 Compatible Common Area Parameter** on page 209.

Function Code #03: Read Holding Register

Query Field Name	Response Field Name
Station ID	Station ID
Function(0x03)	Function (0x03)
Starting Address Hi	Byte Count
Starting Address Lo	Data Hi
# of Points Hi	Data Lo
# of Points Lo	...
CRC Lo	...
CRC Hi	Data Hi
	Data Lo
	CRC Lo
	CRC Hi

number of Points

Function Code #04: Read Input Register

Query Field Name	Response Field Name
Station ID	Station ID
Function(0x04)	Function (0x04)
Starting Address Hi	Byte Count
Starting Address Lo	Data Hi
# of Points Hi	Data Lo
# of Points Lo	...
CRC Lo	...
CRC Hi	Data Hi
	Data Lo
	CRC Lo
	CRC Hi

number of Points

Function Code #06: Preset Single Register

Query Field Name	Response Field Name
Station ID	Station ID
Function (0x06)	Function (0x06)
Starting Address Hi	Register Address Hi
Register Address Lo	Register Address Lo
Preset Data Hi	Preset Data Hi
Preset Data Lo	Preset Data Lo
CRC Lo	CRC Lo
CRC Hi	CRC Hi

Function Code #16 (hex 0h10): Preset Multiple Register

Query Field Name	Response Field Name
Station ID	Station ID
Function (0x10)	Function (0x10)
Starting Address Hi	Starting Address Hi
Starting Address Lo	Starting Address Lo
# of Register Hi	# of Register Hi
# of Register Lo	# of Register Lo
Byte Count	CRC Lo
Data Hi	CRC Hi
Data Lo	
...	
...	
Data Hi	
Data Lo	
CRC Lo	
CRC Hi	

number of Points

Exception Code

Code
01: ILLEGAL FUNCTION
02: ILLEGAL DATA ADDRESS
03: ILLEGAL DATA VALUE
06: SLAVE DEVICE BUSY

Response

Field Name
Station ID
Function*
Exception Code
CRC Lo
CRC Hi

* The function value uses the top level bit for all query values.

Example of Modbus-RTU Communication in Use

When the Acc time (Communication address 0x1103) is changed to 5.0 sec and the Dec time (Communication address 0x1104) is changed to 10.0 sec.

Frame Transmission from Master to Slave (Request)

Items	Station ID	Function	Starting Address	# of Register	Byte Count	Data 1	Data 2	CRC
Hex	0x01	0x10	0x1102	0x0002	0x04	0x0032	0x0064	0x1202
Description	CM.01 Int485 St ID	Preset Multiple Register	Starting Address -1 (0x1103-1)	-	-	50 (ACC time 5.0sec)	100 (DEC time 10.0sec)	-

Frame Transmission from Slave to Master (Response)

Items	Station ID	Function	Starting Address	# of Register	CRC
Hex	0x01	0x10	0x1102	0x0002	0xE534
Description	CM.01 Int485 St ID	Preset Multiple Register	Starting Address -1 (0x1103-1)	-	-

7.4 Compatible Common Area Parameter

The following are common area parameters compatible with iS5, iP5A, iV5, and iG5A.

Comm. Address	parameter	Scale	Unit	R/W	Assigned Content by Bit		
0h0000	Inverter model	-	-	R	16: G100		
0h0001	Inverter capacity	-	-	R	0: 0.75kW, 1: 1.5kW, 2: 2.2kW, 3: 3.7kW, 4: 5.5kW, 5: 7.5kW, 6: 11kW, 7: 15kW, 8: 18.5kW, 9: 22kW 256 : 0.4kW, 257 :1.1kW, 258:3.0kW 259: 4.0kW		
0h0002	Inverter input voltage	-	-	R	0: 220V level, 1: 440V level		
0h0003	Version	-	-	R	(Ex) 0h0100: Version 1.00 0h0101: Version 1.01		
0h0004	Reserved	-	-	R/W	-		
0h0005	Target frequency	0.01	Hz	R/W	-		
0h0006	Operation command (option)	-	-	R	B15	Reserved	
					B14	0: Keypad Freq	
					B13	1: Keypad Torq	
					B12	2-16 Terminal block	
					B11	multi-step speed	
					B10	17: Up, 18: Down	
					B9	19: STEADY	
						22: V1, 24: V0, 25: I2	
						26: Reserved	
						27: Built-in 485	
					B8	28: Communication option	
						30: JOG, 31: PID	
						B8	0: Keypad
						B7	1: Fx/Rx-1
B6	2: Fx/Rx-2						
	3: Built-in 485						
R/W	4: Communication option						
	B5	Reserved					
	B4	Emergency stop					
	B3	W: W: Trip initialization (0 →1)					
		R: Trip status					
	B2	Reverse operation (R)					
	B1	Forward operation (F)					
	B0	Stop (S)					
0h0007	Acceleration time	0.1	sec	R/W	-		

Comm. Address	parameter	Scale	Unit	R/W	Assigned Content by Bit	
0h0008	Deceleration time	0.1	sec	R/W	-	
0h0009	Output current	0.1	A	R	-	
0h000A	Output frequency	0.01	Hz	R	-	
0h000B	Output voltage	1	V	R	-	
0h000C	DC link voltage	1	V	R	-	
0h000D	Output power	0.1	kW	R	-	
0h000E	Operation status	-	-	R	B15	Reserved
					B14	1: Frequency command source by communication (built-in, option)
					B13	1: Operation command source by communication (built-in, option)
					B12	Reverse operation command
					B11	Forward operation command
					B10	Brake release signal
					B9	Jog mode
					B8	Drive stopped.
					B7	DC Braking
					B6	Speed reached
					B5	Decelerating
					B4	Accelerating
					B3	Fault Trip - operates according to OU.30 setting
B2	Operating in reverse direction					
B1	Operating in forward direction					
B0	Stopped					
0h000F	Fault trip information	-	-	R	B15	Reserved
					B14	Reserved
					B13	Reserved
					B12	Reserved
					B11	Reserved
					B10	H/W-Diag
					B9	Reserved
					B8	Reserved
B7	Reserved					
B6	Reserved					

Comm. Address	parameter	Scale	Unit	R/W	Assigned Content by Bit
					B5 Reserved
					B4 Reserved
					B3 Level Type trip
					B2 Reserved
					B1 Reserved
					B0 Latch Type trip
0h0010	Input terminal information	-	-	R	B15–B5 Reserved
					B4 P5
					B3 P4
					B2 P3
					B1 P2
					B0 P1
0h0011	Output terminal information	-	-	R	B15 Reserved
					B14 Reserved
					B13 Reserved
					B12 Reserved
					B11 Reserved
					B10 Reserved
					B9 Reserved
					B8 Reserved
					B7 Reserved
					B6 Reserved
					B5 Reserved
					B4 Reserved
					B3 Reserved
					B2 Reserved
					B1 Relay 2
					B0 Relay 1
0h0012	V1	0.01	%	R	V1 voltage input
0h0013	V0	0.01	%	R	V2 input voltage
0h0014	I2	0.01	%	R	I2 current input
0h0015	Motor rotation speed	1	Rpm	R	Displays existing motor rotation speed
0h0016 - 0h0019	Reserved	-	-	-	-
0h001A	Select Hz/rpm	-	-	R	0: Hz, 1: Rpm
0h001B	Display the number of poles for the selected motor	-	-	R	Display the number of poles for the selected motor

7.5 G100 Expansion Common Area Parameter

7.5.1 Monitoring Area Parameter (Read Only)

Comm. Address	parameter	Scale	Unit	Assigned Content by Bit
0h0300	Inverter model	-	-	16: G100
0h0301	Inverter capacity	-	-	0.4kW : 1900h, 0.75kW: 3200h 1.1kW: 4011h, 1.5kW: 4015h 2.2kW: 4022h, 3.0kW: 4030h 3.7kW: 4037h, 4.0kW: 4040h 5.5kW: 4055h, 7.5kW: 4075h 11kW: 40B0h, 15kW: 40F0h 18.5kW: 4125h, 22kW: 4160h
0h0302	Inverter input voltage/power (Single phase, 3-phase)/cooling method	-	-	100 V single phase self cooling: 0120h 200 V 3-phase forced cooling: 0231h 100 V single phase forced cooling: 0121h 400V single phase self cooling: 0420h 200V single phase self cooling: 0220h 400 V 3-phase self cooling: 0430h 200V 3-phase self cooling: 0230h 400V single phase forced cooling: 0421h 200V single phase forced cooling: 0221h 400V 3-phase forced cooling: 0431h
0h0303	Inverter S/W version	-	-	(Ex) 0h0100: Version 1.00 0h0101: Version 1.01
0h0304	Reserved	-	-	-
0h0305	Inverter operation state	-	-	B15 : 0: Normal state B14 : 4: Warning occurred B13 : 8: Fault occurred [operates according to Pr. 30 (Trip Out Mode) setting] B12 : B11 - : B8 : B7 : 1: Speed searching 2: Accelerating B6 : 3: At constant speed B5 : 4: Decelerating 5: Decelerating to stop B4 : 6: H/W OCS 7: S/W OCS 8: Dwell operating

Comm. Address	parameter	Scale	Unit	Assigned Content by Bit		
				B3	0: Stopped	
				B2	1: Operating in forward direction	
				B1	2: Operating in reverse direction	
				B0	3: DC operating (0 speed control)	
0h0306	Inverter operation frequency command source	-	-	B15	Operation command source 0: Keypad 1: Communication option 2: - 3: Built-in 485 4: Terminal block	
				B14		
				B13		
				B12		
				B11		
				B10		
				B9		
				B8		
				B7		Frequency command source
				B6		0: Keypad speed
				B5		1: Keypad torque
				B4		2-4: Up/Down operation speed
				B3		5: V1, 7: V0, 8: I2
				B2		9: -
B1	10: Built-in 485 11: Communication option 12: -					
B0	13: Jog, 14: PID 25-39: Multi-step speed frequency					
0h0307-0h30F	Reserved	-	-	-	-	
0h0310	Output current	0.1	A	-	-	
0h0311	Output frequency	0.01	Hz	-	-	
0h0312	Output rpm	0	Rpm	-	-	
0h0313	Motor feedback speed	0	Rpm	-32768Rpm-32767Rpm(directional)	-	
0h0314	Output voltage	1	V	-	-	
0h0315	DC link voltage	1	V	-	-	
0h0316	Output power	0.1	kW	-	-	
0h0317	Output torque	0.1	%	-	-	
0h0318	PID reference	0.1	%	-	-	
0h0319	PID feedback	0.1	%	-	-	
0h031A	Display the number of poles for the 1 st motor	-	-	-	Displays the number of poles for the first motor	
0h031B	Display the number of poles for the 2 nd motor	-	-	-	Displays the number of poles for the 2nd motor	
0h031C	Display the number of poles for the selected motor	-	-	-	Display the number of poles for the selected motor	

RS-485 Communication Features

Comm. Address	parameter	Scale	Unit	Assigned Content by Bit	
0h031D	Select Hz/rpm	-	-	0: Hz, 1: Rpm	
0h031E - 0h031F	Reserved	-	-	-	
0h0320	Digital input information			B15	Reserved
				-	-
				B5	Reserved
				B4	P5(I/O board)
				B3	P4(I/O board)
				B2	P3(I/O board)
				B1	P2(I/O board)
0h0321	Digital output information			B0	P1(I/O board)
				B15	Reserved
				-	Reserved
				B4	Reserved
				B3	Reserved
				B2	Reserved
0h0322	Virtual digital input information			B1	Relay 2
				B0	Relay 1
				B15	Reserved
				-	Reserved
				B8	Reserved
				B7	Virtual DI 8(CM.77)
				B6	Virtual DI 7(CM.76)
				B5	Virtual DI 6(CM.75)
				B4	Virtual DI 5(CM.74)
B3	Virtual DI 4(CM.73)				
0h0323	Display the selected motor			B2	Virtual DI 3(CM.72)
				B1	Virtual DI 2(CM.71)
0h0324	AI1	0.01	%	Analog input V1 (I/O board)	
0h0325	Reserved	0.01	%	-	
0h0326	AI3	0.01	%	Analog input V2 (I/O board)	
0h0327	AI4	0.01	%	Analog input I2 (I/O board)	
0h0328	AO1	0.01	%	Analog output 1 (I/O board)	
0h0329	AO2	0.01	%	Analog output 2 (I/O board)	
0h032A	AO3	0.01	%	Reserved	
0h032B	AO4	0.01	%	Reserved	
0h032C	Reserved	-	-	-	
0h032D	Inverter module temperature	1	°C	-	
0h032E	Inverter power consumption	1	kWh	-	

Comm. Address	parameter	Scale	Unit	Assigned Content by Bit	
0h032F	Inverter power consumption	1	MWh	-	
0h0330	Latch type trip information - 1	-	-	B15	Fuse Open Trip
				B14	Over Heat Trip
				B13	Arm Short
				B12	External Trip
				B11	Overvoltage Trip
				B10	Overcurrent Trip
				B9	NTC Trip
				B8	Reserved
				B7	Reserved
				B6	Input imaging trip
				B5	Output image trip
				B4	Ground Fault Trip
				B3	E-Thermal Trip
				B2	Inverter Overload Trip
				B1	Underload Trip
B0	Overload Trip				
0h0331	Latch type trip information - 2	-	-	B15	Reserved
				B14	Pre Over Heat Trip
				B13	Reserved
				B12	Reserved
				B11	Reserved
				B10	Bad option card
				B9	No motor trip
				B8	External brake trip
				B7	Bad contact at basic I/O board
				B6	Pre PID Fail
				B5	Reserved
				B4	Reserved
				B3	FAN Trip
				B2	Reserved
				B1	Reserved
B0	Reserved				
0h0332	Level type trip information	-	-	B15	Reserved
				-	-
				B8	Reserved
				B7	Reserved
				B6	Reserved
				B5	Reserved
				B4	Reserved
				B3	Keypad Lost Command
B2	Lost Command				
B1	LV				

Comm. Address	parameter	Scale	Unit	Assigned Content by Bit	
				B0	BX
0h0333	H/W Diagnosis Trip information	-	-	B15	Reserved
				-	Reserved
				B6	Reserved
				B5	QueueFull
				B4	Reserved
				B3	Watchdog-2 error
				B2	Watchdog-1 error
				B1	EEPROM error
				B0	ADC error
0h0334	Warning information	-	-	B15	Reserved
				-	Reserved
				B10	Reserved
				B9	Auto Tuning failed
				B8	Keypad lost
				B7	Encoder disconnection
				B6	Wrong installation of encoder
				B5	DB
				B4	FAN running
				B3	Lost command
				B2	Inverter Overload
B1	Underload				
B0	Overload				
0h0335	Latch type trip information - 3	-	-	B3	Under Torque Detection 2
				B2	Over Torque Detection 2
				B1	Under Torque Detection 1
				B0	Over Torque Detection 1
0H03356 - 0h033F	Reserved	-	-	-	
0h0340	On Time date	0	Day	Total number of days the inverter has been powered on	
0h0341	On Time minute	0	Min	Total number of minutes excluding the total number of On Time days	
0h0342	Run Time date	0	Day	Total number of days the inverter has driven the motor	
0h0343	Run Time minute	0	Min	Total number of minutes excluding the total number of Run Time days	
0h0344	Fan Time date	0	Day	Total number of days the heat sink fan	
0h0345	Fan Time minute	0	Min	Total number of minutes excluding the total number of Fan Time days	

Comm. Address	parameter	Scale	Unit	Assigned Content by Bit
0h0346 -0h0348	Reserved	-	-	-
0h0349	Reserved	-	-	-
0h034A	Option 1	-	-	0: None, 9: CANopen
0h034B	Reserved	-	-	
0h034C	Reserved			

7.5.2 Control Area Parameter (Read/ Write)

Comm. Address	parameter	Scale	Unit	Assigned Content by Bit	
0h0380	Frequency command	0.01	Hz	Command frequency setting	
0h0381	RPM command	1	Rpm	Command rpm setting	
0h0382	Operation command	-	-	B7	Reserved
				B6	Reserved
				B5	Reserved
				B4	Reserved
				B3	0 → 1: Free-run stop
				B2	0 → 1: Trip initialization
				B1	0: Reverse direction command, 1: Forward direction command
				B0	0: Stop command, 1: Run command
0h0383	Acceleration time	0.1	sec	Acceleration time setting	
0h0384	Deceleration time	0.1	sec	Deceleration time setting	
0h0385	Virtual digital input control (0: Off, 1: On)	-	-	B15	Reserved
				-	Reserved
				B8	Reserved
				B7	Virtual DI 8(CM.77)
				B6	Virtual DI 7(CM.76)
				B5	Virtual DI 6(CM.75)
				B4	Virtual DI 5(CM.74)
				B3	Virtual DI 4(CM.73)
				B2	Virtual DI 3(CM.72)
B1	Virtual DI 2(CM.71)				
B0	Virtual DI 1(CM.70)				
0h0386	Digital output control (0: Off, 1: On)	-	-	B15	Reserved
				B14	Reserved

Comm. Address	parameter	Scale	Unit	Assigned Content by Bit	
				B13	Reserved
				B12	Reserved
				B11	Reserved
				B10	Reserved
				B9	Reserved
				B8	Reserved
				B7	Reserved
				B6	Reserved
				B5	Reserved
				B4	Reserved
				B3	Reserved
				B2	Reserved
				B1	Relay 2(0.4-7.5kW, OU-33: None)
				B0	Relay 1(0.4-7.5kW, OU-31: None)
0h0387	Reserved	-	-	Reserved	
0h0388	PID reference	0.1	%	PID reference command	
0h0389	PID feedback value	0.1	%	PID feedback value	
0h038A	Motor rated current	0.1	A	-	
0h038B	Motor rated voltage	1	V	-	
0h038C - 0h038F	Reserved	-	-	Reserved	
0h0390	Torque Ref	0.1	%	Torque command	
0h0391	Fwd Pos Torque Limit	0.1	%	Forward motoring torque limit	
0h0392	Fwd Neg Torque Limit	0.1	%	Positive-direction regeneration torque limit	
0h0393	Rev Pos Torque Limit	0.1	%	Reverse motoring torque limit	
0h0394	Rev Neg Torque Limit	0.1	%	Negative-direction regeneration torque limit	
0h0395	Torque Bias	0.1	%	Torque bias	

Note

A frequency set via communication using the common area frequency address (0h0380, 0h0005) is not saved even when used with the parameter save function. To save a changed frequency to use after a power cycle, follow these steps:

- 1** Set a frequency reference after setting the dr.07 code to 1 (Keypad-1).
- 2** Set the frequency via communication into the parameter area frequency address (0h1101).
- 3** Perform the parameter save (0h03E0: '1') before turning off the power. After the power cycle, the frequency set before turning off the power is displayed.

7.5.3 Memory Control Area Parameter (Read and Write)

Comm. Address	parameter	Scale	Unit	Changeable During Operation	Function
0h03E0	Save parameters	-	-	X	0: No, 1: Yes
0h03E1	Monitor mode initialization	-	-	O	0: No, 1: Yes
0h03E2	Parameter initialization	-	-	X	0: No, 1: All Grp, 2: Drv Grp 3:bA Grp, 4: Ad Grp, 5:Cn Grp 6:In Grp, 7:OU Grp, 8: CM Grp 9: AP Grp, 12: Pr Grp, 13: M2 Grp, 14: Operation group Setting is prohibited during fault trip interruptions.
0h03E3	Changed parameter display	-	-	O	0: No, 1: Yes
0h03E4	Reserved	-	-	-	Reserved
0h03E5	Delete all fault history	-	-	O	0: No, 1: Yes
0h03E6	Delete user-registered codes	-	-	O	0: No, 1: Yes
0h03E7	Hide parameter mode	0	Hex	O	Write: 0~9999 Read: 0: Unlock, 1: Lock
0h03E8	Lock parameter mode	0	Hex	O	Write: 0~9999 Read: 0: Unlock, 1: Lock
0h03E9	Reserved	-	-	-	Reserved
0h03EA	Initializing power consumption	-	-	O	0: No, 1: Yes
0h03EB	Initialize inverter operation accumulative time	-	-	O	0: No, 1: Yes
0h03EC	Initialize cooling fan accumulated operation time	-	-	O	0: No, 1: Yes

Note

- When setting parameters in the inverter memory control area, the values are reflected to the inverter operation and saved. Parameters set in other areas via communication are reflected to the inverter operation, but are not saved. All set values are cleared following an inverter power cycle and revert back to its previous values. Therefore, make sure to save the parameter after setting the parameter of a different area as communication and before turning off the inverter power. But it is not necessary to save the parameter at the inverter memory control area and the value will be saved to the inverter immediately once the setup is complete.

- Define the parameter carefully. After setting a parameter to 0 via communication, set it to another value. If a parameter has been set to a value other than 0 and a non-zero value is entered again, an error message is returned. The previously-set value can be identified by reading the parameter when operating the inverter via communication.
- The addresses 0h03E7 and 0h03E8 are parameters for entering the password. When the password is entered, the condition will change from Lock to Unlock, and vice versa. When the same parameter value is entered continuously, the parameter is executed just once. Therefore, if the same value is entered again, change it to another value first and then re-enter the previous value.

For example, if you want to enter 244 twice, enter it in the following order: 244 → 0 → 244.

⚠ Caution

It may take longer to set the parameter values in the inverter memory control area because all data is saved to the inverter. Be careful as communication may be lost during parameter setup if parameter setup is continues for an extended period of time.

8 Table of Functions

This chapter lists all the function settings for G100 series inverter. Set the parameters required according to the following references. If a set value input is out of range, the following messages will be displayed on the keyboard. In these cases, the inverter will not operate with the [ENT] key.

- Set value not allocated: **rd**
- Set value repetition (multi-function input, PID reference, PID feedback related): **OL**
- Set value not allowed (select value, V2, I2): **no**

8.1 Operation Group

SL: Sensorless vector control (dr.09), Property: Write-enabled during operation

Code	Comm. Address	Name	Keypad Display	Setting Range	Initial Value	Property*	V/F	SL	Ref.
-	0h1D00	Target frequency	0.00	0-Maximum frequency (Hz)	0.00	O	O	O	p.45
-	0h1D01	Acceleration time	ACC	0.0–600.0(s)	20.0	O	O	O	p.77
-	0h1D02	Deceleration time	DEC	0.0–600.0(s)	30.0	O	O	O	p.77
-	0h1D03	Command Source	drv	0 Keypad	1: Fx/Rx-1	X	O	O	p.72
				1 Fx/Rx-1					
				2 Fx/Rx-2					
				3 Int 485					
4 Fieldbus ¹									
-	0h1D04	Frequency reference source	Frq	0 Keypad-1	0: Keypad-1	X	O	O	p.60
				1 Keypad-2					
				2 V1					
				4 V0					
				5 I2					
				6 Int 485					
				8 Fied Bus ¹					
-	0h1D05	Multi-step speed frequency 1	St1	0.00-Maximum frequency (Hz)	10.00	O	O	O	p.70
-	0h1D06	Multi-step speed frequency 2	St2	0.00-Maximum frequency (Hz)	20.00	O	O	O	p.70

¹ Table of options are provided separately in the option manual.

Table of Functions

Code	Comm. Address	Name	Keypad Display	Setting Range	Initial Value	Property*	V/F	SL	Ref.	
-	0h1D07	Multi-step speed frequency 3	St3	0.00-Maximum frequency (Hz)	30.00	O	O	O	p.70	
-	0h1D08	Output current	CUr			-	O	O	p.53	
-	0h1D09	Motor revolutions per minute	Rpm			-	O	O	-	
-	0h1D0A	Inverter DC voltage	dCL	-	-	-	O	O	p.53	
-	0h1D0B	Inverter output voltage	vOL			-	O	O	p.53	
-	0h1D0C	Out of order signal	nOn			-	O	O	-	
-	0h1D0D	Select rotation direction	drC	F r	Forward direction operation Reverse run	F	O	O	O	-

8.2 Drive Group (PAR→dr)

In the following table, data shaded in grey will be displayed when the related code has been selected.

SL: Sensorless vector control (dr.09), Property: Write-enabled during operation

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.
dr-00	-	Jump Code	1-99	9	O	O	O	p.42
dr-09	0h1109	Control mode	0 V/F 2 Slip Compen 4 IM Sensorless	0: V/F	X	O	O	p.84 , p.117 , p.129
dr-11	0h110B	Jog Frequency	0.00, Start frequency- Maximum frequency(Hz)	10.00	O	O	O	p.109
dr-12	0h110C	Jog run acceleration time	0.0-600.0(s)	20.0	O	O	O	p.109
dr-13	0h110D	Jog run deceleration time	0.0-600.0(s)	30.0	O	O	O	p.109

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.	
dr-14	0h110E	Motor capacity	0: 0.2kW 1: 0.4kW 2: 0.75kW 3: 1.1kW 4: 1.5kW 5: 2.2kW 6: 3.0kW 7: 3.7kW 8: 4.0kW 9: 5.5kW 10: 7.5kW 11: 11.0kW	Varies by Motor capacity	X	O	O	p.126	
dr-15	0h110F	Torque boost mode	0	Manual	0: Manual	X	O	X	p.88
			1	Auto					
dr-16	0h1110	Forward Torque boost	0.0–15.0(%)	2.0	X	O	X	p.88	
dr-17	0h1111	Reverse torque boost	0.0–15.0(%)	2.0	X	O	X	p.88	
dr-18	0h1112	Base frequency	30.00–400.00(Hz) [V/F, Slip Compen] 40.00–120.00(Hz) [IM Sensorless]	60.00	X	O	O	p.84	
dr-19	0h1113	Start frequency	0.01–10.00(Hz)	0.50	X	O	O	p.84	
dr-20	0h1114	Maximum frequency	40.00–400.00(Hz) [V/F, Slip Compen] 40.00–120.00(Hz) [IM Sensorless]	60.00	X	O	O	p.95	
dr-26 ²	0h111A	Auto torque boost filter gain	1~1000	2	O	O	X		
dr-27 ²	0h111B	Auto torque boost motoring gain	0.0–300.0[%]	50.0	O	O	X		
dr-28 ²	0h111C	Auto torque boost regeneration gain	0.0–300.0[%]	50.0	O	O	X		

² Appears when Dr15 is 1 (automatic torque boost).

Table of Functions

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.	
dr-80	0h1150	Select ranges at power input	Select ranges inverter displays at power input	0: Operation frequency	0	0	0	-	
			0						Operation frequency
			1						Acceleration time
			2						Deceleration time
			3						Command Source
			4						Frequency reference source
			5						Multi-step speed frequency 1
			6						Multi-step speed frequency 2
			7						Multi-step speed frequency 3
			8						Output current
			9						Motor RPM
			10						Inverter DC voltage
			11						User select signal (dr.81)
			12						Currently out of order
			13						Select run direction
			14						Output current 2
			15						Motor RPM 2
			16						Inverter DC voltage 2
17	User select signal 2 (dr.81)								
dr-81	0h1151	Select monitor code	Monitors user selected code	0: Output voltage	0	0	0	-	
			0						Output voltage (V)
			1						Output power (kW)
			2						Torque(kgf · m)
dr-89	0h03E3	Display changed parameter Display	0 View All	0: View All	0	0	0	p.152	
			1 View Changed						
dr-91	0h115B	Smart copy	0 None	0:None	X	0	0	-	
			1 SmartDownload						
			3 SmartUpLoad						
			4 RemoteUpLoad						
			5 RemoteDownload						

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.	
dr-93	0h115D	Parameter initialization	0	No	0:No	X	O	O	p.150
			1	All Grp					
			2	dr Grp					
			3	bA Grp					
			4	Ad Grp					
			5	Cn Grp					
			6	In Grp					
			7	OU Grp					
			8	CM Grp					
			9	AP Grp					
			11	AO Grp					
			12	Pr Grp					
			13	M2 Grp					
			14	run Grp					
dr-94	0h115E	Password registration	0~9999		O	O	O	p.151	
dr-95	0h115F	Parameter lock settings	0~9999		O	O	O	p.151	
dr-97	0h1161	Software version			-	O	O	-	
dr-98	0h1162	Display I/O board version			-	O	O	-	

8.3 Basic Function Group (PAR→bA)

In the following table, data shaded in grey will be displayed when the related code has been selected.

SL: Sensorless vector control (dr.09), **Property:** Write-enabled during operation

Code	Comm. Address	Name	Setting Range	Initial Value	Property *	V/F	SL	Ref.	
bA-00	-	Jump Code	1~99	20	O	O	O	p.42	
bA-01	0h1201	Auxiliary reference source	0	None	0:None	X	O	O	p.105
			1	V1					
			3	V0					

Table of Functions

Code	Comm. Address	Name	Setting Range	Initial Value	Property *	V/F	SL	Ref.
			4 I2					
bA-02 ³	0h1202	Auxiliary command calculation type	0 M+(G*A)	0: M+(GA)	X	O	O	p.105
			1 Mx (G*A)					
			2 M/(G*A)					
			3 M+[M*(G*A)]					
			4 M+G*2(A-50%)					
			5 Mx[G*2(A-50%)]					
			6 M/[G*2(A-50%)]					
			7 M+M*G*2(A-50%)					
bA-03 ³	0h1203	Auxiliary frequency reference gain	-200.0–200.0(%)	100.0	O	O	O	p.105
bA-04	0h1204	2nd command source	0 Keypad	1: Fx/Rx-1	X	O	O	p.98
			1 Fx/Rx-1					
			2 Fx/Rx-2					
			3 Int 485					
			4 FieldBus ⁴					
bA-05	0h1205	2nd frequency source	0 Keypad-1	0: Keypad-1	O	O	O	p.98
			1 Keypad-2					
			2 V1					
			4 V0					
			5 I2					
			6 Int 485					
			8 FieldBus ⁴					
bA-07	0h1207	V/F pattern	0 Linear	0: Linear	X	O	X	p.84
			1 Square					
			2 User V/F					
			3 Square 2					
bA-08	0h1208	Acc/Dec reference	0 Max Freq	0: Max Freq	X	O	O	p.77
			1 Delta Freq					
bA-09	0h1209	Time scale setting	0 0.01 sec	1:0.1 sec	X	O	O	p.77
			1 0.1 sec					
			2 1 sec					
bA-10	0h120A	input power frequency	0 60Hz	0:60Hz	X	O	O	p.149
			1 50Hz					

³ Displayed if bA.01 is not set to 0 (None).

⁴ Table of options are provided separately in the option manual.

Code	Comm. Address	Name	Setting Range	Initial Value	Property *	V/F	SL	Ref.	
bA-11	0h120B	Number of motor poles	2~48	Dependent on motor setting	X	O	O	p.117	
bA-12	0h120C	Rated slip speed	0-3000(Rpm)		X	O	O	p.117	
bA-13	0h120D	Motor rated current	1.0-1000.0(A)		X	O	O	p.117	
bA-14	0h120E	Motor no-load current	0.0-1000.0(A)		X	O	O	p.117	
bA-15	0h120F	Motor rated voltage	0, 170-480(V)	0	X	O	O	p.89	
bA-16	0h1210	Motor efficiency	64-100(%)	Dependent on motor setting	X	O	O	p.117	
bA-17	0h1211	Load inertia rate	0~8	0	X	O	O	p.117	
bA-18	0h1212	Trim power display	70~130(%)	100%	O	O	O	-	
bA-19	0h1213	Input power voltage	170~480V	220/380V	O	O	O	p.149	
bA-20	-	Auto tuning	0	None	0:None	X	X	O	p.126
			1	All (Rotation type)					
			2	All (Static type)					
			3	Rs+Lsigma (Rotation type)					
			6	Tr (Static type)					
bA-21	-	Stator resistance	Dependent on motor setting	Dependent on motor setting	X	X	O	p.126	
bA-22	-	Leakage inductance			X	X	O	p.126	
bA-23	-	Stator inductance			X	X	O	p.126	
bA-24 ⁵	-	Rotor time constant	25-5000(ms)	-	X	X	O	p.126	
bA-41 ⁶	0h1229	User Frequency 1	0.00- Maximum frequency (Hz)	15.00	X	O	X	p.86	

Trouble-shooting

⁵ Displayed when dr.09 is set to 4(IM Sensorless).

⁶ Displayed if either bA.07 or M2.25 is set to 2 (User V/F).

Table of Functions

Code	Comm. Address	Name	Setting Range	Initial Value	Property *	V/F	SL	Ref.
bA-42 ⁶	0h122A	User Voltage 1	0-100(%)	25	X	O	X	p.86
bA-43 ⁶	0h122B	User Frequency 2	0.00-Maximum frequency (Hz)	30.00	X	O	X	p.86
bA-44 ⁶	0h122C	User Voltage 2	0-100(%)	50	X	O	X	p.86
bA-45 ⁶	0h122D	User Frequency 3	0.00-Maximum frequency (Hz)	45.00	X	O	X	p.86
bA-46 ⁶	0h122E	User Voltage 3	0-100(%)	75	X	O	X	p.86
bA-47 ⁶	0h122F	User Frequency 4	0.00-Maximum frequency (Hz)	Maximum frequency	X	O	X	p.86
bA-48 ⁶	0h1230	User Voltage 4	0-100(%)	100	X	O	X	p.86
bA-53 ⁷	0h1235	Multi-step speed frequency 4	0.00-Maximum frequency (Hz)	40.00	O	O	O	p.70
bA-54 ⁷	0h1236	Multi-step speed frequency 5	0.00-Maximum frequency (Hz)	50.00	O	O	O	p.70
bA-55 ⁷	0h1237	Multi-step speed frequency 6	0.00-Maximum frequency (Hz)	Maximum frequency	O	O	O	p.70
bA-56 ⁷	0h1238	Multi-step speed frequency 7	0.00-Maximum frequency (Hz)	Maximum frequency	O	O	O	p.70
bA-70	0h1246	Multi-step acceleration time 1	0.0–600.0(s)	20.0	O	O	O	p.79
bA-71	0h1247	Multi-step deceleration time 1	0.0–600.0(s)	20.0	O	O	O	p.79
bA-72 ⁸	0h1248	Multi-step acceleration time 2	0.0–600.0(s)	30.0	O	O	O	p.79

⁷ Displayed if one of In.65-71 is set to Speed–L/M/H.

⁸ Displayed one of In.65-71 is set to Xcel–L/M/H.

Code	Comm. Address	Name	Setting Range	Initial Value	Property *	V/F	SL	Ref.
bA-73 ⁸	0h1249	Multi-step deceleration time 2	0.0–600.0(s)	30.0	○	○	○	p.79
bA-74 ⁸	0h124A	Multi-step acceleration time 3	0.0–600.0(s)	40.0	○	○	○	p.79
bA-75 ⁸	0h124B	Multi-step deceleration time 3	0.0–600.0(s)	40.0	○	○	○	p.79
bA-76 ⁸	0h124C	Multi-step acceleration time 4	0.0–600.0(s)	50.0	○	○	○	p.79
bA-77 ⁸	0h124D	Multi-step deceleration time 4	0.0–600.0(s)	50.0	○	○	○	p.79
bA-78 ⁸	0h124E	Multi-step acceleration time 5	0.0–600.0(s)	40.0	○	○	○	p.79
bA-79 ⁸	0h124F	Multi-step deceleration time 5	0.0–600.0(s)	40.0	○	○	○	p.79
bA-80 ⁸	0h1250	Multi-step acceleration time 6	0.0–600.0(s)	30.0	○	○	○	p.79
bA-81 ⁸	0h1251	Multi-step deceleration time 6	0.0–600.0(s)	30.0	○	○	○	p.79
bA-82 ⁸	0h1252	Multi-step acceleration time 7	0.0–600.0(s)	20.0	○	○	○	p.79
bA-83 ⁸	0h1253	Multi-step deceleration time 7	0.0–600.0(s)	20.0	○	○	○	p.79

8.4 Expanded Function Group (PAR→Ad)

In the following table, data shaded in grey will be displayed when the related code has been selected.

SL: Sensorless vector control (dr.09), **Property:** Write-enabled during operation

Table of Functions

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.
Ad-00	-	Jump Code	1-99	24	O	O	O	p.42
Ad-01	0h1301	Acceleration pattern	0 Linear	0: Linear	X	O	O	p.82
Ad-02	0h1302	Deceleration pattern	1 S-curve		X	O	O	p.82
Ad-03 ⁹	0h1303	S-curve acceleration start point gradient	1-100(%)	40	X	O	O	p.82
Ad-04 ⁹	0h1304	S-curve acceleration end point gradient	1-100(%)	40	X	O	O	p.82
Ad-05 ¹⁰	0h1305	S-curve deceleration start point gradient	1-100(%)	40	X	O	O	p.82
Ad-06 ¹⁰	0h1306	S-curve deceleration end point gradient	1-100(%)	40	X	O	O	p.82
Ad-07	0h1307	Start Mode	0 Acc 1 Dc-Start	0:Acc	X	O	O	p.90
Ad-08	0h1308	Stop Mode	0 Dec 1 Dc-Brake 2 Free-Run 4 Power Braking	0:Dec	X	O	O	p.92
Ad-09	0h1309	Run prevention options	0 None 1 Forward Prev 2 Reverse Prev	0: None	X	O	O	p.74
Ad-10	0h130A	Starting with power on	0 No 1 Yes	0:No	O	O	O	p.75
Ad-12 ¹¹	0h130C	Start DC braking time	0.00-60.00(s)	0.00	X	O	X	p.90
Ad-13	0h130D	Amount of applied DC	0-inverter rated current(%)	50	X	O	X	p.90

⁹ Displayed when Ad. 01 is set to 1 (S-curve).

¹⁰ Displayed when the Ad. 02 code is set to 1 (S-curve).

¹¹ Displayed when Ad. 07 is set to 1 (DC-Start).

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.
Ad-14 ¹²	0h130E	Output blocking time before DC braking	0.00–60.00(s)	0.10	X	O	O	p.92
Ad-15 ¹²	0h130F	DC braking time	0.00–60.00(s)	1.00	X	O	O	p.92
Ad-16 ¹²	0h1310	DC braking rate	0-inverter rated current(%)	50	X	O	O	p.92
Ad-17 ¹²	0h1311	DC braking frequency	Start frequency-60Hz	5.00	X	O	O	p.92
Ad-20	0h1314	Dwell frequency on acceleration	Start frequency-Maximum frequency(Hz)	5.00	X	O	O	p.115
Ad-21	0h1315	Dwell operation time on acceleration	0.0–60.0(s)	0.0	X	O	O	p.115
Ad-22	0h1316	Dwell frequency during deceleration	Start frequency-Maximum frequency(Hz)	5.00	X	O	O	p.115
Ad-23	0h1317	Operation time during deceleration	0.0–60.0(s)	0.0	X	O	O	p.115
Ad-24	0h1318	Frequency limit	0 No 1 Yes	0:No	X	O	O	p.96
Ad-25 ¹³	0h1319	Frequency lower limit value	0.00-Upper limit frequency(Hz)	0.50	O	O	O	p.96
Ad-26 ¹³	0h131A	Frequency upper limit value	Lower limit frequency-Maximum frequency(Hz)	Maximum frequency	X	O	O	p.96
Ad-27	0h131B	Frequency jump	0 No 1 Yes	0:No	X	O	O	p.97
Ad-28 ¹⁴	0h131C	Jump frequency lower limit 1	0.00-Jump frequency upper limit1(Hz)	10.00	O	O	O	p.97

¹² Displayed when Ad. 08 is set to 1 (DC-Brake).

¹³ Displayed when the Ad.24 code is set to 1 (Yes).

¹⁴ Displayed when the Ad.27 code is set to 1 (Yes).

Table of Functions

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.	
Ad-29 ¹⁴	0h131D	Jump frequency upper limit 1	Jump frequency lower limit1- Maximum frequency(Hz)	15.00	O	O	O	p.97	
Ad-30 ¹⁴	0h131E	Jump frequency lower limit 2	00-Jump frequency upper limit2(Hz)	20.00	O	O	O	p.97	
Ad-31 ¹⁴	0h131F	Jump frequency upper limit 2	Jump frequency lower limit2- Maximum frequency(Hz)	25.00	O	O	O	p.97	
Ad-32 ¹⁴	0h1320	Jump frequency lower limit 3	0.00-Jump frequency upper limit3(Hz)	30.00	O	O	O	p.97	
Ad-33 ¹⁴	0h1321	Jump frequency upper limit 3	Jump frequency lower limit3- Maximum frequency(Hz)	35.00	O	O	O	p.97	
Ad-41 ¹⁵	0h1329	Brake release current	0.0-180.0(%)	50.0	O	O	O	p.153	
Ad-42 ¹⁵	0h132A	Brake release delay time	0.00-10.00(s)	1.00	X	O	O	p.153	
Ad-44 ¹⁵	0h132C	Brake release Forward frequency	0.00-Maximum frequency (Hz)	1.00	X	O	O	p.153	
Ad-45 ¹⁵	0h132D	Brake release Reverse frequency	0.00-Maximum frequency (Hz)	1.00	X	O	O	p.153	
Ad-46 ¹⁵	0h132E	Brake engage delay time	0.00-10.00(s)	1.00	X	O	O	p.153	
Ad-47 ¹⁵	0h132F	Brake engage frequency	0.00-Maximum frequency (Hz)	2.00	X	O	O	p.153	
Ad-50	0h1332	Energy saving operation	0	None	0:None	X	O	X	p.138
			1	Manual					
			2	Auto					

¹⁵ Displayed if either OU.31 or OU.33 is set to 35 (BR Control).

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.	
Ad-51 ¹⁶	0h1333	Energy saving amount	0–30(%)	0	O	O	X	p.138	
Ad-60	0h133C	Acc/Dec time transition frequency	0.00-Maximum frequency (Hz)	0.00	X	O	O	p.81	
Ad-61	0h133D	Rotation count speed gain	0.1–6000.0[%]	100.0	O	O	O	-	
Ad-62	0h133E	Rotation count speed scale	0	x 1	0: x 1	O	O	O	-
			1	x 0.1					
			2	x 0.01					
			3	x 0.001					
			4	x 0.0001					
Ad-63	0h133F	Rotation count speed unit	0	Rpm	0: rpm	O	O	O	-
			1	mpm					
Ad-64	0h1340	Cooling fan control	0	During Run	0:During Run	O	O	O	p.148
			1	Always ON					
			2	Temp Control					
Ad-65	0h1341	Up/down operation frequency save	0	No	0:No	O	O	O	p.111
			1	Yes					
Ad-66	0h1342	Output contact On/Off control options	0	None	0:None	X	O	O	p.154
			1	V1					
			3	V0					
			4	I2					
Ad-67	0h1343	Output contact On level	Output contact off level–100.00 %	90.00	X	O	O	p.154	
Ad-68	0h1344	Output contact Off level	-100.00-output contact on level (%)	10.00	X	O	O	p.154	
Ad-70	0h1346	Safe operation selection	0	Always Enable	0:Always Enable	X	O	O	p.114
			1	DI Dependent					

¹⁶ Displayed if Ad.50 is not set to 0 (None).

Table of Functions

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.	
Ad-71 ¹⁷	0h1347	Safe operation stop options	0	Free-Run	0:Free-Run	X	O	O	p.114
			1	Q-Stop					
			2	Q-Stop Resume					
Ad-72 ¹⁷	0h1348	Safe operation deceleration time	0.0–600.0(s)	5.0	O	O	O	p.114	
Ad-74	0h134A	Selection of regeneration evasion function for press	0	No	0:No	X	O	O	p.155
			1	Yes					
Ad-75	0h134B	Voltage level of regeneration evasion motion for press	200V : 300–400V	350	X	O	O	p.155	
			400V : 600–800V	700					
Ad-76 ¹⁸	0h134C	Compensation frequency limit of regeneration evasion for press	0.00–10.00 Hz	1.00	X	O	O	p.155	
Ad-77 ¹⁸	0h134D	Regeneration evasion for press P gain	0.0–100.0%	50.0	O	O	O	p.155	
Ad-78 ¹⁸	0h134E	Regeneration evasion for press I gain	20–30000(ms)	500	O	O	O	p.155	
Ad-79	0h134F	DB Unit turn on voltage level	200V: Min ¹⁹ –400[V]	390[V]	X	O	O	-	
			400V: Min ¹⁹ –800[V]	780[V]					
Ad-80	0h1350	Fire Mode selection	0	None	0:None	X	O	O	p.100
			1	Fire Mode					
			2	Fire Mode Test					

¹⁷ Displayed when Ad.70 is set to 1 (DI Dependent).

¹⁸ Displayed when the Ad.74 code is set to 1 (Yes).

¹⁹ Voltage type which DC converted the bA.19 AC input voltage: +20V (200Vtype), +40V (400V type). 200V type is limited to 350V and 400V type is limited to 600V.

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.
Ad-81 ²⁰	0h1351	Fire Mode Operation frequency	Start frequency- Maximum frequency [Hz]	60.00	X	O	O	p.100
Ad-82 ²⁰	0h1352	Fire Mode Run direction	0 Forward 1 Reverse	0: Forward	X	O	O	p.100
Ad-83 ²⁰		Fire Mode operation count	Not configurable	-	-	-	-	p.100

8.5 Control Function Group (PAR→Cn)

In the following table, data shaded in grey will be displayed when the related code has been selected.

SL: Sensorless vector control (dr.09), **Property:** Write-enabled during operation

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.	
Cn-00	-	Jump Code	1–99	4	O	O	O	p.42	
Cn-04	0h1404	Carrier frequency	Heavy Duty	V/F: 2.0–15.0 (kHz) IM: 2.0–15.0 (kHz)	3.0	X	O	O	p.144
			Normal Duty	V/F: 2.0–5.0 (kHz) IM: 2.0–5.0 (kHz)	2.0				p.144
Cn-05	0h1405	Switching mode	0 Normal PWM	0:Normal PWM	X	O	O	p.144	
Cn-09	0h1409	Initial excitation time	0.00–60.00(s)	1.00	X	X	O	p.131	
Cn-10	0h140A	Initial excitation amount	100.0–300.0(%)	100.0	X	X	O	p.131	
Cn-11	0h140B	Continued operation duration	0.00–60.00(s)	0.00	X	X	O	p.131	
Cn-20	0h1414	Sensorless second gain display setting	0 No	0:No	O	X	O	p.131	
			1 Yes						
Cn-21	0h1415	Stator resistance scale	50–300(%)	Varies by Motor capacity	X	X	O	p.131	

²⁰ Displayed if Ad.80 is not set to 0 (None).

Table of Functions

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.	
Cn-22	0h1416	Stator leakage inductance scale	50–300(%)	Varies by Motor capacity	X	X	O	p.131	
Cn-23 ²¹	0h1417	Stator inductance scale	50–300(%)	Varies by Motor capacity	X	X	O	p.131	
Cn-24 ²¹	0h1418	Rotor time constant scale	50–300(%)	Varies by Motor capacity	X	X	O	p.131	
Cn-25 ²¹	0h1419	No-load current scale	50–300(%)	Varies by Motor capacity	X	X	O	-	
Cn-26 ²¹	0h141A	Speed controller bandwidth	1–10(Hz)	4	O	X	O	p.131	
Cn-27 ²¹	0h141B	PLL BandWidth	5–50(Hz)	20	O	X	O	p.131	
Cn-28 ²¹	0h141C	Speed low-pass filter bandwidth	5–50(Hz)	20	O	X	O	p.131	
Cn-29 ²¹	0h141D	Flux controller extreme point weight	0.50~2.00	1.06	O	X	O	p.131	
Cn-30 ²¹	0h141E	Speed controller adjustment gain	2.0~10.0	4.0	O	X	O	p.131	
Cn-31 ²¹	0h141F	Current controller bandwidth	50–400(Hz)	70	O	X	O	p.131	
Cn-53	0h1435	Torque limit setting	0	Keypad-1	0: Keypad-1	X	X	O	p.131
			1	Keypad-2					
			2	V1					
			4	V0					
			5	I2					
			6	Int 485					
			8	FieldBus					

²¹ Displayed when dr.09 is set to 4 (IM Sensorless) and Cn.20 is set to 1 (YES).

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.	
Cn-54 ²²	0h1436	Positive-direction reverse torque limit	0.0–200.0(%)	180	O	X	O	p.131	
Cn-55 ²²	0h1437	Positive-direction regeneration torque limit	0.0–200.0(%)	180	O	X	O	p.131	
Cn-56 ²²	0h1438	Negative-direction regeneration torque limit	0.0–200.0(%)	180	O	X	O	p.131	
Cn-57 ²²	0h1439	Negative-direction reverse torque limit	0.0–200.0(%)	180	O	X	O	p.131	
Cn-70	0h 1446	Speed search mode selection	0	Flying Start-1 ²³	0: Flying Start-1	X	O	O	p.139
			1	Flying Start-2					
Cn-71	0h1447	Speed search operation selection	bit	0000–1111	0000 ²⁴	X	O	O	p.139
			0001	Selects the speed search function at acceleration.					
			0010	Initialization after a fault trip					
			0100	Restart after instantaneous power interruption					
			1000	Starting with power-on					
Cn-72 ²⁵	0h1448	Speed search reference current	80–200(%)	150	O	O	O	p.139	

²² Displayed when dr.09 is set to 4 (IM Sensorless). This will change the initial value of the parameter at Ad.74 (Torque limit) to 150%.

²³ Will not be displayed if dr.09 is set to 4 (IM Sensorless).

²⁴ The initial value 0000 will be displayed on the keypad as .

²⁵ Displayed when any of the Cn.71 code bits are set to 1 and Cn70 is set to 0 (Flying Start-1).

Table of Functions

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.	
Cn-73 ²⁶	0h1449	Speed search proportional gain	0~9999	Flying Start-1 : 100	O	O	O	p.139	
				Flying Start-2 : 600 ²⁷					
Cn-74 ²⁶	0h144A	Speed search integral gain	0~9999	Flying Start-1 : 200	O	O	O	p.139	
				Flying Start-2 : 1000					
Cn-75 ²⁶	0h144B	Output block time before speed search	0.0~60.0(s)	1.0	X	O	O	p.139	
Cn-76 ²⁶	0h144C	Speed search Estimator gain	50~150(%)	100	O	O	O	-	
Cn-77	0h144D	Energy buffering selection	0	No	0:No	X	O	O	p.135
			1	KEB-1					
			2	KEB-2					
Cn-78 ²⁸	0h144E	Energy buffering start level	110.0~200.0(%)	125.0	X	O	O	p.135	
Cn-79 ²⁸	0h144F	Energy buffering stop level	Cn78~210.0(%)	130.0	X	O	O	p.135	
Cn-80 ²⁸	0h1450	Energy buffering P gain	0~20000	1000	O	O	O	p.135	
Cn-81 ²⁸	0h1451	Energy buffering I gain	1~20000	500	O	O	O	p.135	
Cn-82 ²⁸	0h1452	Energy buffering Slip gain	0~2000.0%	30.0	O	O	O	p.135	
Cn-83 ²⁸	0h1453	Energy buffering acceleration time	0.0~600.0(s)	10.0	O	O	O	p.135	

²⁶ Displayed when any of the Cn.71 code bits are set to 1.

²⁷ The initial value is 1200 when the motor-rated capacity is less than 7.5 kW

²⁸ Displayed when Cn.77 is not set to 0 (No).

8.6 Input Terminal Block Function Group (PAR→In)

In the following table, data shaded in grey will be displayed when the related code has been selected.

SL: Sensorless vector control (dr.09), Property: Write-enabled during operation

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.
In-00	-	Jump Code	1-99	65	O	O	O	p.42
In-01	0h1501	Frequency for maximum analog input	Start frequency- Maximum frequency(Hz)	Maximum frequency	O	O	O	p.61
In-02	0h1502	Torque at maximum analog input	0.0-200.0(%)	100.0	O	X	X	-
In-05	0h1505	V1 input voltage display	-12.00-12.00(V)	0.00	-	O	O	p.61
In-06	0h1506	V1 input polarity selection	0	Unipolar	0: Unipolar	X	O	O
			1	Bipolar				
In-07	0h1507	Time constant of V1 input filter	0-10000(ms)	100	O	O	O	p.61
In-08	0h1508	V1 Minimum input voltage	0.00-10.00(V)	0.00	O	O	O	p.61
In-09	0h1509	V1 output at Minimum voltage (%)	0.00-100.00(%)	0.00	O	O	O	p.61
In-10	0h150A	V1 Maximum input voltage	0.00-12.00(V)	10.00	O	O	O	p.61
In-11	0h150B	V1 output at Maximum voltage (%)	0.00-100.00(%)	100.00	O	O	O	p.61
In-12 ²⁹	0h150C	V1 Minimum input voltage	-10.00-0.00(V)	0.00	O	O	O	p.65
In-13 ²⁹	0h150D	V1 output at Minimum voltage (%)	-100.00-0.00(%)	0.00	O	O	O	p.65
In-14 ²⁹	0h150E	V1 Maximum input voltage	-12.00-0.00(V)	-10.00	O	O	O	p.65

²⁹ Displayed when In.06 is set to 1 (Bipolar).

Table of Functions

Code	Comm. Address	Name	Setting Range	Initial Value	Prop erty*	V/ F	SL	Ref.	
In-15 ²⁹	0h150F	V1 output at Maximum voltage (%)	-100.00–0.00(%)	-100.00	O	O	O	p.65	
In-16	0h1510	Changing rotation direction of V1	0	No	0: No	O	O	O	p.61
			1	Yes					
In-17	0h1511	V1 quantization level	0.00 ³⁰ , 0.04–10.00(%)	0.04	X	O	O	p.61	
In-35	0h1523	V0 input voltage display	0.00–5.00(V)	0.00	-	O	O	p.67	
In-37	0h1525	Time constant of V0 input filter	0–10000(ms)	100	O	O	O	p.67	
In-38	0h1526	V0 Minimum input voltage	0.00–5.00(V)	0.00	O	X	O	p.67	
In-39	0h1527	V0 output at Minimum voltage (%)	0.00–100.00(%)	0.00	O	O	O	p.67	
In-40	0h1528	V0 Maximum input voltage	0.00–5.00(V)	5.00	O	X	O	p.67	
In-41	0h1529	V0 output at Maximum voltage (%)	0.00–100.00(%)	100.00	O	O	O	p.67	
In-46	0h152E	Changing rotation direction of V0	0	No	0:No	O	O	O	p.67
			1	Yes					
In-47	0h152F	V0 quantization level	0.00 ³⁰ , 0.04–10.00(%)	0.04	O	O	O	p.67	
In-50	0h1532	I2 input voltage display	0–24(mA)	0.00	-	O	O	p.67	
In-52	0h1534	I2 input filter time constant	0–10000(ms)	100	O	O	O	p.67	

³⁰ Quantizing is not used when set to 0.

Code	Comm. Address	Name	Setting Range		Initial Value	Prop erty*	V/ F	SL	Ref.
In-53	0h1535	I2 minimum input current	0.00–20.00(mA)		4.00	O	O	O	p.67
In-54	0h1536	I2 output at Minimum current (%)	0.00–100.00(%)		0.00	O	O	O	p.67
In-55	0h1537	I2 maximum input current	0.00–24.00(mA)		20.00	O	O	O	p.67
In-56	0h1538	I2 output at Maximum current (%)	0.00–100.00(%)		100.00	O	O	O	p.67
In-61	0h153D	Changing rotation direction of I2	0	No	0:No	O	O	O	p.67
			1	Yes					
In-62	0h153E	I2 quantization level	0.00 ²⁹ ,0.04–10.00(%)		0.04	O	O	O	p.67
In-65	0h1541	P1 terminal function setting	0	None	1:Fx	X	O	O	p.72
			1	Fx					
In-66	0h1542	P2 terminal function setting	2	Rx	2:Rx	X	O	O	p.72
			3	RST					p.184
In-67	0h1543	P3 terminal function setting	4	External Trip	5:BX	X	O	O	p.175
			5	BX					p.184
In-68	0h1544	P4 terminal function setting	6	JOG	3:RST	X	O	O	p.109
			7	Speed-L					p.70
In-69	0h1545	P5 terminal function setting	8	Speed-M	7:Sp-L	X	O	O	p.70
			9	Speed-H					p.70
			11	XCEL-L					p.79
			12	XCEL-M					p.79
			13	RUN Enable					p.114
			14	3-Wire					p.113
			15	2nd Source					p.98
			16	Exchange					p.147
			17	Up					p.111
			18	Down					p.111
			20	U/D Clear					p.111
			21	Analog Hold					p.69

Table of Functions

Code	Comm. Address	Name	Setting Range	Initial Value	Prop erty*	V/ F	SL	Ref.
			22	I-Term Clear				p.119
			23	PID Openloop				p.119
			24	P Gain2				p.119
			25	XCEL Stop				p.84
			26	2nd Motor				p.146
			27	U/D Enable				
			33	Baseblock				
			34	Pre Excite				p.92
			38	Timer In				p.152
			40	dis Aux Ref				p.105
			46	FWD JOG				p.110
			47	REV JOG				p.110
			49	XCEL-H				p.79
			51	Fire Mode				p.100
			52	KEB-1 Select				p.135
In-84	0h1554	Multi-function input terminal On filter selection	P5 – P1 0 Disable(Off) 1 Enable(On)	1 1111 ³¹	O	O	O	p.99
In-85	0h1555	Multi-function input terminal On filter	0–10000(ms)	10	O	O	O	p.99
In-86	0h1556	Multi-function input terminal Off filter	0–10000(ms)	3	O	O	O	p.99
In-87	0h1557	Multi-function input terminal selection	P5 – P1 0 A contact (NO) 1 B contact (NC)	0 0000 ³²	X	O	O	p.99
In-88	0h1558	Selects the NO/NC operation command	0 NO 1 NO/NC	0	X	O	O	
In-89	0h1559	Multi-step command delay time	1-5000(ms)	1	X	O	O	p.70

³¹ The initial value 11111 will be displayed on the keypad as .

³² The initial value 0000 will be displayed on the keypad as .

Code	Comm. Address	Name	Setting Range	Initial Value	Prop erty*	V/ F	SL	Ref.	
In-90	0h155A	Multi-function input terminal status	P5 – P1		0 0000	-	O	O	p.99
			0	release(Off)					
			1	Connection (On)					
In-99	0h1563	SW1(NPN/PNP), status	Bit	0~1	0	-	O	O	-
			0	NPN					
			1	PNP					

8.7 Output Terminal Block Function Group (PAR→OU)

In the following table, data shaded in grey will be displayed when the related code has been selected.

SL: Sensorless vector control (dr.09), **Property:** Write-enabled during operation

Code	Comm. Address	Name	Setting Range	Initial Value	Prop erty*	V/ F	SL	Ref.	
OU-00	-	Jump Code	1–99	30	O	O	O	p.42	
OU-01	0h1601	Analog output 1 item	0	Frequency	0: Frequency	O	O	O	p.157
			1	Output Current					
			2	Output Voltage					
			3	DCLink Voltage					
			4	Torque					
			5	Output Power					
			6	Idse					
			7	Iqse					
			8	Target Freq					
			9	Ramp Freq					
			10	Speed Fdb					
			12	PID Ref Value					
			13	PID Fdb Value					
			14	PID Output					
			15	Constant					
OU-02	0h1602	Analog output 1 gain	-1000.0–1000.0(%)	100.0	O	O	O	p.157	
OU-03	0h1603	Analog output 1 bias	-100-100(%)	0	O	O	O	p.157	
OU-04	0h1604	Analog output 1 filter	0–10000(ms)	5	O	O	O	p.157	

Table of Functions

Code	Comm. Address	Name	Setting Range	Initial Value	Prop erty*	V/F	SL	Ref.
OU-05	0h1606	Analog constant output1	0.0–100.0(%)	0.0	0	0	0	p.157
OU-06	0h1606	Analog output1 monitor	0.0–1000.0(%)	0.0	-	0	0	p.157
OU-30	0h161E	Fault output item	bit 000–111	010 ³³	0	0	0	p.163
			1 Low voltage					
			2 Any faults other than low voltage					
3 Final failure of automatic restart								
OU-31	0h161F	Multi-function relay 1 item	0 None	29:Trip	0	0	0	p.159
			1 FDT-1					
			2 FDT-2					
			3 FDT-3					
			4 FDT-4					
			5 Over Load					
			6 IOL					
			7 Under Load					
			8 Fan Warning					
			9 Stall					
			10 Over Voltage					
			11 Low Voltage					
			12 Over Heat					
			13 Lost Command					
			14 Run					
			15 Stop					
			16 Steady					
17 Inverter Line								
18 Comm Line								
19 Speed Search								
21 Regeneration								
22 Ready								
23 Zero Speed								
28 Timer Out								
29 Trip								
31 DB Warn%ED								
34 On/Off Control								

³³ The initial value 0000 will be displayed on the keypad as .

Code	Comm. Address	Name	Setting Range	Initial Value	Prop erty*	V/F	SL	Ref.	
			35	BR Control					
			36	Reserved					
			37	FAN Exchange					
			38	Fire Mode					
			40	KEB Operating					
			41	Pre Overheat					
			42	Minor fault					
			44	Torque Detect2					
OU-33	0h1621	Multi-function relay 2 item	0	None	14:Run	O	O	O	p.159
			1	FDT-1					
			2	FDT-2					
			3	FDT-3					
			4	FDT-4					
			5	Over Load					
			6	IOL					
			7	Under Load					
			8	Fan Warning					
			9	Stall					
			10	Over Voltage					
			11	Low Voltage					
			12	Over Heat					
			13	Lost Command					
			14	Run					
			15	Stop					
			16	Steady					
			17	Inverter Line					
			18	Comm Line					
			19	Speed Search					
			21	Regeneration					
			22	Ready					
			23	Zero Speed					
			28	Timer Out					
			29	Trip					
			31	DB Warn%ED					
			34	On/Off Control					
			35	BR Control					
			36	Reserved					
			37	FAN Exchange					
			38	Fire Mode					
			40	KEB Operating					
41	Pre Overheat								
42	Minor fault								
43	Torque Detect1								
44	Torque Detect2								

Table of Functions

Code	Comm. Address	Name	Setting Range	Initial Value	Prop erty*	V/F	SL	Ref.
OU-41	0h1629	Multi-function output monitor	-	00	-	-	-	p.159
OU-50	0h1632	Multi-function output On delay	0.00–100.00(s)	0.00	○	○	○	p.164
OU-51	0h1633	Multi-function output Off delay	0.00–100.00(s)	0.00	○	○	○	p.164
OU-52	0h1634	Multi-function output contact selection	Relay2, Relay1	00 ³⁴	X	○	○	p.164
			0 A contact (NO)					
			1 B contact (NC)					
OU-53	0h1635	Fault output On delay	0.00–100.00(s)	0.00	○	○	○	p.163
OU-54	0h1636	Fault output Off delay	0.00–100.00(s)	0.00	○	○	○	p.163
OU-55	h1637	Timer On delay	0.00–100.00(s)	0.00	○	○	○	p.152
OU-56	0h1638	Timer Off delay	0.00–100.00(s)	0.00	○	○	○	p.152
OU-57	0h1639	Detection frequency	0.00-Maximum frequency (Hz)	30.00	○	○	○	p.159
OU-58	0h163A	Detection frequency band	0.00-Maximum frequency (Hz)	10.00	○	○	○	p.159

8.8 Communication Function Group (PAR→CM)

In the following table, data shaded in grey will be displayed when the related code has been selected.

SL: Sensorless vector control (dr.09), Property: Write-enabled during operation

Code	Comm. Address	Name	Setting Range	Initial Value	Prop erty*	V/F	SL	Ref.
CM-00	-	Jump Code	1–99	20	○	○	○	p.42
CM-01	0h1701	Built-in communication inverter ID	1~250	1	○	○	○	p.196

³⁴ The initial value 0000 will be displayed on the keypad as .

Code	Comm. Address	Name	Setting Range	Initial Value	Property *	V/F	SL	Ref.	
CM-02	0h1702	Built-in communication protocol	0	ModBus RTU	0: ModBus RTU	O	O	O	p.196
			2	LS Inv 485					
CM-03	0h1703	Built-in communication speed	0	1200 bps	3: 9600 bps	O	O	O	p.196
			1	2400 bps					
			2	4800 bps					
			3	9600 bps					
			4	19200 bps					
			5	38400 bps					
			6	56 Kbps					
			7	115 Kbps ³⁵					
CM-04	0h1704	Built-in communication frame setting	0	D8/PN/S1	0: D8/PN/S1	O	O	O	p.196
			1	D8/PN/S2					
			2	D8/PE/S1					
			3	D8/PO/S1					
CM-05	0h1705	Transmission delay after reception	0~1000(ms)	5ms	O	O	O	p.196	
CM-06 ³⁶	0h1706	Communication option S/W version	-	0.00	O	O	O	-	
CM-07 ³⁶	0h1707	Communication option inverter ID	0~255	1	O	O	O	-	
CM-08 ³⁶	0h1708	FIELD BUS communication speed	-	12Mbps	-	O	O	-	
CM-09 ³⁶	0h1709	Communication option LED status	-	-	O	O	O	-	
CM-30	0h171E	Number of output parameters	0~8	3	O	O	O	p.200	
CM-31	0h171F	Output communication address 1	0000-FFFF Hex	000A	O	O	O	p.200	

³⁵ 115200 bps

³⁶ Displayed only when a communication option card is installed.

Table of Functions

Code	Comm. Address	Name	Setting Range	Initial Value	Prop erty *	V/ F	SL	Ref.
CM-32	0h1720	Output communication address 2	0000-FFFF Hex	000E	O	O	O	p.200
CM-33	0h1721	Output communication address 3	0000-FFFF Hex	000F	O	O	O	p.200
CM-34	0h1722	Output communication address 4	0000-FFFF Hex	0000	O	O	O	p.200
CM-35	0h1723	Output communication address 5	0000-FFFF Hex	0000	O	O	O	p.200
CM-36	0h1724	Output communication address 6	0000-FFFF Hex	0000	O	O	O	p.200
CM-37	0h1725	Output communication address 7	0000-FFFF Hex	0000	O	O	O	p.200
CM-38	0h1726	Output communication address 8	0000-FFFF Hex	0000	O	O	O	p.200
CM-50	0h1732	Number of input parameters	0~8	2	O	O	O	p.200
CM-51	0h1733	Input communication address 1	0000-FFFF Hex	0005	X	O	O	p.200
CM-52	0h1734	Input communication address 2	0000-FFFF Hex	0006	X	O	O	p.200
CM-53	0h1735	Input communication address 3	0000-FFFF Hex	0000	X	O	O	p.200
CM-54	0h1736	Input communication address 4	0000-FFFF Hex	0000	X	O	O	p.200
CM-55	0h1737	Input communication address 5	0000-FFFF Hex	0000	X	O	O	p.200
CM-56	0h1738	Input communication address 6	0000-FFFF Hex	0000	X	O	O	p.200
CM-57	0h1739	Input communication address 7	0000-FFFF Hex	0000	X	O	O	p.200

Code	Comm. Address	Name	Setting Range	Initial Value	Property *	V/F	SL	Ref.	
CM-58	0h173A	Input communication address 8	0000-FFFF Hex	0000	X	O	O	p.200	
CM-68	0h1744	Field bus data swap	0	No	0	X	O	O	p.200
			1	Yes					
CM-70	0h1746	Communication multi-function input 1	0	None	0:None	O	O	O	p.217
CM-71	0h1747	Communication multi-function input 2	1	Fx	0:None	O	O	O	p.217
CM-72	0h1748	Communication multi-function input 3	2	Rx	0:None	O	O	O	p.217
CM-73	0h1749	Communication multi-function input 4	3	RST	0:None	O	O	O	p.217
CM-74	0h174A	Communication multi-function input 5	4	External Trip	0:None	O	O	O	p.217
CM-75	0h174B	Communication multi-function input 6	5	BX	0:None	O	O	O	p.217
CM-76	0h174C	Communication multi-function input 7	6	JOG	0:None	O	O	O	p.217
CM-77	0h174D	Communication multi-function input 8	7	Speed-L	0:None	O	O	O	p.217
			8	Speed-M					
			9	Speed-H					
			11	XCEL-L					
			12	XCEL-M					
			13	RUN Enable					
			14	3-Wire					
			15	2nd Source					
			16	Exchange					
			17	Up					
			18	Down					
			20	U/D Clear					
			21	Analog Hold					
22	I-Term Clear								
23	PID Openloop								
24	P Gain2								

Table of Functions

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.
			25 XCEL Stop					
			26 2nd Motor					
			27 U/D Enable					
			33 Baseblock					
			34 Pre Excite					
			38 Timer In					
			40 dis Aux Ref					
			46 FWD JOG					
			47 REV JOG					
			49 XCEL-H					
			51 Fire Mode					
			52 KEB-1 Select					
CM-86	0h1756	Communication multi-function input monitoring	-	0	X	O	O	p.198
CM-90	0h175A	Selection of data frame communication monitor	0 Int485 1 KeyPad	0	O	O	O	-
CM-91	0h175B	Data frame Rev count	0-65535	-	X	O	O	-
CM-92	0h175C	Data frame Err count	0-65535	-	X	O	O	-
CM-93	0h175D	NAK frame count	0-65535	-	X	O	O	-
CM-94 ³⁷	-	Communication data upload	0 No 1 Yes	0:No	X	O	O	-

8.9 Application Function Group (PAR→AP)

In the following table, data shaded in grey will be displayed when the related code has been selected.

SL: Sensorless vector control (dr.09), **Property:** Write-enabled during operation

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.
AP-00	-	Jump Code	1-99	20	O	O	O	p.42

³⁷ Displayed only when a communication option card is installed.

Code	Comm. Address	Name	Setting Range	Initial Value	Prop erty*	V/ F	SL	Ref.	
AP-01	0h1801	Application function selection	0	None	0: None	X	O	O	p.119
			1	-					
			2	Proc PID					
AP-16 ³⁸	0h1810	PID output monitor	(%)	0.00	-	O	O	p.119	
AP-17 ³⁸	0h1811	PID reference monitor	(%)	50.00	-	O	O	p.119	
AP-18 ³⁸	0h1812	PID feedback monitor	(%)	0.00	-	O	O	p.119	
AP-19 ³⁸	0h1813	PID reference setting	-100.00–100.00(%)	50.00	O	O	O	p.119	
AP-20 ³⁸	0h1814	PID reference source	0	Keypad	0: Keypad	X	O	O	p.119
			1	V1					
			3	V0					
			4	I2					
			5	Int 485					
			7	FieldBus					
AP-21 ³⁸	0h1815	PID feedback source	0	V1	0:V1	X	O	O	p.119
			2	V0					
			3	I2					
			4	Int 485					
			6	FieldBus					
AP-22 ³⁸	0h1816	PID controller proportional gain	0.0–1000.0(%)	50.0	O	O	O	p.119	
AP-23 ³⁸	0h1817	PID controller integral time	0.0–200.0(s)	10.0	O	O	O	p.119	
AP-24 ³⁸	0h1818	PID controller differentiation time	0–1000(ms)	0	O	O	O	p.119	
AP-25 ³⁸	0h1819	PID controller feed-forward compensation gain	0.0–1000.0(%)	0.0	O	O	O	p.119	
AP-26 ³⁸	0h181A	Proportional gain scale	0.0–100.0(%)	100.0	X	O	O	p.119	
AP-27 ³⁸	0h181B	PID output filter	0–10000(ms)	0	O	O	O	p.119	
AP-28 ³⁸	0h181C	PID Mode	0	Process PID	0	X	O	O	-
			1	Normal PID					

³⁸ Displayed when AP.01 is set to 2 (Proc PID).

Table of Functions

Code	Comm. Address	Name	Setting Range	Initial Value	Prop erty*	V/ F	SL	Ref.
AP-29 ³⁸	0h181D	PID upper limit frequency	PID lower limit frequency-300.00(Hz)	60.00	O	O	O	p.119
AP-30 ³⁸	0h181E	PID lower limit frequency	-300.00 -PID upper limit frequency(Hz)	-60.00	O	O	O	p.119
AP-32 ³⁸	0h1820	PID output scale	0.1–1000.0(%)	100.0	X	O	O	p.119
AP-33 ³⁸	0h181F	PID output inverse	0 No 1 Yes	0:No	X	O	O	p.119
AP-34 ³⁸	0h1822	PID controller motion frequency	0.00- Maximum frequency (Hz)	0.00	X	O	O	p.119
AP-35 ³⁸	0h1823	PID controller motion level	0.0–100.0(%)	0.0	X	O	O	p.119
AP-36 ³⁸	0h1824	PID controller motion delay time	0–9999(s)	600	O	O	O	p.119
AP-37 ³⁸	0h1825	PID sleep mode delay time	0.0–999.9(s)	60.0	O	O	O	p.119
AP-38 ³⁸	0h1826	PID sleep mode frequency	0.00- Maximum frequency (Hz)	0.00	O	O	O	p.119
AP-39 ³⁸	0h1827	PID wake-up level	0-100(%)	35	O	O	O	p.119
AP-40 ³⁸	0h1828	PID wake-up mode setting	0 Below Level 1 Above Level 2 Beyond Level	0:Below Level	O	O	O	p.119
AP-42 ³⁸	0h182A	PID controller unit selection	0 % 1 Bar 2 mBar 3 Pa 4 kPa 5 Hz 6 Rpm 7 V 8 I	0:%	O	O	O	p.119

Code	Comm. Address	Name	Setting Range	Initial Value	Prop erty*	V/ F	SL	Ref.
			9 kW					
			10 HP					
			11 °C					
			12 °F					
AP-43 ³⁸	0h182B	PID unit gain	0.00–300.00(%)	100.00	O	O	O	p.119
AP-44 ³⁸	0h182C	PID unit scale	0 x100	2:x 1	O	O	O	p.119
			1 x10					
			2 x 1					
			3 x 0.1					
			4 x 0.01					
AP-45 ³⁸	0h182D	PID 2nd proportional gain	0.0–1000.0(%)	100.0	X	O	O	p.119

8.10 Protection Function Group (PAR→Pr)

In the following table, data shaded in grey will be displayed when the related code has been selected.

SL: Sensorless vector control (dr.09), Property: Write-enabled during operation

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.
Pr-00	-	Jump Code	1–99	40	O	O	O	p.42
Pr-04	0h1B04	Load level setting	0 Normal Duty	1:Heavy Duty	X	O	O	p.169
			1 Heavy Duty					
Pr-05	0h1B05	Input/output open-phase protection	bit 00~11	00 ³⁹	X	O	O	p.174
			01 Output open phase					
			10 Input open phase					
Pr-06	0h1B06	Input voltage range during open-phase	1–100(V)	15	X	O	O	p.174

³⁹ The initial value 0000 will be displayed on the keypad as .

Table of Functions

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.
Pr-07	0h1B07	Deceleration time at fault trip	0.0–600.0(s)	3.0	○	○	○	-
Pr-08	0h1B08	Selection of startup on trip reset	0	No	0:No	○	○	○
			1	Yes				
Pr-09	0h1B09	Number of automatic restarts	0~10	0	○	○	○	p.143
Pr-10 ⁴⁰	0h1B0A	Automatic restart delay time	0.0–60.0(s)	1.0	○	○	○	p.143
Pr-12	0h1B0C	Motion at speed command loss	0	None	0:None	○	○	○
			1	Free-Run				
			2	Dec				
			3	Hold Input				
			4	Hold Output				
			5	Lost Preset				
Pr-13 ⁴¹	0h1B0D	Time to determine speed command loss	0.1–120(s)	1.0	○	○	○	p.177
Pr-14 ⁴¹	0h1B0E	Operation frequency at speed command loss	0, Start frequency-Maximum frequency(Hz)	0.00	○	○	○	p.177
Pr-15 ⁴¹	0h1B0F	Analog input loss decision level	0	Half of x1	0:Half of x1	○	○	○
			1	Below x1				
Pr-17	0h1B11	Overload warning selection	0	No	0:No	○	○	○
			1	Yes				
Pr-18	0h1B12	Overload warning level	30–180(%)	150	○	○	○	p.169
Pr-19	0h1B13	Overload warning time	0.0–30.0(s)	10.0	○	○	○	p.169

⁴⁰ Displayed when Pr.09 is set higher than 0.

⁴¹ Displayed when Pr.12 is not set to 0 (NONE).

Code	Comm. Address	Name	Setting Range		Initial Value	Property*	V/F	SL	Ref.
Pr-20	0h1B14	Motion at overload fault	0	None	1:Free-Run	0	0	0	p.169
			1	Free-Run					
			2	Dec					
Pr-21	0h1B15	Overload fault level	30–200(%)		180	0	0	0	p.169
Pr-22	0h1B16	Overload fault time	0.0–60.0(s)		60.0	0	0	0	p.169
Pr-25	0h1B19	Under load warning selection	0	No	0:No	0	0	0	p.181
			1	Yes					
Pr-26	0h1B1A	Under load warning time	0.0–600.0(s)		10.0	0	0	0	p.181
Pr-27	0h1B1B	Under load fault selection	0	None	0:None	0	0	0	p.181
			1	Free-Run					
			2	Dec					
Pr-28	0h1B1C	Under load fault time	0.0–600.0(s)		30.0	0	0	0	p.181
Pr-29	0h1B1D	Under load lower limit level	10–30(%)		30	0	0	0	p.181
Pr-30	0h1B1E	Under load upper limit level	30-100(%)		30	0	0	0	p.181
Pr-31	0h1B1F	No motor motion at detection	0	None	0:None	0	0	0	p.186
			1	Free-Run					
Pr-32	0h1B20	No motor detection current level	1-100(%)		5	0	0	0	p.186
Pr-33	0h1B21	No motor detection time	0.1–10.0(s)		3.0	0	0	0	p.186
Pr-40	0h1B28	Electronic thermal fault selection	0	None	0:None	0	0	0	p.167
			1	Free-Run					
			2	Dec					
Pr-41	0h1B29	Motor cooling fan type	0	Self-cool	0:Self-cool	0	0	0	p.167
			1	Forced-cool					
Pr-42	0h1B2A	Electronic thermal 1 minute rating	120–200(%)		150	0	0	0	p.167

Table of Functions

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.	
Pr-43	0h1B2B	Electronic thermal continuous rating	50–150(%)	120	O	O	O	p.167	
Pr-45	0h1B2D	BX trip mode	0	Free-Run	0	X	O	O	-
			1	Dec					
Pr-50	0h1B32	Stall prevention motion and flux braking	bit	0000–1111	0000	X	O	X	p.171
			0001	Accelerating					
			0010	At constant speed					
			0100	Decelerating					
			1000	FluxBraking					
Pr-51	0h1B33	Stall frequency 1	Start frequency-Stall frequency2(Hz)	60.00	O	O	X	p.171	
Pr-52	0h1B34	Stall level 1	30–250(%)	180	X	O	X	p.171	
Pr-53	0h1B35	Stall frequency 2	Start frequency1-Stall frequency2(Hz)	60.00	O	O	X	p.171	
Pr-54	0h1B36	Stall level 2	30–250(%)	180	X	O	X	p.171	
Pr-55	0h1B37	Stall frequency 3	Start frequency2-Stall frequency4(Hz)	60.00	O	O	X	p.171	
Pr-56	0h1B38	Stall level 3	30–250(%)	180	X	O	X	p.171	
Pr-57	0h1B39	Stall frequency 4	Stall frequency3-Maximum frequency(Hz)	60.00	O	O	X	p.171	
Pr-58	0h1B3A	Stall level 4	30–250(%)	180	X	O	X	p.171	
Pr-59	0h1B3B	Flux braking Gain value	0–150(%)	0	O	O	O	-	
Pr-66	0h1B42	DB resistor warning level	0–30(%)	10	O	O	O	p.179	
Pr-73	0h1B49	Speed deviation Error	0	No	0:No	O	O	O	
			1	Yes					
Pr-74 ⁴²	0h1B4A	Speed deviation band	1.0–20.0(Hz)	5.0 (Hz)	O	O	O		

⁴² Displayed when Pr.73 is set to 1(YES).

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.	
Pr-75 ⁴²	0h1B4B	Speed deviation time	0-120(s)	60(s)	O	O	O		
Pr-77	0h1B4D	Pre-overheat warning temperature	90-110	90	O	O	O	p.187	
Pr-78	0h1B4E	Pre-overheat warning operation selection	0	NONE	0	O	O	O	p.187
			1	Warning					
			2	Freerun					
			3	Dec					
Pr-79	0h1B4F	Cooling fan fault selection	0	Trip	1:Warning	O	O	O	p.182
			1	Warning					
Pr-80	0h1B50	Motion selection at option trip	0	None	1:Free-Run	O	O	O	p.185
			1	Free-Run					
			2	Dec					
Pr-81	0h1B51	Low voltage fault decision delay time	0.0-60.0(s)	0.0	X	O	O	p.183	
Pr-82	0h1B52	LV2 Selection	0	No	0	X	O	O	-
			1	Yes					
Pr-86	0h1B56	Accumulated percent of fan usage	0.0-100.0[%]	0.0	-	O	O	-	
Pr-87	0h1B57	Fan exchange warning level	0.0-100.0[%]	90.0	O	O	O	-	
Pr-88	0h1B58	Fan reset time	0	No	0	X	O	O	-
			1	Yes					
Pr-89	0h1B59	FAN Status	Bit	00-01	0	-	O	O	-
			00	-					
			01	FAN Exchange					
Pr-90	0h1B5A	Relay Open Trip selection	-	-	X	O	O	-	
Pr-91	0h1B5B	Fault history 1	-	-	-	O	O	-	
Pr-92	0h1B5C	Fault history 2	-	-	-	O	O	-	
Pr-93	0h1B5D	Fault history 3	-	-	-	O	O	-	
Pr-94	0h1B5E	Fault history 4	-	-	-	O	O	-	
Pr-95	0h1B5F	Fault history 5	-	-	-	O	O	-	
Pr-96	0h1B60	Fault history deletion	0	No	0:No	O	O	O	-
			1	Yes					

8.11 2nd Motor Function Group (PAR→M2)

The 2nd Motor function group will be displayed if any of In.65-71 is set to 26 (2nd MOTOR).

In the following table, data shaded in grey will be displayed when the related code has been selected.

SL: Sensorless vector control (dr.09), Property: Write-enabled during operation

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.	
M2-00	-	Jump Code	1-99	14	O	O	O	p.42	
M2-04	0h1C04	Acceleration time	0.0-600.0(s)	20.0	O	O	O	p.146	
M2-05	0h1C05	Deceleration time	0.0-600.0(s)	30.0	O	O	O	p.146	
M2-06	0h1C06	Motor capacity	0	0.2 kW	-	X	O	O	p.146
			1	0.4 kW					
			2	0.75 kW					
			3	1.1 kW					
			4	1.5 kW					
			5	2.2 kW					
			6	3.0 kW					
			7	3.7 kW					
			8	4.0 kW					
			9	5.5 kW					
			10	7.5 kW					
11	11.0kW								
M2-07	0h1C07	Base frequency	30.00-400.00 (Hz)	60.00	X	O	O	p.146	
M2-08	0h1C08	Control mode	0	V/F	0:V/F	X	O	O	p.146
			2	Slip Compen					
			4	IM Sensorless					
M2-10	0h1C0A	Number of motor poles	2~48	Dependent on motor setting	X	O	O	p.146	
M2-11	0h1C0B	Rated slip speed	0-3000(Rpm)		X	O	O	p.146	
M2-12	0h1C0C	Motor rated current	1.0-1000.0(A)		X	O	O	p.146	
M2-13	0h1C0D	Motor no-load current	0.5-1000.0(A)		X	O	O	p.146	
M2-14	0h1C0E	Motor rated voltage	170-480(V)		X	O	O	p.146	
M2-15	0h1C0F	Motor efficiency	64-100(%)		X	O	O	p.146	
M2-16	0h1C10	Load inertia rate	0~8		X	O	O	p.146	

Code	Comm. Address	Name	Setting Range	Initial Value	Prop erty*	V/ F	SL	Ref.	
M2-17	-	Stator resistance	Dependent on motor setting		X	O	O	p.146	
M2-18	-	Leakage inductance			X	O	O	p.146	
M2-19	-	Stator inductance			X	O	O	p.146	
M2-20 ⁴³	-	Rotor time constant			25-5000(ms)	X	O	O	p.146
M2-25	0h1C19	V/F pattern	0	Linear	0: Linear	X	O	O	p.146
			1	Square					
			2	User V/F					
M2-26	0h1C1A	Forward Torque boost	0.0–15.0(%)	2.0	X	O	O	p.146	
M2-27	0h1C1B	Reverse torque boost	0.0–15.0(%)		X	O	O	p.146	
M2-28	0h1C1C	Stall prevention level	30–150(%)	150	X	O	O	p.146	
M2-29	0h1C1D	Electronic thermal 1 minute rating	100–200(%)	150	X	O	O	p.146	
M2-30	0h1C1E	Electronic thermal continuous rating	50–Electronic thermal 1 minute rating	100	X	O	O	p.146	
M2-31	0h1C1F	Stator resistance scale	50–300(%)	Varies by Motor capacity	X	X	O	p.131	
M2-32	0h1C20	Stator leakage inductance scale	50–300(%)	Varies by Motor capacity	X	X	O	p.131	
M2-33	0h1C21	Stator inductance scale	50–300(%)	Varies by Motor capacity	X	X	O	p.131	
M2-34	0h1C12	Rotor time constant scale	50–300(%)	Varies by Motor capacity	X	X	O	p.131	
M2-35	0h1C13	No-Load Current Scale	50–300(%)	Varies by Motor Capacity	X	X	O	-	
M2-40	0h1C28	Rotation count speed gain	0.1–6000.0[%]	100.0	O	O	O	-	

⁴³ Displayed when M2.08 is set to 4(IM Sensorless).

Table of Functions

Code	Comm. Address	Name	Setting Range	Initial Value	Property*	V/F	SL	Ref.	
M2-41	0h1C29	Rotation count speed scale	0	x 1	0: x 1	0	0	0	-
			1	x 0.1					
			2	x 0.01					
			3	x 0.001					
			4	x 0.0001					
M2-42	0h1C2A	Rotation count speed unit	0	Rpm	0: rpm	0	0	0	-
			1	mpm					

9 Troubleshooting

This chapter explains how to troubleshoot a problem when inverter protective functions, fault trips, warning signals, or a fault occurs. If the inverter does not work normally after following the suggested troubleshooting steps, please contact the LSIS customer service center.

9.1 Trip and Warning

When the inverter detects a fault, it stops the operation (trips) or sends out a warning signal. When a trip or warning occurs, trip information and warning information will be briefly displayed on the keypad. Users can read the warning message at Pr.90. If two or more trips occur, the trip information with a higher priority will be displayed first on the keypad.

The fault conditions can be categorized as follows:

- Level: When the fault is corrected, the trip or warning signal disappears and the fault is not saved in the fault history.
- Latch: When the fault is corrected and a reset input signal is provided, the trip or warning signal disappears.
- Fatal: When the fault is corrected, the fault trip or warning signal disappears only after the user turns off the inverter, waits until the charge indicator light goes off, and turns the inverter on again. If the inverter is still in a fault condition after powering it on again, please contact the supplier or the LSIS customer service center.

9.1.1 Fault Trips

Protection Functions for Output Current and Input Voltage

Keypad Display	Name	Type	Description
	Over Load	Latch	Displayed when the motor overload trip is activated and the actual load level exceeds the set level. Operates when Pr.20 is set to a value other than 0.
	Under Load	Latch	Displayed when the motor underload trip is activated and the actual load level is less than the set level. Operates when Pr.27 is set to a value other than 0.
	Over Current1	Latch	Displayed when inverter output current exceeds 200% of the rated current.

Troubleshooting







Keypad Display	Name	Type	Description
	Over Voltage	Latch	Displayed when internal DC circuit voltage exceeds the specified value.
	Low Voltage	Level	Displayed when internal DC circuit voltage is less than the specified value.
	Low Voltage2	Latch	Displayed when internal DC circuit voltage is less than the specified value during inverter operation. Operates when Pr.82 is set to 1.
	Ground Trip*	Latch	Displayed when a ground fault trip occurs on the output side of the inverter and causes the current to exceed the specified value. The specified value varies depending on inverter capacity.
	E-Thermal	Latch	Displayed based on inverse time-limit thermal characteristics to prevent motor overheating. Operates when Pr.40 is set to a value other than 0.
	Out Phase Open	Latch	Displayed when a 3-phase inverter output has one or more phases in an open circuit condition. Operates when bit 1 of Pr.05 is set to 1.
	In Phase Open	Latch	Displayed when a 3-phase inverter input has one or more phases in an open circuit condition. Operates only when bit 2 of Pr.05 is set to 1.
	Inverter OLT	Latch	Displayed when the inverter has been protected from overload and resultant overheating, based on inverse time-limit thermal characteristics. Allowable overload rates for the inverter are 150% for 1 min and 200% for 4 sec. Protection is based on inverter rated capacity, and may vary depending on the device's capacity.
	No Motor Trip	Latch	Displayed when the motor is not connected during inverter operation. Operates when Pr.31 is set to 1.
	Relay Open Trip	Latch	Occurs when the DC voltage relay is not operating when power the is input. The Pr-90 code must be set to 1 to operate.
	Over torque trip1	Latch	Occurs when the output current is higher than the level set in Ou-68. Operates when OU-67 is set to 3, 4.
	Over torque trip2	Latch	Occurs when the output current is higher than the level set in OU-71. Operates when OU-70 is set to 3, 4.
	Under torque trip1	Latch	Occurs when the output current is lower than the level set in OU-68. Operates when OU-67 is set to 7, 8.
	Under torque trip2	Latch	Occurs when the output current is lower than the level set in OU-71. Operates when OU-70 is set to 7, 8.

*Ground Trip (GFT) feature is not provided in the products under 4.0 kW. Over current trip (OCT) or over voltage trip (OVT) may occur during low resistance grounding.

Protection Functions Using Abnormal Internal Circuit Conditions and External Signals

Keypad Display	Name	Type	Description
	Over Heat	Latch	Displayed when the temperature of the inverter heat sink exceeds the specified value.
	Over Current2	Latch	Displayed when the DC circuit in the inverter detects a specified level of excessive, short circuit current.
	External Trip	Latch	Displayed when an external fault signal is provided by the multi-function terminal. Set one of the multi-function input terminals at In.65-69 to 4 (External Trip) to enable external trip.
	BX	Level	Displayed when the inverter output is blocked by a signal provided from the multi-function terminal. Set one of the multi-function input terminals at In.65-69 to 5 (BX) to enable input block function.
	H/W-Diag	Fatal	Displayed when an error is detected in the memory (EEPROM), analog-digital converter output (ADC Off Set), or CPU watchdog (Watch Dog-1, Watch Dog-2). <ul style="list-style-type: none"> • EEP Err: An error in reading/writing parameters due to keypad or memory (EEPROM) fault. • ADC Off Set: An error in the current sensing circuit (U/V/W terminal, current sensor, etc.).
	NTC Open	Latch	Displayed when an error is detected in the temperature sensor of the Insulated Gate Bipolar Transistor (IGBT).
	Fan Trip	Latch	Displayed when an error is detected in the cooling fan. Set Pr.79 to 0 to activate fan trip (for models below 22kW capacity).
	Pre-PID Fail	Latch	Displayed when pre-PID is operating with functions set at AP.34–AP.36. A fault trip occurs when a controlled variable (PID feedback) is measured below the set value and the low feedback continues, as it is treated as a load fault.
	Ext-Brake	Latch	Operates when the external brake signal is provided by the multi-function terminal. Occurs when the inverter output starting current remains below the set value at Ad.41. Set either OU.31 or OU.32 to 35 (BR Control).
	Overheat Pre Alarm	Latch	When the user has set Pr-78 to 2: Free-Run or 3: Dec, pre-overheating warning trip of inverter occurs if the inverter temperature exceeds the temperature set by the user in Pr-77.

Protection Functions for Communication Options

Keypad Display	Name	Type	Description
	Lost Command	Level	Displayed when a frequency or operation command error is detected during inverter operation by controllers other than the keypad (e.g., using a terminal block and a communication mode). Operates when Pr.12 is set to a value other than 0.
 	IO Board Trip	Latch	Displayed when the I/O board or external communication card is not connected to the inverter or there is a bad connection.
			Displayed when the  error code continues for more than 5 sec. (‘Errc’ -> ‘-rrc’ -> ‘E-rc’ -> ‘Er-c’ -> ‘Err-’ -> ‘--rc’ -> ‘Er--’ -> ‘----’ -> ‘Errc’ -> ...)
	Option Trip-1	Latch	Displayed when a communication error is detected between the inverter and the communication board. Occurs when the communication option card is installed.

9.1.2 Warning Messages

Keypad Display	Name	Description
	Over Load	Displayed when the motor is overloaded. Operates when Pr.17 is set to 1. To operate, select 5. Set the digital output terminal or relay (OU.31 or OU.33) to 5 (Over Load) to receive overload warning output signals.
	Under Load	Displayed when the motor is underloaded. Operates when Pr.25 is set to 1. Set the digital output terminal or relay (OU.31 or OU.33) to 7 (Under Load) to receive underload warning output signals.
	INV Over Load	Displayed when the overload time equivalent to 60 % of the inverter overheat protection (inverter IOLT) level, is accumulated. Set the digital output terminal or relay (OU.31 or OU.33) to 6 (IOL) to receive inverter overload warning output signals.
	Lost Command	Lost command warning alarm occurs even with Pr.12 set to 0. The warning alarm occurs based on the condition set at Pr.13-15. Set the digital output terminal or relay (OU.31 or OU.33) to 13 (Lost Command) to receive lost command warning output signals. If the communication settings and status are not suitable for P2P, a Lost Command alarm occurs.
	Fan Exchange	An alarm occurs when the value set at PRT-86 is less than the value set at PRT-87. To receive fan exchange output signals, set the digital output terminal or relay (OUT-31 or OUT-33) to 38 (Fan Exchange).
	Fan Warning	Displayed when an error is detected from the cooling fan while Pr.79 is set to 1. Set the digital output terminal or relay (OU.31 or OU.33) to 8 (Fan Warning) to receive fan warning output signals.
	DB Warn %ED	Displayed when the DB resistor usage rate exceeds the set value. Set the detection level at Pr.66.
	Retry Tr Tune	Operates when dr.9 is set to 4. The warning alarm occurs when the motor's rotor time constant (Tr) is either too low or too high.
	Overheat Pre Alarm	When the user has set Pr-78 to 1: Warning, pre-overheating warning of inverter occurs if the inverter temperature exceeds the temperature set by the user in Pr-77.

9.2 Troubleshooting Fault Trips

When a fault trip or warning occurs due to a protection function, refer to the following table for possible causes and remedies.

Items	Cause	Remedy
OLT	The load is greater than the motor's rated capacity.	Replace the motor and inverter with models that have increased capacity.
	The set value for the overload trip level (Pr.21) is too low.	Increase the set value for the overload trip level.
ULT	There is a motor-load connection problem.	Replace the motor and inverter with models with lower capacity.
	The set value for underload level (Pr.29, Pr.30) is less than the system's minimum load.	Reduce the set value for the underload level.
OCT	Acc/Dec time is too short, compared to load inertia (GD2).	Increase Acc/Dec time.
	The inverter load is greater than the rated capacity.	Replace the inverter with a model that has increased capacity.
	The inverter supplied an output while the motor was idling.	Operate the inverter after the motor has stopped or use the speed search function (Cn.60).
	The mechanical brake of the motor is operating too fast.	Check the mechanical brake.
	A ground fault has occurred in the inverter output wiring.	Check the output wiring.
	The motor insulation is damaged.	Replace the motor.
OVT	Deceleration time is too short for the load inertia (GD2).	Increase the acceleration time.
	A generative load occurs at the inverter output.	Use the braking unit.
	The input voltage is too high.	Determine if the input voltage is above the specified value.
	A ground fault has occurred in the inverter output wiring.	Check the output wiring.
	The motor insulation is damaged.	Replace the motor.
LVT	The input voltage is too low.	Determine if the input voltage is below the specified value.
	A load greater than the power capacity is connected to the system (e.g., a welder, direct motor connection, etc.).	Increase the power capacity.
	The magnetic contactor connected to the power source has a faulty connection.	Replace the magnetic contactor.

Items	Cause	Remedy
LV2	The input voltage has decreased during operation.	Determine if the input voltage is below the specified value.
	An input open-phase has occurred when input voltage is low.	Check the input wiring.
	The magnetic contactor connected to the power source has a faulty connection.	Replace the magnetic contactor.
GFT	A ground fault has occurred in the inverter output wiring.	Check the output wiring.
	The motor insulation is damaged.	Replace the motor.
ETH	The motor has overheated.	Reduce the load or operation frequency.
	The inverter load is greater than the rated capacity.	Replace the inverter with a model that has increased capacity.
	The set value for electronic thermal protection is too low.	Set an appropriate electronic thermal level.
	The inverter has been operated at low speed for an extended duration.	Replace the motor with a model that supplies extra power to the cooling fan.
POT	The magnetic contactor on the output side has a connection fault.	Check the magnetic contactor on the output side.
	The output wiring is faulty.	Check the output wiring.
IPO	The magnetic contactor on the input side has a connection fault.	Check the magnetic contactor on the input side.
	The input wiring is faulty.	Check the input wiring.
	The DC link capacitor needs to be replaced.	Replace the DC link capacitor. Contact the retailer or the LSIS customer service center.
IOLT	The load is greater than the rated motor capacity.	Replace the motor and inverter with models that have increased capacity.
	The torque boost level is too high.	Reduce the torque boost level.
OHT	There is a problem with the cooling system.	Determine if a foreign object is obstructing the air inlet, outlet, or vent.
	The inverter cooling fan has been operated for an extended period.	Replace the cooling fan.
	The ambient temperature is too high.	Keep the ambient temperature below 50°C.

Items	Cause	Remedy
OC2	Output wiring is short-circuited.	Check the output wiring.
	There is a fault with the electronic semiconductor (IGBT).	Do not operate the inverter. Contact the retailer or the LSIS customer service center.
	A ground fault has occurred in the inverter output wiring.	Check the output wiring.
	The motor insulation is damaged.	Replace the motor.
NTC	The ambient temperature is too low.	Keep the ambient temperature above -10°C.
	There is a fault with the internal temperature sensor.	Contact the retailer or the LSIS customer service center.
FAN	A foreign object is obstructing the fan's air vent.	Remove the foreign object from the air inlet or outlet.
	The cooling fan needs to be replaced.	Replace the cooling fan.

9.3 Other Faults

When a fault other than those identified as fault trips or warnings occurs, refer to the following table for possible causes and remedies.

Items	Cause	Remedy
Parameters cannot be set.	The inverter is in operation (driving mode).	Stop the inverter to change to program mode and set the parameter.
	The parameter access is incorrect.	Check the correct parameter access level and set the parameter.
	The password is incorrect.	Check the password, disable the parameter lock and set the parameter.
	Low voltage is detected.	Check the power input to resolve the low voltage and set the parameter.
The motor does not rotate.	The frequency command source is set incorrectly.	Check the frequency command source setting.
	The operation command source is set incorrectly.	Check the operation command source setting.
	Power is not supplied to the terminal R/S/T.	Check the terminal connections R/S/T and U/V/W.
	The charge lamp is turned off.	Turn on the inverter.
	The operation command is off.	Turn on the operation command (RUN).
	The motor is locked.	Unlock the motor or lower the load level.

Items	Cause	Remedy
	The load is too high.	Operate the motor independently.
	An emergency stop signal is input.	Reset the emergency stop signal.
	The wiring for the control circuit terminal is incorrect.	Check the wiring for the control circuit terminal.
	The input option for the frequency command is incorrect.	Check the input option for the frequency command.
	The input voltage or current for the frequency command is incorrect.	Check the input voltage or current for the frequency command.
	The PNP/NPN mode is selected incorrectly.	Check the PNP/NPN mode setting.
	The frequency command value is too low.	Check the frequency command and input a value above the minimum frequency.
	The [STOP/RESET] key is pressed.	Check that the stoppage is normal, if so resume operation normally.
	Motor torque is too low.	Change the operation modes (V/F, IM, and Sensorless). If the fault remains, replace the inverter with a model with increased capacity.
The motor rotates in the opposite direction to the command.	The wiring for the motor output cable is incorrect.	Determine if the cable on the output side is wired correctly to the phase (U/V/W) of the motor.
	The signal connection between the control circuit terminal (forward/reverse rotation) of the inverter and the forward/reverse rotation signal on the control panel side is incorrect.	Check the forward/reverse rotation wiring.
The motor only rotates in one direction.	Reverse rotation prevention is selected.	Remove the reverse rotation prevention.
	The reverse rotation signal is not provided, even when a 3-wire sequence is selected.	Check the input signal associated with the 3-wire operation and adjust as necessary.
The motor is overheating.	The load is too high.	Reduce the load. Increase Acc/Dec time.
		Check the motor parameters and set the correct values.
		Replace the motor and the inverter with models with appropriate capacity for the load.
	The ambient temperature of the motor is too high.	Lower the ambient temperature of the motor.

Items	Cause	Remedy
	The phase-to-phase voltage of the motor is insufficient.	Use a motor that can withstand phase-to-phase voltages surges greater than the maximum surge voltage.
		Only use motors suitable for applications with inverters.
		Connect the AC reactor to the inverter output (set the carrier frequency to 2 kHz).
	The motor fan has stopped or the fan is obstructed with debris.	Check the motor fan and remove any foreign objects.
The motor stops during acceleration or when connected to load.	The load is too high.	Reduce the load.
		Replace the motor and the inverter with models with appropriate capacity for the load.
The motor does not accelerate. /The acceleration time is too long.	The frequency command value is low.	Set an appropriate value.
	The load is too high.	Reduce the load. Increase the acceleration time. Check the mechanical brake status.
	The acceleration time is too long.	Change the acceleration time.
	The combined values of the motor properties and the inverter parameter are incorrect.	Change the motor related parameters.
	The stall prevention level during acceleration is low.	Change the stall prevention level.
	The stall prevention level during operation is low.	Change the stall prevention level.
	Starting torque is insufficient.	Change to vector control operation mode. If the fault remains, replace the inverter with a model with increased capacity.
Motor speed varies during operation.	There is a high variance in load.	Replace the motor and inverter with models that have increased capacity.
	The input voltage varies.	Reduce input voltage variation.
	Motor speed variations occur at a specific frequency.	Adjust the output frequency to avoid a resonance area.
The motor rotation is different from the setting.	The V/F pattern is set incorrectly.	Set a V/F pattern that is suitable for the motor specification.

Items	Cause	Remedy
The motor deceleration time is too long even with Dynamic Braking (DB) resistor connected.	The deceleration time is set too long.	Change the setting accordingly.
	The motor torque is insufficient.	If motor parameters are normal, it is likely to be a motor capacity fault.
	Replace the motor with a model with increased capacity.	Replace the inverter with a model that has increased capacity.
Operation is difficult in underload applications.	The carrier frequency is too high.	Reduce the carrier frequency.
	Over-excitation has occurred due to an inaccurate V/F setting at low speed.	Reduce the torque boost value to avoid over-excitation.
While the inverter is in operation, a control unit malfunctions or noise occurs.	Noise occurs due to switching inside the inverter.	Change the carrier frequency to the minimum value.
		Install a micro surge filter in the inverter output.
When the inverter is operating, the earth leakage breaker is activated.	An earth leakage breaker will interrupt the supply if current flows to ground during inverter operation.	Connect the inverter to a ground terminal.
		Check that the ground resistance is less than 100Ω for 200V inverters and less than 10Ω for 400V inverters.
		Check the capacity of the earth leakage breaker and make the appropriate connection, based on the rated current of the inverter.
		Reduce the carrier frequency.
		Make the cable length between the inverter and the motor as short as possible.
The motor vibrates severely and does not rotate normally.	Phase-to-phase voltage of 3-phase power source is not balanced.	Check the input voltage and balance the voltage.
		Check and test the motor's insulation.

Items	Cause	Remedy
The motor makes humming, or loud noises.	Resonance occurs between the motor's natural frequency and the carrier frequency.	Slightly increase or decrease the carrier frequency.
	Resonance occurs between the motor's natural frequency and the inverter's output frequency.	Slightly increase or decrease the carrier frequency.
		Use the frequency jump function to avoid the frequency band where resonance occurs.
The motor vibrates/hunts.	The frequency input command is an external, analog command.	In situations of noise inflow on the analog input side that results in command interference, change the input filter time constant (In.07).
	The wiring length between the inverter and the motor is too long.	Ensure that the total cable length between the inverter and the motor is less than 200 m (50 m for motors rated 3.7 kW or lower).
The motor does not come to a complete stop when the inverter output stops.	It is difficult to decelerate sufficiently, because DC braking is not operating normally.	Adjust the DC braking parameter.
		Increase the set value for the DC braking current.
		Increase the set value for the DC braking stopping time.
The output frequency does not increase to the frequency reference.	The frequency reference is within the jump frequency range.	Set the frequency reference higher than the jump frequency range.
	The frequency reference is exceeding the upper limit of the frequency command.	Set the upper limit of the frequency command higher than the frequency reference.
	Because the load is too heavy, the stall prevention function is working.	Replace the inverter with a model that has increased capacity.
The cooling fan does not rotate.	The control parameter for the cooling fan is set incorrectly.	Check the control parameter setting for the cooling fan.

10 Maintenance

This chapter explains how to replace the cooling fan, the regular inspections to complete, and how to store and dispose of the product. An inverter is vulnerable to environmental conditions and faults also occur due to component wear and tear. To prevent breakdowns, please follow the maintenance recommendations in this section.

⚠ Caution

- Before you inspect the product, read all safety instructions contained in this manual.
- Before you clean the product, ensure that the power is off.
- Clean the inverter with a dry cloth. Cleaning with wet cloths, water, solvents, or detergents may result in electric shock or damage to the product.

10.1 Regular Inspection Lists

10.1.1 Daily Inspections

Inspection area	Inspection item	Inspection details	Inspection method	Judgment standard	Inspection equipment
All	Environmental factors	Is the ambient temperature and humidity within the design range, and is there any dust or foreign objects present?	Refer to 1.3 Installation Considerations on page 5 .	No icing (ambient temperature: -10 - +40) and no condensation (ambient humidity below 50 %)	Thermometer, hygrometer, recorder
	Inverter	Is there any abnormal vibration or noise?	Visual inspection	No abnormality	
	Power voltage	Are the input and output voltages normal?	Measure voltages between R/ S/ T-phases in. the inverter terminal block.	Refer to 11.1 input and Output Specification on page 279 .	Digital multimeter tester

Inspection area	Inspection item	Inspection details	Inspection method	Judgment standard	Inspection equipment
Input/Output circuit	Smoothing capacitor	Is there any leakage from the inside?	Visual inspection	No abnormality	-
		Is the capacitor swollen?			
Cooling system	Cooling Fan	Is there any abnormal vibration or noise?	Turn off the system and check operation by rotating the fan manually.	Fan rotates smoothly	-
Display	Measuring device	Is the display value normal?	Check the display value on the panel.	Check and manage specified values.	Voltmeter, ammeter, etc.
Motor	All	Is there any abnormal vibration or noise?	Visual inspection	No abnormality	-
		Is there any abnormal smell?	Check for overheating or damage.		

10.1.2 Annual Inspections

Inspection area	Inspection item	Inspection details	Inspection method	Judgment standard	Inspection equipment
Input/Output circuit	All	Megger test (between input/output terminals and earth terminal)	Disconnect inverter and short R/S/T/U/V/W terminals, and then measure from each terminal to the ground terminal using a Megger.	Must be above 5 MΩ	DC 500 V Megger
		Is there anything loose in the device?	Tighten up all screws.	No abnormality	

Inspection area	Inspection item	Inspection details	Inspection method	Judgment standard	Inspection equipment
		Is there any evidence of parts overheating?	Visual inspection		
	Connection conductor /cable	Are there any corroded cables?	Visual inspection	No abnormality	-
		Is there any damage to cable insulation?			
	Terminal block	Is there any damage?	Visual inspection	No abnormality	-
	Smoothing capacitor	Measure electrostatic capacity.	Measure with capacity meter.	Rated capacity over 85%	Capacity meter
	Relay	Is there any chattering noise during operation?	Visual inspection	No abnormality	-
		Is there any damage to the contacts?	Visual inspection		
Braking resistor	Is there any damage from resistance?	Visual inspection	No abnormality	Digital multimeter / analog tester	
	Check for disconnection	Disconnect one side and measure with a tester.	Must be within $\pm 10\%$ of the rated value of the resistor.		
Control circuit Protection circuit	Operation check	Check for output voltage imbalance while the inverter is in operation.	Measure voltage between the inverter output terminal U/ V/ W.	Balance the voltage between phases: within 4 V for 200 V series and within 8 V for 400 V series.	Digital multimeter or DC voltmeter
		Is there an error in the display circuit after the sequence protection test?	Test the inverter output protection in both short and open circuit conditions.	The circuit must work according to the sequence.	
Cooling system	Cooling Fan	Are any of the fan parts loose?	Check the connecting part of the connector.	No abnormality	-

Inspection area	Inspection item	Inspection details	Inspection method	Judgment standard	Inspection equipment
Display	Display device	Is the display value normal?	Check the command value on the display device.	Specified and managed values must match.	Voltmeter, ammeter, etc.

10.1.3 Bi-annual Inspections

Inspection area	Inspection item	Inspection details	Inspection method	Judgment standard	Inspection equipment
Motor	Insulation resistance	Megger test (between the input, output and earth terminals).	Disconnect the cables for terminals U/V/W and test the wiring.	Must be above 5 MΩ	DC 500 V Megger

⚠ Caution

Do not run an insulation resistance test (Megger) on the control circuit as it may result in damage to the product. This may cause damage to the inverter.

10.2 Storage and Disposal

10.2.1 Storage

If you are not using the product for an extended period, store it in the following way:

- Store the product in the same environmental conditions as specified for operation (refer to **1.3 Installation Considerations** on page 5).
- When storing the product for a period longer than 3 months, store it between -10 °C and 30 °C, to prevent depletion of the electrolytic capacitor.
- Do not expose the inverter to snow, rain, fog, or dust.
- Package the inverter in a way that prevents contact with moisture. Keep the moisture level below 70% in the package by including a desiccant, such as silica gel.
- Do not leave the inverter in a humid or dusty environment (e.g. Used as a device or control panel at a construction site). Disassemble the product and store in a place that is suitable for operation.

10.2.2 Disposal

When disposing of the product, categorize it as general industrial waste. The product contains materials that can be recycled. Please consider the environment, energy, and resources and recycle unused products. The packing materials and all metal parts can be recycled. Although plastic can also be recycled, it can be incinerated under controlled conditions in some regions.

⚠ Caution

If the product is left in a prolonged state without a flow of current, the condenser will deteriorate due to its characteristics. To prevent the deterioration of the electrolytic capacitor, turn on the power of inverter at least once a year to apply a current for 30–60 seconds. Run the device under no-load conditions.

11 Technical Specification

11.1 Input and Output Specification

3 Phase 200V (0.4-7.5 kW)

Model Name □ □ □ □ G100-2 □ □ □ □			0004	0008	0015	0022	0040	0055	0075	
Applied motor	Heavy load	HP	0.5	1.0	2.0	3.0	5.4	7.5	10	
		kW	0.4	0.75	1.5	2.2	4.0	5.5	7.5	
	Normal load	HP	1.0	2.0	3.0	5.4	7.5	10	15	
		kW	0.75	1.5	2.2	4.0	5.5	7.5	11	
Rated output	Rated capacity (kVA)	Heavy load	1.0	1.9	3.0	4.2	6.5	9.1	12.2	
		Normal load	1.2	2.3	3.8	4.6	6.9	11.4	15.2	
	Rated current [3-Phase input] (A)	Heavy load	2.5	5.0	8.0	11.0	17.0	24.0	32.0	
		Normal load	3.1	6.0	9.6	12.0	18.0	30.0	40.0	
	Output frequency		0-400Hz(IM Sensorless: 0-120Hz)							
	Output voltage (V)		3-phase 200-240 V							
Rated input	Working voltage (V)		3-phase 200-240 VAC (-15% to +10%) Single phase 240VAC (-5% to +10%)							
	Input frequency		50-60 Hz (±5 %)							
	Rated current [3-Phase input] (A)	Heavy load	2.2	4.9	8.4	11.8	18.5	25.8	34.9	
		Normal load	3.0	6.3	10.8	13.1	19.4	32.7	44.2	
Weight (lb /kg)			1.04	1.06	1.36	1.4	1.89	3.08	3.21	

- The standard motor capacity is based on a standard 4-pole motor.
- The standard used for 200 V inverters is based on a 220 V supply voltage, and for 400 V inverters is based on a 440 V supply voltage.
- The rated output current is limited based on the carrier frequency set at Cn.04.
- The output voltage becomes 20-40 % lower during no-load operations to protect the inverter from the impact of the motor closing and opening (0.4-4.0 kW models only).

3 Phase 400V (0.4-7.5 kW)

Model Name □ □ □ □ G100-4 □ □ □ □			0004	0008	0015	0022	0040	0055	0075	
Applied motor	Heavy load	HP	0.5	1.0	2.0	3.0	5.4	7.5	10	
		kW	0.4	0.75	1.5	2.2	4.0	5.5	7.5	
	Normal load	HP	1.0	2.0	3.0	5.4	7.5	10	15	
		kW	0.75	1.5	2.2	4.0	5.5	7.5	11	
Rated output	Rated capacity (kVA)	Heavy load	1.0	1.9	3.0	4.2	6.5	9.1	12.2	
		Normal load	1.5	2.4	3.9	5.3	7.6	12.2	17.5	
	Rated current [3-Phase input] (A)	Heavy load	1.3	2.5	4.0	5.5	9.0	12.0	16.0	
		Normal load	2.0	3.1	5.1	6.9	10.0	16.0	23.0	
	Output frequency		0-400Hz(IM Sensorless: 0-120Hz)							
	Output voltage (V)		3-phase 380-480 V							
Rated input	Working voltage (V)		3-phase 380-480VAC (-15% to +10%) Single phase 480VAC (-5% to +10%)							
	Input frequency		50-60 Hz (±5 %)							
	Rated current [3-Phase input] (A)	Heavy load	1.1	2.4	4.2	5.9	9.8	12.9	17.5	
		Normal load	2.0	3.3	5.5	7.5	10.8	17.5	25.4	
Weight (lb /kg) (Built-in EMC filter)			1.02 (1.04)	1.06 (1.08)	1.4 (1.44)	1.42 (1.46)	1.92 (1.98)	3.08 (3.24)	3.12 (3.28)	

- The standard motor capacity is based on a standard 4-pole motor.
- The standard used for 200 V inverters is based on a 220 V supply voltage, and for 400 V inverters is based on a 440 V supply voltage.
- The rated output current is limited based on the carrier frequency set at Cn.04.
- The output voltage becomes 20-40 % lower during no-load operations to protect the inverter from the impact of the motor closing and opening (0.4-4.0 kW models only).

11.2 Product Specification Details


Items		Description
Control	Control method	V/F control, slip compensation, sensorless vector
	Frequency settings power resolution	Digital command: 0.01Hz Analog command: 0.06 Hz(60 Hz standard)
	Frequency accuracy	1% of maximum output frequency
	V/F pattern	Linear, square reduction, user V/F
	Overload capacity	Heavy load rated current: 150%, 1 minute, Rated light load current: 120%, 1minute
	Torque boost	Manual torque boost, automatic torque boost
Run	Operation type	Select key pad, terminal strip, or communication operation
	Frequency setting	Analog type: -10-10 V, 0-10 V, 4-20 mA Digital type: key pad, pulse train input
	Operation function	<ul style="list-style-type: none"> • PID Control • 3-Wire Operation • Frequency limit • Frequency limit • Anti-forward and reverse direction rotation • Commercial transition • Speed search • Power braking • Up-down operation <ul style="list-style-type: none"> • DC braking • Frequency jump • Slip compensation • Automatic restart • Auto tuning • Energy buffering • Flux braking • Fire Mode
	Input	<p>Select PNP (Source) or NPN (Sink) mode. Functions can be set according to In.65- In.69 codes and parameter settings. (Standard I/O is only provided for P5.)</p> <ul style="list-style-type: none"> • Forward direction operation • Reset • Emergency stop • Multi step speed frequency-high/med/low • DC braking during stop • Frequency increase • 3-wire • Select acc/dec/stop <ul style="list-style-type: none"> • Reverse run • External trip • Jog operation • Multi step acc/dec-high/med/low • Second motor selection • Frequency reduction • Fix analog command frequency • Transition from PID to general operation

Items		Description
	Output	<p>Fault output and inverter operation status output</p> <p>Less than (N.O., N.C.) AC 250 V, 1 A, Less than DC 30 V, 1 A</p>
	Analog output	0–12Vdc: Select frequency, output current, output voltage, DC terminal voltage and others
Protection function	Trip	<ul style="list-style-type: none"> • Over current trip • External signal trip • ARM short current fault trip • Over heat trip • Input imaging trip • Ground trip • Motor over heat trip • I/O board link trip • No motor trip • Parameter writing trip • Emergency stop trip • Command loss trip • External memory error • CPU watchdog trip • Motor light load trip <ul style="list-style-type: none"> • Over voltage trip • Temperature sensor trip • Inverter over heat • Option trip • Output image trip • Inverter overload trip • Fan trip • Pre-PID operation failure • External brake trip • Low voltage trip during operation • Low voltage trip • Analog input error • Motor overload trip • Over torque trip • Under torque trip
	Alarm	Command loss trip warning, overload warning, light load warning, inverter overload warning, fan operation warning, braking resistance braking rate warning, rotor time constant tuning error, inverter pre-overheat warning, over torque warning, under torque warning
	Instantaneous blackout	<p>Heavy load less than 15 ms (normal load less than 8 ms): (must be within the rated input voltage and rated output range)</p> <p>Heavy load more than 15 ms (normal load more than 8 ms): auto restart operation</p>
Structure/ working environment	Cooling type	Forced fan cooling structure
	Protection structure	IP 20, UL Open Type (UL Enclosed Type 1 is satisfied by conduit installation option.)
	Ambient temperature	<p>Heavy load: - 10-50°C, Normal load: - 10-40°C</p> <p>No ice or frost should be present.</p> <p>Working under normal load at 50°C (122°F), it is recommended that less than 80 % load is applied.</p>
	Ambient humidity	Relative humidity less than 90% RH (to avoid condensation forming)

Items	Description
Storage temperature	-20 °C-65 °C
Environmental factors	Prevent contact with corrosive gases, inflammable gases, oil stains, dust, and other pollutants (Pollution Degree 2 Environment).
Operation altitude/oscillation	No higher than 3280 ft (1,000 m). Less than 9.8 m/sec ² (1G).
Air Pressure	70–106 kPa

11.3 External Dimensions



0.4–0.8kW



Items	W1	W2	H1	H2	H3	D1	A	B	Φ
0004G100-2, 0008G100-2, 0004G100-4, 0008G100-4	85 (3.35)	75 (2.95)	153 (6.02)	153 (6.02)	163 (6.42)	131.5 (5.18)	5 (0.20)	4.5 (0.18)	4.5 (0.18)

Units: mm(inches)



1.5-2.2kW



Items	W1	W2	H1	H2	H3	D1	A	B	Φ
0015G100-2, 0022G100-2, 0015G100-4, 0022G100-4,	100 (3.94)	90 (3.54)	167 (6.57)	167 (6.57)	177 (6.97)	150.5 (5.93)	5 (0.20)	4.5 (0.18)	4.5 (0.18)

Units: mm(inches)



4.0kW



Items	W1	W2	H1	H2	H3	D1	A	B	Φ
0040G100-2	135	125	183	183	193	150.5	5	5	4.5
0040G100-4	(5.31)	(4.92)	(7.20)	(7.20)	(7.60)	(5.93)	(0.20)	(0.20)	(0.18)

Units: mm(inches)

5.5-7.5kW



Items	W1	W2	H1	H2	H3	D1	A	B	Φ1
0055G100-2									
0075G100-2	180	162	220	229.5	240	144	5	5	5
0055G100-4	(7.09)	(6.37)	(8.66)	(9.04)	(9.45)	(5.67)	(0.20)	(0.20)	(0.20)
0075G100-4									

Units: mm(inches)

11.4 Peripheral Devices

Compatible Circuit Breaker, Leakage Breaker and Magnetic Contactor Models (manufactured by LSIS)

Capacity (kW)		Circuit Breaker			Leakage Breaker		Magnetic contactor			
		Model	Current (A)	Specific Model Name	Model	Current (A)	Model	Current (A)		
3-phase 200 V	0.4	UTE 100H	15	UTE100-H-FTU-15-3P-UL	EBS33c	5	MC-6a	9		
	0.75					10	MC-9a, MC-9b	11		
	1.5					15	MC-18a, MC-18b	18		
	2.2					20	UTE100-H-FTU-20-3P-UL	20	MC-22b	22
	4.0					30	UTE100-H-FTU-30-3P-UL	30	MC-32a	32
	5.5	UTS 150H	50	UTS150-H-FTU-50-3P-UL	EBS53c	50	MC-50a	55		
	7.5	60	UTS150-H-FTU-60-3P-UL	EBS63c	60	MC-65a	65			
3-phase 400 V	0.4	UTE 100E	15	UTE100-E-FTU-15-3P-UL	EBS33c	5	MC-6a	7		
	0.75						MC-6a			
	1.5					10	MC-9a, MC-9b	9		
	2.2						MC-12a, MC-12b	12		
	4.0					20	UTE100-E-FTU-20-3P-UL	20	MC-18a, MC-18b	18
	5.5					30	UTE100-E-FTU-30-3P-UL	30	MC-22b	22
	7.5								MC-32a	32

11.5 Fuse and Reactor Specifications

Capacity (kW)		AC Input Fuse			AC Reactor		DC Reactor	
		Model	Current (A)	Voltage (V)	Inductance (mH)	Current (A)	Inductance (mH)	Current (A)
3-phase 200 V	0.4	DFJ-10 ¹⁾	10	600	1.20	10	4	8.67
	0.75				0.88	14	3	13.05
	1.5	DFJ-15	15		0.56	20	1.33	18.45
	2.2	DFJ-20	20		0.39	30		26.35
	4.0	DFJ-30	30		0.30	34	1.60	32
	5.5	DFJ-50	50		0.22	45	1.25	43
	7.5	DFJ-60	60		4.81	4.8	16	4.27
3-phase 400 V	0.4	DFJ-10	10	3.23	7.5	12	6.41	
	0.75			2.34	10	8	8.9	
	1.5			DFJ-15	15	1.22	15	5.4
	2.2	DFJ-20	20	1.12	19	3.20	17	
	4.0	DFJ-30	30	0.78	27	2.50	25	
	5.5	DFJ-30	30					
	7.5	DFJ-35	35					

Note¹⁾ DFJ is Class J/600V level model name of the Bussmann company.

⚠ Caution

Use Class CC, G, J, L, R or T UL Listed Input Fuse and UL Listed Breaker Only. See the table above for the Voltage and Current rating of the fuse and the breaker.

⚠ Attention

Utiliser UNIQUEMENT des fusibles d'entrée homologués de Classe CC, G, J, L, R ou T UL et des disjoncteurs UL. Se reporter au tableau ci-dessus pour la tension et le courant nominal des fusibles et des disjoncteurs.

11.6 Terminal Screw Specification

Input/output Terminal Screw Specification

Capacity (kW)		Terminal Screw Size	Rated Screw Torque (Kgf·cm/Nm)
3-phase 200 V	0.4	R/S/T, U/V/W : M3	R/S/T, U/V/W : 5.1 / 0.5
	0.75		
	1.5	R/S/T, U/V/W : M4	R/S/T, U/V/W : 12.1 / 1.2
	2.2		
	4	R/S/T, U/V/W : M4	R/S/T, U/V/W : 18.4 / 1.8
	5.5	R/S/T : M5 U/V/W : M4 (Ground : M3)	R/S/T : 24.0 / 2.4 U/V/W : 15.0 / 1.5 (Ground : 5.1 / 0.5)
	7.5		
3-phase 400 V	0.4	R/S/T, U/V/W : M3.5	R/S/T, U/V/W : 10.3 / 1.0
	0.75		
	1.5		
	2.2		
	4	R/S/T, U/V/W : M4	R/S/T, U/V/W : 18.4 / 1.8
	5.5	R/S/T, U/V/W : M4 (Ground : M3)	R/S/T : 14.3 / 1.4 U/V/W : 18.4 / 1.8 (Ground : 5.1 / 0.5)
	7.5		

Control Circuit Terminal Screw Specification

Terminals	Terminal Screw Size	Screw Torque (Kgf·cm/Nm)
P1- P5/CM/VR/V1/I2/AO/24/S+/S-	M2	2.2-2.5/0.22-0.25
A1/B1/C1, A2/C2	M2.6	4.0/0.4

⚠ Caution

Apply rated torques to the terminal screws. Loose screws may cause short circuits and malfunctions. Tightening the screw too much may damage the terminals and cause short circuits and malfunctions. Use copper wires only with 600 V, 75 °C rating for the power terminal wiring, and 300 V, 75 °C rating for the control terminal wiring.

⚠ Attention

Appliquer des couples de marche aux vis des bornes. Des vis desserrées peuvent provoquer des courts-circuits et des dysfonctionnements. Ne pas trop serrer la vis, car cela risque d'endommager les bornes et de provoquer des courts-circuits et des dysfonctionnements. Utiliser uniquement des fils de cuivre avec une valeur nominale de 600 V, 75 °C pour le câblage de la borne d'alimentation, et une valeur nominale de 300 V, 75 °C pour le câblage de la borne de commande.

11.7 Braking Resistor Specification

	Capacity (kW)	Resistance (Ω)	Rated Capacity (W)
3-phase 200 V	0.4	300	100
	0.75	150	150
	1.5	60	300
	2.2	50	400
	3.7	33	600
	4	33	600
	5.5	20	800
	7.5	15	1,200
3-phase 400 V	0.4	1,200	100
	0.75	600	150
	1.5	300	300
	2.2	200	400
	3.7	130	600
	4	130	600
	5.5	85	1,000
	7.5	60	1,200


- The standard for braking torque is 150 % and the working rate (%ED) is 5 %. If the working rate is 10 %, the rated capacity for braking resistance must be calculated at twice the standard.

11.8 Continuous Rated Current Derating

Carrier Frequency


The continuous rated current of the inverter is limited based on the carrier frequency. Refer to the following graph.

Continuous rated current for heavy load



200V		400V	
Carrier frequency (kHz)	Continuous rated current	Carrier frequency (kHz)	Continuous rated current
1~6	100	1~6	100
9	84.4	9	81.1
12	76.7	12	71.7
15	72.0	15	66.0



Continuous rated current for light load



200V		400V	
Capacity (kW)	DR(%)	Capacity (kW)	DR(%)
0.4	88	0.4	74
0.75	88	0.75	86
1.5	88	1.5	84
2.2	94	2.2	85
4.0	96	4.0	93
5.5	85	5.5	81
7.5	85	7.5	77


Input Voltage

The continuous rated current of the inverter is limited based on the input voltage. Refer to the following graph.




Ambient Temperature/Installation Method

The constant-rated current of the inverter is limited based on the ambient temperature and installation type. Refer to the following graph.



11.9 Heat Emission


The following graph shows the inverters' heat emission characteristics (by product capacity).



Heat emission has been measured based on the room temperature when the carrier frequency of inverter is set as default. For more information on carrier frequency, refer to **5.15 Operational Noise Settings (Change of Carrier Frequency Settings)** on page **144**.

11.10 Remote Keypad Option

It is comprised of a remote keypad and cables (1 m, 2 m, 3 m, 5 m).



Units: mm

Installation

- 1 Remove the RJ45 terminal cover on the inverter I/O cover. Connect the remote keypad cable to the I/O RJ45 connector.
- 2 Connect the other end of the connector of the remote keypad cable to the remote keypad.

Enable

- 1 Once connected to the remote keypad, the key of the inverter keypad and the button input of the jog controller are ignored. The input is replaced by the key and volume input from the remote keypad.
 - Within 2 seconds of detaching the remote keypad, the input for the key and volume is reset to the inverter keypad. (If the frequency setting is set to volume input, the command frequency will instantly switch between the inverter keypad volume and the remote keypad volume when attaching and detaching. Take care so that the motor does not switch to the wrong frequency.)
 - If communication is not linked between the inverter and the remote keypad, "E.vEr" is displayed on the 7-Seg of the remote keypad.

- 2 The parameter setting saved in the inverter can be copied to the remote keypad by setting the dr 91 parameter to 4 while the remote keypad is connected.
 - During the process, "r-UL" is displayed on the 7-Seg of the remote keypad. Once the parameter setting is saved, the message is removed and the default screen is displayed.
 - If there is an error, such as bad communication, while the upload is processing, the warning message "E.vEr" is displayed for 3 seconds. Also, the action of saving the parameter to the remote keypad is failed.

- 3 Connect the remote with the copied parameter settings to the inverter of the same product model. Then, set the dr 91 parameter to 5 to copy the saved parameter settings to the inverter.
 - During the save process, "W-dL" is displayed on the 7-Seg. Once the parameter setting is saved, the message is removed and the default screen is displayed.
 - If the version of the parameter code is wrong or there is an error, such as a bad communication error, the warning message "E.vEr" is displayed for 3 seconds. Also, the action of saving the parameter to the inverter is failed.

Product Warranty

Warranty Information

Fill in this warranty information form and keep this page for future reference or when warranty service may be required. Fill in this warranty information form and keep this page for future reference or when warranty service may be required.

Product Name	LSIS Standard Inverter		Date of Installation	
Model Name	LSLV-G100		Warranty Period	
Customer Info	Name (or company)			
	Address			
	Contact Info.			
Retailer Info	Name (or company)			
	Address			
	Contact Info.			

Warranty Period

The product warranty covers product malfunctions, under normal operating conditions, for 12 months from the date of installation. If the date of installation is unknown, the product warranty is valid for 18 months from the date of manufacturing. Please note that the product warranty terms may vary depending on purchase or installation contracts.

Warranty Service Information

During the product warranty period, warranty service (free of charge) is provided for product malfunctions caused under normal operating conditions. For warranty service, contact an official LSIS agent or service center.

Non-Warranty Service

A service fee will be incurred for malfunctions in the following cases:

- intentional abuse or negligence
- power supply problems or from other appliances being connected to the product
- acts of nature (fire, flood, earthquake, gas accidents etc.)
- modifications or repair by unauthorized persons
- missing authentic LSIS rating plates
- expired warranty period

Visit Our Website

Visit us at <http://www.lsis.com> for detailed service information.

UL mark

The UL mark applies to products in the United States and Canada. This mark indicates that UL has tested and evaluated the products and determined that the products satisfy the UL standards for product safety. If a product received UL certification, this means that all components inside the product had been certified for UL standards as well.

Suitable for Installation in a compartment Handling Conditioned Air

CE mark

The CE mark indicates that the products carrying this mark comply with European safety and environmental regulations. European standards include the Machinery Directive for machine manufacturers, the Low Voltage Directive for electronics manufacturers and the EMC guidelines for safe noise control.

Low Voltage Directive

We have confirmed that our products comply with the Low Voltage Directive (EN 61800-5-1).

EMC Directive

The Directive defines the requirements for immunity and emissions of electrical equipment used within the European Union. The EMC product standard (EN 61800-3) covers requirements stated for drives.

EAC mark

The EAC (EurAsian Conformity) mark is applied to the products before they are placed on the market of the Eurasian Customs Union member states.

It indicates the compliance of the products with the following technical regulations and requirements of the Eurasian Customs Union:

Technical Regulations of the Customs Union 004/2011 "On safety of low voltage equipment"

Technical Regulations of the Customs Union 020/2011 "On electromagnetic compatibility of technical products"

Manual Revision History

Revision History

No	Date	Edition	Changes
1	2019.01	First Release	-

Index

0	
0 – +10 V voltage input.....	61
1	
-10 – +10 V voltage input.....	65
2	
24 terminal.....	25, 28
2nd Motor Function group.....	Refer to M2 (2nd Motor function group)
2nd Motor Operation.....	146
2nd Operation mode.....	98
2nd command source.....	98
Shared command (Main Source).....	98
3	
3 Phase 200V (0.4-4 kW).....	279
3 Phase 400V (0.4-4 kW).....	280
3-Wire Operation.....	113
7	
7-segment display.....	38
A	
A terminal (Normal Open).....	99
A1/C1/B1 terminal.....	25
AC power input terminal.....	Refer to R/S/T terminal
Acc/Dec pattern.....	58, 82
linear pattern.....	82
S-curve pattern.....	82
Acc/Dec reference.....	77, 78
Delta Freq.....	77
Max Freq.....	77
Acc/Dec stop.....	84
Acc/Dec time.....	77
Acc/Dec time switch frequency.....	81
configuration via multi-function terminal.....	79
Maximum frequency.....	77
operation frequency.....	78
Ad (Advanced function group).....	40, 229
Advanced feature group.....	Refer to AP (Advanced function group)
Advanced function group.....	Refer to Ad (Advanced function group)
analog frequency hold.....	69
Analog Hold.....	69
Analog Hold.....	Refer to analog frequency hold
Analog input.....	24, 40
I2 current input.....	67
V1 voltage input.....	61
Analog output.....	25, 40, 157
AO terminal.....	25
voltage and current output.....	157
AO terminal.....	25, 75, 157
AP (Advanced function group).....	40, 250
ARM short current fault trip.....	Refer to Over Current2
ASCII Code.....	205
Asymmetric ground power.....	30
EMC filter.....	30
asynchronous communications system.....	193
auto restart settings.....	143
Auto torque boost	
Auto tuning.....	126
Auto tuning.....	126, 227
All (Rotation type).....	127
All (static).....	127
default parameter setting.....	127
Tr (Static type).....	127
Automatic restart after reset of a fault trip	
condition.....	76
auxiliary frequency.....	105
auxiliary frequency reference	
configuration.....	105
auxiliary reference.....	105
auxiliary reference gain.....	106
Configuration.....	105
final command frequency calculation.....	107

main reference.....105

B

B terminal (Normal Close)99
bA (Basic function group) 40, 225
Basic configuration diagram12
Basic group ...Refer to bA (Basic function group)
Basic operations.....37
Bipolar.....25, 65
Bit99
 bit setting100
 Bit setting Off Status.....100
 Bit Setting On Status100
 multi-function input setting..... 99
 multi-function output setting.....164
 speed search Setting140
 stall prevention.....171
brake control.....153
 BR Control.....153
 brake engage sequence.....153
 brake release sequence.....153
Brake unit..... 12, 155
braking resistance.....21
 braking resistor circuit.....179
 Braking Resistor Specification.....290
 braking torque.....290
 DB Warn %ED.....179
broadcasting.....202
built-in communicationRefer to RS-485
BX.....263

C

Cable.....10
 Copper cable..... 10
 Ground Cable Specifications..... 10
 Power I/O Cable Specifications 10
 Shielded twisted pair 33
 Signal (Control) Cable Specifications.... 10
cable tie.....27
Carrier frequency..... 21, 144
 derating.....291
 Factory default output.....145
Charge indicator 16, 261, 268
Cleaning273

CM (Communication function group).....40, 246
CM terminal24, 28, 48
commercial power source transition.....147
Communication193
 Comm. Address..... 206
 command loss protective operation .. 198
 communication line connection 195
 communication parameters 196
 Communication speed..... 196
 communication standards..... 193
 communication system diagram 195
 Memory Map..... 199
 PLC 193
 protocol 200
 saving parameters defined by
 communication 199
 setting virtual multi-function input ... 198
Communication function group...Refer to COM
 (Communication function group)
compatible common area parameter209
CON (Control function group)40, 235
Control groupRefer to CON (Control function
 group)
Control terminal board wiring 23
Cooling Fan148
 cooling fan malfunction 182
 Fan control..... 148
Crimp terminal connector..... 10, 26
customer service center261

D

DC braking after start..... 91
DC braking after stop..... 93
DC braking frequency 93
DC link voltage..... 103, 135
Delta wiring..... 30
derating..... 145, 291
Digital Output.....159
Disposal.....273, 277
Dr (Drive group).....40, 222
draw operation103
Drive Group.....Refer to dr (Drive group)
Dwell Operation115
 Acc/Dec dwell frequency 115
 acceleration Dwell 115

deceleration Dwell..... 115

E

electronic thermal motor overheating
prevention (ETH)..... 167
ETH trip..... 167
EMC filter..... 30
Asymmetric power..... 30
Disable..... 30
Enable..... 31
Emergency stop trip..... Refer to BX
Enclosed Type 1..... 282
Energy buffering..... 135
Energy saving operation..... 138
automatic energy saving operation 138
manual energy saving operation 138
error code..... 204
FE(frame error)..... 204
IA(illegal data address)..... 204
ID(illegal data value)..... 204
IF(illegal function)..... 204
WM(write mode error)..... 204
ESC key..... 39
Cancel input..... 39
ETH..... Refer to electronic thermal motor
overheating prevention (ETH)
Excitation Current..... 131
External 24V power source. Refer to 24 terminal
External dimensions
0.8–1.5kW(Single Phase), 1.5–2.2kW(3
Phase)..... 284
2.2kW(Single Phase), 3.7-4.0kW(3 Phase)
..... 285
5.5-22kW(3-Phase)..... 286
External trip..... Refer to External Trip
External Trip..... 175, 263
external trip signal..... 175

F

Factory default output..... 48, 49
Fan trip..... Refer to Fan Trip
Fan Trip..... 182, 263
Fan Warning..... 182, 265, Refer to Fan Warning
fatal..... 261

fault..... 190
fatal..... 261
fault/warning list..... 190
latch..... 261
Level type..... 261
major fault..... 190
minor fault..... 191
trip..... 261
warning..... 191, 265
Fault signal output terminal...Refer to A1/C1/B1
terminal
FE(frame error)..... 204
Ferrite..... 27
Fieldbus..... 60, 72, Refer to Fieldbus
Communication option 98
Flux braking..... 171
Free-run stop..... 94
Frequency jump..... 97
Frequency limit..... 95
Frequency jump..... 97
Frequency upper and lower limit value 96
Maximum/start frequency..... 95
Frequency setting..... 60
I2 current input 67
Keypad 60, 61
RS-485..... 69
V1 voltage input 61
Frequency setting (voltage) terminal..... Refer to
V1 terminal

G

Ground..... 18
Class 3 ground..... 18
Ground Cable Specifications 10
Ground Terminal 18
Special class 3 ground..... 18
Ground trip..... Refer to Ground Trip
Ground Trip 262
ground fault trip..... 262

H

half duplex system..... 193
Heavy load..... 5, 145

I	
I2 terminal.....	25, 67
Voltage/current input for frequency reference input.....	25
IA(illegal data address).....	204
ID(illegal data value).....	204
IF(illegal function).....	204
IN (Input terminal function group).....	40, 239
In Phase Open.....	262
Input open-phase protection	175
Initial excitation time.....	131
input and output specification.....	279
Input imaging trip.....	Refer to In Phase Open
input power frequency.....	149
Input power voltage	149
Input terminal	24
CM terminal	24
I2 terminal	25
P1–P7 terminal	24
V1 terminal.....	25
VR terminal.....	24
Input terminal function groupRefer to IN (Input terminal function group)	
Input/output open-phase protection	174
Inrush current.....	12
Inspections	
annual Inspections.....	274
bi-annual Inspections.....	276
Daily inspections.....	273
Installation.....	11
Basic configuration diagram	12
Installation Flowchart	11
Mounting the Inverter	13
Selecting location.....	6
Wiring.....	16
Installation Environment.....	5
Air Pressure.....	5
Ambient humidity	5
Ambient temperature.....	5
Environmental factors.....	5
Operation altitude/oscillation	5
Instantaneous blackout	135, 140, 142
inverse time-limit thermal characteristics..	262
Inverter Overload Protection	176
IP 20.....	282

J	
Jog operation.....	109
Jog Frequency.....	109
Jump Code	42
jump frequency.....	97

K	
Keypad.....	37
Display.....	37
Operation key	37
Keypad display.....	38
Keypad key	39
[ESC] key.....	39
[RUN] key.....	39
[STOP/RESET] key.....	39

L	
latch	261
LCD loader	17
Leakage Breaker.....	271, 287
Level.....	13
Level type.....	261
Lifetime diagnosis of components	183
lifetime diagnosis for fans.....	183
lift-type load	82, 88, 115
linear pattern.....	82
Linear V/F pattern operation	84
Base frequency.....	85
Start frequency.....	85
Lost Command.....	264, 265
command loss fault trip warning.....	191
Command loss trip	190
Low Voltage.....	183, 262
Low voltage trip.....	183, 190
low voltage trip 2.....	186, 187
LS INV 485 protocol.....	200

M	
M2 (2nd Motor function group)	40, 258
Magnetic contactor.....	22, 287
Maintenance	273
manual torque boost.....	88

Master.....	195
megger test.....	274, 276
Micro surge filter.....	21
Modbus-RTU Protocol.....	206, Refer to Modbus-RTU Protocol
monitor.....	53
Monitor Registration Detailed Protocol.....	203
Motor output voltage adjustment.....	90
motor protection.....	167
Motor rotational direction.....	34
mounting bolts.....	13
Mounting bracket.....	14
multi-drop Link System.....	193
Multi-function (open collector) output terminal	
Multi-function output item1(Q1 Define).....	245
multi-function output on/off control..	154
multi-function output terminal and relay settings.....	159
multi-function output terminal delay time settings.....	164
Multi-function relay 1 item(Relay 1)....	244
trip output by multi-function output terminal and relay.....	163
Multi-function input terminal.....	24
Control.....	99
Factory default output.....	24
In.65-71.....	241
Multi-function input terminal Off filter	99
Multi-function input terminal On filter.	99
Px terminal setting options.....	241
Multi-function key.....	38
multi-function output	
multi-function output terminal delay time settings.....	164
trip output by multi-function output terminal and relay.....	163
Multi-step speed frequency.....	70
Configuration.....	70
Speed-L/Speed-M/Speed-H.....	71

N

No motor trip.....	Refer to no motor trip
No Motor Trip.....	186, 262

No. of time constant filter.....	62, 99
Noise.....	30, 63
Low-pass filter.....	62
Normal load.....	5, 145
NPN mode (Sink).....	29

O

Operation command.....	72
Configuration.....	72
fwd/rev command terminal.....	72
Keypad.....	72
RS-485.....	74
run command/rotational direction configuration.....	73
Operation frequencyRefer to frequency setting	
Operation Group.....	40, 221
Operation noise.....	144, 293
Carrier frequency.....	144
Frequency jump.....	97
Option trip.....	Refer to Option Trip-x
Option Trip-x	
Option trip.....	185, 190
OUT (output terminal function group)....	40, 243
Out Phase Open.....	262
output block by multi-function terminal.....	184
Output image trip.....	Refer to Out Phase Open
Output terminal.....	Refer to R/S/T terminal
Output terminal function group....	Refer to OUT (output terminal function group)
Output/communication terminal.....	25
24 terminal.....	25
A1/C1/B1 terminal.....	25
AO terminal.....	25
S+/S-/SG terminal.....	25
Over current trip.....	Refer to Over Current1
Over Current1.....	261
Over Current2.....	263
Over Heat.....	263
Over heat trip.....	Refer to Over Heat
Over Load.....	261
overload trip.....	169, 191
overload warning.....	169, 191, 265
Over Voltage.....	262
Over voltage trip.....	Refer to Over Voltage
overload rate.....	145

overload trip.....Refer to Over Load
 overload warning.....Refer to Over Load

P

P/I gain..... 142
 P1–P7Multi-function Input
 parameter
 Changed parameter display 152
 initialization 150
 parameter lock..... 151
 password..... 151
 Table of Functions..... 221
 part names..... 3
 parts illustrated..... 3
 password..... 151, 219
 peripheral devices..... 287
 phase-to-phase voltage..... 270
 PID Control..... 118
 Basic PID operation 119
 Configuration 118
 differential time..... 121
 integral time 121
 oscillation 121
 P-gain 121
 PID feedback 263
 PID Operation Sleep mode 124
 PID output 120
 PID reference..... 120
 PID Switching 125
 Pre-PID Fail..... 124
 Pre-PID Operation 124
 PLC..... 193
 PNP mode (Source)..... 28
 PNP/NPN mode selection switch (SW1)..... 23
 NPN mode (Sink)..... 29
 PNP mode (Source)..... 28
 Post-installation checklist..... 32
 Potentiometer..... 24, 49, 61
 Power resolution 63
 Power terminal board wiring..... 19
 Power Terminal Wiring See power terminals
 Power terminals..... 21
 R/S/T terminals 21
 U/V/W terminal..... 21
 Power-on Run Refer to start at power-on

Pr (Protection function group)..... 40, 253
 press regeneration prevention..... 155
 P gain/I gain 156
 Protection feature group Refer to Pr (Protection
 function group)
 protocol..... 200
 LS INV 485 protocol..... 200
 Modbus-RTU Protocol..... 206
 PWM..... 144
 PWM
 frequency modulation 144

Q

Quantizing..... 63, Refer to Quantizing
 Noise 63

R

R/S/T terminals..... 21, 22, 268
 Rated..... 279
 braking resistance rated capacity 290
 derating 291
 Motor rated current..... 117
 Motor rated voltage..... 126
 Rated input..... 279
 Rated output..... 279
 rated slip frequency 117
 Rated slip speed..... 117
 rated torque current 157
 rating plate 1
 Reactor..... 12, 288
 Regenerated energy..... 94, 135, 171
 Reset Restart..... Refer to restarting after a trip
 resonance frequencies 97
 Carrier frequency..... 144
 Frequency jump..... 97
 Ripple..... 63
 RS-232 195
 Communication..... 195
 converter 195
 RS-485 193
 built-in communication..... 69
 Communication..... 195
 converter 195
 Signal terminal 25, 69

RS-485 signal input terminal...Refer to S+/S-/SG terminal	
run prevention	
Fwd	75
Rev.....	75

S

S+/S-/SG terminal	25
S100 expansion common area parameter ...	212
control area parameter (Read/ Write) .	217
memory control area parameter (Read and Write)	219
Monitoring Area Parameter (Read Only)	212
Safe Operation mode.....	114
Safety Information.....	ii
screw specification.....	289
control circuit terminal screw	289
input/output terminal screw	
specification	289
screw size.....	289
screw torque.....	289
S-curve pattern.....	82
Calculation method for actual acc/dec time.....	83
Selecting the installation site.....	6
Side by side.....	8
sensorless vector control.....	129
Configuration.....	130
Hold Time	132
IM Sensorless.....	130
Initial excitation time	131
sensorless vector control operation	
guide	133
Sequence common terminal..... Refer to CM terminal	
SET indicator	38
setting virtual multi-function input.....	198
Side by side.....	8, 293, See side by side
Slave.....	195
Slip	117
slip compensation operation.....	117
speed command loss	177
speed search operation.....	139
Flying Start-1	139

Flying Start-2.....	139
options	140
P/I gain	142
Square reduction.....	58
Square reduction load.....	85
V/F pattern operation.....	85
stall.....	171
stall bit on/off	171
stall prevention.....	171
standard 4-pole motor	279, 280
start at power-on.....	75
Start Mode.....	90
Accelerating start.....	90
DC braking after start	91
Station ID.....	206
Stop Mode.....	92
DC braking after stop.....	93
Deceleration stop.....	92
Free-run stop	94
Power braking.....	94
storage.....	276
Storage temperature.....	5
Surge killer	22, 32
SW1 ...Refer to PNP/NPN mode selection switch (SW1), Refer to PNP/NPN mode selection switch (SW1)	
SW2.....Refer to analog input selection switch (SW2)	
Switch.....	23
PNP/NPN mode selection switch (SW1)23	

T

Target frequency.....	60, 90
Technical Specification.....	279
specification details.....	281
terminal.....	99
A terminal.....	99, 165, 176
B terminal	99, 165, 176
Terminal for frequency reference setting... Refer to VR terminal	
Test run	34
Time scale setting.....	77
0.01sec.....	78
0.1sec	78
1sec.....	78

Timer.....	152, 161
Torque.....	16, 21
Torque boost.....	88
manual torque boost	88
Over-excitation.....	88
trip.....	261
fault trips.....	261
fault/warning list.....	190
trip condition monitor.....	54
trip status reset.....	184
Troubleshooting Fault Trips.....	266
troubleshooting.....	261
other faults.....	268
Troubleshooting Fault Trips.....	266

U

U/V/W terminal	21, 22, 268
Under Load	
under load trip.....	181, 191, 261
under load warning	181, 191, 265
under load trip.....	Refer to Under Load
Unipolar.....	25
update	203
Up-Down Operation	111
User V/F pattern Operation.....	86
Using the keypad.....	40
groups/codes.....	41
Jump Code.....	42

V

V/F control.....	84
------------------	----

Linear V/F pattern operation	84
square reduction V/F pattern operation	85
User V/F pattern Operation.....	86
V1 terminal.....	25, 61
Variable torque load	86, 137
voltage drop.....	21
Voltage Drop.....	10
Voltage/current output terminal	Refer to AO terminal
VR terminal.....	24, 61

W

warning.....	261
fault/warning list.....	190
warning messages.....	265
Wiring.....	16
3 core cables	21
Circuit Breaker	287
Control terminal board wiring	23
Copper cable.....	16
Cover disassembly.....	17
Ferrite	27
Ground.....	18
Power terminal board wiring.....	19
Pre-insulated Crimp Terminal.....	26
Re-assembling the covers.....	31
Wiring length.....	21, 27
WM(write mode error).....	204