


# Soft-Starter

SSW7000

## User's Manual







# **User's Manual**

Series: SSW7000

Language: English

Document Number: 10001461783 / 07

Publication Data: 05/2018





The table describes the revisions made to this manual.

| Revision | Description   | Chapter       |
|----------|---|---------------|
| 1        | First edition                                       | -             |
| 2        | Correction of table 8.1                             | 8             |
| 3        | Section update 10.3.1 – safe sectioning             | 10            |
|          | D.O.L. starting description – section 10.4          | 10            |
| 4        | SSW7000C Description                                | 3, 5, 6 and 9 |
| 5        | General Revision                                    | 1 - 10        |
| 6        | Inclusion of the 500A and 600A models               | 3             |
|          | PFC description with capacitor discharge adjustment | 3             |
|          | Change of D.O.L. mode operation                     | 10            |
| 7        | Inclusion of the 6,9 kV models – SSW7000C           | 3, 5, 6 and 9 |

|          |  |            |
|----------|--|------------|
| <b>1</b> | <b>SAFETY INSTRUCTIONS .....</b>                   | <b>1-1</b> |
| 1.1.     | SAFETY WARNINGS IN THE MANUAL.....                 | 1-1        |
| 1.2.     | SAFETY WARNINGS IN THE PRODUCT .....               | 1-1        |
| 1.3.     | PRELIMINARY RECOMMENDATIONS.....                   | 1-2        |
| <b>2</b> | <b>ABOUT THE MANUAL.....</b>                       | <b>2-1</b> |
| 2.1.     | TERMS AND DEFINITIONS.....                         | 2-1        |
| 2.1.1.   | Terms and Definitions Used in the Manual .....     | 2-1        |
| <b>3</b> | <b>ABOUT THE SSW7000.....</b>                      | <b>3-1</b> |
| 3.1.     | MAIN CHARACTERISTICS.....                          | 3-1        |
| 3.1.1.   | Disconnect Switch.....                             | 3-1        |
| 3.1.2.   | Fuses .....  | 3-2        |
| 3.1.3.   | Line Contactor.....                                | 3-2        |
| 3.1.4.   | Bypass Contactor.....                              | 3-2        |
| 3.1.5.   | Power Arms.....                                    | 3-2        |
| 3.1.6.   | Control .....                                      | 3-3        |
| 3.1.7.   | Motor thermal Protection .....                     | 3-3        |
| 3.1.8.   | Tests .....  | 3-3        |
| 3.1.9.   | Ground Fault Protection.....                       | 3-3        |
| 3.1.10.  | Command for Power Factor Correction.....           | 3-4        |
| 3.2.     | SSW7000 IDENTIFICATION LABEL .....                 | 3-6        |
| 3.3.     | HOW TO SPECIFY THE SSW7000 MODEL (SMART CODE)..... | 3-7        |
| 3.4.     | RECEIVING AND STORAGE .....                        | 3-7        |
| 3.4.1.   | Unpacking .....                                    | 3-8        |
| 3.4.2.   | Panel and Power Arm Storage .....                  | 3-9        |
| <b>4</b> | <b>HMI.....</b>                                    | <b>4-1</b> |
| 4.1.     | BATTERY.....                                       | 4-1        |
| 4.2.     | HMI CABLE .....                                    | 4-1        |
| <b>5</b> | <b>INSTALLATION AND CONNECTION .....</b>           | <b>5-1</b> |
| 5.1.     | MECHANICAL INSTALLATION.....                       | 5-1        |
| 5.1.1.   | Environmental Conditions.....                      | 5-1        |
| 5.1.2.   | Dimensions with Package .....                      | 5-1        |
| 5.1.3.   | Panel and Arm Dimensions .....                     | 5-2        |
| 5.1.4.   | Handling Recommendations .....                     | 5-5        |
| 5.1.5.   | Hoisting.....                                      | 5-5        |
| 5.1.6.   | Moving .....                                       | 5-5        |
| 5.1.7.   | Positioning and Mounting.....                      | 5-6        |
| 5.1.8.   | Medium Voltage Compartment.....                    | 5-8        |
| 5.1.9.   | Low Voltage Compartment.....                       | 5-9        |
| 5.1.10.  | Power Cable Entry.....                             | 5-9        |
| 5.1.11.  | Control Cable Entry .....                          | 5-11       |
| 5.1.12.  | Power Arm Insertion .....                          | 5-11       |

|  |             |
|--|-------------|
| <b>5.2. ELECTRICAL INSTALLATION .....</b>  | <b>5-13</b> |
| 5.2.1. Power Arm Electrical and Fiber Optic Connections.....                     | 5-13        |
| 5.2.2. SSW7000 Simplified Block Diagram.....                                     | 5-18        |
| 5.2.3. Location of the Power and Grounding Connections.....                      | 5-19        |
| 5.2.4. Recommended Power and Grounding Cables.....                               | 5-21        |
| 5.2.5. Fuses.....  | 5-22        |
| 5.2.6. Connection of the Power Supply to the SSW7000.....                        | 5-23        |
| 5.2.7. Power Supply Short Circuit Rating.....                                    | 5-23        |
| 5.2.8. Motor Connection.....   | 5-23        |
| 5.2.9. Grounding Connection.....   | 5-24        |
| 5.2.10. User Signal and Control Connections .....                                | 5-25        |
| 5.2.11. Auxiliary Low Voltage Supply Connection .....                            | 5-29        |
| <b>6 INTERNAL CONNECTIONS .....</b>  | <b>6-1</b>  |
| <b>6.1. SSW7000 ELECTRONIC BOARDS .....</b>                                      | <b>6-1</b>  |
| 6.1.1. CC11 Board.....   | 6-1         |
| 6.1.2. CSM Board Connections .....   | 6-2         |
| 6.1.3. FSMT Board Connections.....   | 6-3         |
| 6.1.4. Power Arm Internal Connections.....                                       | 6-5         |
| 6.1.5. Connections between the CSM Board and the TF Transformer.....             | 6-7         |
| 6.1.6. Connections between the Low Voltage and the Medium Voltage Controls ..... | 6-8         |
| <b>7 FIRST ENERGIZATION.....</b>   | <b>7-1</b>  |
| <b>7.1. SSW7000 OPERATION VERIFICATION .....</b>                                 | <b>7-1</b>  |
| 7.1.1. Test without Three-phase Voltage.....                                     | 7-2         |
| 7.1.2. Test with Medium Voltage.....   | 7-2         |
| 7.1.3. Test with Low Voltage .....   | 7-3         |
| <b>7.2. COMMISSIONING .....</b>  | <b>7-4</b>  |
| <b>7.3. CONNECTION TO A PC.....</b>  | <b>7-5</b>  |
| <b>7.4. FLASH MEMORY MODULE.....</b>   | <b>7-5</b>  |
| <b>8 ACCESSORIES .....</b>   | <b>8-1</b>  |
| <b>9 TECHNICAL SPECIFICATIONS .....</b>  | <b>9-1</b>  |
| <b>9.1. POWER DATA.....</b>  | <b>9-1</b>  |
| 9.1.1. Operational Capacity .....  | 9-1         |
| <b>9.2. CONTROL DATA .....</b>   | <b>9-5</b>  |
| <b>10 TROUBLESHOOTING AND MAINTENANCE.....</b>                                   | <b>10-1</b> |
| <b>10.1. FAULT TRIPS AND ALARMS .....</b>  | <b>10-1</b> |
| <b>10.2. MOST FREQUENT PROBLEMS.....</b>   | <b>10-2</b> |
| <b>10.3. FAULTS ON THE FSMT BOARD.....</b>                                       | <b>10-3</b> |
| <b>10.4. PREVENTIVE MAINTENANCE .....</b>  | <b>10-4</b> |
| 10.4.1. SSW7000 Disconnection Sequence .....                                     | 10-5        |
| <b>10.5. DIRECT ONLINE START – DOL .....</b>                                     | <b>10-6</b> |
| <b>10.6. DATA FOR CONTACT WITH THE TECHNICAL SUPPORT .....</b>                   | <b>10-6</b> |



## 1 SAFETY INSTRUCTIONS

This manual contains the information necessary for the correct use of the SSW7000.

It has been written to be used by qualified personnel with suitable training or technical qualification for operating this type of equipment.

### 1.1. SAFETY WARNINGS IN THE MANUAL

The following safety notices are used in the manual:



#### **DANGER!**

The procedures recommended in this warning have the purpose of protecting the user against death, serious injuries and considerable material damage.



#### **ATTENTION!**

The procedures recommended in this warning have the purpose of avoiding material damage.



#### **NOTE!**

The information mentioned in this warning is important for the proper understanding and good operation of the product.

### 1.2. SAFETY WARNINGS IN THE PRODUCT

The following symbols are attached to the product, serving as safety notices:



High voltages are present



Components sensitive to electrostatic discharge.  
Do not touch them



Mandatory connection to the protective earth (PE).



Connection of the shield to the ground.

### 1.3. PRELIMINARY RECOMMENDATIONS



#### **DANGER!**

Only qualified personnel familiar with the SSW7000 soft-starter and associated equipment should plan or implement the installation, start-up and subsequent maintenance of this equipment.

These personnel must follow all the safety instructions included in this manual and/or defined by local regulations.

Failure to comply with these instructions may result in life threatening and/or equipment damage



#### **NOTES!**

For the purposes of this manual, qualified personnel are those trained to be able to:

1. Install, ground, energize and operate the SSW7000 according to this manual and the effective legal safety procedures
2. Use protective equipment according to the established standards.
3. Give first aid services.



#### **DANGER!**

Always disconnect the input power before touching any electrical component associated to the SSW7000. Follow the SSW7000 disconnection sequence, according to the item [10.4.1 - SSW7000 Disconnection Sequence](#).

High voltages and rotating parts (fans, if installed) may be present on the SSW7000 even after shut down or power disconnection. Wait at least 3 minutes for the complete discharge of the capacitors and the stopping of the fans.

Always connect the equipment frame to the protective earth (PE) at the suitable connection point.



#### **ATTENTION!**

Electronic boards have components sensitive to electrostatic discharges. Do not touch directly on components or connectors. If necessary, touch the grounded metallic frame before or use an adequate grounded wrist strap.

**Do not perform any high pot tests with the SSW7000!**  
If it is necessary, consult WEG.



#### **NOTE!**

Soft-starters may interfere with other electronic equipments. In order to minimize these effects, take the precautions recommended in the chapter [5 - Installation and Connection](#).



#### **NOTE!**

Read the user's manual completely before installing or operating the SSW7000.

## 2 ABOUT THE MANUAL

This manual presents the necessary information for the installation and commissioning, as well as the product main technical characteristics, and how to troubleshoot the SSW7000 most common problems.

This manual must be used together with the SSW7000 programming manual.



### ATENÇÃO!

The operation of this equipment requires installation instructions and detailed operation provided in the user's manual, programming manual and communication manuals. The user's manual and the programming manual are supplied in a hard copy together with the soft-starter. The user guides are also provided in a hard copy along with the accessories. The other manuals can be downloaded from the WEG website at - [www.weg.net](http://www.weg.net).

In order to obtain more information on the accessories and its operation, refer to the following manuals:

- RS-232/RS-485 Serial Communication Manual.
- Anybus-CC Communication Manual.
- SoftPLC Manual

Reproduction of this manual content is prohibited, as a whole or in parts, without written permission from WEG.

### 2.1. TERMS AND DEFINITIONS

#### 2.1.1. Terms and Definitions Used in the Manual

**Amp, A:** ampere

**AC:** alternating current.

**DC:** direct current.

**DOL:** Direct Online start.

**°C:** celsius degrees.

**HMI:** Human-Machine Interface; it is the device that allows the control of the motor, the visualization and the modification of the SSW7000 parameters. It presents keys for commanding the motor, navigation keys and a graphic LCD display.

**hp:** "Horse Power" = 746 Watts (power measurement unit, normally used to indicate the mechanical power of electric motors).

**Hz:** hertz.

**kg:** kilogram= 1000 gramas.

**kHz:** kilohertz = 1000 hertz.

**kV:** kilovolts = 1000 volts.

**mA:** miliampere = 0.001 ampères.

**min:** minute.

**ms:** millisecond = 0.001 segundos.

**Nm:** newton meter; torque measurement unit.

**OEM:** Original Equipment Manufacturer.

**$\Omega$ :** ohm.

**PE:** Protective Earth.

**PFC:** Power Factor Correction.

**rms:** “Root mean square”; effective value

**rpm:** revolutions per minute, speed measurement unit.

**s:** second.

**UCBT:** Low voltage control unit.

**UCMT:** Medium voltage control unit.

**USB:** “Universal Serial BUS”; it is a type of connection in the perspective of the “Plug and Play” concept.

**V:** volts.



## 3 ABOUT THE SSW7000

The “Soft-Starter WEG 7000” is a high performance product that allows the starting/stopping control and protection of medium voltage three-phase induction motors, thus preventing mechanical shocks ant the load, current peaks in the supply line and damage to the motor.




Figure 3.1: General block diagram of SSW7000.



### NOTE!

The capacitor bank for power factor correction is provided in an additional column coupled to the SSW7000

### 3.1. MAIN CHARACTERISTICS

The soft-starter SSW7000 has three panel versions: one IP41 version, one IP54 version and one NEMA version. The NEMA and IP54 are compacts versions – SSW7000C, 36” wide. The operation is the same for all versions. The specific differences among the versions will be detailed in this manual.

#### 3.1.1. Disconnect Switch

The standard SSW7000 panel has a medium voltage input disconnect switch that allows the electrical disconnection of the internal circuit of the SSW7000 from the power supply.

This disconnect switch is interlocked with the cabinet door, so that the door can only be opened when the disconnect switch is also open. When open, the connections on the upper side of the fuses are grounded.



### DANGER!

Even with the disconnect switch open, voltage may still be present on the side of medium voltage power supply of the disconnect switch. When maintenance is required on the medium voltage side of the disconnect switch, the medium voltage power supply must be disconnected and grounded in a point before the SSW7000.



### DANGER!

The SSW7000 has another power supply for the low voltage control. Make sure there is no voltage before touching any component

### 3.1.2. Fuses

The standard panel of the SSW7000 features R-type medium voltage fuses against short circuit on the panel, on the motor and on the cables to the motor.

### 3.1.3. Line Contactor

The standard SSW7000 panel has a line vacuum contactor with utilization category AC-3, which makes it possible to disconnect the SSW7000 power section whenever the motor is deactivated.

The line contactor is driven by the control electronics of SSW7000.

### 3.1.4. Bypass Contactor

The standard SSW7000 panel has a vacuum contactor with utilization category AC-3, which makes it possible to bypass the power arms after starting the motor. This function allows energy saving by eliminating losses on the SCRs during the motor full operating duty and it also eliminates the necessity of using fans for the operation of the SSW7000 in its rated start operation duty, which is specified in the section [9.1 – Power Data](#).

This contactor is sized to withstand direct on line starting and the SSW7000 rated current at full load. It also allows the implementation of a direct on line starting logic.

The bypass contactor is driven by the control electronics of SSW7000.

### 3.1.5. Power Arms

The SSW7000 power arms are assembled as modules with wheels that facilitate their installation and replacement during maintenance. For the SSW7000C version, the power arms don't have wheels and are attached to the back of the panel.



(a) SSW7000



(b) SSW7000C

Figure 3.2: Power Arms

Each arm is comprised of the SCRs, heatsinks, snubbers, supply transformers and firing boards. The firing commands and the temperature readings are performed through fiber optic cables.

If it is necessary to increase the start duty of the SSW7000, increasing the number of starts per hour, for instance, it is possible to install fans on the power arms. In such case, refer to the manufacturer.

## 3.1.6. Control

The SSW7000 control is implemented using two electronic control boards, isolated from each other through fiber optic cables.

The C1 (CC11) control board is responsible for all the user access means: HMI, analog and digital inputs and outputs, communication accessories, PT100 input and SoftPLC. It presents the possibility of firmware update either via USB communication or via flash memory.

The C2 (CSM) control board is responsible for the motor control, the firing signals, the voltage and current readings, and the synchronism. It is mounted in the medium voltage compartment and it does not allow direct access to the user. The board firmware can be updated via USB communication.

## 3.1.7. Motor thermal Protection

Besides the possibility of using overload protection on the motor by means of preset thermal class, the SSW7000 has an eight channel PT100 input accessory (IOE-04 module), which allows monitoring the motor winding and bearing temperatures.

The advantage of this module is the possibility of using the motor overload protection combined with the PT100 temperature measurements. Besides, these temperature measurements are also available on the HMI and through network communication.

The fault and alarm levels of the motor thermal protection through the motor PT100 sensors can be totally programmed. For further details, refer to sections 15.5 - Motor Thermal Protection and 15.6 - Motor Thermal Class Protection, of the programming manual.

## 3.1.8. Tests

The SSW7000 has a test routine with the purpose of verifying the main panel connections. For more details, refer to the section [7.1- SSW7000 Operation Verification](#) in this manual and to the section 14.2 - Test Mode in the SSW7000 programming manual.

There is also the possibility of performing test with low voltage; however, it becomes necessary to change the voltage reading connections, as well as the SSW7000 parameterization (P0296).

## 3.1.9. Ground Fault Protection

The SSW7000 has two ground fault detection methods. One by neutral to ground voltage measurement (in the standard panel) for isolated networks, and another by ground fault current measurement (the current transformer is optional).




Figure 3.3: Ground fault detection by voltage



### NOTE!

The ground fault by voltage detected by the SSW7000 may have occurred in any point of the power supply system from the transformer to the motor.

The ground fault protection by voltage has the advantage that the SSW7000 also detects the ground fault when the ground fault current does not pass through the SSW7000.




Figure 3.4: Ground fault detection by current.

### 3.1.10. Command for Power Factor Correction


**NOTE!**

The capacitor bank for power factor correction is provided in an additional column coupled to the SSW7000


**DANGER!**

Power factor correction capacitors must never be installed at the SSW7000 output (U / 2T1, V / 4T2 and W / 6T3).


**NOTE!**

The current carrying capacity of digital outputs DO1, DO2 and DO3 is 1A, as described in [9.2 Control Data](#).

### Control for a SSW7000

The SSW7000 can control the motor power factor correction (PFC) capacitor bank directly through a digital output (DO1, DO2 or DO3) programmed for “PFC Control”. The digital output will then be activated after the motor starts and after the bypass contactor closes, thus preventing the capacitor bank from being activated with the motor turned off or during the motor start or stop.




Figure 3.5: Connection to PFC Control for a SSW7000

## Control for Multiple SSW7000

Multiple SSW7000 may be connected in parallel, sharing the same power supply transformer.




Figure 3.6: Parallel connections between "n" SSW7000

In order to automatically control the motor power factor correction (PFC) capacitor banks for multiple SSW7000, a digital input (DI1, DI2, DI3, DI4, DI5 or DI6) must be set to "PFC Lock", a digital output (DO1, DO2 or DO3) must be set to "PFC Control", and another digital output must be set to "PFC Lock".

The electrical connections between the CC11 control boards of the Soft Starters must be done so that all the digital inputs receive the signal from the digital output "PFC Lock", as shown in the example of [figure 3.7](#). In this example, digital outputs DO1 and DO2 and digital input DI5 were used. The parameters configured in the example are "15=PFC Lock" (DO1), "14=PFC Control" (DO2) and "16=PFC Lock" (DI5).




Figure 3.7 : Connection to PFC Controls for Multiple SSW7000 (example).

The start of multiple SSW7000 is done sequentially and/or simultaneously. For the simultaneous start condition of two or more SSW7000, the PFC capacitor banks will be enabled at the same time after the start of the last motor. As described by IEC 60871-1, the peak value of the capacitor bank inrush current must not exceed 100 times the value of the rated current. If the inrush current is higher, a reactance must be installed in series with each capacitor bank. The reactance will reduce the peak current and attenuate the effect of transient overvoltage.

### Discharge of the Power Factor Correction Capacitors

When the power factor correction capacitor is disconnected from the line, a residual voltage remains on it. When the capacitor is reconnected, such residual voltage can cause an inrush current of up to twice the value obtained when the capacitor is discharged during reconnection, thus reducing its useful life. In order to prevent the increase of the inrush current, the capacitors must be internally equipped with a discharge device able to reduce the residual voltage to a value close to zero after its disconnection.

Parameter P0280 - CAPACITOR DISCHARGE TIME defines the time the SSW7000 waits for the discharge of the power factor correction capacitors so as to allow a new connection. P0280 can be programmed with values between 60 to 600 seconds, and the standard value is 300 seconds (NBR5282 standard).

### 3.2. SSW7000 IDENTIFICATION LABEL

The SSW7000 identification label is affixed inside the product cabinet. This label contains important information on the SSW7000.




Figure 3.8. Identification label of SSW7000 (example).

Other important information can be found on the label of the Power Arms.




Figure 3.9 Identification label of Power Arm (example).



### 3.3. HOW TO SPECIFY THE SSW7000 MODEL (SMART CODE)

In order to specify the correct model of WEG Soft-Starter, use the product smart code. It is composed of several parts, which are described below:

SSW7000    A    180    I    4    11    41  
 1            2       3       4       5       6       7

Table 3.1. Smart Code

| 1<br>Model   | 2<br>Frame  | 3<br>Rated Current | 4<br>Number of Phases | 5<br>Rated Voltage | 6<br>Electronics Power Supply | 7<br>Degree of Protection | 8<br>Blower Cooled | 9<br>Special Hardware | 10<br>Special Software | 11<br>Market |
|--|-------------|--------------------|-----------------------|--------------------|-------------------------------|---------------------------|--------------------|-----------------------|------------------------|--------------|
| SSW7000<br>= Soft-Starter<br>WEG<br>series<br>7000 | A = Panel   | 070 = 70A          | T =<br>Three-phase    | 2 = up to 2.3kV    | 11 = 110/220V                 | 41 = IP41                 | Blank =            | Blank =               | Blank =                | Blank =      |
|  | Frame       | 180 = 180A         |                       | 4 = up to 4.16kV   |                               |                           | Standard           | Standard              | Standard               | Global       |
|  | A           | 300 = 300A         |                       | 6 = up to 6.9kV    |                               |                           | F = Blower-Cooled  |                       |                        |              |
|  |             | 360 = 360A         |                       |                    |                               |                           |                    |                       |                        |              |
|  | B = Panel   | 500 = 500A         | T =<br>Three-phase    | 2 = up to 2.3kV    | 11 = 110/220V                 | 41 = IP41<br>N2 = NEMA 12 | Blank =            | Blank =               | Blank =                | Blank =      |
|  | Frame       | 600 = 600A         |                       | 4 = up to 4.16kV   |                               |                           | Standard           | Standard              | Standard               | Global       |
|  | B           |                    |                       | 6 = up to 6.9kV    |                               |                           | F = Blower-Cooled  |                       |                        |              |
|  | (2 columns) |                    |                       |                    |                               |                           |                    |                       |                        |              |
|  | C = Panel   | 125 = 125A         | T =<br>Three-phase    | 2 = up to 2.3kV    | 11 = 110/220V                 | 41 = IP54<br>N2 = NEMA 12 | Blank =            | Blank =               | Blank =                | Blank =      |
|  | Compact     | 250 = 250A         |                       | 4 = up to 4.16kV   |                               |                           | Standard           | Standard              | Standard               | Global       |
|  |             | 359 = 360A         |                       | 6 = up to 6.9kV    |                               |                           | F = Blower-Cooled  |                       |                        |              |
|  |             |                    |                       |                    |                               |                           |                    |                       |                        |              |
|  | D = Panel   | 180 = 180A         | T =<br>Three-phase    | 9= up to 13,8kV    | 11 = 110/220V                 | 4X = IP4X                 | Blank =            | Blank =               | Blank =                | Blank =      |
|  | Frame       | 300 = 300A         |                       |                    |                               |                           | Standard           | Standard              | Standard               | Global       |
|  | D           | 360 = 360A         |                       |                    |                               |                           | F =                |                       |                        |              |
|  | (MTW)       | 500 = 500A         |                       |                    |                               |                           | Blower-Cooled      |                       |                        |              |
|  |             | 600 = 600A         |                       |                    |                               |                           |                    |                       |                        |              |

### 3.4. RECEIVING AND STORAGE

The standard SSW7000 is supplied with the power arms separated from the panel and packed individually.

The SSW7000 panel is supplied in a package composed by cardboard, plastic and wood.

Wood and polystyrene wedges compose the power arm package. There is an identification label outside this package, which is identical to the one affixed to the power arms. Confront the content of this label with the purchase order.

The contents of the packages should be verified on product receiving.



#### NOTES!

If any component is found damaged, it is recommended to:

1. Stop the package opening immediately.
2. Contact the carrier and fill in a format complaint of the problem found.
3. Take pictures of the damaged parts/components.
4. Contact your WEG representative or WEG service.

Guidance for handling, transportation, mechanical and electric installation of the product, is presented in the chapter 5 - [Installation and Connection](#)

### 3.4.1. Unpacking

Use proper tools to unpack the SSW7000 panel and its power arms. During this process, make sure that all the items listed in the documentation that comes with the product are present and in perfect conditions. Contact your local WEG representative or WEG service in case of any irregularity.

Remove the arm packages carefully. Note that the arms have hoisting eyes, as showed in the [figure 3.10](#).

The SSW7000 power arms have fragile components (electronic boards, fiber optic connectors, busbars, wiring, etc.). Avoid touching these components.

The arms must always be handled through their external metallic frame. While opening the package, inspect the arms for transportation damage. Do not install the arms if they are damaged or if you suspect of any damage.




Figure 3.10: a) SSW7000 Power Arms with package






Figure 3.11: b) SSW7000C Power Arms with package

## 3.4.2. Panel and Power Arm Storage

If the panel and/or the power arms are not installed soon after unpacked, the following storage instructions must be followed:

- They must be packed again in their original packages, but without the plastic film, in order to avoid moisture condensation.
- They must be stored in a clean and dry environment (temperature between -25 °C and 50 °C (-13 °F and 122 °F) with moisture below 85 %).
- They must be covered up in order to avoid dust accumulation or water splashing.



## 4 HMI

### 4.1. BATTERY

The battery located inside the HMI is used to keep the clock operation while the soft-starter is deenergized. Its location and replacement are shown in [figure 4.1](#).

The battery life expectancy is of approximately 10 years. To remove it rotate the cover located at the rear part of the HMI, according to the [figure 4.1](#). When necessary, replace the battery by another of the CR2032 type.




Figure 4.1: Location and battery replacement HMI



#### NOTE!

The battery is necessary only for clock-related functions. In the event of the battery being discharged or not installed in the keypad (HMI), the clock time becomes incorrect and the alarm A182 – “Invalid Clock Value” will be indicated every time the SSW7000 is powered up.

### 4.2. HMI CABLE

The HMI can be installed and removed even when power is applied to the SSW7000.

The HMI supplied with the product can also be used to command the SSW7000 remotely. Therefore, use a cable with male and female D-Sub9 (DB9) connectors, with pin-to-pin connections, or a market standard Null Modem cable. Maximum allowed cable length of 10 m (32.81 ft).

Examples:

Mouse extension cable - 1.8 m (5.91 ft); Manufacturer: Clone.

Belkin pro series DB9 serial extension cable 5 m (16.4 ft); Manufacturer: Belkin.

Cables Unlimited PCM195006 cable, 6 ft DB9 m/f; Manufacturer: Cables Unlimited.

The M3 x 5.8 metallic stand-offs supplied with the product must be used. Recommended tightening torque: 0.5 N.m (4.50 lbf.in).



## 5 INSTALLATION AND CONNECTION

This chapter describes the SSW7000 electrical and mechanical installation procedures. The presented instructions and guidelines must be followed aiming personnel and equipment safety, as well as the SSW7000 proper operation.



### ATTENTION!

Only trained personnel, qualified to work with medium voltage installations, must handle the SSW7000 and perform the mechanical and electrical installation.

### 5.1. MECHANICAL INSTALLATION

#### 5.1.1. Environmental Conditions

Avoid:

- Direct exposure to sunlight, rain, high humidity, or sea-air.
- Inflammable or corrosive gases or liquids.
- Excessive vibration.
- Dust, metallic particles, and oil mist.

Allowed environmental conditions:

- Temperature: -10 °C a 40 °C (14 °F a 104 °F) – at nominal conditions (surrounding the soft-starter).
- From 40 °C to 50 °C (104°F to 122 °F) - current derating of 2% for each Celsius degree above 40 °C (104 F).
- Maximum ambient temperature: 50 °C (122 °F).
- Relative humidity: from 5 % to 95 % non-condensing.
- Altitude: up to 1000 m (3280.83 ft) - nominal conditions. Consult WEG for other altitudes.
- Pollution degree: 2 (according to UL508) with non-conductive pollution. Condensation shall not originate conduction through the accumulated residues.

#### 5.1.2. Dimensions with Package

Table 5.1; SSW7000 Panel Dimensions – IP41 with package

| Width<br>mm (in) | Height<br>mm (in) | Depth<br>mm (in) | Weight<br>kg (lb) |
|------------------|-------------------|------------------|-------------------|
| 1460<br>(57.48)  | 2530<br>(99.61)   | 1320<br>(51.97)  | 855<br>(1884.95)  |

Table 5.2: SSW7000C NEMA 12 dimensions with package

| Model    | Width<br>mm (in) | Height<br>mm (in) | Depth<br>mm (in) | Weight<br>kg (lb) |
|----------|------------------|-------------------|------------------|-------------------|
| SSW7000C | 1178<br>(46.36)  | 2514<br>(99.0)    | 1168<br>(46.0)   | 600<br>(1346)     |

Table 5.3. Power arms dimensions with package – SSW7000.

| Rated Voltage<br>kV | Width<br>mm (in) | Height<br>mm (in) | Depth<br>mm (in) | Weight<br>kg (lb) |
|---------------------|------------------|-------------------|------------------|-------------------|
| 2,3                 | 935<br>(36.81)   | 561<br>(22.09)    | 643<br>(25.31)   | 87<br>(191.8)     |
| 4,16                | 935<br>(36.81)   | 561<br>(22.09)    | 760<br>(29.92)   | 103<br>(227.07)   |
| 6,9                 | 935<br>(36.81)   | 561<br>(22.09)    | 877<br>(34.53)   | 122<br>(268.96)   |

Table 5.4. Power Arms dimensions with package – SSW7000C

| Rated Voltage<br>kV | Width<br>mm (in) | Height<br>mm (in) | Depth mm (in)  | Weight<br>kg (lb) |
|---------------------|------------------|-------------------|----------------|-------------------|
| 2,3                 | 760<br>(29.92)   | 660<br>(25.98)    | 430<br>(16.93) | 38<br>(83.78)     |
| 4,16                | 793<br>(31.22)   | 813<br>(32.01)    | 430<br>(16.93) | 56<br>(123.5)     |
| 6,9                 | 826<br>(32.52)   | 813<br>(32.01)    | 430<br>(16.93) | 69<br>(152.1)     |

## 5.1.3. Panel and Arm Dimensions

The SSW7000 is supplied in panels with the following external dimensions:




Figure 5.1 SSW7000 IP41 panel

Table 5.5. SSW7000 IP41 panel

| Width<br>mm(in) | Height<br>mm (in) | Depth<br>mm (in) | Weight<br>(without the arms)<br>kg (lb) |
|-----------------|-------------------|------------------|---|
| 1200<br>(47.24) | 2365<br>(93.11)   | 1007<br>(39.64)  | 720,1<br>(1587.55)                      |

The power arms of the SSW7000 are supplied separately from the panel and individually packed.

Table 5.6: SSW7000 Power arm dimensions without package

| Rated Voltage<br>kV | Width<br>mm (in) | Height<br>mm (in) | Depth<br>mm (in) | Weight<br>kg (lb) |
|---------------------|------------------|-------------------|------------------|-------------------|
| 2,3                 | 262<br>(10.31)   | 722<br>(28.42)    | 430<br>(16.93)   | 53<br>(116.84)    |
| 4,16                | 262<br>(10.31)   | 722<br>(28.42)    | 546<br>(21.5)    | 68,6<br>(151,24)  |
| 6,9                 | 262<br>(10.31)   | 722<br>(28.42)    | 664<br>(26.14)   | 83,3<br>(183.64)  |

The dimensions for the compacts versions NEMA12 and IP54 - SSW7000C are given below.




Figure 5.2 (a): Nema 12 panel - SSW7000C.

Table 5.7: SSW7000C Nema 12 and IP54 panel

| Width<br>mm<br>(in) | Height<br>mm (in) | Depth<br>mm (in) | Weight<br>(without arms)<br>kg (lb) |
|---------------------|-------------------|------------------|-------------------------------------|
| 915<br>(36)         | 2418<br>(95)      | 813<br>(32)      | 546,4<br>(1205)                     |




Figure 5.2 (b): IP54 panel - SSW7000C.

The power arms of the SSW7000C are supplied mounted on the panel.

Table 5.8 SSW7000C Power Arms dimensions without package

| Rated Voltage<br>kV | Width<br>mm (in) | Height<br>mm (in) | Depth<br>mm (in) | Weight<br>kg (lb) |
|---------------------|------------------|-------------------|------------------|-------------------|
| 2,3                 | 226<br>(8.90)    | 458<br>(18,03)    | 482<br>(19.0)    | 20<br>(44,1)      |
| 4,16                | 230<br>(9.50)    | 585<br>(23.03)    | 482<br>(19.0)    | 30<br>(66,2)      |
| 6,9                 | 265<br>(10.43)   | 585<br>(23.03)    | 482<br>(19.0)    | 40<br>(88,2)      |

The mechanical panel B used for models with currents of 500A and 600A, has a similar mechanical design as the compacts versions. The mechanical panel D used for 13,8kV models, has a similar mechanical design as the MTW panel WEG. The width and depth of the panels are larger to accommodate higher current and voltage capacity power arms. Consult the manufacturer for more details.



### 5.1.4. Handling Recommendations

Remove the package completely only at the installation site, where the panel will be operated.

Before hoisting or moving the panel, locate the hoisting eyes and fragile spots in the documentation that comes with the product.

Follow the handling instructions contained in the documentation that comes with the panel.

### 5.1.5. Hoisting

Make sure that the lifting device used to hoist the panel and the arms is suitable for their shape and weight indicated in the [figure 5.1](#) at [figure 5.](#) and in the [table 5.5](#) at [table 5.8](#).

Observe the gravity center and ensure that the hoisting mechanism is adequate and safe. Use the configuration shown in the [figure 5.3](#).

The cables or chains used for hoisting must be at a minimum angle of 45° regarding the horizontal plane.

Hoisting must be done in a slow and stable manner. Before starting, make sure the entire pass is clear of obstacles. If any alteration or damage in the panel structure is noticed, stop the hoisting and rearrange the cables or chains.



#### **NOTE!**

The hoisting eye supplied with the Nema 12 panel is optional.




Figure 5.3: Recommended hoisting mechanism for the panel movement.

### 5.1.6. Moving

Make sure that all the panel doors are closed and locked and that the door handles are in a protected position.

When cranes or pulleys are used, make sure that the movements are slow and smooth, so that the panel and the arms do not suffer excessive swings and vibration.

When using movable hydraulic jacks, forklifts, rollers or other movement means, distribute the support points from one extreme of the panel through the other, avoiding pressure on fragile areas.

### 5.1.7. Positioning and Mounting

The SSW7000 panel must be placed on a flat leveled surface, thus avoiding mechanical instability, door misalignment, among other problems.

The permanent panel operation position must allow heat radiation from all its surfaces.

The area in front of the panel must remain unobstructed, so that the total opening of the doors is possible, as well as the insertion and extraction of the soft-starter arms and the installation and/or handling of the power and control cables. The connection of the power supply and motor cables is done at the rear of the cabinet.

The [figure 5.4](#) presents the dimensions for the panel anchoring and the passage of the cables under the panel.



#### ATTENTION!

Make sure there is access for the electrical connections: power supply input and motor cables, command, motor protections, analog and digital inputs and outputs.





Figure 5.4 (a): Expansion bolt for anchoring of the SSW7000 panel to the floor – dimensions in mm [in]



(a): IP41 48" Panel - SSW7000A

(b): NEMA 12 36" Panel - SSW7000C

Figure 5.4 (b): Anchoring of the SSW7000 panel to the floor – dimensions in mm [in]

The adjustment of the mechanical interlock of the doors of the medium voltage compartment of the SSW7000 and SSW7000C is carried out at the factory. If any problem is detected in the mechanical interlock operation, which may be caused by irregular surface where the panel is installed, for instance, adjust the locking part by means of the bolts indicated in [figure 5.5](#) and [figure 5.6](#).




Figure 5.5: Position of the door interlock adjustment bolts of the medium voltage compartment – SSW7000.




Figure 5.6 (a): Position of the door interlock adjustment bolts of the medium voltage compartment, model 1 SSW7000C.




Figure 5.6 (b): Position of the door interlock adjustment bolts of the medium voltage compartment, model 2 - SSW7000C.

### 5.1.8. Medium Voltage Compartment

The disconnect switch, the fuses, the input contactor, the bypass contactor, the power arms and the control board 2 are stored in the medium voltage compartment.




Figure 5.7: Medium voltage compartment (from view and rear view) – IP41



Figure 5.8: Medium voltage compartment (from view) SSW7000C – Nema 12

## 5.1.9. Low Voltage Compartment

In the low voltage compartment are the direct access components to the user's control connections: control board, power supply for control board, power supply for the medium voltage boards, auxiliary contactors and access terminals.




**CONTROL VERSION 2 AND 3**

Figure 5.9: Low voltage compartment.


For more details see chapter [6 - Internal Connections](#).

## 5.1.10. Power Cable Entry

The passage of power cables in the panels IP41 and Nema 12 is shown in [figure 5.10](#) and [figure 5.11](#).



**(a) Passage of the cables by the upper part of the panel**



**(b) Passage of the cables by the lower part of the panel**

Figure 5.10. (a) and (b): Passage of the power cables – IP41.






Figure 5.11. (a) and (b): Passage of the power cables – Nema 12





Figure 5.11. (c) and (d): Passage of the power cables – Nema 12.

### 5.1.11. Control Cable Entry

The passage of the control cables (digital and analog inputs and outputs, thermistor PT100 and low voltage supply cables) in the panels IP41 and Nema 12 of the SSW7000 is shown in [figure 5.12](#) and [figure 5.13](#) respectively.



(a) Passage of cables by the upper part of the panel

(b) Passage of the cables by the lower part of the panel

Figure 5.12: (a) e (b): Passage of the control cables – IP41.



Figure 5.13: Passage of the control cables by the lower part of the left side of the panel – Nema 12.

### 5.1.12. Power Arm Insertion

First, remove any packing residues (plastic, wood, polystyrene, metal, nails, bolts, nuts, etc.) that might have been left inside the power arms.

Insert the arms according to the following procedure:

1. Use the auxiliary guide brackets, shown in [figure 5.14](#) (a), to move the arms. These auxiliary guide brackets are supplied with the product and are positioned at the internal part of the medium voltage compartment door when they are not used.
2. The arm must be inserted until the locking pins, located at the rear of the arm, fit into the rail base, refer to [figure 5.14](#) (b).
3. 3. Install the locking bolts at the arm front bottom part, refer to [figure 5.14](#) (c).




Figure 5.14 (a) to (c): Details of the arm insertion stages

For the SSW7000C, the power arms are lighter and are fixed at the panel rear by means of screws, as shown in [figure 5.15](#).




Figure 5.15 SSW7000C Power arms installation.



## 5.2. ELECTRICAL INSTALLATION



### **DANGER!**

Before beginning the connections, make sure the power supply is disconnected.



### **DANGER!**

The SSW7000 cannot be used as an emergency stop mechanism.



### **ATTENTION!**

The following information is intended to be a guide for a proper installation. You must also comply with applicable local regulations for electrical installations.



### **ATTENTION!**

During the commissioning, apply power first to the electronics and program the minimum necessary parameters to be able to run the Test Mode (according to the programming manual, section 14.2 - Test Mode).

The Test Mode execution is essential for the confirmation of the correct operation of the SSW7000 panel main components.

Start the motor only if the Test Mode results were satisfactory.

### 5.2.1. Power Arm Electrical and Fiber Optic Connections

After inserting the power arms (R-U, S-V and T-W phases) connect them to the power cables, to the fiber optic cables and to the firing board power supply. All the power arm connections are easy to access.

#### Power connections:

The input and output power connections are made with cables with lugs, connected to the module copper terminals. For SSW7000C, the input connection is at the top of the module and is made using cables with lugs. The output connection is made using copper bars.




Figure 5.16: Connection of the power cables to the power arms

Table 5.9: Power cable identification

| Power Cable Identification | Arm Terminal   |
|----------------------------|----------------|
| R                          | R-U arm input  |
| U                          | R-U arm output |
| S                          | S-V arm input  |
| V                          | S-V arm output |
| T                          | T-W arm input  |
| W                          | T-W arm output |

### Fiber optic cable connections:

The firing and temperature monitoring connections are made through fiber optic cables connected to the terminals available at the front of the power arm. The firing cables are connected to the blue terminals and the temperature reading to the gray one. The number of firing cables changes according to the power arm rated voltage. All the power arm firing connections are interchangeable amongst themselves.



Figure 5.17: Firing and temperature Reading fiber optic cable connections – SSW7000




Figure 5.18: Firing and temperature Reading fiber optic cable connections – SSW7000C

Table 5.10: Number of firing fiber optic cables per power arm

| Rated Voltage | Number of Firing Cables |
|---------------|-------------------------|
| 2,30 kV       | 2                       |
| 4,16 kV       | 4                       |
| 6,90 kV       | 6                       |

Table 5.11: Fiber optic cable identification

| Power Arm | Fiber Optic Cable Identification | Terminal Color at the Power Arm |
|-----------|----------------------------------|---------------------------------|
| R-U arm   | Fire R – SCR firing cables       | Blue                            |
|           | Temp. R – NTC thermistor cable   | Gray                            |
| S-V arm   | Fire S – SCR firing cables       | Blue                            |
|           | Temp. S – NTC thermistor cable   | Gray                            |
| T-W arm   | Fire T – SCR firing cables       | Blue                            |
|           | Temp. T – NTC thermistor cable   | Gray                            |



## NOTES!

Precautions with the fiber optic cables:

1. Handle them with caution, in order not to fold, bend, squeeze or cut them.
2. To insert or disconnect the cables, apply pressure or pull only at the connector, and never at the cable.
3. Never bend the cables with a radius smaller than 40 mm (1.57 in).

## Firing boards power supply connections:

The connections of the firing boards power supply depends on the power arm rated voltage. In order to achieve the proper supply operation, in version 2 (V2), always connect the three transformer sets in series, in version 3 (V3), always connect the transformers in parallel.




Figure 5.19: Insulated supply connections between the CSM2 board and the power arms of the model 2300 V (V2).




Figure 5.20: Insulated supply connections between the CSM2 board and the power arms of the model 4160 V (V2).




Figure 5.21: Insulated supply connections between the CSM2 board and the power arms of the model 6900 V (V2).





Figure 5.22: Insulated supply connections between the CSM3 board and the power arms of the model 6900 V (V3).



**NOTE!**  
All the power supply connection cables must have medium voltage insulation, according to the following specifications: 15 kVac, 200 °C (392 °F), 14 AWG or superior.

Table 5.12: Identification of the power supply cables of the electronic boards of the power arms


| Power Supply cable Identification | Identification on the Arm |
|-----------------------------------|---------------------------|
| A1 – Power supply cable           | X1:1                      |
| A2 – Power supply cable           | X1:2                      |
| A3 – Power supply cable           | X1:3                      |
| A4 – Power supply cable           | X1:4                      |



(a)



(b)



(c)

Figure 5.23 (a) a (c): Details of the cable installation on the power arms



## 5.2.2. SSW7000 Simplified Block Diagram




Figure 5.24: SSW7000 simplified block diagram

## 5.2.3. Location of the Power and Grounding Connections

T / 5L3, S / 3L2, R / 1L1: medium voltage line.




Figure 5.25 (a): Rear panel view. Power input and grounding connections – IP41



Figure 5.25 (b): Power input and grounding connections – Nema 12

U / 2T1, V / 4T2, W / 6T3: motor connection.



Figure 5.26 (a): Rear panel view. Motor connections – IP41




Figure 5.26 (b): Motor connections – SSW7000C




Figure 5.27: Cable shield connection



## 5.2.4. Recommended Power and Grounding Cables

The cables that connect the medium voltage line to the SSW7000 panel input disconnect switch and those that connect the medium voltage to the panel output, showed in the [figure 5.28](#), must be specific for medium voltage application and dimensioned for the motor rated currents.




Figure 5.28: Connections of power and grounding

- Minimum insulation voltage of the cables according to the power supply.  
Commercial examples: Cofiban – Cofialt, Pirelli – Eprotenax, Ficap – Fibep.

Table 5.13: Recommended cable for 100 % of the rated current

| Model | Power Cable Cross Section mm <sup>2</sup> (in <sup>2</sup> ) | Grounding Cable Cross Section mm <sup>2</sup> (in <sup>2</sup> ) |
|-------|--|--|
| 70 A  | 35 (0.06)  | 25 (0.04)  |
| 125 A | 50 (0.08)  | 25 (0.04)  |
| 180 A | 70 (0.11)  | 35 (0.05)  |
| 250 A | 150 (0.24)   | 95 (0.15)  |
| 300 A | 185 (0.29)   | 95 (0.15)  |
| 360 A | 240 (0.37)   | 120 (0.19)   |
| 500 A | 2 x 150 (2 x 0.24)   | 2x 95 (2 x 0.15)   |
| 600 A | 2 x 185 (2 x 0.29)   | 2x 95 (2 x 0.15)   |

- Use adequate lugs for the power and grounding connections.
- Tighten the connections with the adequate torque.

Table 5.14: Tightening torque at the power connections

| Terminal  | Bolt | Torque (Nm) $\pm 20\%$ |
|-----------|------|------------------------|
| R / 1L1   | M10  | 30                     |
| S / 3L2   |      |                        |
| T / 5L3   |      |                        |
| U / 2T1   |      |                        |
| V / 4T2   |      |                        |
| W / 6T3   |      |                        |
| Grounding |      |                        |



## NOTE!

For the correct selection of the cables consider the installation conditions, the maximum allowed voltage drop and use the applicable local regulations on electrical installations.

### 5.2.5. Fuses

In the panel IP41, the R-type fuses are installed inside the cabinet, close to the disconnect switch, and they protect both motor and installation against short circuit. They must comply with the rated medium voltage supply voltage.

In the panel Nema 12 the disconnect switch is installed in the medium voltage upper compartment and the R-type fuses are in the medium voltage lower compartment beside the line and bypass contactors.

The [table 5.15](#) presents the fuses used in the standard SSW7000. They comply with the standard operational SSW7000 capacity.

Table 5.15: Recommended fuses

| Rated Current | Fuse        |
|---------------|-------------|
| 70 A          | 12R (ou 6R) |
| 125 A         | 12R (ou 6R) |
| 180 A         | 12R         |
| 250 A         | 18R         |
| 300 A         | 18R         |
| 360 A         | 24R         |
| 500 A         | 32R         |
| 600 A         | 36R         |

Table 5.16: Fuse manufacturer codes

| Manufacturer | Voltage  |           |               |
|--------------|----------|-----------|---------------|
|              | 2300V    | 4160V     | 6900V         |
| Bussmann     | JCK-x-rr | JCL-x-rr  | JCR-x-rr      |
| Ferraz       | A240Rxx  | A480Rxx-1 | A720xxDxRO-xx |

xx = Recommended fuse



## NOTE!

The fuses will not protect the SCRs in a short circuit event. If a short circuit occurs, retest the SSW7000 according to the procedures described in chapter [7 - First Energization](#), before activating the motor.

## 5.2.6. Connection of the Power Supply to the SSW7000



### DANGER!

The line voltage must be compatible with the soft-starter rated voltage.



### DANGER!

Provide a device for cutting off the SSW7000 power supply. This device must be able to remove the power supply at the soft-starter input whenever necessary (for instance during maintenance work at the SSW7000 panel disconnect switch).

## 5.2.7. Power Supply Short Circuit Rating

When protected by the fuses supplied in the panel, the SSW7000 is suitable to be used in a circuit able to supply at most the current (Symmetric arms) established for each respective model and voltage (V) according to [table 5.17](#).

Table 5.17: Maximum current capacity of the power supply

| Model  | Maximum current capacity |
|--------|--------------------------|
| 2300 V | 40 kA                    |
| 4160 V | 40 kA                    |
| 6900 V | 40 kA                    |

## 5.2.8. Motor Connection



### DANGER!

Power factor correction capacitors must never be installed at the SSW7000 output (U/2T1, V/4T2 and W/6T3).



### DANGER!

The SSW7000 has been designed for standard motor connection (three cables).

Connection inside the motor delta is not allowed (six cables).

Multimotor connection is not allowed.




Figure 5.29: Connection of the SSW7000 to the motor.

**ATTENTION!**

In order that the protections based on the current reading and indication (motor overload for example) operate properly, the motor rated current must not be less than 20% of the SSW7000 rated current.

We do not recommend the use of motors that operate in steady state with load of less than 50% of their rated current.

**NOTES!**

The majority of medium voltage motors are special and able to withstand high starting duties, therefore, also special protection methods must be used:

1. The electronic overload protection must be adjusted according to the data supplied by the manufacturer of the used motor.
2. It is recommended to use thermal sensors for the motor protection.

### 5.2.9. Grounding Connection

**DANGER!**


The SSW7000 must obligatorily be connected to a protective earth (PE). The grounding connection must comply with the local regulations. Use at least the wire gauge indicated in the [table 5.13](#). Connect it to a specific grounding rod, or to a specific grounding point or to the installation general ground (10 ohm resistance).

**DANGER!**

Use a specific conductor to the ground, never use the neutral conductor.


## 5.2.10. User Signal and Control Connections

The signal connections (analog inputs and outputs) and control (digital inputs and outputs) available to the user are performed in the control board 1 (CC11).



| Terminal Strip | Factory Setting Function | Specifications                              |
|----------------|--------------------------|---|
| 1              | +REF                     | Potentiometer positive referente            |
| 2              | AI1+                     | Analog Input 1:<br>No function              |
| 3              | AI1-                     |   |
| 4              | REF                      | Potentiometer negative reference            |
| 5              | AI2+                     | Analog Input 2:<br>No function              |
| 6              | AI2-                     |   |
| 7              | AO1                      | Analog output 1:<br>No function             |
| 8              | AGND (24 V)              | Reference (0 V) for analog outputs          |
| 9              | AO2                      | Analog output 2:<br>No function             |
| 10             | AGND (24 V)              | Reference (0 V) for the analog outputs      |
| 11             | DGND*                    | Reference (0 V) for the 24 Vdc power supply |
| 12             | COM                      | Common point of the digital Inputs          |
| 13             | 24 Vcc                   | 24 Vdc power supply                         |
| 14             | COM                      | Common point of the digital Inputs          |
| 15             | DI1                      | Digital Input 1:<br>Start / Stop            |
| 16             | DI2                      | Digital Input 2:<br>Reset                   |
| 17             | DI3                      | Digital Input 3:<br>No function             |
| 18             | DI4                      | Digital Input 4:<br>No function             |
| 19             | DI5                      | Digital Input 5:<br>No function             |
| 20             | DI6                      | Digital Input 6:<br>No function             |
| 21             | NF1                      | Digital output 1 DO1<br>Running             |
| 22             | C1                       |   |
| 23             | NA1                      | Digital output 2 DO2<br>Bypass              |
| 24             | NF2                      |   |
| 25             | C2                       | Digital output 3 DO3<br>Fault               |
| 26             | NA2                      |   |
| 27             | NF3                      |   |
| 28             | C3                       |   |
| 29             | NA3                      |   |

Figure 5.30: XC1 terminal strip description



**Note:** in order to check the accessories available for each slot, refer to table 8.1.

Figure 5.31: Disposition of the connections on the control board 1

Directions for signal and control wiring:

- The SSW7000 digital inputs allow several types of electrical connection. They can be activated by the internal auxiliary +24 Vdc supply using as the common point the DGND\* or the +24 Vdc. They can also be activated through an external +24 Vdc (wired to a PLC) using either the 0 V of that power supply or the +24 Vdc as the common point, according to the application needs:




Figure 5.32: Wiring diagram of the digital inputs using the internal power supply




Figure 5.33: Wiring diagram of the digital inputs using an external power supply

- The analog inputs and outputs are programmed to operate in the 0 to 10 V range as the factory setting, and they can be changed through the S1 DIP switches, according to the [table 5.18](#).

Table 5.18: Configuration of the DIP-switches for the analog input and output signal type selection

| Signal at | Factory setting Function | DIP Switch | Type of Signal Selection  | Ajuste de fábrica |
|-----------|--------------------------|------------|---|-------------------|
| AI1       | No function              | S1.4       | OFF: 0 to 10 V (factory setting)<br>ON: 4 to 20 mA / 0 to 20 mA       | OFF               |
| AI2       | No function              | S1.3       | OFF: 0 to $\pm 10$ V (factory setting)<br>ON: 4 to 20 mA / 0 to 20 mA | OFF               |
| AO1       | No function              | S1.1       | OFF: 4 to 20 mA / 0 to 20 mA<br>ON: 0 to 10 V (factory setting)       | ON                |
| AO2       | No function              | S1.2       | OFF: 4 to 20 mA / 0 to 20 mA<br>ON: 0 to 10 V (factory setting)       | ON                |

The parameters related to AI1, AI2, AO1 and AO2 must also be adjusted according to the DIP switch selection and the desired values

- Wire gauge: 0.5 mm<sup>2</sup> (20 AWG) to 1.5 mm<sup>2</sup> (14 AWG).
- Maximum tightening torque: 0.5 N.m (4.50 lbf.in).
- The wiring at XC1 must be made with shielded cables and laid separately from other wirings (power, 110 V / 220 V commands, etc.), according to the [table 5.19](#).

Table 5.19: Separation distances between wirings

| Wiring Length   | Minimum Separatin Distance |
|-----------------|----------------------------|
| 30 m (100 ft)   | 10 mm (3.94 in)            |
| > 30 m (100 ft) | 25 mm (9.84 in)            |

- The [figure 5.34](#) shows the cable shield connection. Refer to the shield connection example showed in the [figure 5.35](#).




Figure 5.34: Shielding conection

- Relays, contactors and solenoids installed inside the SSW7000 cabinet may generate interferences in the control circuit. In order to eliminate this effect, RC suppressors must be installed in parallel with the coils in case of AC power supply, and freewheeling diodes in case of DC power supply.
- When the HMI is installed outside the SSW7000 cabinet, its cable must be laid separately from the other installation cables, distant at least 100 mm (3.94 in) from those cables.




Figure 5.35: Example of cable shield connection of connector XC1

## Motor starting control through digital inputs:

- The SSW7000 presents 5 command sources: HMI, digital inputs, serial communication, fieldbus communication and SoftPLC. The command source is selected through the parameters P0220, P0228, P0229 and P0230. For more details, refer to the section 10.1 - Local/Remote Configuration, in the programming manual.
- When the command source is selected as digital inputs, then the programming is done through the parameters P0263 to P0268. For more details, refer to the section 10.4 - Digital Inputs, in the programming manual.
- The digital inputs feature programmable functions; [figure 5.36](#) shows some examples of programming.




Figure 5.36: Digital input command examples



#### 5.2.11. Auxiliary Low Voltage Supply Connection

Check the electric project that accompanies the product, which must contain the indication of the connections, including the power supply and the use of circuit breakers to protect the power supply circuit.

Components fed by the auxiliary power supply:

- The electronic board FSMT.
- The coils of the line and by-pass contactors.
- Auxiliary contactors used in the cabinet.
- Power arm fans (if used).

**NOTE!**

The auxiliary low voltage power supply value must match the electronics supply value specified in the product code. Refer to the section [3.3 - How to Specify the SSW7000 Model \(Smart Code\)](#).



## 6 INTERNAL CONNECTIONS

### 6.1. SSW7000 ELECTRONIC BOARDS

The SSW7000 is supplied with the versions of electronic boards 2 (V2) and 3 (V3). The both versions use the same source board (FSMT), but with different firmware. The version 3 was developed to attend the electrical isolation class required for the SSW7000 of 13.8kV. The two versions of electronic boards operate with voltage supply at 110/220Vac (automatic selection).

Table 6.1: Versions of electronic boards SSW7000/SSW7000C

| Version 2           |   |                     |   | Version 3           |   |
|---------------------|---|---------------------|---|---------------------|---|
| SSW7000 (110V/220V) |   | SSW7000C (110/220V) |   | SSW7000C (110/220V) |   |
| Name                | Description   | Name                | Description   | Name                | Description   |
| CC11                | Control board C1 – interface with the user            | CC11                | Control board C1 – interface with the user            | CC11                | Control board C1 – interface with the user            |
| CSM2.00             | Control board C2 – medium voltage control for 2.3 kV  | CSM2.00             | Control board C2 – medium voltage control for 2.3 kV  | CSM3.02             | Control board C2 – medium voltage control for 6.9 kV  |
| CSM2.01             | Control board C2 – medium voltage control for 4.16 kV | CSM2.01             | Control board C2 – medium voltage control for 4.16 kV | CSM3.03             | Control board C2 – medium voltage control for 13.8 kV |
| CSM2.02             | Control board C2 – medium voltage control for 6.9 kV  | FSMT.00             | Power supply of board CC11, fixed relay outputs       | FSMT.01             | Power supply of board CC11, fixed relay outputs       |
| FSMT.00             | Power supply of board CC11, fixed relay outputs       | GDSMC.00            | Gate driver with temperature measurement              | GDSMC2.00           | Gate driver with temperature measurement              |
| GD1SM               | Upper gate driver                                     | GDSMC.01            | Gate driver without temperature measurement           | GDSMC2.01           | Gate driver without temperature measurement           |
| GD2SM               | Lower gate driver                                     |                     |   |                     |   |

Note. In the CSM board is connected a specific toroidal transformer for each version of electronic boards.

#### 6.1.1. CC11 Board

Table 6.2: Description of the CC11board connectors

| Terminal Strip |     | Description   |
|----------------|-----|---|
| XC1            |     | User connections  |
| 1 a 29         |     | Refer to the item 5.2.10. - User Signal and Control Connections |
| SLOT           |     | User connections  |
| 1              |     | Accessory for the motor temperature measurement                 |
| 2              |     |   |
| 3              |     | Communication accessories                                       |
| 4              |     | Anybus-CC communication accessories                             |
| 5              |     | Flash memory  |
| Interface      |     | User connections  |
| XC20           |     | USB   |
| XC21           |     | HMI   |
| CC11           | FSM | Connections between boards                                      |
| XC60           | XC1 | Signals and CC11 feeding  |



#### NOTE!

The SSW7000 CC11 hardware is identical to that of the CFW-11 CC11. However, the firmware version and the PLD code are different. Because of the different PLD code, it is not possible to transform a CFW-11 board into an SSW7000 one by simply updating the firmware. Only the CC11xy.Sz boards are adequate for the SSW7000. If an SSW7000 firmware version is flashed into a board with a CFW-11 PLD, then the fault “Incompatible PLD Firmware” will appear on the display.

## 6.1.2. CSM Board Connections

Table 6.3: Description of the CSM2/CSM3 board connections

| CSM2           |   |  |
|----------------|---|--|
| Terminal Strip | Description   |  |
| XC1 CSM2       | Isolated supply                                     |  |
| 1 a 5          | CT input, common points (red)                       |  |
| 6              | CT input (yellow)                                   |  |
| XC2 CSM2       | Isolated supply                                     |  |
| 1 a 6          | Common points for the connections of the CTs (blue) |  |

| CSM3           |   |  |
|----------------|---|--|
| Terminal Strip | Description   |  |
| XC1 CSM3       | Isolated supply                                     |  |
| 1              | CT input (blue)                                     |  |
| 2 a 6          | Common points for the connections of the CTs (red)  |  |
| XC2 CSM3       | Isolated supply                                     |  |
| 1 a 2          | CT input (yellow)                                   |  |
| 3 a 6          | Common points for the connections of the CTs (blue) |  |

| CSM2 / CSM3    |  |   |
|----------------|--|---|
| Terminal Strip | Description                                  |   |
| XC4            | CT cable                                     | Current Reading   |
| 1              | Red  | CT - R-U arm current  |
| 2              | Black  |   |
| 3              | Red  | CT –S-V arm current   |
| 4              | Black  |   |
| 5              | Red  | CT – T-W arm current  |
| 6              | Black  |   |
| 7              | Red  | CT – Ground fault   |
| 8              | Black  |   |
| Terminal Strip | Description                                  |   |
| Optocouplers   | Power arm SCR firing and temperature reading |   |
| N27 a N32      | R-U arm firing                               |   |
| N21 a N26      | S-V arm SCR firing                           |   |
| N15 a N20      | T-W arm SCR firing                           |   |
| N7             | R-U arm temperature                          |   |
| N8             | S-V arm temperature                          |   |
| N9             | T-W arm temperature                          |   |
| CSM2/CSM3      | FSMT   | Connections between boards  |
| N3             | N3   | Communication between the C1 and C2 control boards through fiber optic cables |
| N4             | N4   |   |
| N5             | N5   |   |
| N11            | N11  | Current and voltage synchronism feedback                                      |
| N12            | N12  |   |

Table 6.4: CSM2/CSM3 board voltage measurement connections

| 500V | 2300V | 4160V | 6900V <sup>(1)</sup> | Voltage measurent |
|------|-------|-------|----------------------|-------------------|
| X1   | X3    | X4    | X4                   | R / 1L1           |
| X5   | X7    | X8    | X8                   | U / 2T1           |
| X9   | X11   | X12   | X12                  | S / 3L2           |
| X13  | X15   | X16   | X16                  | V / 4T2           |
| X17  | X19   | X20   | X20                  | T / 5L3           |
| X21  | X23   | X24   | X24                  | W / 6T3           |
| X25  | X27   | X28   | X28                  | PE                |




Figure 6.1: CSM2/CSM3 board layout

## 6.1.3. FSMT Board Connections

Table 6.5: Description of the FSMT board connectors

| Terminal Strip |             | Description  |
|----------------|-------------|--|
| X1             |             | AC supply  |
| 1              | Phase       | Control Unit Version 2:<br>- 110 to 230 Vac (-15 % ( 93,5 Vac ) to 10 % ( 253 Vac ) ) or 125 to 320 Vdc<br>Control Unit Version 3:<br>- 100 to 230 Vac (-15 % ( 85 Vac ) to 10 % ( 253 Vac ) ) or 110 to 320 Vdc |
| 2              | Neutral     |  |
| 3              | Ground      |  |
| X8             |             | Command output for the contactors  |
| 1              | NO          | AC – Coil – Bypass contactor   |
| 2              | Phase       | Supply for the contactors  |
| 3              | NO          | AC – Coil – Line contactor   |
| 4              | Phase       | Supply for the contactors  |
| 5              | NO          | AC – Coil – Rotation direction   |
| 6              | Phase       | Supply for the contactors  |
| 7              | NO          | NO relay – Fan   |
| 8              | NO          | NO relay - Fan   |
| 9              | NC          | Not connected  |
| <b>FSMT</b>    | <b>CC11</b> | <b>Connections between boards</b>  |
| XC1            | XC60        | Signals and CC11 feeding   |
| <b>FSMT</b>    | <b>CSM</b>  | <b>Connections between boards</b>  |
| N3             | N3          | Communication between the C1 and C2 control boards through optic cables  |
| N4             | N4          |  |
| N5             | N5          |  |
| N11            | N11         | Current and voltage synchronism feedback   |
| <b>FSMT</b>    | <b>TF</b>   | <b>Connections between FSMT and CSM transformer</b>  |
| XC2: 1         | Red         | Phase – transformer TF primary - CSM   |
| XC2: 2         | Black       | Phase – transformer TF primary - CSM   |
| XC2: 3         | Shield      | Shield ground - PE   |

**NOTE!**

The timer delay must be set for 0.2 seconds.

Connection diagram of the digital outputs with defined functions to control contactors with AC coil and auxiliary closing coil.




Figure 6.2: FSMT AC contactor wiring diagram.

#### 6.1.4. Power Arm Internal Connections

Refer to the item [5.2.1 - Power Arm Electrical and Fiber Optic Connections](#) to make the external power arm connections.

##### GDSMC2.00:

Table 6.6: GDSMC2.00 boards connections

| Conector        | Description                   |
|-----------------|-------------------------------|
| XC3:1 and XC4:1 | SCRs gate                     |
| XC3:2 and XC4:2 | SCRs cathode                  |
| XC1 and XC2     | Supply CTs                    |
| XC5             | Heatsink NTC                  |
| N3 and N4       | Firing fiber optic cables     |
| N5              | Temperature fiber optic cable |

##### GDSMC2.01:

Table 6.7: GDSMC2.01 boards connections

| Conector        | Description               |
|-----------------|---------------------------|
| XC3:1 and XC4:1 | SCRs gate                 |
| XC3:3 and XC4:2 | SCRs cathode              |
| XC1 and XC2     | Supply CTs                |
| N3 and N4       | Firing fiber optic cables |

##### GD1SM / GDSMC.00:

Table 6.8: GD1SM and GDSMC.00 boards connections

| Conector | Description                   |
|----------|-------------------------------|
| XC1:1    | SCR gate                      |
| XC1:3    | SCR cathode                   |
| XC2      | Supply CT                     |
| XC3      | Heatsink NTC                  |
| N1       | Firing fiber optic cable      |
| N4       | Temperature fiber optic cable |
| J1       | SCR anode                     |
| J2       | SCR cathode                   |

##### GDSMC.01:

Table 6.9: GDSMC.01 board connections

| Conector | Description              |
|----------|--------------------------|
| XC1:1    | SCR gate                 |
| XC1:3    | SCR cathode              |
| XC2      | Supply CT                |
| N1       | Firing fiber optic cable |
| J1       | SCR anode                |
| J2       | SCR cathode              |

##### GD2SM:

Table 6.10: GD2SM board connections

| Conector | Description              |
|----------|--------------------------|
| XC1:1    | SCR gate                 |
| XC1:3    | SCR cathode              |
| XC2      | Supply CT                |
| N1       | Firing fiber optic cable |
| J1       | SCR anode                |
| J2       | SCR cathode              |
| J3       | Snubber connection       |

The location of the GD1SM, GD2SM, (SSW7000A) and GDSMC, GDSMC2 (SSW7000C) boards in the power arm is showed in the [figure 6.3](#) and [figure 6.4](#).




Figure 6.3: GD1SM, GD2SM (SSW7000) and GDSMC (SSW7000C) firing boards.




Figure 6.4: GDSMC2.00 e GDSMC2.01 (SSW7000C) firing boards.



### 6.1.5. Connections between the CSM Board and the TF Transformer




Figure 6.5: Connection of the transformer to the CSM board (Version 2)




Figure 6.6: Connection of the transformer to the CSM3 board (Version 3)

- Transformer TF2 (version 2), supplied at 90Vac, 800Hz.
- Transformer TF3 (version 3), supplied at 66Vac, 400Hz.

### 6.1.6. Connections between the Low Voltage and the Medium Voltage Controls




Figure 6.7 (a): Connections between the low voltage and the medium voltage controls – Version 2




Figure 6.7 (b): Connections between the low voltage and the medium voltage controls – Version 3

- Use a two wire shielded cable with 0.5 mm<sup>2</sup> cross section, 300 V insulation and the shield connected to the ground at the FSMT cable end, in order to make the connection between the FSMT.00/FSMT.01 and the TF2/TF3.

## 7 FIRST ENERGIZATION

After finishing the electrical installation according to the section [5.2 - Electrical Installation](#) and before starting any test with the SSW7000, check the following points:



**DANGER!**

Switch on the medium voltage only after the proper installation of the power arms.

1. Verify whether the power, ground, motor and control connections are correct and tight.
2. Verify whether the CSM voltage reading connections match the line voltage.
3. Remove all the tools and odd materials from the SSW7000 panel.
4. Verify whether the motor current and voltage match the SSW7000 model.
5. Decouple the motor from the load.
6. Switch on the electronics and execute the test mode to check the wiring with the panel door open.
7. Close the doors of the SSW7000 panel.
8. Measure the line voltage and verify whether it is within the allowed tolerances for the SSW7000 model and for the motor.
9. Carry out the tests described in section [7.1 - SSW7000 Operation Verification](#), in order to check the proper operation of the SSW7000.



**DANGER!**

Always disconnect the main supply before performing any connection inside the SSW7000 cabinet.



**DANGER!**

Disconnect the upstream voltage and connect the SSW7000 input to the ground at an adequate point when any maintenance is performed at the SSW7000 disconnect switch.

### 7.1. SSW7000 OPERATION VERIFICATION



**DANGER!**

In case the power supply of the low voltage circuits of the SSW7000 is performed by transformer with primary connected to the medium voltage circuit, tests must not be carried out with the panel door open. In this case, the test sequence described in item [7.1.1 - Test without Three-phase Voltage](#) must not be carried out and, additionally, maintenance procedures on the SSW7000 must be carefully planned in order to prevent accidents.

The SSW7000 has a test mode that allows verifying if the cables of the panel are properly connected. The test mode commands the selected signals and does not allow starting the motor.

There are two stages in the test mode. The first stage is executed with the three-phase supply off and with the cabinet door open. The second stage of the test mode requires the three-phase supply switched on and a connected motor. During this stage, the cabinet door must be closed.

The test can be performed either with medium voltage or with low voltage.

### 7.1.1. Test without Three-phase Voltage

1. Switch on the low voltage.
2. Verify whether all the red LEDs on the gate driver boards (GD1SM, GD2SM, GD5MC and GD5MC2) and on the CSM board are on.
3. Remove each arm temperature reading fiber optic cable at a time and check if the error indicated on the HMI is related to the respective phase, then connect the cable again and reset the fault
4. Start the test mode and verify the results with P0321 options from 1 to 5. To get more details, refer to the SSW7000 programming manual.
5. Switch off the low voltage.

### 7.1.2. Test with Medium Voltage

In order to carry out the medium voltage test, follow the procedures below.

1. Connect the SSW7000 input to the supply line, according to the section [5.2 - Electrical Installation](#).
2. Connect the motor to the SSW7000 output, according to the section [5.2 - Electrical Installation](#).
3. Close the cabinet door.
4. Decouple the motor from the load.
5. Switch on the low voltage. Refer to the item [5.2.11 - Auxiliary Low Voltage Supply Connection](#). Verify the energization success through the SSW7000 HMI.
6. Read the programming manual chapters 6 - About the SSW7000 Soft-Starter, 7 - HMI and 8 - Programming Basic Instructions, and then perform the recommended programming.
7. Program the motor parameters, P0400 to P0405 according to its nameplate data.
8. Follow the test mode routine according to the programming manual, section 14.2 - Test Mode (P0321 options 6 to 9).

**NOTE!**

In order to perform the functional test and the CT tests the motor rated current must be at least 10% of the SSW7000 rated current.

9. If the test mode results are satisfactory, perform a functional test running the motor with the desired control type. For more details, refer to the programming manual, chapter 11 - Control Type.

## 7.1.3. Test with Low Voltage

It is possible to perform the tests of the item [7.1.2 - Test with Medium Voltage](#), with low voltage. Therefore, a hardware modification and a parameter change are necessary. It is very important to undo these modifications before energizing the SSW7000 in medium voltage.

In order to carry out the low voltage test, follow the procedures below.

1. Change the CSM board voltage measurement cables to the 500 V position. Refer to the item [6.1.2 - CSM Board Connections](#).
2. Connect the SSW7000 input to a supply line of up to 500 Vac, according to the section [5.2 - Electrical Installation](#).
3. Connect the motor to the SSW7000 output, according to the section [5.2 - Electrical Installation](#).
4. Close the cabinet door.
5. Switch on the low voltage. Refer to the item [5.2.11 - Auxiliary Low Voltage Supply Connection](#). Verify the energization success through the SSW7000 HMI.
6. Program the line rated voltage parameter, P0296, to 220/500 V.
7. Program the motor parameters, P0400 to P0405 according to its nameplate data.
8. Follow the test mode routine according to the programming manual, section 14.2 - Test Mode.



### NOTE!

In order to perform the functional test and the CT tests the motor rated current must be at least 10% of the SSW7000 rated current.

9. If the test results are satisfactory, leave the test mode.
10. Perform a functional test running the motor with the desired control type. For more details, refer to the programming manual, chapter 11 - Control Type.



### DANGER!

After the low voltage motor test, reconnect the voltage measurement cables to their original positions and adjust the SSW7000 rated voltage at P0296. Refer to the item [6.1.2 - CSM Board Connections](#).

### 7.2. COMMISSIONING

If the test mode results are satisfactory, perform a functional test with the motor decoupled from the load.

1. Initially, voltage ramp control can be used to start the motor, with long starting times ( $P0102 \approx 25$  s) and low initial voltages ( $P0101 \approx 40$  %), in order to minimize the starting currents. For details on the control method to be used, refer to the programming manual, chapters 11 - Control Type and 20 - Programming Information and Suggestions.
2. Before coupling the load to motor, verify the rotation direction and program the protections as explained in the programming manual, chapter 15 – Protections.
3. Program a motor thermal protection method.
4. Couple the load to the motor shaft, power up the system and start the motor.
5. Data from this starting can be monitored in several ways:
  - Diagnosis parameters such as maximum starting current, average starting current and real starting time. Refer to the programming manual, section 16.3 - Diagnostics.
  - In the trace function, it is possible to register the current and voltage variable of the SSW7000. Refer to chapter 19 - Trace Function, of the programming manual.
  - Through the SuperDrive G2 graphic monitoring. Check out information about the SuperDrive G2 at WEG website ([www.weg.net](http://www.weg.net)).
6. By means of the monitoring, it is possible to set a better programming of the SSW7000 to be applied in the next starts at full operation duty



#### **ATTENTION!**

Pay close attention to the SSW7000 limits:

- Maximum starting time.
- Maximum starting current.
- Interval between starts.

The nonobservance of these limits may lead to damage to the SSW7000.

### 7.3. CONNECTION TO A PC

**NOTE!**

For the USB connection, use a laptop computer isolated from the ground or a desktop connected to the same protection earth (PE) as the SSW7000.

The USB connection is electrically isolated from the supply line and from other internal high voltages; however, it is not isolated from the protection earth (PE)..

**NOTE!**

Always use a shielded USB cable, "standard host/device shielded USB cable". Cables without shield may cause communication errors.

Example of cables: Samtec:

USBC-AM-MB-B-B-S-1 (1 meter [3.28 ft]);

USBC-AM-MB-B-B-S-2 (2 meter [6.56 ft]);

USBC-AM-MB-B-B-S-3 (3 meter [9.84 ft]).

To control the SSW7000, and to visualize or program its parameters through a personal computer (PC), it is necessary to install the SuperDrive G2 in the PC. The SuperDrive G2 can be downloaded from the website [www.weg.net](http://www.weg.net).

Basic procedure for transferring data from the PC to the SSW7000:

1. Install the SuperDrive G2 software in the PC.
2. Connect the PC to the SSW7000 through the USB cable
3. Start the SuperDrive G2.

For more details on the SuperDrive G2 operation, refer to its help menu.

### 7.4. FLASH MEMORY MODULE

Location of the module according to the [figure 5.31](#).

Functions:

- Storage of an image of the SSW7000 parameters.
- It allows transferring parameters stored in the flash memory module to the SSW7000
- It allows transferring the firmware stored in the flash memory module to the SSW7000.
- It stores the program used by the SoftPLC..

Every time the SSW7000 is energized, the SoftPLC program is transferred to the RAM memory located on the SSW7000 control board 1, and it is executed.

For more details, refer to the SSW7000 programming and SoftPLC manuals.

**ATTENTION!**

Before installing or removing the flash memory module, remove the power from the SSW7000 and wait until the HMI and LEDs go off.





## 8 ACCESSORIES

Accessories are incorporated to the SSW7000 in a simple and fast manner, using the plug and play concept. When an accessory is fitted into the slot, the control circuit identifies its model and presents the installed accessory code in P0027 or P0028. Accessories must be installed and removed with the control circuit of the SSW7000 de-energized.

The part number of each accessory and the available models are presented in the [table 8.1](#). They can be ordered separately and are shipped in their own packages, which contain the parts and manuals for their installation, programming and operation.


**NOTE!**

Each slot accommodates just one module at a time.

Table 8.1: Accessory models

| Part number   | Name           | Description   | Slot    | Identification Parameter |        |
|---|----------------|---|---------|--------------------------|--------|
|   |                |   |         | P0027                    | P0028  |
| Control accessories for installation in the slots 1, 2 e 3                          |                |   |         |                          |        |
| 11638312  | IOE-04         | Module for 8 temperature sensors PT100 type   | 1 and 2 | 28                       | ---    |
| 11008102  | RS485-01       | RS-485 serial communication module (Modbus)   | 3       | ---                      | CE--   |
| 11008103  | RS232-01       | RS-232C serial communication module (Modbus)  | 3       | ---                      | CC--   |
| 11008104  | RS232-02       | RS-232C serial communication module with switches fo the microcontroller flash memory programming | 3       | ---                      | CC--   |
| Anybus-CC accessories for Installation in the Slot 4                                |                |   |         |                          |        |
| 11008107  | PROFDP-05      | ProfibusDP Interface module   | 4       | ---                      | ---(2) |
| 11550548  | PROFINETIO-05  | ProfinetIO interface module   | 4       | ---                      | ---(2) |
| 11008158  | DEVICENET-05   | DeviceNet Interface module  | 4       | ---                      | ---(2) |
| 10933688  | ETHERNET/IP-05 | Ethernet/IPInterface module   | 4       | ---                      | ---(2) |
| 11008160  | RS232-05       | RS-232 Interface module (passive) (Modbus)  | 4       | ---                      | ---(2) |
| 11008161  | RS485-05       | RS-485 Interface module (passive) (Modbus)  | 4       | ---                      | ---(2) |
| Flash memory module for Installation in the slot 5 – Included as a factory standard |                |   |         |                          |        |
| 11008912  | MMF-01         | Flash memory module   | 5       | ---                      | ---(1) |
| Other accessories   |                |   |         |                          |        |
| 11008913  | HMI-01         | SeparatedHMI (3)  | HMI     | ---                      | ---    |
| 11010521  | RHMIF-01       | Frame for remote HMI mounting (IP56 protection degree)  | HMI     | ---                      | ---    |
| 11940242  | TC FT          | Ground fault CT   | ---     | ---                      | ---    |

(1) See programming manual.

(2) See Anybus-CC Communication Manual.

(3) See section [4.2 - HMI Cable](#) for cable details.



## 9 TECHNICAL SPECIFICATIONS

### 9.1. POWER DATA

Table 9.1 Power data

|              |   |   |
|--------------|---|---|
| Power supply | Power section voltage (R/1L1, S/3L2, T/5L3)     | Low voltage test:<br>500Vac: (-60% to +10%) or (200 a 550Vca)<br>Models:<br>2300Vac: (-60% to +10%) or (920 to 2530Vca)<br>4160Vac: (-60% to +10%) or (1664 to 4576Vca)<br>6900Vac: (-60% to +10%) or (2760 to 7590Vca) |
|              | Frequency                                       | (50 to 60Hz): (±10%) or (45 a 66Hz)   |
| Capacity     | Number maximum of starts                        | 5 starts in 2 hours<br>(one start every 30 minutes)   |
|              | Starting cycle – SSW7000                        | AC-53a: 4,5-30:50–2   |
|              | Starting cycle – SSW7000C                       | AC-53a: 4,0-20:50–2   |
| Thyristors   | Medium voltage SCRs per power arm               | 2300Vac: 2 SCRs per power arm<br>4160Vac: 2 matched pairs of SCRs<br>6900Vac: 2 sets of 3 matched SCRs  |
|              | Maximum reverse peak voltage on the power arms. | 2300Vac: 6,5k V<br>4160Vac: 13 kV<br>6900Vac: 19,5 kV   |
| Protections  | Hardware protections                            | dV/dt filter<br>Active overvoltage protection at the SCRs   |

#### 9.1.1. Operational Capacity

**180A: AC-53a: 4,5-30:50-2**

|        |   |
|--------|---|
| 180A   | SSW7000 rated current.  |
| AC-53a | Utilization category according to the IEC 60947-4-2 standard. |
| 4,5    | Starting current regarding the rated current.                 |
| 30     | Starting time in seconds.                                     |
| 50     | Duty cycle in percentage.                                     |
| 2      | Number of starts per hour.                                    |

Table 9.2. Maximum motor power driven by SSW7000A,B and D

| Model | Voltage |      |       |      |       |      |
|-------|---------|------|-------|------|-------|------|
|       | 2300V   |      | 4160V |      | 6900V |      |
|       | cv      | kW   | cv    | kW   | cv    | kW   |
| 70 A  | 300     | 220  | 600   | 440  | 1000  | 730  |
| 180 A | 800     | 590  | 1500  | 1100 | 2500  | 1840 |
| 300 A | 1350    | 1000 | 2500  | 1840 | 3900  | 2870 |
| 360 A | 1600    | 1180 | 3000  | 2200 | 4700  | 3500 |
| 500 A | 2200    | 1620 | 4000  | 2940 | 6600  | 4860 |
| 600 A | 2600    | 1910 | 4900  | 3600 | 7800  | 5740 |

Table 9.3: Maximum motor power driven by SSW7000C

| Model | Voltage |      |       |      |        |      |
|-------|---------|------|-------|------|--------|------|
|       | 2300V   |      | 4160V |      | 6900V* |      |
|       | cv      | kW   | cv    | kW   | cv     | kW   |
| 125 A | 500     | 400  | 1000  | 730  | 1650   | 1220 |
| 250 A | 1100    | 810  | 2100  | 1550 | 3250   | 2400 |
| 360 A | 1600    | 1180 | 3000  | 2200 | 4700   | 3500 |

For bigger motor power, please contact WEG.

The SSW7000 standard is designed to withstand a 4,5xIn overload duty for 30s, the SSW7000C standard is designed to withstand a 4xIn overload duty for 20s.

In order to select the SSW7000 model according to the desired overload duty, see [table 9.4](#) to [table 9.11](#), which inform the maximum motor starting time for different current levels and different quantities of starts per hour.



## NOTE!

For different overload duties, it is important to take into account the correct sizing of the medium-voltage fuses.

## SSW7000A – 180A

Table 9.4: Maximum time per start for the SSW7000A – 180A

| SSW7000 - 180A     | Starts per Hour ( Initial Temperature 40°C ) |     |     |     |     |     |     |     |     |     |
|--------------------|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| Current limitation | 1  | 2   | 3   | 4   | 5   | 6   | 7   | 8   | 9   | 10  |
| 150% ( 270A )      | 60s  | 60s | 60s | 60s | 60s | 60s | 60s | 60s | 60s | 60s |
| 200% ( 360A )      | 60s  | 60s | 60s | 60s | 60s | 60s | 60s | 60s | 60s | 60s |
| 250% ( 450A )      | 60s  | 60s | 60s | 60s | 60s | 60s | 57s | 50s | 44s | 40s |
| 300% ( 540A )      | 60s  | 60s | 60s | 60s | 54s | 45s | 38s | 34s | 30s | 27s |
| 350% ( 630A )      | 60s  | 60s | 60s | 45s | 36s | 30s | 26s | 23s | 20s | 18s |
| 400% ( 720A )      | 60s  | 59s | 39s | 30s | 24s | 20s | 17s | 15s | 13s | 12s |
| 450% ( 810A )      | 60s  | 36s | 24s | 18s | 15s | 12s | 10s | 9s  | 8s  | 7s  |
| 500% ( 900A )      | 39s  | 19s | 13s | 10s | 8s  | 6s  | 6s  | 5s  | 4s  | 4s  |
| 550% ( 990A )      | 12s  | 6s  | 4s  | 3s  | 3s  | 3s  | 2s  | 2s  | 2s  | 2s  |
| 600% ( 1080A )     | 2s   | 2s  | 2s  | 2s  | 2s  | 1s  | 1s  | 1s  | 1s  | 1s  |

## SSW7000A – 300A

Table 9.5: Maximum time per start for the SSW7000A – 300A

| SSW7000 - 300A     | Starts per Hour ( Initial Temperature 40°C ) |     |     |     |     |     |     |     |     |     |
|--------------------|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| Current limitation | 1  | 2   | 3   | 4   | 5   | 6   | 7   | 8   | 9   | 10  |
| 150% ( 450A )      | 60s  | 60s | 60s | 60s | 60s | 60s | 60s | 60s | 60s | 60s |
| 200% ( 600A )      | 60s  | 60s | 60s | 60s | 60s | 60s | 60s | 55s | 49s | 44s |
| 250% ( 750A )      | 60s  | 60s | 60s | 60s | 59s | 49s | 42s | 37s | 33s | 29s |
| 300% ( 900A )      | 60s  | 60s | 60s | 51s | 40s | 34s | 29s | 25s | 22s | 20s |
| 350% ( 1050A )     | 60s  | 60s | 47s | 35s | 28s | 23s | 20s | 18s | 16s | 14s |
| 400% ( 1200A )     | 60s  | 49s | 32s | 24s | 19s | 16s | 14s | 12s | 11s | 10s |
| 450% ( 1350A )     | 60s  | 33s | 22s | 16s | 13s | 11s | 9s  | 8s  | 7s  | 7s  |
| 500% ( 1500A )     | 41s  | 21s | 14s | 10s | 8s  | 7s  | 6s  | 5s  | 5s  | 4s  |
| 550% ( 1650A )     | 23s  | 11s | 8s  | 6s  | 5s  | 4s  | 3s  | 3s  | 3s  | 3s  |
| 600% ( 1800A )     | 8s   | 4s  | 3s  | 3s  | 2s  | 2s  | 2s  | 2s  | 2s  | 2s  |

## SSW7000A – 360A

Table 9.6: Maximum time per start for the SSW7000A – 360A

| SSW7000 - 360A     | Starts per Hour ( Initial Temperature 40°C ) |     |     |     |     |     |     |     |     |     |
|--------------------|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| Current limitation | 1  | 2   | 3   | 4   | 5   | 6   | 7   | 8   | 9   | 10  |
| 150% ( 540A )      | 60s  | 60s | 60s | 60s | 60s | 60s | 60s | 60s | 60s | 60s |
| 200% ( 720A )      | 60s  | 60s | 60s | 60s | 60s | 60s | 60s | 58s | 52s | 46s |
| 250% ( 900A )      | 60s  | 60s | 60s | 60s | 60s | 57s | 49s | 43s | 38s | 34s |
| 300% ( 1080A )     | 60s  | 60s | 60s | 60s | 52s | 43s | 37s | 32s | 29s | 26s |
| 350% ( 1260A )     | 60s  | 60s | 60s | 51s | 41s | 34s | 29s | 25s | 23s | 20s |
| 400% ( 1440A )     | 60s  | 60s | 54s | 41s | 32s | 27s | 23s | 20s | 18s | 16s |
| 450% ( 1620A )     | 60s  | 60s | 44s | 33s | 26s | 22s | 19s | 16s | 15s | 13s |
| 500% ( 1800A )     | 60s  | 54s | 36s | 27s | 21s | 18s | 15s | 13s | 12s | 11s |
| 550% ( 1980A )     | 60s  | 44s | 29s | 22s | 18s | 15s | 13s | 11s | 10s | 9s  |
| 600% ( 2160A )     | 60s  | 37s | 24s | 18s | 15s | 12s | 10s | 9s  | 8s  | 7s  |

## SSW7000D – 500A

Table 9.7: Maximum time per start for the SSW7000D – 500A

| SSW7000D - 500A    | Starts per Hour ( Initial Temperature 40°C ) |     |     |     |     |     |     |     |     |     |
|--------------------|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| Current limitation | 1  | 2   | 3   | 4   | 5   | 6   | 7   | 8   | 9   | 10  |
| 150% ( 750A )      | 60s  | 60s | 60s | 60s | 60s | 60s | 60s | 55s | 49s | 44s |
| 200% ( 1000A )     | 60s  | 60s | 60s | 60s | 58s | 49s | 42s | 36s | 32s | 29s |
| 250% ( 1250A )     | 60s  | 60s | 60s | 51s | 41s | 34s | 29s | 26s | 23s | 21s |
| 300% ( 1500A )     | 60s  | 60s | 50s | 38s | 30s | 25s | 22s | 19s | 17s | 15s |
| 350% ( 1750A )     | 60s  | 57s | 38s | 28s | 23s | 19s | 16s | 14s | 13s | 11s |
| 400% ( 2000A )     | 60s  | 43s | 29s | 22s | 17s | 14s | 12s | 11s | 10s | 9s  |
| 450% ( 2250A )     | 60s  | 33s | 22s | 17s | 13s | 11s | 9s  | 8s  | 7s  | 7s  |
| 500% ( 2500A )     | 51s  | 25s | 17s | 13s | 10s | 8s  | 7s  | 6s  | 6s  | 5s  |
| 550% ( 2750A )     | 39s  | 19s | 13s | 10s | 8s  | 6s  | 6s  | 5s  | 4s  | 4s  |
| 600% ( 3000A )     | 29s  | 14s | 10s | 7s  | 6s  | 5s  | 4s  | 4s  | 3s  | 3s  |

## SSW7000D – 600A

Table 9.8: Maximum time per start for the SSW7000D – 600A

| SSW7000D - 600A    | Starts per Hour ( Initial Temperature 40°C ) |     |     |     |     |     |     |     |     |     |
|--------------------|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| Current limitation | 1  | 2   | 3   | 4   | 5   | 6   | 7   | 8   | 9   | 10  |
| 150% ( 900A )      | 60s  | 60s | 60s | 60s | 60s | 60s | 57s | 49s | 44s | 40s |
| 200% ( 1200A )     | 60s  | 60s | 60s | 60s | 53s | 44s | 38s | 33s | 29s | 27s |
| 250% ( 1500A )     | 60s  | 60s | 60s | 47s | 38s | 32s | 27s | 24s | 21s | 19s |
| 300% ( 1800A )     | 60s  | 60s | 47s | 35s | 28s | 23s | 20s | 18s | 16s | 14s |
| 350% ( 2100A )     | 60s  | 54s | 36s | 27s | 21s | 18s | 15s | 13s | 12s | 11s |
| 400% ( 2400A )     | 60s  | 42s | 28s | 21s | 17s | 14s | 12s | 10s | 9s  | 8s  |
| 450% ( 2700A )     | 60s  | 32s | 22s | 16s | 13s | 11s | 9s  | 8s  | 7s  | 6s  |
| 500% ( 3000A )     | 51s  | 25s | 17s | 13s | 10s | 8s  | 7s  | 6s  | 6s  | 5s  |
| 550% ( 3300A )     | 40s  | 20s | 13s | 10s | 8s  | 7s  | 6s  | 5s  | 4s  | 4s  |
| 600% ( 3600A )     | 31s  | 15s | 10s | 8s  | 6s  | 5s  | 4s  | 4s  | 3s  | 3s  |

## SSW7000C – 125A

Table 9.9: Maximum time per start for the SSW7000C – 125A

| SSW7000C - 125A    | Starts per Hour ( Initial Temperature 40°C ) |     |     |     |     |     |     |     |     |     |
|--------------------|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| Current limitation | 1  | 2   | 3   | 4   | 5   | 6   | 7   | 8   | 9   | 10  |
| 150% ( 188A )      | 60s  | 60s | 60s | 60s | 60s | 60s | 60s | 60s | 60s | 60s |
| 200% ( 250A )      | 60s  | 60s | 60s | 60s | 60s | 60s | 60s | 60s | 60s | 60s |
| 250% ( 313A )      | 60s  | 60s | 60s | 60s | 60s | 60s | 60s | 60s | 60s | 60s |
| 300% ( 375A )      | 60s  | 60s | 60s | 60s | 60s | 60s | 60s | 56s | 50s | 45s |
| 350% ( 438A )      | 60s  | 60s | 60s | 60s | 60s | 55s | 48s | 42s | 37s | 33s |
| 400% ( 500A )      | 60s  | 60s | 60s | 60s | 50s | 42s | 36s | 31s | 28s | 25s |
| 450% ( 563A )      | 60s  | 60s | 60s | 48s | 38s | 32s | 27s | 24s | 21s | 19s |
| 500% ( 625A )      | 60s  | 60s | 48s | 36s | 29s | 24s | 21s | 18s | 16s | 14s |
| 550% ( 688A )      | 60s  | 54s | 36s | 27s | 22s | 18s | 16s | 14s | 12s | 11s |
| 600% ( 750A )      | 60s  | 40s | 27s | 20s | 16s | 13s | 11s | 10s | 9s  | 8s  |

## SSW7000C – 250A

Table 9.10: Maximum time per start for the SSW7000C – 250A

| SSW7000C - 250A    | Starts per Hour ( Initial Temperature 40°C ) |     |     |     |     |     |     |     |     |     |
|--------------------|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| Current limitation | 1  | 2   | 3   | 4   | 5   | 6   | 7   | 8   | 9   | 10  |
| 150% ( 375A )      | 60s  | 60s | 60s | 60s | 60s | 60s | 60s | 60s | 60s | 60s |
| 200% ( 500A )      | 60s  | 60s | 60s | 60s | 60s | 60s | 60s | 58s | 52s | 47s |
| 250% ( 625A )      | 60s  | 60s | 60s | 60s | 60s | 54s | 46s | 40s | 36s | 32s |
| 300% ( 750A )      | 60s  | 60s | 60s | 57s | 46s | 38s | 33s | 29s | 26s | 23s |
| 350% ( 875A )      | 60s  | 60s | 56s | 42s | 34s | 28s | 24s | 21s | 19s | 17s |
| 400% ( 1000A )     | 60s  | 60s | 41s | 31s | 25s | 21s | 18s | 16s | 14s | 12s |
| 450% ( 1125A )     | 60s  | 46s | 31s | 23s | 18s | 15s | 13s | 11s | 10s | 9s  |
| 500% ( 1250A )     | 60s  | 33s | 22s | 17s | 13s | 11s | 10s | 8s  | 7s  | 7s  |
| 550% ( 1375A )     | 48s  | 24s | 16s | 12s | 10s | 8s  | 7s  | 6s  | 5s  | 5s  |
| 600% ( 1500A )     | 32s  | 16s | 11s | 8s  | 6s  | 5s  | 5s  | 4s  | 4s  | 3s  |

## SSW7000C – 360A

Table 9.11: Maximum time per start for the SSW7000C – 360A

| SSW7000C - 360A    | Starts per Hour ( Initial Temperature 40°C ) |     |     |     |     |     |     |     |     |     |
|--------------------|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| Current limitation | 1  | 2   | 3   | 4   | 5   | 6   | 7   | 8   | 9   | 10  |
| 150% ( 540A )      | 60s  | 60s | 60s | 60s | 60s | 60s | 60s | 60s | 59s | 53s |
| 200% ( 720A )      | 60s  | 60s | 60s | 60s | 60s | 60s | 52s | 45s | 40s | 36s |
| 250% ( 900A )      | 60s  | 60s | 60s | 60s | 53s | 44s | 38s | 33s | 30s | 27s |
| 300% ( 1080A )     | 60s  | 60s | 60s | 51s | 41s | 34s | 29s | 25s | 23s | 20s |
| 350% ( 1260A )     | 60s  | 60s | 53s | 40s | 32s | 26s | 23s | 20s | 18s | 16s |
| 400% ( 1440A )     | 60s  | 60s | 42s | 32s | 25s | 21s | 18s | 16s | 14s | 13s |
| 450% ( 1620A )     | 60s  | 51s | 34s | 26s | 21s | 17s | 15s | 13s | 11s | 10s |
| 500% ( 1800A )     | 60s  | 42s | 28s | 21s | 17s | 14s | 12s | 11s | 9s  | 8s  |
| 550% ( 1980A )     | 60s  | 35s | 23s | 17s | 14s | 12s | 10s | 9s  | 8s  | 7s  |
| 600% ( 2160A )     | 57s  | 29s | 19s | 14s | 11s | 10s | 8s  | 7s  | 6s  | 6s  |

## 9.2. CONTROL DATA

Table 9.12: Control data.

|                                |                  |  |
|--------------------------------|------------------|--|
| Supply                         | Control voltage  | Control Unit Version 2:<br>- 110 to 230 Vac(-15 % ( 93,5 Vac) to 10 % ( 253 Vac)) or 125 to 320 Vdc<br>Control Unit Version 3:<br>- 100 to 230 Vac(-15 % ( 85 Vac) to 10 % ( 253 Vac)) or 110 to 320 Vdc<br>*Note: The values informed are specific for the Control Units; they do not cover other components of the SSW7000, such as contactor coils.   |
|                                | Frequency        | .. (50 a 60 Hz): (±10 %) or (45 a 66 Hz)   |
|                                | Consumption      | <ul style="list-style-type: none"> <li>■ 110 Vac:</li> <li>- Continuous: 1400 mA</li> <li>- Peak: 9,5 A</li> <li>■ 220 Vac:</li> <li>- Continuous: 700 mA</li> <li>- Peak: 6,0 A</li> </ul>  |
| Control                        | Method           | <ul style="list-style-type: none"> <li>■ Voltage ramp</li> <li>■ Current limit</li> <li>■ Pumb control</li> <li>■ Torque control</li> <li>■ Current ramp</li> </ul>  |
| Inputs                         | Digital          | ■ 6 isolated digital inputs, 24 Vdc, with programmable functions   |
|                                | Analog           | <ul style="list-style-type: none"> <li>■ 2 differential inputs isolated by differential amplifier</li> <li>■ AI1 with a 12 bit resolution</li> <li>■ AI2 with 11bit resolution + sign, (0 to 10) V, (0 a 20) mA or (4 to 20) mA</li> <li>■ Impedance: 400 kΩ for (0 to 10 V), 500 Ω for (0 a 20 mA) or (4 to 20 mA), programmable functions</li> </ul>   |
| Outputs                        | Digital          | ■ 3 relays with NO/NC contacts, 240 Vac, 1 A, programmable functions   |
|                                | Analog           | ■ 2 isolated outputs,, (0 a 10 V) $RL \geq 10 \text{ k}\Omega$ (maximum load), 0 to 20 mA or 4 to 20 mA $RL \leq 500 \Omega$ , 11 bit resolution, programmable functions   |
| HMI<br>Human Machine Interface | Standard HMI     | <ul style="list-style-type: none"> <li>■ 9 keys: Start/Stop, Increment, Decrement, rotation direction, Jog, Local/remote, right soft key and Left soft key</li> <li>■ Graphic LCD display</li> <li>■ It allows access/modification of all the parameters</li> <li>■ Indication accuracy <ul style="list-style-type: none"> <li>- Current 3% of the rated current</li> </ul> </li> <li>■ Accessible at the cabinet door</li> </ul>  |
| Safety                         | Main protections | <ul style="list-style-type: none"> <li>■ Under-, overcurrent and current imbalance</li> <li>■ Under-, overvoltage and voltage imbalance</li> <li>■ Under-, overtorque and active overpower</li> <li>■ Phase loss</li> <li>■ Inverted phase sequence</li> <li>■ Power arm overtemperature</li> <li>■ Motor overload</li> <li>■ Motor overtemperature (optional)</li> <li>■ External fault</li> <li>■ Ground fault by voltage or by current</li> <li>■ Power arm faults</li> <li>■ Power contactor faults</li> <li>■ Control board faults</li> <li>■ Communication fault of the HMI and between control boards</li> <li>■ Communication network faults</li> <li>■ Programming error</li> <li>■ For more details and more implemented functions, refer to the programming manual</li> </ul> |
| Enclosure                      | IP41             | ■ Standard cabinet   |
|                                | IP54             | ■ Compact cabinet  |
| PC connection for programming  | USB connector    | <ul style="list-style-type: none"> <li>■ USB standard Ver. 2.0 (basic speed)</li> <li>■ USB plug Type B "device"</li> <li>■ Interconnection cable: Standard host/device shielded USB cable</li> </ul>  |





## 10 TROUBLESHOOTING AND MAINTENANCE

### 10.1. FAULT TRIPS AND ALARMS


In order to avoid dangerous situations, damages to the motor, damages to the soft-starter or other materials, the protections of the SSW7000 may actuate so that certain physical limits will not be exceeded.

In this regard, a fault is a condition that requires immediate stop of the soft-starter so as to prevent possible losses. When a fault occurs, the SSW7000 is automatically disabled, and it cannot be restarted until the cause of the fault is removed.

When a fault "FXXX" is detected, the following occurs:

- Disabling of the SCR firing.
- Opening of the vacuum contactors (line and bypass).
- Indication of the fault code and description on the display.
- Indication of the present fault at P0020.
- Indication of the occurrence in the status word – P0680.
- Status LED transition to flashing red.
- Opening of the relay programmed for "No Fault".
- It saves the following data in the control circuit EEPROM:
  - The code of the occurred fault (it shifts the nine previous faults).
  - The motor overload integrator status.
  - The status of the enabled time (P0043) and powered time (P0042) counters.

In order to be able to operate the SSW7000 again after a fault trip, reset in one of the following manners:

- Pressing the HMI  key (manual reset).
- Through the reset soft key.
- Automatically through P0208 setting (auto-reset time).
- Through a digital input: DIx = 10 (P0263 to P0268).
- Removing the power supply and reapplying it again (power-on reset).

When an alarm is detected, the following occurs:

- Indication of the alarm code and description on the display.
- Indication of the present alarm at P0021.
- Indication of the occurrence in the status word – P0680.
- Status LED transition to yellow.
- The SCR firing is not disabled, the contactors do not open and the SSW7000 remains in operation.

Alarms are automatically removed when the condition that caused them no longer exists.



#### NOTE!

Fault and alarm occurrences are described in the programming manual, chapter 2 - Faults and Alarms.

## 10.2.MOST FREQUENT PROBLEMS

Table 10.1: Frequent problem cause

| Problem                                      | Most Likely Causes                         | Cause Description  |
|--|--|--|
| The SSW7000 does not respond to the commands | Fault                                      | HMI indication: "FXXX"<br>The SSW7000 does not allow motor starting during a fault situation. Verify what fault it is. Refer to the programming manual, chapter 2 - Faults and Alarms  |
|  | Time interval after stopping               | IHMI indication: "T <sub>mp</sub> P831"<br>The SSW7000 is waiting the time after the motor stopping, programmed in P0831. Refer to the programming manual, section 15.9 - Timer Protections.   |
|  | General enabling                           | IHMI indication: "Des.Ger"<br>General disabled. Verify the command source. If any DI is programmed for general enable, this input can disable the soft-starter even if the commands are from other sources. Refer to the programming manual, section 10.4 - Digital Inputs.  |
|  | ConFiguRetion mode                         | HMI indication: "Config"<br>It indicates that the SSW7000 is in a special condition while it cannot start the motor. Refer to the programming manual - P0692   |
|  | Command source<br><b>LOC/REM</b>           | Verify whether the active command source is Local or Remote.<br>HMI indication: "LOC" or "REM"<br>Verify at P0220 what the origin of the LOC/REM selection is.<br>If in "LOC", verify which the local command source is.<br>If in "REM", verify which the remote command source is.<br>Refer to the programming manual, section 10.1 - Local/Remote Configuration.   |
|  | Commands by<br><b>HMI</b> – I/O keys       | Verify fault conditions, the time after stopping, general enable input, configuration mode and the command source indicated on the HMI.<br>Refer to the programming manual, chapter 7 - HMI.   |
|  | Commands by<br><b>Dlx</b> – Digital Inputs | Verify fault conditions, the time after stopping, general enable input, configuration mode and the command source indicated on the HMI.<br>Verify the type of starting, 2-wire or 3-wire. Refer to the item <a href="#">5.2.10 - User Signal and Control Connections</a> .<br>Verify digital input connections; Dlx, 24 V and COM. Refer to the item <a href="#">5.2.10 - User Signal and Control Connections</a> .<br>Refer to the programming manual, section 10.4 - Digital Inputs. |
|  | Commands by<br><b>Serial/USB</b>           | Verify fault conditions, the time after stopping, general enable input, configuration mode, and the command source indicated on the HMI.<br>Verify at P0682 the commands sent through the Serial/USB.<br>Verify at P0680 the SSW7000 status word.<br>Refer to the programming manual - P0680 and P0682 and to the serial communication manual.   |
|  | Commands by<br><b>Anybus-CC</b>            | Verify fault conditions, the time after stopping, general enable input, configuration mode, and the command source indicated on the HMI.<br>Verify at P0686 the commands sent through the Anybus-CC.<br>Verify at P0680 the SSW7000 status word.<br>Refer to the programming manual - P0680 and P0686 and to the Anybus-CC communication manual.   |
| The motor does not reach the rated speed     | Motor does not start                       | Current or torque limits are too low for the load applied to the motor.  |
|  | Motor starts                               | The line voltage is too low or the medium voltage transformers are undersized.   |
| The motor speed is too high or too low       | Motor data                                 | Verify whether the used motor matches the application requirements.  |
| Jerking during motor deceleration            | General applications                       | The stopping (deceleration) time must only be used with centrifugal hydraulic pump applications. For other applications P0104 must remain in 0 = Inactive.   |
|  | Pumps                                      | The deceleration control method is not appropriated for the application.<br>Refer to the programming manual, chapters 11 - Control Type and 20 - Programming Information and Suggestions.  |

*Table 10.2 (cont.): Frequent problem causes*

| Problem   | Most Likely Causes   | Cause Description   |
|---|----------------------|---|
| Noise at the motor                                    | While starting       | The noise produced by the motor while starting depends on the used starting method and on the involved times. However, it is continuous, with medium level and with no jerks.   |
|   | During JOG           | The SSW7000 JOG function applies a low frequency to the motor, which produces high and pulsing noises at the motor, according to the JOG level.   |
|   | While braking        | The optimal braking method produces high and intermittent noises at the motor, which decrease and become more continuous while stopping.<br>The DC braking method produces constant medium level noises at the motor.<br>The reverse stopping method produces noises similar to the starting motor noises, becoming like the optimal braking at the stopping end.   |
| Increase of the motor current during the deceleration | General applications | The stopping (deceleration) time must only be used with centrifugal hydraulic pump applications. For other applications P0104 must remain in 0 = Inactive.  |
|   | Pumps                | It is normal that during controlled decelerations of centrifugal hydraulic pumps the motor current increases as the motor stops, because the motor is entering the blocked rotor condition.<br>In order to reduce this effect, P0105 can be adjusted for the voltage value (in % of the motor voltage) present at the moment the motor stops, and this value can be visualized at P0007.<br>Refer to the programming manual - P0007 and P0105 |
| HMI display off                                       | HMI connection       | Verify the cable that connects the HMI to the control board C1 (CC11).  |
|   | Power supply         | Verify the low voltage power supply at X1 of the FSM board. It must be in the range from 94 to 253 Vac.<br>Verify the connection between the FSM (XC1) and CC11 (XC60) boards.  |
|   | Fuse                 | Inspect the FSM board fuse  |


**NOTE!**

The operation of alarms and faults is described in the programming manual, chapter 2 - Faults and Alarms.

### 10.3. FAULTS ON THE FSMT BOARD

The FSMT power supply board is responsible for supplying the CC11 and CSM electronic boards, and for driving the relays.

The FSMT board has two versions. The version FSMT.01 modulates a voltage of 66Vac at 400Hz, and is used in the SSW7000C 6.9kV. The version FSMT.00 modulates a voltage of 87Vac at 800Hz and is used in the other lines of the Soft-Starter.

The faults presented by the FSMT board are indicated by LEDs. The description of each LED is detailed [table 10.3](#).

*Table 10.3: Description of the faults indicated by the LEDs of the FSMT board.*

| LED | Description           | Fault Actuation   |
|-----|-----------------------|---|
| H4  | Active processor      | In the OFF state, the processor is in fault or powered down.  |
| H6  | Undervoltage fault    | Monitors and actuates if the voltage on the link is below 94.5 Vdc (70 Vac), resets above 121.5Vdc (90 Vac) for Dip2 closed or 90Vdc (66.6Vac) for Dip2 open.   |
| H8  | Overcurrent fault     | Above 3.0A (positive or negative). Reset by time after 60 seconds. After three overcurrent faults in a row, resets by time will no longer occur (only by powering down the board)   |
| H9  | Overload fault        | Actuates with current above 1.8A, and resets with current below 1.5A. It does not check while in the starting ramp. Reset by time after 60 seconds. After three overloads in a row, resets by time will no longer occur (only by powering down the board) |
| H10 | Overvoltage fault     | Actuates above 356 Vdc (263.7Vac) on the link and resets below 324 Vdc (240 Vac).   |
| H11 | Overtemperature fault | Actuates with temperature above 90°C (2.22V on the A/D) and resets with temperature below 80°C (1.99V on the A/D).  |




Figure 10.1: Location of the fault LEDs of the FSMT board.

**Dip Switch 1:** Defines the maximum output voltage of the FSMT board (connector XC2). If open (default option), the output voltage will be 83 Vac (FSMT.00) and 66 Vac (FSMT.01). If closed, it will be 87 Vac (FSMT.00) and 69 Vac (FSMT.00).

**Dip Switch 2:** Enables protection against power supply undervoltage of the FSMT board during the motor start. The reset limit is 121.5Vdc (90 Vac).

## 10.4.PREVENTIVE MAINTENANCE



### DANGER!

Always disconnect the input power before touching any electrical component associated to the SSW7000. Follow the disconnection sequence described in this manual, item [10.4.1 - SSW7000 Disconnection Sequence](#).

High voltages may be present even after disconnecting the power supply.

Wait at least 3 minutes for the complete discharge of the power capacitors.

Always connect the equipment frame to the protective earth (PE) at the suitable connection point.



### ATTENTION!

Electronic boards have components sensitive to electrostatic discharges.

Do not touch directly on components or connectors. If necessary, touch the grounded metallic frame before or use an adequate grounded wrist strap.

**Do not perform any high pot tests with the SSW7000!**  
If it is necessary, consult WEG.

### 10.4.1. SSW7000 Disconnection Sequence

The safe disconnection sequence is the following:

1. Program P0330 = 1 in order to enter the safe disconnection mode.
2. Parameter P0331 will show the steps of the safe disconnection.
3. The HMI will display P0331 = 0, and also a message asking if the medium voltage power supply was turned off.
4. Manually open the isolating switch of the SSW7000.
5. After opening the isolating switch, select P0331 and answer "OK".
6. Then, the main and bypass contactors will be automatically closed and opened in order to eliminate possible residual voltages on the product.
7. During the entire procedure, messages will be displayed on the HMI screen, informing the sequence of commands executed by the function.


**DANGER!**

The whole procedure must be carried out with the SSW7000 panel door closed.


**NOTE!**

The safe disconnection procedure is for the connections of the circuits on the output of the isolating switch only. In order to perform operations which require access to the input circuits, make sure they are not energized.

Table 10.4: Preventive maintenance

| Maintenance                    | Intervalo                   | Instruções                                 |
|--------------------------------|-----------------------------|--|
| Replacement of fans (if used)  | After 50000 operation hours | Take out the power arm and replace the fan |
| Replacement of the HMI battery | Every 10 years              | Refer to the chapter 4 - HMI               |

Table 10.5: Periodic inspections every 6 months

| Component              | Abnormality                               | Corrective Action                          |
|------------------------|---|--|
| Terminals, connectors  | Loose screws                              | Tighten                                    |
|                        | Loose connectors                          |  |
| Fans (if used)         | Dirty fans                                | Cleaning                                   |
|                        | Abnormal acoustic noise                   | Take out the power arm and replace the fan |
|                        | Stopped fan                               |  |
|                        | Abnormal vibration                        |  |
| Printed circuit boards | Accumulation of dust, oil, humidity, etc. | Cleaning                                   |
|                        | Odor                                      | Replacement                                |
| Power arms             | Accumulation of dust, oil, humidity, etc. | Cleaning                                   |
|                        | Loose connection bolts                    | Tighten                                    |
|                        | Power module bolts                        | Checking and tighten                       |
| Snubber resistors      | Discoloration                             | Replacement                                |
|                        | Odor                                      |  |
| Heatsinks              | Dust accumulation                         | Cleaning                                   |
|                        | Dirty                                     |  |

### 10.5. DIRECT ONLINE START – DOL

In emergency situations, in which a defect in one or more power arms occurs, it is possible to use the direct online start mode (DOL) to drive the motor, enabling the continuation of the production process. In this mode, when a “RUN” command is sent, the by-pass and main contactors are activated so as to apply full voltage to the motor terminals, effectively performing a direct online start.

**NOTE!**

Refer to section 11 – Control Types of the programming manual in order to select the DOL start mode.

When using the D.O.L. start mode, it is responsibility of the user to check the following items:

- Capacity of the power supply suitable for the direct online starting current to be drained by the motor under the existing load conditions. It is recommended that the maximum voltage drop at the start be limited to 20% of the rated supply voltage.
- Programming of protection relays present in the installation that feeds the SSW7000.
- The cycle of direct online starts to be performed must be compatible with the specified motor start capacity.

**NOTE!**

All the protections, except for the detection of “Motor Not Connected – F015” remain active when the DOL start is used. Parameter P0102 is used as reference for the maximum starting time.

**ATTENTION!**

The motor current at the end of the start (P0102) must be smaller than 120% of the rated motor current (P0401).

### 10.6. DATA FOR CONTACT WITH THE TECHNICAL SUPPORT

**NOTE!**

In order to request support or services, it is important to have the following data at hand:

- The SSW7000 model, serial number and manufacturing date, presented on the product nameplate (refer to the section [3.2 - SSW7000 Identification Label](#)).
- The installed software versions (refer to P0023 and P0099).
- Motor nameplate data (power, voltage, current and number of poles)
- Application data and parameter settings