



Manual

# WERMA-WIN

Version: 4.6 - 07/2018

310.860.005

## **PROCESS OPTIMISATION SYSTEMS**

You need a system to measure unproductive times to identify hidden potential in production, logistics or in mail-order retail – whether at manual workstations, shipping workstations or in automated production.

### **SmartMONITOR – the solution for factories**

The clever MDE alternative for manufacturing companies.

- Identify and document faults and unproductive times more quickly
- Shorten response times and avoid downtimes
- Highlight opportunities for improving processes and productivity using reports

### **AndonSPEED – for shipping logistics**

The ideal call-for-action system that makes permanent time savings possible.

- Fast troubleshooting
- Intelligent reporting for long-term improvement
- Makes potential optimisation visible

### **Legal Notices**

Any mention of company names is solely for instruction purposes. Reference to actual existing organisations is not intended, with the exception of the companies below. The following companies and brands are mentioned in the Help Manual:

- Microsoft, Windows 10, Windows 8.1, Windows 8, Windows 7 and Excel are trademarks of Microsoft Corporation
- Adobe Acrobat Reader is a trademark of Adobe Systems Software Ireland Ltd.

WERMA reserves the right to make technical improvements to the product and accepts no responsibility for mistakes or printing errors which may be contained in this documentation.

© Copyright 2018, WERMA Signaltechnik GmbH + Co.KG.

All rights reserved.

### **WERMA Signaltechnik GmbH + Co.KG**

78604 Riethem-Weilheim, Germany

Phone: +49 (0)7424 / 9557-222

Fax: +49 (0)7424 / 9557-44

support@werma.com

www.werma.com

# Table of Contents


<b>1</b>	<b>Installation</b>	<b>6</b>
1.1	Installing WERMA-WIN	6
1.2	Installing the WERMA-WIN database	8
1.2.1	Installing the database locally	9
1.2.2	Connecting to an existing database	10
1.2.3	IT expert installation	10
1.3	Firewall configuration	18
1.4	Manual driver installation	18
1.4.1	Windows 7	19
1.4.2	Windows 10	20
<b>2</b>	<b>Activation of the WIN devices</b>	<b>24</b>
2.1	WIN receiver	24
2.2	WIN ethernet receiver	27
2.2.1	Automatically obtaining an IP address via DHCP	30
2.2.2	Using a static IP address	30
2.2.3	Advanced network configuration	32
2.3	WIN transmitter	33
2.4	WIN transmitter performance	36
2.5	WIN transmitter control	38
2.6	Changing transmission channel	41
2.7	Firmware update	42
2.8	Swapping WIN receiver and WIN ethernet receiver	44
<b>3</b>	<b>Program functions</b>	<b>48</b>
3.1	Control station	48
3.1.1	Control station display	48
3.1.2	Views	52
3.1.3	Configuring WERMA-WIN devices	56
3.1.4	Resetting the counter	66
3.1.5	Manual control	67
3.1.6	Status change message	67
3.1.7	Status transmission	68
3.1.8	Report	71
3.2	Productivity	71
3.2.1	Views	72
3.2.2	Productivity view	75
3.2.3	Report	78
3.3	Runtime	79
3.3.1	Views	79
3.3.2	Runtime display	81

3.3.3	Notes/Fault conditions .....	84
3.3.4	Job .....	86
3.3.5	Report .....	87
3.4	Job .....	88
3.4.1	Job overview .....	89
3.4.2	Job details .....	89
3.4.3	Entering a job .....	93
3.4.4	Starting a job .....	98
3.4.5	Ending a job .....	100
3.4.6	Enabling Auto jobs .....	101
3.4.7	Disabling Auto jobs .....	101
3.4.8	Editing a job .....	101
3.4.9	Correction of a completed job .....	102
3.4.10	Deleting a job .....	102
3.4.11	Duplicating a job .....	103
3.4.12	Report .....	103
3.5	Control .....	104
3.5.1	Overview of rules .....	105
3.5.2	Defining new rules .....	106
3.5.3	Enabling a rule .....	119
3.5.4	Disabling a rule .....	119
3.5.5	Editing a rule .....	119
3.5.6	Duplicating a rule .....	120
3.5.7	Deleting a rule .....	121
3.6	Routing .....	122
3.6.1	Displaying connection status .....	124
3.6.2	Optimising radio communication .....	124
3.7	Settings .....	124
3.7.1	General .....	125
3.7.2	Views .....	127
3.7.3	Status transmission .....	129
3.7.4	Sound .....	135
3.7.5	Reports .....	136
3.7.6	WIN devices .....	137
3.7.7	Database .....	138
3.7.8	Time period .....	140
3.7.9	Fault conditions .....	142
3.7.10	Functions .....	144
3.8	Reports and exports .....	145
3.8.1	Pasting a watermark .....	148
3.8.2	Deleting the watermark .....	148
3.8.3	File formats .....	149

<b>4</b>	<b>Automation interfaces</b>	<b>150</b>
4.1	XML interface	150
4.1.1	Export	150
4.1.2	Import	159
4.1.3	Interface status	167
4.2	WINtoApplication	168
4.2.1	Adding a task	169
4.2.2	Editing a task	173
4.2.3	Duplicating a task	177
4.2.4	Enabling or disabling an individual task	181
4.2.5	Enabling or disabling all tasks	181
4.2.6	Deleting a task	181
4.2.7	Exporting tasks	182
4.2.8	Importing tasks	182
4.2.9	History	183
4.2.10	Settings	183
4.2.11	Exiting WINtoApplication	183
4.3	WERMA-WIN CLI Tool	184
<b>5</b>	<b>Fault diagnostics</b>	<b>186</b>
5.1	WIN transmitter, WIN transmitter performance, WIN transmitter control	186
5.2	WIN transmitter control	186
5.3	WIN receiver	187
5.4	WIN ethernet receiver	187
<b>6</b>	<b>Software update</b>	<b>189</b>
<b>7</b>	<b>System requirements</b>	<b>190</b>
7.1	Network stability and security	191
<b>8</b>	<b>Keyboard shortcuts</b>	<b>192</b>
8.1	Windows standard	192
8.2	General	192
8.3	Control station	193
8.4	Productivity	193
8.5	Runtime	194
8.6	Job	194
8.7	Control	195
8.8	Routing	195
<b>9</b>	<b>FAQ – Frequently Asked Questions</b>	<b>196</b>


# 1 Installation

WERMA-WIN is installed first during installation. The WERMA-WIN database is then installed and set up or a connection is made to an existing database.

 Administrator rights are needed to install WERMA-WIN.

## 1.1 Installing WERMA-WIN

1. Make sure that the system requirements are met.
2. Download the latest version of WERMA-WIN at [www.werma.com/win](http://www.werma.com/win).
3. Extract the downloaded ZIP file.
4. Double-click on the **WERMA-WIN-x-x-x-xxxx.exe** file to start the installation.  
→ The installation assistant starts.




5. Follow the instructions in the installation assistant.  
→ Once the installation assistant has ended, the assistant to install the WERMA-WIN database appears.

WERMA-WIN database setup

**Database setup**


Please select...

**Install database**





Install the WERMA-WIN database and Server Service on this PC (1 x per network)


**Connect to existing database**



Connect to an existing database and Server Service via a WERMA Link File




 **IT expert installation**  
Further installation options

 **Next**  
OK

## 1.2 Installing the WERMA-WIN database

There are three options available to you for installing the WERMA-WIN database.



Install the database locally:

- The WERMA-WIN database is installed locally on the PC on which WERMA-WIN is installed.

Connect to existing database:

- A connection to an existing WERMA-WIN database is established using a link file previously installed.

IT expert installation:

- Establishment of a connection to a WERMA-WIN database on another desktop PC.
- Establishment of a connection to an empty Microsoft SQL server database in the network.
- Establishment of a connection to a Microsoft SQL server database in the network already containing WERMA-WIN data.




## 1.2.1 Installing the database locally

**i** To access the WERMA-WIN database, WERMA-WIN creates a user and an associated password with the following data:

- User: wermawin
- Password: Tyz19\$Ix50WsR3Ed7m


**i** The **WERMA WIN 4 Server Service** and the **WERMA WIN 4 Connector Service** are both installed when the WERMA-WIN database is installed. These services run in the background when the PC is switched on. All collected WERMA-WIN data is written to the WERMA-WIN database without WERMA-WIN running and a user being logged on.

1. Click on **Install database**.



2. Click on **Next**.

- The WERMA-WIN database is installed locally on the PC.
- Once the database has been installed, a window appears in which to save the link file.



3. Click on **Save** to save the link file.

---

**i** The link file lets you connect other workplaces to the WERMA-WIN database.

---


## 1.2.2 Connecting to an existing database

---

**i** The **WERMA WIN 4 Connector Service** is installed when connecting to the existing WERMA-WIN database. This service runs in the background when the PC is switched on. All collected WERMA-WIN data from the connected WIN receiver is written to the WERMA-WIN database without WERMA-WIN running and a user being logged on.

---

1. Click on **Connect to existing database**.



2. Click on **Next**.


3. Open the link file.

→ The installation assistant checks the connection settings and establishes the connection to the existing WERMA-WIN database.

## 1.2.3 IT expert installation

1. Click on **IT expert installation**.

→ The **WERMA-WIN database setup** window appears.




IT expert installation offers the following options:


- Use of the database installed by WERMA-WIN
- Use of a newly created empty Microsoft SQL server database
- Use of a Microsoft SQL server database with WERMA-WIN files

### 1.2.3.1 Using the database installed by WERMA-WIN


1. Select **A database that has been installed by WERMA-WIN**.
2. Click on **Next**.



3. In the **Server name** field, enter the name of the server on which the WERMA-WIN database has been installed.

 The server name can be found in the WERMA-WIN link file (.wde) saved when installing the WERMA-WIN database.

4. Click on **Next**.




The screenshot shows the 'Expert installation' window for WERMA-WIN database setup. It has two radio button options: 'Install the Server Service on this PC' (unselected) and 'Connect to the following Server Service' (selected). The first option includes a 'Check' button and a 'TCP-Port' dropdown set to 9710. The second option includes a 'Server name' text field containing 'WERMA-WIN-0718', a 'TCP-Port' dropdown set to 9710, and a 'Check' button. At the bottom, there are 'Back Cancel' and 'Next OK' buttons.

5. Select whether the **WERMA WIN 4 Server Service** is to be installed on this PC or whether you wish to establish a connection to an existing server service.

## Installing the WERMA WIN 4 Server Service

If the **WERMA WIN 4 Server Service** is to be installed on this PC:

1. Select **Install the Server Service on this PC**.




This screenshot shows the same 'Expert installation' window as above, but with the 'Install the Server Service on this PC' radio button selected. The 'Connect to the following Server Service' option is now unselected. The 'TCP-Port' dropdown is still set to 9710 and the 'Check' button is visible.

2. You may need to change the server service TCP port in the **TCP-Port** field.
3. Click on **Next**.  
→ The connection to the WERMA-WIN database is created.

## Connection to an existing server service

If a connection is to be made to an existing server service:

### 1. Select **Connect to the following Server Service**.



2. In the **Server name** field, enter the name of the server on which the server service has been installed.

3. Enter the server service TCP port in the **TCP-Port** field.

4. Click on **Next**.

→ The connection to the WERMA-WIN database is created.



The **WERMA WIN 4 Connector Service** is installed during installation. This service runs in the background when the PC is switched on. All collected WERMA-WIN data from the connected WIN receiver is written to the WERMA-WIN database without WERMA-WIN running and a user being logged on.

### 1.2.3.2 Using a newly created empty Microsoft SQL server database

#### Requirements:

- An empty database has been set up on the Microsoft SQL server.
- A corresponding database user is linked to the database login.
- The database meets the following requirements:

Compatible from:	Microsoft SQL Server 2008
Recommendation:	Microsoft SQL Server 2014
Collation	Latin1_General_CI_AS
Role membership:	db_datareader db_datawriter db_ddladmin oder db_owner

1. Select **A newly created empty Microsoft SQL server database**.

2. Click on **Next**.

WERMA-WIN database setup

**Expert installation**

Please enter the database server connection settings.

The Server name is the name of the computer on which you have installed SQL Server for WERMA WIN. In the Instance name box, enter the name of the instance of SQL Server that you want to use for WERMA WIN. Alternatively, you can combine these as 'Servername\instancename' in the Server name box

If you have not specified an instance name for your SQL Server installation, leave the Instance name box empty.

This information is available from your network administrator.

Server name  (e.g. srv-sqldb-01)

Instance name  (e.g. WERMAWIN)

Database  (e.g. WERMAWIN)

User name  (e.g. WERMAWIN)

Password  (e.g. Tyz19\$lx50WsR3Ed7m)

Cancel  OK

3. Enter the access data for the empty database in the appropriate fields.

You do not have to complete the **Instance name** field.

4. Click on **Next**.

WERMA-WIN database setup

**Expert installation**

Install the Server Service on this PC

The Server Service must be installed and activated once per database. We recommend installing the Server Service on the PC where the database is installed.

The Server Service uses the TCP Port 9710 as standard. If this port is already in use for a different network service please select an alternative TCP-Port

TCP-Port

Connect to the following Server Service

Server name

TCP-Port


Cancel  OK

5. Select whether the **WERMA WIN 4 Server Service** is to be installed on this PC or whether you wish to establish a connection to an existing server service.

### Installing the WERMA WIN 4 Server Service

If the **WERMA WIN 4 Server Service** is to be installed on this PC:

1. Select **Install the Server Service on this PC**.



Install the Server Service on this PC

The Server Service must be installed and activated once per database. We recommend installing the Server Service on the PC where the database is installed.

The Server Service uses the TCP Port 9710 as standard. If this port is already in use for a different network service please select an alternative TCP-Port


TCP-Port:

2. You may need to change the server service TCP port in the **TCP-Port** field.
3. Click on **Next**.  
→ The connection to the database is created.

### Connection to an existing server service

If a connection is to be made to an existing server service:

1. Select **Connect to the following Server Service**.



Connect to the following Server Service

Server name:

TCP-Port:

Note: The Server Service is currently installed on this PC. If you continue the Server Service will be uninstalled.

2. In the **Server name** field, enter the name of the server on which the server service has been installed.
3. Enter the server service TCP port in the **TCP-Port** field.
4. Click on **Next**.  
→ The connection to the database is created.



The **WERMA WIN 4 Connector Service** is installed during installation. This service runs in the background when the PC is switched on. All collected WIN data from the connected WIN receiver is written to the WIN database without WIN software running and a user being logged on.

### 1.2.3.3 Using a Microsoft SQL server database with WERMA-WIN files

1. Select **Microsoft SQL server database with WERMA-WIN files**.
2. Click on **Next**.

WERMA-WIN database setup

**Expert installation**

Please enter the database server connection settings.

The Server name is the name of the computer on which you have installed SQL Server for WERMA WIN. In the Instance name box, enter the name of the instance of SQL Server that you want to use for WERMA WIN. Alternatively, you can combine these as 'Servername\instancename' in the Server name box

If you have not specified an instance name for your SQL Server installation, leave the Instance name box empty.

This information is available from your network administrator.

Server name  (e.g. srv-sqldb-01)

Instance name  (e.g. WERMAWIN)

Database  (e.g. WERMAWIN)

User name  (e.g. WERMAWIN)

Password  (e.g. Tyz19\$lx50WsR3Ed7m)

Cancel  OK

3. Enter the access data for the empty database in the appropriate fields.

You do not have to complete the **Instance name** field.

4. Click on **Next**.

WERMA-WIN database setup

**Expert installation**

Install the Server Service on this PC

The Server Service must be installed and activated once per database. We recommend installing the Server Service on the PC where the database is installed.

The Server Service uses the TCP Port 9710 as standard. If this port is already in use for a different network service please select an alternative TCP-Port

TCP-Port

Connect to the following Server Service

Server name

TCP-Port

Cancel  OK




5. Select whether the **WERMA WIN 4 Server Service** is to be installed on this PC or whether you wish to establish a connection to an existing server service.

### Installing the WERMA WIN 4 Server Service

If the **WERMA WIN 4 Server Service** is to be installed on this PC:

1. Select **Install the Server Service on this PC**.



Install the Server Service on this PC

The Server Service must be installed and activated once per database. We recommend installing the Server Service on the PC where the database is installed.

The Server Service uses the TCP Port 9710 as standard. If this port is already in use for a different network service please select an alternative TCP-Port


TCP-Port:

2. You may need to change the server service TCP port in the **TCP-Port** field.
3. Click on **Next**.  
→ The connection to the WERMA-WIN database is created.

### Connection to an existing server service

If a connection is to be made to an existing server service:

1. Select **Connect to the following Server Service**.



Connect to the following Server Service

Server name:

TCP-Port:

Note: The Server Service is currently installed on this PC. If you continue the Server Service will be uninstalled.

2. In the **Server name** field, enter the name of the server on which the server service has been installed.
3. Enter the server service TCP port in the **TCP-Port** field.
4. Click on **Next**.  
→ The connection to the WERMA-WIN database is created.



The **WERMA WIN 4 Connector Service** is installed during installation. This service runs in the background when the PC is switched on. All collected WERMA-WIN data from the connected WIN receiver is written to the WERMA-WIN database without WERMA-WIN running and a user being logged on.

## 1.3 Firewall configuration

All necessary port enables are configured by default when WERMA-WIN is installed. If you are using additional firewall or network products, it may be necessary to adapt them manually.

1. Make sure that the following network connections are not blocked:


Source	Destination	Type	Port	Remark
Server Client	Microsoft SQL Server	UDP/TCP	–	We recommend allowing all network connections for <code>sqlservr.exe</code> and <code>sqlbrowser.exe</code> in the Microsoft SQL Server installation. Refer to the Administration Manual for the Microsoft SQL server for a different configuration.
Server Client	Server	TCP	9710*	Database connection to the <b>WERMA WIN 4 Server Service</b>
Server	WIN ethernet receiver	TCP	80*	http data connection
Server	WIN ethernet receiver	UDP broadcast	5000	Retrieval of device information
Server	External mail server	TCP	25*	Mail sent by SMTP to the configured server
Server	www.werma-win.com**	TCP	443	Mail sent using the integrated mail function. Configuration of a web proxy is possible.
Server Client	www.werma.com** www.werma-win.com**	TCP	80	Update testing, retrieval of the Online Help and Contact site

\* Can be configured differently in WERMA-WIN with activation of the WERMA-WIN devices.

\*\* We recommend enabling access to other subdomains for future updates of WERMA-WIN.


## 1.4 Manual driver installation

---


 Manual driver installation is only required if the device driver software has not been automatically installed when connecting a WERMA-WIN device.

---


## 1.4.1 Windows 7



### 1. Click on **Change setting...**




### 2. Click on **Browse my computer for driver software.**




### 3. Click on **Browse.**

4. Navigate to the WERMA-WIN installation directory and open the `Driver` folder.
5. Click on **Next**.  
→ The device drivers are installed.




6. Once successfully installed, click on **Close** to close the hardware assistant.  
→ The WERMA-WIN device is now ready for operation.


## 1.4.2 Windows 10




1. Open **Device Manager**.




→ The **Device Manager** window appears.



2. Right-click on **WIRELESS DEVICE**.
3. Select **Update driver** in the pop-up menu.



4. Click on **Browse my computer for driver software**.




5. Click on **Browse**.

6. Navigate to the WERMA-WIN installation directory and open the `Driver` folder.

7. Click on **Next**.

→ The device drivers are installed.



8. Once successfully installed, click on **Close** to close the hardware assistant.  
→ The WERMA-WIN device is now ready for operation.

## 2 Activation of the WIN devices

WIN receiver or WIN ethernet receiver must be connected to a PC and configured before WERMA-WIN data from the signal towers can be received. WIN transmitters should then be configured and assigned to a WIN receiver or WIN ethernet receiver.


### 2.1 WIN receiver

1. Click on **Activation** in the toolbar.



2. Click on **Activate WIN device**.






3. Read the information text and click on **Next**.




4. Connect WIN receiver to the computer and click on **Search**.  
→ WERMA-WIN searches for the connected WIN receiver.




5. Once WIN receiver has been recognised, click on **Next**.

 A message appears if a new firmware version is available. Click on **Yes** to install the new firmware version.



6. Enter the description of the WIN receiver in the **Name** field.

 The transmission channel of the individual systems can be changed to enable the best possible radio connection when several WERMA-WIN systems are run in parallel. We recommend only operating one WIN receiver per transmission channel.

7. Select another transmission channel in the **Channel** selection list if necessary.

8. Click on **Next**.

→ The configuration is transferred to the WIN receiver.


## 2.2 WIN ethernet receiver

1. Click on **Activation** in the toolbar.




2. Click on **Activate WIN device**.

3. Click on **Next**.



4. Read the information text and click on **Next**.




5. Use the USB cable to connect WIN ethernet receiver to the computer and click on **Search**.  
→ WERMA-WIN searches for the connected WIN ethernet receiver.




6. After WIN ethernet receiver has been recognised, click on **Next**.



A message appears if a new firmware version is available. Click on **Yes** to install the new firmware version.




7. Enter the description of the WIN ethernet receiver in the **Name** field.

 The transmission channel of the individual systems can be changed to enable the best possible radio connection when several WERMA-WIN systems are run in parallel.

We recommend only operating one WIN receiver per transmission channel.

8. Select another transmission channel in the **Channel** selection list if necessary.

9. Click on **Next**.



There are three options available to connect to the network:

- Automatically obtaining an IP address via DHCP
- Using a static IP address
- Advanced network configuration




The **Advanced network configuration** must be used on the following cases:

- The WIN ethernet receiver and WERMA-WIN server service are in the same sub-network.
- UDP broadcast is not allowed.
- A static IP address should not be assigned.

## 2.2.1 Automatically obtaining an IP address via DHCP


1. Select **Automatically obtain an IP address via DHCP**.
2. Click on **Next**.
  - The configuration is transferred to the WIN ethernet receiver.
  - The configuration has been successfully completed.



3. Now choose whether you wish to perform further configuration or finish configuration.
4. Click on **Next**.

## 2.2.2 Using a static IP address

1. Select **Use the following static IP address**.



2. Enter the network data into the corresponding fields.

 Your network administrator will provide the requisite data.

3. Click on **Next**.

- The configuration is transferred to the WIN ethernet receiver.
- The configuration has been successfully completed.




4. Now choose whether you wish to perform further configuration or finish configuration.

5. Click on **Next**.

## 2.2.3 Advanced network configuration

1. Select **Use the following static IP address:**.




The screenshot shows the 'Activation' dialog box for WIN ethernet receiver. The title bar reads 'Activation' with a close button. The logo 'win wireless information network' is at the top. The main heading is 'Network configuration for WIN ethernet receiver'. There are two radio buttons: 'Automatically obtain an IP address via DHCP' (unselected) and 'Use the following static IP address:' (selected). Below the static IP option are four input fields: 'IP-Address' (0 . 0 . 0 . 0), 'Subnet mask' (0 . 0 . 0 . 0), 'Default gateway' (0 . 0 . 0 . 0), and 'DNS-Server' (0 . 0 . 0 . 0). A checkbox 'Show advanced network configuration' is unselected. A warning icon and text state: 'The configuration data can be obtained from your network administrator. Please also refer to the notes regarding the configuration in the user manual.' with a 'Download manual' link. At the bottom are 'Cancel' and 'Next' buttons.

2. Enter the network data into the corresponding fields.

 Your network administrator will provide the requisite data.

3. Enable **Advanced network configuration**.

4. Click on **Next**.



The screenshot shows the 'Activation' dialog box for advanced network configuration. The title bar reads 'Activation' with a close button. The logo 'win wireless information network' is at the top. The main heading is 'Advanced network configuration for WIN ethernet receiver'. The text reads: 'By default, the TCP/IP connection will be directly established with the IP address of the WIN ethernet receiver. You can however define a DNS name which has been appropriately configured in your DNS server.' Below this are two input fields: 'IP / DNS name' (192.168.50.173) and 'TCP-Port' (80) with '(Default value: 80)' next to it. At the bottom are 'Cancel' and 'Next' buttons.




5. Enter the IP address or DNS name of WIN ethernet receiver in the **IP / DNS name** field.
6. You may need to change the TCP port in the **TCP-Port** field.

---

 Your network administrator will provide the requisite data.

---

7. Click on **Next**.  
→ The configuration has been successfully completed.



8. Now choose whether you wish to perform further configuration or finish configuration.
9. Click on **Next**.

## 2.3 WIN transmitter


1. Start WERMA-WIN.
2. Use the USB cable to connect WIN transmitter to the computer.




→ The **Activation** window appears.



3. Click on **Search** if WIN transmitter has not automatically been found.  
→ WERMA-WIN searches for the connected WIN transmitter.
4. Once WIN transmitter has been recognised, click on **Next**.



5. Enter the description of the WIN transmitter in the **Name** field.
6. Configure WIN transmitter in the **Signal tower** and **Blink recognition** tabs.
7. Assign WIN transmitter in the selection list **Assign the device to the following WIN receiver** to a WIN receiver.
8. Click on **Next**.  
→ The configuration has been successfully completed.



9. Now choose whether you wish to perform further configuration or finish configuration.
10. Click on **Next**.
11. Disconnect the USB connection from the WIN transmitter.  
→ The WIN transmitter is configured and can be fitted on the signal tower.

## 2.4 WIN transmitter performance


1. Start WERMA-WIN.
2. Use the USB cable to connect WIN transmitter performance to the computer.




→ The **Activation** window appears.



3. Click on **Search** if WIN transmitter performance has not automatically been found.  
→ WERMA-WIN searches for the connected WIN transmitter performance.
4. Once WIN transmitter performance has been recognised, click on **Next**.



5. Enter the description of the WIN transmitter performance in the **Name** field.
6. Configure WIN transmitter performance in the **Signal tower** and **Blink recognition** tabs.
7. Assign WIN transmitter performance in the selection list **Assign the device to the following WIN receiver** to a WIN receiver.
8. Click on **Next**.  
→ The configuration has been successfully completed.



9. Now choose whether you wish to perform further configuration or finish configuration.
10. Click on **Next**.
11. Disconnect the USB connection from the WIN transmitter.  
→ The WIN transmitter performance is configured and can be fitted on the signal tower.

## 2.5 WIN transmitter control


1. Start WERMA-WIN.
2. Use the USB cable to connect WIN transmitter control to the computer.




→ The **Activation** window appears.



3. Click on **Search** if WIN transmitter control has not automatically been found.  
→ WERMA-WIN searches for the connected WIN transmitter control.
4. Once WIN transmitter control has been recognised, click on **Next**.



5. Enter the description of the WIN transmitter control in the **Name** field.
6. Configure WIN transmitter control in the **Signal tower** and **Blink recognition** tabs.
7. Assign WIN transmitter control in the selection list **Assign the device to the following WIN receiver** to a WIN receiver.
8. Click on **Next**.




9. Configure the switching status of the individual tiers in the respective selection lists.




The switching status is activated as soon as power is supplied to the WIN transmitter control.

10. Click on **Next**.



11. Select the switching condition of the WIN transmitter control.
12. Click on **Next**.  
→ The configuration has been successfully completed.




13. Now choose whether you wish to perform further configuration or finish configuration.
14. Click on **Next**.
15. Disconnect the USB connection from the WIN transmitter.  
→ The WIN transmitter control is configured and can be fitted on the signal tower.



## 2.6 Changing transmission channel


The transmission channel of the individual systems can be changed to enable the best possible radio connection when several WERMA-WIN systems are run in parallel. Four different transmission channels are available.

 We recommend only operating one WIN receiver per transmission channel.

1. Click on **Activation** in the toolbar.  
→ The **Activation** window appears.




2. Click on **Change transmission channel**.



3. Read the information text and click on **Next**.  
→ The activation assistant for a WERMA-WIN device appears.



4. Start up WIN receiver or WIN ethernet receiver again.
5. Select the preferred transmission channel in the **Channel** selection list during activation.



---

**i** WIN transmitter must be reconfigured if the WIN receiver transmission channel is changed after WIN transmitter has been configured.


---

## 2.7 Firmware update


1. Click on **Activation** in the toolbar.  
→ The **Activation** window appears.




2. Click on **Firmware update**.



3. Read the information text and click on **Next**.  
→ The activation assistant for a WERMA-WIN device appears.



4. Start up WIN receiver or WIN ethernet receiver again.
5. During activation, confirm the firmware update message with **Yes**.  
→ The **Firmware update** window appears.



6. Click on **Start update**.  
→ The firmware is updated.


## 2.8 Swapping WIN receiver and WIN ethernet receiver

A WIN receiver can be replaced by a WIN ethernet receiver. An assistant can be used to transmit all the WIN transmitters assigned to the WIN receiver to the WIN ethernet receiver.

1. Click on **Activation** in the toolbar.  
→ The **Activation** window appears.




2. Click on **Swap WIN receiver (USB) and WIN ethernet receiver**.  
→ The **Activation** window appears.




3. Connect WIN receiver and WIN ethernet receiver to the computer.
4. Click on **Search**.  
→ WERMA-WIN searches for the connected WIN receiver and WIN ethernet receiver.



5. Once WIN receiver has been recognised, click on **Next**.  
→ WIN receiver and WIN ethernet receiver are swapped.



6. Once they have been successfully swapped, amend or strike through the MAC addresses printed on the type labels.
7. Click on **Next** to complete the swap and check the configuration of the WIN ethernet receiver.



**Activation**

**win®**  
wireless information network

**Network configuration for WIN ethernet receiver**

Automatically obtain an IP address via DHCP  
If you select this option, please ensure that UDP broadcasts are permitted on your network. Your network administrator can provide further details.

Use the following static IP address:


IP-Address  .  .  .  z.B. 192.168.0.42


Subnet mask  .  .  .  z.B. 255.255.255.0


Default gateway  .  .  .

DNS-Server  .  .  .

Show advanced network configuration  
Please enter, for example, a DNS name for the WIN ethernet receiver if it is in a different sub-network or UDP broadcast is not possible.

 The configuration data can be obtained from your network administrator. Please also refer to the notes regarding the configuration in the user manual.  
[Download manual](#)

 **Cancel**  
Close

 **Next**  
Next step

8. Check the configuration of the WIN ethernet receiver and adapt if necessary.
9. Click on **Next** to save the configuration.  
→ The swap has been successfully completed.



**Activation**

**win®**  
wireless information network

**Configuration saved**


Configuration successfully saved. You can now remove the WIN receiver or WIN transmitter.


How do you want to continue?

Finish configuration

Configure a WIN receiver

Configure a WIN transmitter

 **Cancel**  
Close

 **Next**  
Next step

10. Now choose whether you wish to perform further configuration or finish configuration.
11. Click on **Next**.

# 3 Program functions

WERMA-WIN is subdivided into six main modules:


- Control station
- Productivity
- Runtime
- Job
- Control
- Routing

## 3.1 Control station

The statuses and job details of up to 50 machines, systems and workplaces are displayed in an overview in the **Control station** module. The overview shows which machine is running or has a fault. This enables reaction times and downtimes to be effectively shortened.

The job details show how far the jobs have progressed on the individual machines.

The position of a machine can be easily identified by the integration of a building plan into the Control station module.




### 3.1.1 Control station display





The control station display of the WIN transmitter shows the status of the respective signal tower or machine and enables the WIN transmitters to be configured.



### 3.1.1.1 WIN transmitter


The control station display of the WIN transmitter includes the following information:








Item	Description
1	Enable, disable and set up status transmission  Status transmission is disabled.  Status transmission is enabled.
2	Enable, disable and set up status change message option  Status change message option is disabled.  Status change message option is enabled.
3	Edit WIN transmitter configuration
4	Status display of tiers
5	Name of the WIN transmitter

### 3.1.1.2 WIN transmitter performance with running job

The control station display of a WIN transmitter performance with running job includes the following information:





Item	Description
1	Display of running job with job name
2	Call up job details
3	Current quantity
4	Edit WIN transmitter configuration
5	Enable, disable and set up status transmission  <b>Status transmission is disabled.</b>  Status transmission is enabled.
6	Enable, disable and set up status change message option  Status change message option is disabled.  Status change message option is enabled.
7	Mouse over function for additional job details
8	Job progression of job
9	Status display of tiers
10	Name of the WIN transmitter




 The additional job details (7) appear as soon as the cursor hovers over the job progression of the job (8).

### 3.1.1.3 WIN transmitter performance without running job

The control station display of a WIN transmitter performance without running job includes the following information:










Item	Description
1	<b>No running job</b> information
2	Enter new job
3	Reset counter value
4	Enable, disable and set up status transmission  Status transmission is disabled.

Item	Description
	 Status transmission is enabled.
5	Enable, disable and set up status change message option   Status change message option is disabled.   Status change message option is enabled.
6	Edit WIN transmitter configuration
7	Current quantity without plan specification
8	Status display of tiers
9	Name of the WIN transmitter

### 3.1.1.4 WIN transmitter control

The control station display of the WIN transmitter control includes the following information:




Item	Description
1	Enable, disable and set up status transmission   Status transmission is disabled.   Status transmission is enabled.
2	Enable, disable and set up status change message option   Status change message option is disabled.   Status change message option is enabled.
3	Edit WIN transmitter configuration
4	Status display of tiers   Tier can be switched manually   Tier is controlled with a switching rule
5	Name of the WIN transmitter

## 3.1.2 Views

The **Control station main view** or a user-defined view can be used in the **Control station** module.

### 3.1.2.1 Control station main view


The **Control station main view** gives an overview of all WIN transmitters that have been configured. The **Control station main view** can be provided with a background image.



### 3.1.2.2 User-defined views

Additional user-defined views can be created in addition to the **Control station main view**.


The user-defined views can be named as required and be provided with a background image. Different WIN transmitters can be displayed in every user-defined view.



 The user-defined views of the **Control station**, **Productivity** and **Runtime** modules are always identical. All view settings are applied.

### Naming a user-defined view


1. Click on **Settings** in the toolbar.  
→ The **Settings** window appears.
2. Select the **Views** tab.
3. Highlight the required view.
4. Click on **Edit**.  
→ The **Edit view** window appears.



5. Enter the name of the view in the **Name** field.
6. Click on **OK**.  
→ The name of the view has been changed.
7. Click on **OK** to apply the settings.

### Adding WIN transmitter to a view


1. Call up the required view.
2. Click on **Add WIN transmitter**.  
→ The **Select WIN transmitter** window appears.



3. Highlight the required WIN transmitter.
4. Click on **OK**.  
→ The WIN transmitter has been added to the view.

### Removing WIN transmitter from the view


1. Call up the required view.
2. Right-click on the WIN transmitter to be removed.
3. Select **Remove** in the pop-up menu.




4. Confirm the prompt with **Yes**.  
→ The WIN transmitter has been removed from the view.

### 3.1.2.3 Selecting the background image of a view

1. Call up the required view.
2. Click on **Select background**.  
→ The **Background image** window appears.



3. Select **Selected image**.

4. Click on **Browse**  and open the required background image.



The background image needs to be saved on the local PC.

If more than one computer is accessing a WERMA-WIN database, then the background image must be saved on a network drive.

5. Select **As original** to paste the background image in its original size.

6. Select **Zoom out / zoom in** to paste the background imaged scaled.



Clicking on **Preview** allows a **preview** of the background image to be displayed.


7. Click on **Save** to paste the background image into the view.

### 3.1.2.4 Removing the background

1. Call up the required view.

2. Click on **Select background**.

→ The **Background image** window appears.




3. Select **No background image**.

4. Click on **Save** to paste the background image into the view.

- or -

1. Call up the required view.


2. Right-click in the view.
3. Select **Remove Background**.



### 3.1.2.5 Repositioning a WIN transmitter

Every WIN transmitter can be repositioned anywhere in the view.

1. Left-click on the name of the WIN transmitter and hold down the mouse key.



2. Drag the WIN transmitter to the desired position and release the mouse key.

### 3.1.2.6 Full screen mode

Every view can be displayed in full screen and without the menu bar.

1. Call up the required view.
2. Click on **Full screen** in the menu bar.

To close the full screen view:

1. Press **ESC**.


## 3.1.3 Configuring WERMA-WIN devices

Every WIN transmitter can be individually named and configured in accordance with the scope of its functions.

### 3.1.3.1 Configuring WIN transmitter

1. Click on **Edit WIN transmitter**  in the control station display of the desired WIN transmitter.  
→ The **WIN transmitter configuration** window appears.





## 2. Configure the following settings:

- Name of the WIN transmitter
- Tiers and colours of the signal tower
- Blink recognition
- Display of the WIN transmitter

## 3. Once configuration has been completed, click on **OK** to save the settings.

### Modifying the name

Every WIN transmitter can be individually named.


#### 1. Enter the name of the WIN transmitter in the **Name** field.



### Modifying the tiers and colours of the signal tower

The tiers and colours can be modified on the signal tower installed. A productive state can be defined, if required, for every tier and the states **Off** and **Connection error**. The productive states are evaluated in the **Productivity** module.

#### 1. Select the **Signal tower** tab.



#### 2. Specify a **Name** and **Colour/Function** for the tiers of the WIN transmitter.



A user-defined name can be entered in the **Name** selection list. As soon as the configuration of the WIN transmitter has been saved, this user-defined name can be called up again using the selection list.

If a user-defined name is no longer used, it will not be displayed in the selection list any longer. Consequently, it is possible to remove misspelt or incorrectly created names (for example, `material mter ia`) from the selection list.

## Selecting productive states

To define the productive states of the tiers:

1. Select check box **Select productive state**.
2. The **Productive** column to select the productive states is shown.

	Description	Colour/Function	Productive
4th tier	Tier 4	Blue	Undefined
3rd tier	Tier 3	Red	Undefined
2nd tier	Tier 2	Yellow	Undefined
1st tier	Tier 1	Green	Undefined
Off			Undefined
Connection error			Do not analyse

3. Select productive states for the tiers of the WIN transmitter.



The productive states are calculated in the evaluation based on the following priority:

- Non productive
- Productive
- Do not analyse
- Undefined

## Modifying blink recognition

If the signal tower installed has a blinking function, it can be evaluated using blink recognition. A productive state can be defined for every tier. The productive states are evaluated in the **Productivity** module.



Blink recognition detects blinking signals between 15 Hz and 0.8 Hz switching frequency generated by a machine or control (e.g via the PLC).

1. Select the **Blink recognition** tab.

	Blink recognition	Description
4th tier	<input checked="" type="checkbox"/>	Tier 4 blinking
3rd tier	<input checked="" type="checkbox"/>	Tier 3 blinking
2nd tier	<input checked="" type="checkbox"/>	Tier 2 blinking
1st tier	<input checked="" type="checkbox"/>	Tier 1 blinking

2. Enable or disable the **Blink recognition** checkbox to enable or disable blink recognition for the individual tiers of the WIN transmitter.
3. Define a **description** for the tiers of the WIN transmitter.




A user-defined description can be entered in the **Description** selection list. As soon as the configuration of the WIN transmitter has been saved, this description can be called up again using the selection list.

## Selecting productive states

To define the productive states of the tiers:

### 1. Enable **Select productive state**.

→ The **Productive** column to select the productive states is shown.



	Blink recognition	Description	Productive
4th tier	<input checked="" type="checkbox"/>	Tier 4 blinking	Undefined
3rd tier	<input checked="" type="checkbox"/>	Tier 3 blinking	Undefined
2nd tier	<input checked="" type="checkbox"/>	Tier 2 blinking	Undefined
1st tier	<input checked="" type="checkbox"/>	Tier 1 blinking	Undefined


### 2. Select productive states for the tiers of the WIN transmitter.

- i** The productive states are calculated in the evaluation based on the following priority:
- Non productive
  - Productive
  - Do not analyse
  - Undefined

## Modifying the control station display

The control station display of the WIN transmitter can be modified.

### 1. Select the **Design** tab.





### 2. Select the design variant of the WIN transmitter.

### 3. If necessary, select the size of the control station display in the **Size** selection list.

- i** If you have selected a display variant with **individual light** and the signal tower displays two states, the control station display automatically switches to the **Signal tower without text** display variant.

### 3.1.3.2 Configuring WIN transmitter control

1. Click on **Edit WIN transmitter**  in the control station display of the desired WIN transmitter control.  
→ The **WIN transmitter configuration** window appears.



## 2. Configure the following settings:

- Name of the WIN transmitter control
- Tiers and colours of the signal tower
- Blink recognition
- Control station display of the WIN transmitter control

## 3. Once configuration has been completed, click on **OK** to save the settings.

### Modifying the name

Every WIN transmitter control can be individually named.


#### 1. Enter the name of the WIN transmitter control in the **Name** field.



### Modifying the tiers and colours of the signal tower

The tiers and colours can be modified on the signal tower installed. A productive state can be defined, if required, for every tier and the states **Off** and **Connection error**. The productive states are evaluated in the **Productivity** module.

#### 1. Select the **Signal tower** tab.



#### 2. Specify a **Name** and **Colour/Function** for the tiers of the WIN transmitter control.




A user-defined name can be entered in the **Name** selection list. As soon as the configuration of the WIN transmitter control has been saved, this user-defined name can be called up again using the selection list.

If a user-defined name is no longer used, it will not be displayed in the selection list any longer. Consequently, it is possible to remove misspelt or incorrectly created names (for example, `material mter ia`) from the selection list.

## Selecting productive states

To define the productive states of the tiers:

1. Select check box **Select productive state**.
2. The **Productive** column to select the productive states is shown.



	Description	Colour/Function	Productive
4th tier	Tier 4	Blue	Undefined
3rd tier	Tier 3	Red	Undefined
2nd tier	Tier 2	Yellow	Undefined
1st tier	Tier 1	Green	Undefined
Off			Undefined
Connection error			Do not analyse

3. Select productive states for the tiers of the WIN transmitter control.

- i** The productive states are calculated in the evaluation based on the following priority:
- Non productive
  - Productive
  - Do not analyse
  - Undefined


## Modifying blink recognition

Blink recognition is enabled by default for all tiers with the WIN transmitter control. Blink recognition can be used with the **manual control** function or with the definition of a switching rule.

A productive state can be defined for every tier. The productive states are evaluated in the **Productivity** module.

- i** The blink signal is transmitted to the signal tower and the terminals at a switching frequency of 1 Hz.

1. Select the **Blink recognition** tab.



	Blink recognition	Description
4th tier	<input checked="" type="checkbox"/>	Tier 4 blinking
3rd tier	<input checked="" type="checkbox"/>	Tier 3 blinking
2nd tier	<input checked="" type="checkbox"/>	Tier 2 blinking
1st tier	<input checked="" type="checkbox"/>	Tier 1 blinking

2. Enable or disable **Blink recognition** to enable or disable blink recognition for the individual tiers of the WIN transmitter control.
3. Define a **description** for the tiers of the WIN transmitter control.

- i** A user-defined description can be entered in the **Description** selection list. As soon as the configuration of the WIN transmitter control has been saved, this description can be cal-

---

**i** led up again using the selection list.


---

## Selecting productive states

To define the productive states of the tiers:

### 1. Enable **Select productive state**.

→ The **Productive** column to select the productive states is shown.



### 2. Select productive states for the tiers of the WIN transmitter control.

**i** The productive states are calculated in the evaluation based on the following priority:

- Non productive
- Productive
- Do not analyse
- Undefined

---

## Modifying the control station display


The control station display of the WIN transmitter control can be modified.

---

**i** The **manual control** function is only possible in the **Signal tower with text** display variant.

---

### 1. Select the **Design** tab.




### 2. Select the display variant of the WIN transmitter control.


### 3. If necessary, select the size of the control station display in the **Size** selection list.

**i** If you have selected a display variant with **individual light** and the signal tower displays two states, the control station display automatically switches to the **Signal tower without text** display variant.

---

### 3.1.3.3 Configuring WIN transmitter performance

1. Click on **Edit WIN transmitter**  in the control station display of the desired WIN transmitter performance.  
→ The **WIN transmitter configuration** window appears.



2. Configure the following settings:
  - Name of the WIN transmitter performance
  - Tiers and colours of the signal tower
  - Blink recognition
  - Control station display of the WIN transmitter performance
3. Once configuration has been completed, click on **OK** to save the settings.

#### Modifying the name

Every WIN transmitter performance can be individually named.


1. Enter the name of the WIN transmitter performance in the **Name** field.



#### Modifying the tiers and colours of the signal tower

The tiers and colours can be modified on the signal tower installed. A productive state can be defined, if required, for every tier and the states **Off** and **Connection error**. The productive states are evaluated in the **Productivity** module.

1. Select the **Signal tower** tab.



2. Specify a **Name** and **Colour/Function** for the tiers of the WIN transmitter.



A user-defined name can be entered in the **Name** selection list. As soon as the con-

---

**i** If the configuration of the WIN transmitter has been saved, this user-defined name can be called up again using the selection list.


If a user-defined name is no longer used, it will not be displayed in the selection list any longer. Consequently, it is possible to remove misspelt or incorrectly created names (for example, `material`, `material`) from the selection list.

---

**i** The **Counter input** and **Job input** functions can each only be defined for one tier.

---

**i** The maximum counter frequency of the counter input is 10 Hz (> 50 ms 24 V – > 50 ms 0 V).




**i** The **Counter input** function was assigned to a tier during activation of the WIN transmitter performance. If the **Counter input** function is to be assigned to another tier, you must connect the WIN transmitter performance to the PC using the USB cable to transfer the modified configuration.

---

**i** The impulse at the tier configured for the **Job input** function must be applied for at least five seconds. The first impulse starts the job and the second impulse ends the job. If you have already created another job as **active waiting**, it can be started with a further impulse.

The impulse can also be applied for the whole duration of the job. Then the impulse must be inactive for at least five seconds so that a further impulse ends the job.




## Selecting productive states

To define the productive states of the tiers:

1. Select check box **Select productive state**.
  2. The **Productive** column to select the productive states is shown.
-





	Description	Colour/Function	Productive
4th tier	Counter input	Counter input	Undefined
3rd tier	Tier 3	Red	Undefined
2nd tier	Warning	Yellow	Undefined
1st tier	Operational	Green	Undefined
	Off		Undefined
	Connection error		Do not analyse

3. Select productive states for the tiers of the WIN transmitter performance.


- i** The productive states are calculated in the evaluation based on the following priority:
- Non productive
  - Productive
  - Do not analyse
  - Undefined

### Modifying blink recognition

If the signal tower installed has a blinking function, it can be evaluated using blink recognition. A productive state can be defined for every tier. The productive states are evaluated in the **Productivity** module.

- i** Blink recognition detects blinking signals between 15 Hz and 0.8 Hz switching frequency generated by a machine or control (e.g via the PLC).

1. Select the **Blink recognition** tab.



	Blink recognition	Description
4th tier	<input checked="" type="checkbox"/>	Tier 4 blinking
3rd tier	<input checked="" type="checkbox"/>	Tier 3 blinking
2nd tier	<input checked="" type="checkbox"/>	Tier 2 blinking
1st tier	<input checked="" type="checkbox"/>	Tier 1 blinking

2. Enable or disable the **Blink recognition** checkbox to enable or disable blink recognition for the individual tiers of the WIN transmitter performance.

3. Defining a **description** for the tiers of the WIN transmitter performance.

- i** A user-defined description can be entered in the **Description** selection list. As soon as the configuration of the WIN transmitter performance has been saved, this description can be called up again using the selection list.

### Selecting productive states

To define the productive states of the tiers:

1. Enable **Select productive state**.

→ The **Productive** column to select the productive states is shown.

Signal tower		Blink recognition	Design
<input checked="" type="checkbox"/> Select productive state			
	Blink recognition	Description	Productive
4th tier	<input checked="" type="checkbox"/>	Tier 4 blinking	Undefined
3rd tier	<input checked="" type="checkbox"/>	Tier 3 blinking	Undefined
2nd tier	<input checked="" type="checkbox"/>	Tier 2 blinking	Undefined
1st tier	<input checked="" type="checkbox"/>	Tier 1 blinking	Undefined

2. Select productive states for the tiers of the WIN transmitter performance.



The productive states are calculated in the evaluation based on the following priority:

- Non productive
- Productive
- Do not analyse
- Undefined

## Modifying the control station display

The control station display of the WIN transmitter performance can be modified.

1. Select the **Design** tab.

Signal tower		Blink recognition	Design
Select your desired design for the signal tower:			
<input checked="" type="radio"/>		<input type="radio"/>	
Size	Normal		

2. Select the display variant of the WIN transmitter performance.

3. If necessary, select the size of the control station display in the **Size** selection list.



If you have selected a display variant with **individual light** and the signal tower displays two states, the control station display automatically switches to the **Signal tower without text** display variant.


### 3.1.4 Resetting the counter

Quantities can be counted without or with job with every WIN transmitter performance. The counter can only be reset when counting without a job.

1. In the control station display of the WIN transmitter performance, click on **Reset counter**
2. Confirm the prompt with **Yes** to reset the quantity counter.
  - The counter has been reset.

### 3.1.5 Manual control

Every WIN transmitter control can be switched or controlled manually or via a switching rule.

1. Click on **Switch**  beside the tier to be switched.  
→ The menu to select the switching status appears.



2. Select the switching status of the tier.  
→ The tier of the signal tower is switched and displayed in the control station display.



---

 Tiers that can be controlled with a switching rule () cannot be manually controlled.

---

 The **Blinking** status is only available if the blink recognition of the tier is enabled.


---

 The **Switch**  symbol can flicker during transmission of the switching status. As soon as the transmission of the WIN transmitter control has been confirmed, the symbol changes to a permanent display.


---

### 3.1.6 Status change message


If the status change message of a WIN transmitter is enabled, a pop-up window appears when the status of the signal tower is changed. This allows you to minimise the WERMA-WIN program window without neglecting to monitor the machines.




1. Click on **Status change message option deactivated**  in the control station display of the WIN transmitter.  
→ The **Status Change Message** window appears.



2. Enable the tiers in the **Pop-up active** area for which a pop-up window is to be displayed in the event of a status change.

 A status change message can be generated for a tier with the function **Counter input** with the WIN transmitter performance.

3. Define the **Time delay** in the **Options** area.

 The pop-up window only appears when the new status is unchanged during the defined **time delay**. No pop-up window appears if the status has changed again within the **time delay**.

4. Click on **OK** to save the settings.

→ The status change message has been enabled.

→ The **Status change message option activated** symbol  appears in the control station display of WIN transmitter.

 An individual sound can be defined under Settings for the status change message.

## 3.1.7 Status transmission


If the status transmission of a WIN transmitter is active, an e-mail is sent to one or more recipients when the status of the signal tower changes. This enables WERMA-WIN to be run on an unattended PC or server without neglecting to monitor the machines.

### 3.1.7.1 WIN transmitter and WIN transmitter control

1. In the control station display of the WIN transmitter or WIN transmitter control, click on **Status**


**transmission deactivated** .

→ The **Status transmission** window appears.



2. In the **General** tab, enable the tiers for which an e-mail is to be sent in the event of a status change.

3. Define the **Time delay**.

 The e-mail is only sent if the new status is unchanged during the defined **time delay**. No email is sent if the status has changed again within the **time delay**.


4. Select the **E-mail recipient** tab.

5. Select the e-mail recipient.


Option	Description
<b>As specified in Settings</b>	Send an e-mail to the recipient specified under Settings.
<b>Selected recipients</b>	Send an e-mail to the specified recipient(s). Multiple recipients are separated by a semi-colon (;).
<b>Define a recipient per tier</b>	Send an e-mail to the specified recipient(s) per tier. Multiple recipients are separated by a semi-colon (;).

6. Click on **OK** to save the settings.


→ Status transmission has been enabled.

→ In the control station display of the WIN transmitter or WIN transmitter control, the **Status transmission activated**  symbol appears.

### 3.1.7.2 WIN transmitter performance

1. In the control station display of the WIN transmitter performance, click on **Status transmission deactivated** .

→ The **Status transmission** window appears.




2. In the **Tier status** area of the **General** tab, enable the tiers , for which an email is to be sent in the event of a status change.
3. Define the **Time delay**.

**i** The e-mail is only sent if the new status is unchanged during the defined **time delay**. No email is sent if the status has changed again within the **time delay**.

4. In the **Job status** area, define whether an e-mail is also to be sent if a certain job progression is reached or when a certain quantity is reached.
5. Select the **E-mail recipient** tab.
6. Select the e-mail recipient.


Option	Description
<b>As specified in Settings</b>	Send an e-mail to the recipient specified under Settings.
<b>Selected recipients</b>	Send an e-mail to the specified recipient (s). Multiple recipients are separated by a semi-colon (;).
<b>Define a recipient per tier</b>	Send an e-mail to the specified recipient (s) per tier. Multiple recipients are separated by a semi-colon (;).

7. Click on **OK** to save the settings.
  - Status transmission has been enabled.
  - In the control station display of WIN transmitter performance, the **Status transmission activated**  symbol appears.

### 3.1.8 Report

A report can be generated for each view. In the **Control station main view**, the report takes into account all WIN transmitters. In the user-defined views, the report takes into account the WIN transmitter contained in the respective view.


1. Call up the required view.
2. Click on **Report / Export** in the toolbar.  
→ The **Generate report** window appears.



3. Select the required report in the **Data selection** area.
4. Click on **OK**.  
→ The report is generated.  
→ The Print preview for the report appears.

## 3.2 Productivity

The capacity of the machines can be analysed for any time intervals in the **Productivity** module. Work shifts, errors and downtimes can therefore be detected retrospectively, for instance for the last working day or for defined time intervals.




## 3.2.1 Views

The **Productivity main view** or a user-defined view can be used in the **Productivity** module.

### 3.2.1.1 Productivity main view

The **Productivity main view** gives an overview of all WIN transmitters that have been configured. The **Productivity main view** can be provided with a background image.






### 3.2.1.2 User-defined views

Additional user-defined views can be created in addition to the **Productivity main view**.


The user-defined views can be named as required and be provided with a background image. Different WIN transmitters can be displayed in every user-defined view.



**i** The user-defined views of the **Control station**, **Productivity** and **Runtime** modules are always identical. All view settings are applied.

#### Adding WIN transmitter to a view

1. Call up the required view.
2. Click on **Add WIN transmitter**.  
→ The **Select WIN transmitter** window appears.




3. Highlight the required WIN transmitter.
4. Click on **OK**.

→ The WIN transmitter has been added to the view.

### Removing WIN transmitter from the view


1. Call up the required view.
2. Right-click on the WIN transmitter to be removed.
3. Select **Remove** in the pop-up menu.



4. Confirm the prompt with **Yes**.  
→ The WIN transmitter has been removed from the view.

### Selecting the background image of a view

1. Call up the required view.
2. Click on **Select background**.  
→ The **Background image** window appears.



3. Select **Selected image**.
4. Click on **Browse** and open the required background image.



The background image needs to be saved on the local PC.

If more than one computer is accessing a WERMA-WIN database, then the background image must be saved on a network drive.

5. Select **As original** to paste the background image in its original size.
6. Select **Zoom out / zoom in** to paste the background imaged scaled.



Clicking on **Preview** allows a **preview** of the background image to be displayed.


---

7. Click on **Save** to paste the background image into the view.

### Repositioning a WIN transmitter

Every WIN transmitter can be repositioned anywhere in the view.

1. Left-click on the name of the WIN transmitter and hold down the mouse key.



2. Drag the WIN transmitter to the desired position and release the mouse key.

### 3.2.1.3 Full screen mode

Every view can be displayed in full screen and without the menu bar.


1. Call up the required view.
2. Click on **Full screen** in the menu bar.

To close the full screen view:

1. Press **ESC**.

### 3.2.2 Productivity view

The pie charts of the productivity display show the individual statuses of the WIN transmitters.



The displayed statuses of the WIN transmitters correspond to the settings entered in the **Control station module**. The **Off** (lilac) and **Connection error** (grey) statuses are also displayed. Blink recognition is shown as shaded areas in the pie chart.

**Off** and **Connection error** statuses occur in the following cases:


Status	Description
<b>Off</b>	Signal tower is off but is supplied with power.
<b>Connection error</b>	No radio connection between WIN transmitter and WIN receiver. <b>WERMA WIN 4 Server Service</b> and <b>WERMA WIN 4 Connector Service</b> have not started. PC with WERMA-WIN database (Server PC) is switched off. Microsoft SQL server cannot be accessed and there is no connec-

Status	Description
	<p>tion to the WERMA-WIN database.</p> <p>There is no power supply to the WIN transmitter.</p> <p>WIN receiver is not connected to the PC.</p>

 A yellow warning triangle  indicates a signal overlap.

### 3.2.2.1 Adapting the productivity display

The time interval of the values displayed can be modified in the options bar.



The values displayed can be further filtered and modified by using additional options. The following options are available to you:

Option	Description
<b>Update after</b>	Automatically update productivity display after the set time.
<b>Display values as a %</b>	Display runtime as a percentage.
<b>Hide 'do not analyse'</b>	Ignore all statuses defined as <b>Do not analyse</b> in the WIN transmitter configuration and do not display them in the pie chart.
<b>Analyse only job productivity</b>	Ignore with all WIN transmitter performance times without job.
<b>Analyse productive states</b>	Display all statuses defined as <b>Productive</b> and/or <b>Non productive</b> in the WIN transmitter configuration in the pie chart.

To adapt the productivity display:


1. Select the pre-set time interval in the **Time interval** selection list or enter another time interval in the **From** and **To** fields.

 If time periods have been defined under Settings, they can be selected in the **Time interval** selection list.

2. Enable or disable additional options if necessary.
3. Click on **Refresh**.




### 3.2.2.2 Zoom in or zoom out of the productivity display

1. Click on the magnifying glass  in the productivity display.
  - You zoom into or out of the productivity display.
  - The descriptions of the tiers of the signal tower are also displayed in the zoomed in display.





### 3.2.2.3 Selecting the display variant

It is possible to choose between different display variants with WIN transmitter performance.

Display variant	Display
Status	
Productivity	
Combined	

To select a display variant:


1. Click on the arrow symbol .  
→ The menu to select the display variant appears.



2. Select the display variant.

### 3.2.2.4 Combined productivity

Combined productivity can be shown in each view.



### Showing combined productivity

1. Click on the arrow  at the bottom of the view.

- or -

2. Click on **Show combined productivity** in the toolbar.

### Hiding combined productivity

1. Click on the arrow  above combined productivity.

- or -

2. Click on **Hide combined productivity** in the toolbar.

## 3.2.3 Report


A report can be generated for each view. In the **Productivity main view**, the report takes into account all WIN transmitters. In the user-defined views, the report takes into account the WIN transmitters contained in the respective view.



The report is generated with the times and settings defined in the Options bar.

1. Call up the required view.


2. Click on **Report / Export** in the toolbar.  
→ The **Generate report** window appears.



3. Select **Tabular display of data** or **Graphical display of data**.
4. Click on **OK**.
  - The report is generated.
  - The Print preview for the report appears.

### 3.3 Runtime

The **Runtime** module shows an overview of the operation and downtimes of the machines monitored. This quickly detects patterns of downtime with machines, giving you improved transparency in the production process. This forms the basis for improving the efficiency of the machines monitored.




#### 3.3.1 Views

The **Runtime main view** or a user-defined view can be used in the **Runtime** module.


### 3.3.1.1 Runtime main view

The data of all WIN transmitters already configured can be displayed in the **Runtime main view**.



### 3.3.1.2 User-defined views

The user-defined views defined in the **Control station module** or **Productivity module** are available in addition to the **Runtime main view**. The user-defined views show an overview of the WIN transmitters assigned in each case.






**i** The user-defined views of the **Control station**, **Productivity** and **Runtime** modules are always identical. All view settings are applied.

### 3.3.1.3 Comparing multiple machines

Additional windows can be opened and arranged as required in the **Runtime main view** to compare multiple machines.

1. In the toolbar, expand **Runtime main view** by clicking on the arrow ▾.



2. Select **New window**.


→ A further window appears and can be arranged as required.

## 3.3.2 Runtime display

The runtime display shows a separate diagram for each WIN transmitter.

### 3.3.2.1 WIN transmitter and WIN transmitter control runtime display

The WIN transmitter and WIN transmitter control runtime display includes the following information:




Item	Description
1	Display of statuses in the selected time interval
2	Note field

Item	Description
3	Number of statuses in the selected time interval
	The blink recognition signal is displayed as a shaded area in the colour of the respective tier.

- i** Following a power loss, the **Power loss** ⚠ warning symbol is displayed as soon as power is supplied again to the WIN transmitter or WIN transmitter control. There may be incorrect data during the preceding time interval.

### 3.3.2.2 WIN transmitter performance

The WIN transmitter performance runtime display includes the following information:




Item	Description
1	Status display/quantity display for the selected time interval depending on the display version
2	Note field
3	Job field
4	Number of statuses in the selected time interval
	The blink recognition signal is displayed as a shaded area in the colour of the respective tier.

- i** Following a power loss, the **Power loss** ⚠ warning symbol is displayed as soon as power is supplied again to the WIN transmitter performance. There may be incorrect data during the preceding time interval.

### 3.3.2.3 Modifying the runtime display

The time period of the values displayed can be modified in the options bar. The buttons in the navigation bar can be used to scroll through and zoom into the diagram displayed.

#### Options bar



The values displayed can be further filtered and modified by using additional options. The following options are available:

Option	Description
<b>Update after</b>	Automatically update runtime display after the set time.
<b>Show plan quantity</b>	Show plan quantity with WIN transmitter performance.
<b>Show plan cycle time</b>	Show plan cycle time with WIN transmitter performance.

To modify the runtime display:

1. Select pre-set time interval in the **Time interval** selection list or enter another time interval in the **Start** and **End** fields.



If time periods have been defined under Settings, they can be selected in the **Time interval** selection list.

2. Enable or disable additional options if necessary.
3. Click on **Refresh**.


To hide the options bar and zoom into the display of the diagram:





1. Click on **Hide options**  in the options bar.

To show the options bar again:

1. Click on **Show options** .

#### Navigation bar



Button	Function
	Show earlier time interval.
	Show later time interval.
	Zoom out of diagram and zoom into time interval displayed.
	Zoom into diagram and zoom out of time interval displayed.

### 3.3.3 Notes/Fault conditions

Different notes or fault conditions can be entered for each WIN transmitter in the **Runtime** module.

#### 3.3.3.1 Creating a note/fault condition


Notes or fault conditions can be created for defined time intervals.

The time interval of a note or fault condition can be defined in two ways:

- Manually defining the time interval of the note or fault condition
- Defining the time interval of the note or fault condition based on the duration of a status

#### Manually defining the time interval of the note or fault condition

1. Left-click and hold down the mouse key in the WIN transmitter diagram.
2. With the mouse key held down, move the cursor to the right or left to define the time interval of the note or fault condition.



3. Release the mouse key.  
→ The **Edit note** window appears.


#### Defining the time interval of the note or fault condition based on the duration of a status

1. Click twice on a status in the WIN transmitter diagram.  
→ The **Edit note** window appears.


---

**i** If **Use touch interface to assign fault conditions** has been enabled under Settings, the display option for **touch screen** appears instead of the **Edit note** window. A defined fault condition can only be selected in this case. It is not possible to create a note.


---



### Editing a note/fault condition



1. Select **Fault condition** in the selection list.

 Fault conditions must have previously been defined under Settings. The defined fault conditions can then be selected in the **Fault condition** selection list.

2. Select the **Colour**.
3. Modify the time interval in the **Start** and **End** fields.
4. Enter a note in the **Note** field.
5. Click on **OK** to save the note or fault condition.


#### 3.3.3.2 Displaying a note/fault condition

1. Place the cursor on the note.  
→ The note is displayed in an information window.



### 3.3.3.3 Editing a note/fault condition

1. Right-click on the required note.
  2. Select **Edit** in the pop-up menu.
- or -
1. Double-click on the required note.  
→ The **Edit note** window appears.



2. Modify the note as required.
3. Click on **OK** to save all changes.

### 3.3.3.4 Deleting a note/fault condition

1. Right-click on the note to be deleted.
2. Select **Delete** in the pop-up menu.
3. Confirm the prompt with **Yes**.  
→ The note has been deleted.

### 3.3.3.5 Limiting the view to the time interval of a note/fault condition


1. Right-click on the required note.
2. Check **Select time interval** in the pop-up menu.  
→ The view zooms into or out of the time interval of the note.

## 3.3.4 Job

If a job has been created in the Job module for a WIN transmitter performance, this appears in the diagram.


### 3.3.4.1 Displaying a job

1. Place the cursor on the job or the associated line.  
→ The job information is displayed in an information window.



### 3.3.4.2 Limiting the view to the time interval of a job


1. Right-click on the job.



2. Check **Select time interval** in the pop-up menu.  
→ The view zooms into or out of the time interval of the job.

### 3.3.4.3 Displaying job information

1. Right-click on the job.



2. Select **Go to Job overview** in the pop-up menu.  
→ The **Job** module appears and displays the corresponding job.

## 3.3.5 Report


A report can be generated for each view. In the **Runtime main view** the report takes into account all WIN transmitters. The report takes into account the WIN transmitters contained in the respective view in the user-defined views.

---

 The report is generated with the times and settings defined in the **Options bar**.

---


1. Call up the required view.
2. Click on **Report / Export** in the toolbar.  
→ The **Generate report** window appears.



3. Select the required report in the **Data selection** area.
4. Click on **OK**.
  - The report is generated.
  - The Print preview for the report appears.

## 3.4 Job

The **Job** module shows which job is running on which machine and how far it has progressed.



 No jobs can be created for WIN transmitter and WIN transmitter control.



### 3.4.1 Job overview

The job overview shows all jobs created with the relevant details. Auto jobs are listed in a separate area that can be shown and hidden.

ID  Description  Start date  until   
 Job number  Machine  State

ID	Job number	Description	Machine	State	Job progression
1	4856	841.225.978	Unit 2	Completed	104%
2	6483	846.365.978	<not assigned>	Waiting	0%
3	7984	207.866.124	<not assigned>	Waiting	0%
4	1472	114.458.323	<not assigned>	Waiting	0%
5	8952	846.365.978	<not assigned>	Waiting	0%
6	4856	841.225.978	Unit 2	Completed	26%
7	2323	842.715.777	Unit 2	Running	0%

▼

**Auto jobs**

Job number	Description	Machine	Activated	Weekday	Start time
2323	842.715.777	Unit 2	<input checked="" type="checkbox"/>	Mon, Thu, Fri	10:12
6578	759.681.956	Unit 2	<input checked="" type="checkbox"/>	Tue, Wed	12:12

 Clicking on the column name in the job overview lets you collate the displayed jobs in ascending or descending order.

The fields in the options bar can be used to filter and collate the displayed jobs.

ID  Description  Start date  until   
 Job number  Machine  State

#### 3.4.1.1 Showing Auto jobs

1. Click on the arrow  at the bottom of the view.

- or -

1. Click on **Show Auto jobs** in the toolbar.

#### 3.4.1.2 Hiding Auto jobs

1. Click on the arrow  above the Auto jobs overview.

- or -

1. Click on **Hide Auto jobs** in the toolbar.

### 3.4.2 Job details

Job details show all information on a job selected in the job overview.

Job details



**Job information**

ID: 1 State: Completed

Job number: 4856


Description: 841.225.978

Machine: Unit 2

**Schedule deviation +1.9 hr**

Plan	Actual
Set up time: 0:00 hr	0:00 hr
Start time: 09/08/2017 12:21	09/08/2017 12:21
Runtime: 0 hr 17 min.	2 hr 10 min.
End time: 09/08/2017 12:38	09/08/2017 14:31

**Job progression: 104%**



Button	Function
	Refresh job details and job overview.
	Switch to the <b>Productivity</b> or <b>Runtime</b> module.
	Hide area.
	Show area.

A traffic light display offers a fast overview of how well or poorly the job is running or has run in the **Schedule deviation**, **Job progression** and **Productivity** areas.

**i** The traffic light setting can be individually modified if required.

### 3.4.2.1 Schedule deviation

The **Schedule deviation** area displays information on the set-up, start, run and end time.


**Schedule deviation +1.9 hr**

Plan	Actual
Set up time: 0:00 hr	0:00 hr
Start time: 09/08/2017 12:21	09/08/2017 12:21
Runtime: 0 hr 17 min.	2 hr 10 min.
End time: 09/08/2017 12:38	09/08/2017 14:31

The schedule deviation is specified in machine hours. 0.1 machine hours corresponds to 6 minutes, 1 machine hour corresponds to 60 minutes.

### 3.4.2.2 Job progression

The **Job progression** area displays information on the plan quantity and actual quantity.




The current files are displayed for jobs currently running. The job progression is calculated as the ratio of the current actual quantity to the current plan quantity, expressed as a percentage.

The data for completed jobs is displayed at the end of the job. The job progression is calculated as the ratio of the actual quantity to the plan quantity, expressed as a percentage.

In addition, you can see the actual correction and the factor, entered for this job.

### 3.4.2.3 Productivity

The **Productivity** area displays information on the plan cycle time and the actual cycle time.



The current data is displayed for jobs currently running. The productivity is calculated as the ratio of the current actual cycle time to the current plan cycle time, expressed as a percentage.

The data for completed jobs is displayed at the end of the job. The productivity is calculated as the ratio of the actual cycle time to the plan cycle time, expressed as a percentage.

### 3.4.2.4 Editing traffic light settings

The traffic lights for **Schedule deviation**, **Job progression** and **Productivity** can be individually adapted.

The traffic light settings are saved in a local configuration file. You have to edit this local configuration file to change the traffic light setting.

**i** The configuration file must be copied to transfer the altered traffic light setting to other PCs.

1. Open the following folder on your PC: `C:\ProgramData\WERMA\WERMA-WIN-3.00` or `C:\ProgramData\WERMA\WERMA-WIN-4.0`
2. Use a text editor (e.g. Notepad) to open the configuration file `WERMA-WIN.ini`
3. Search for the following segment in the configuration file.

[Orders]

ProductivityGreenLimit=100

ProductivityYellowLimit=75

CompletionGreenLimit=100

CompletionYellowLimit=90

RuntimeGreenLimit=100

RuntimeYellowLimit=110

Setting	Description	Example
<b>Productivity</b>		
ProductivityGreenLimit	Indicates until what percentage value the traffic light is switched to Green.	ProductivityGreenLimit=100 ProductivityYellowLimit=75 Productivity 0% to 74%: Traffic light is red
ProductivityYellowLimit	Indicates up to what percentage the traffic light is switched to Yellow.	Productivity 75% to 99%: Traffic light is yellow Productivity 100% or higher: Traffic light is green
<b>Job progression</b>		
CompletionGreenLimit	Indicates until what percentage value the traffic light is switched to Green.	CompletionGreenLimit=100 CompletionYellowLimit=90 Job progression 0% to 89%: Traffic light is red
CompletionYellowLimit	Indicates up to what percentage the traffic light is switched to Yellow.	Job progression 90% to 99%: Traffic light is yellow Job progression 100% or higher: Traffic light is green
<b>Schedule deviation</b>		
RuntimeGreenLimit	Indicates until what percentage value the traffic light is switched to Green.	RuntimeGreenLimit=100 RuntimeYellowLimit=110 Schedule deviation 0% or negative: Traffic light is green Schedule deviation 1% to 10%: Traffic light is yellow

Setting	Description	Example
RuntimeYellowLimit	Indicates up to what percentage the traffic light is switched to Yellow.	Schedule deviation greater than 11%: Traffic light is red

4. Save the configuration file once all changes have been made.

 The modified traffic light setting will be available as soon as WERMA-WIN is restarted.

### 3.4.3 Entering a job


Jobs can be manually entered or imported from a job list.

Auto jobs can be created for recurring jobs. Auto jobs start and end the jobs automatically.

 An Auto job is only started if no other job is running on the selected WIN transmitter performance or it has the status **Active waiting**.

#### 3.4.3.1 Entering a job manually

1. Click on **Enter job** in the toolbar.  
→ The **Enter job** window appears.



2. Enter the required **Job number** and the **Description** in the **Job information** area.

 The **ID** is a continuous number and is automatically issued by WERMA-WIN.

3. Select the WIN transmitter performance on which the job is to run in the **Machine** selection list.
4. Enter the required plan values for the job in the **Plan values** area.

Plan values	Description
<b>Quantity</b>	Volume to be produced
<b>Cycle time</b>	Time needed to produce a part
<b>Set up time</b>	Set up time for the job If a part has been produced before the end of the set up time entered, the actual set up time is set to this time.
<b>Runtime</b>	The time calculated by WERMA-WIN that is required to produce the job (including set up time).
<b>Factor</b>	Number of pieces per cycle
<b>Amend actual quantity</b>	Positive or negative correction values (e.g. with poor parts)
<b>Actual set up time</b>	Time from the start of job to the first quantity being transmitted WERMA-WIN automatically sets the time which can be manually altered.

5. Enable **Set end time** and enter the end time if the job is to be ended at a certain time.
6. Enable **End with quantity** if the job is to be ended when the plan quantity is reached.

---

**i** If **Set end time** and **End with quantity** are enabled simultaneously, the job is ended as soon as the end time or the plan quantity has been reached.

---

**i** There can be deviations relating to the actual quantity ( $\geq$  plan quantity) due to radio transmission.


---

Once all information has been entered:

1. Click on **Start** to start the job immediately.
- or -
1. Click on **OK** to save the job and set the status to **Waiting**.

### 3.4.3.2 Entering Auto jobs

1. Click on **Enter job** in the toolbar.  
→ The **Enter job** window appears.



2. Enter the required **Job number** and the **Description** in the **Job information** area.

 The **ID** is a continuous number and is automatically issued by WERMA-WIN.

3. Select the WIN transmitter performance on which the job is to run in the **Machine** selection list.

4. Enter the required plan values for the job in the **Plan values** area.

Plan values	Description
<b>Quantity</b>	Volume to be produced
<b>Cycle time</b>	Time needed to produce a part
<b>Set up time</b>	Set up time for the job If a part has been produced before the end of the set up time entered, the actual set up time is set to this time.
<b>Runtime</b>	The time calculated by WERMA-WIN that is required to produce the job (including set up time).
<b>Factor</b>	Number of pieces per cycle
<b>Amend actual quantity</b>	Positive or negative correction values (e.g. with poor parts)
<b>Actual set up time</b>	Time from the start of job to the first quantity being transmitted WERMA-WIN automatically sets the time which can be manually altered.

 No actual correction and actual set up time can be planned for an Auto job.

5. Enable **Plan Auto job**.  
→ The fields for entering Auto job data are enabled.

6. Enter the required start time in the **Set start time** field in the **Start/End** area.  
→ The end time calculated by WERMA-WIN automatically appears in the **Calculated end time** field.
7. Enable **Set end time** and enter the end time if the job is to be ended at a certain time.
8. Enable **End with quantity** if the job is to be ended when the plan quantity is reached.

**i** If **Set end time** and **End with quantity** are enabled simultaneously, the job is ended as soon as the end time or the plan quantity has been reached.

**i** There can be deviations relating to the actual quantity ( $\geq$  plan quantity) due to radio transmission.

9. Enable the weekdays on which the Auto job is to be performed in the **Recurrence pattern** area.
10. Select the time interval within which the Auto job is to be performed in the **Range of recurrence** area.

Field/Option	Description
<b>Start</b>	Start date of Auto job
<b>No end date</b>	Auto job remains enabled until it is manually disabled.
<b>Ends after x jobs</b>	Auto job is disabled after the specified number of jobs.
<b>End by</b>	Auto job is disabled up to the specified time.

**i** WERMA-WIN checks for a duration of 1 year whether Auto jobs overlap. Overlapping



 Auto jobs cannot be saved.

11. Click on **OK** to save the Auto job.


### 3.4.3.3 Importing a job list


A job list can be imported in CSV form to create several jobs simultaneously.

#### Requirement:

- There is a CSV file available in a suitable format.

1. Click on **Import job list** in the toolbar.  
→ The **Import jobs** window appears.



2. Click on **Browse**  and open the CSV file you require.
3. Adapt the **File format** if necessary.
4. Click on **Next**.  
→ The CSV file is imported and checked.  
→ If the check is successful, the jobs appear in the job overview.

#### Format of the job list

The CSV file must meet the following requirements to correctly import a job list.

Column label or header:

- JOBNUMBER
- DESCRIPTION
- MACHINE
- QUANTITY
- CYCLETIME
- SETUP TIME
- FACTOR

Format rules:

- The Windows standard character set (for example `Western European`) or `Unicode (UTF-8)`
- Header or first row with column label must be specified.
- The delimiters are a semicolon ( ; ), comma ( , ), tab ( \t ) or pipe ( | ). Only one delimiter is allowed per document.
- `SETUP TIME` must be in the format [ hh ] h : mm (e.g. 0 : 00).
- `CYCLETIME` must be in seconds (e.g. 0 . 0).

- Decimal numbers must always use a point as a decimal separator (e.g. 0.8).
- Each data value can be enclosed in double quote marks, thus the data value can also be text, which can include a semicolon (;).
- One decimal place is allowed after the point for the cycle time (CYCLETIME).
- Three decimal places are allowed after the point for the factor (FACTOR).
- The maximum number of characters is checked.

Not relevant:

- The column order is not relevant (data is identified by the header).
- Column labels and headers are not case-sensitive.
- A maximum of 7 columns can be created. Not all columns need to be specified.

**Example:**

JOBNUMBER	DESCRIPTION	MACHINE	QUANTITY	CYCLETIME	SETUPTIME	FACTOR
4800	"Round parts;4711" job	Machine 2	10000	0.8	01:00	2
4801	"Round parts;4500" job	Machine 3	15000	1.0	05:00	1
4802	"Round parts;3520" job	Machine 2	10000	0.7	01:00	2
4803	"Round parts;8466" job	Machine 5	20000	1.2	10:00	5
4804	"Round parts;0124" job	Machine 6	5000	1.5	01:50	1
4805	"Round parts;4500" job	Machine 2	50000	1.0	03:00	1

## 3.4.4 Starting a job

Jobs can be started in the following way:

- Manually
- Quick start
- With the first impulse at the **Counter input** tier
- With the first impulse at the **Job input** tier

### 3.4.4.1 Starting a job manually

1. Select a job with the status **Waiting** in the job overview.

2. Click on **Start job** in the toolbar.

→ The job is started.

- or -

1. Right-click on the job to be started.


2. Select **Start job** in the pop-up menu.

→ The job is started.


### 3.4.4.2 Job quick start

Jobs from all modules can be started using a keyboard shortcut. Once the ID, job number or description has been entered, the program searches for a corresponding job and starts it immediately.

1. In the toolbar, expand **Start job** by clicking on the arrow ▾.



2. Select **Quick start**.  
→ The **Job quick start** window appears.




3. Choose the attribute the program is to search for.
4. Enter the value of the selected attribute into the corresponding field.
5. Click on **OK** to search for a job with the corresponding attribute.  
→ If a job with the corresponding value is available, then it is started immediately.

### 3.4.4.3 Job start with 1st piece

Jobs can be started as soon as the first impulse to the **Counter input** tier of a WIN transmitter performance has been transmitted.

The job can be ended by a further impulse to the **Job input** tier.

1. Select a job with the status **Waiting** in the job overview.
2. In the toolbar, expand **Start job** by clicking on the arrow ▾.



3. Select **Start with 1st piece**.

- The status of the job changes to **Active waiting**.
- The job starts automatically as soon as the first impulse to the **Counter input** tier of a WIN transmitter performance has been transmitted.

- or -


1. Right-click on the job to be started.
2. Select **Start with 1st piece** in the pop-up menu.
  - The status of the job changes to **Active waiting**.
  - The job starts automatically as soon as the first impulse to the **Counter input** tier of a WIN transmitter performance has been transmitted.

### 3.4.4.4 Job start with job input

Jobs can be started as soon as the first impulse to the **Job input** tier of a WIN transmitter performance has been transmitted.

The job can be ended by a further impulse to the **Job input** tier.

1. Select a job with the status **Waiting** in the job overview.
2. In the toolbar, expand **Start job** by clicking on the arrow ▾.



3. Select **Start with job input**.
  - The status of the job changes to **Active waiting**.
  - The job starts automatically as soon as the first impulse to the **Job input** tier of a WIN transmitter performance has been transmitted.

- or -

1. Right-click on the job to be started.
2. Select **Start with job input** in the pop-up menu.
  - The status of the job changes to **Active waiting**.
  - The job starts automatically as soon as the first impulse to the **Job input** tier of a WIN transmitter performance has been transmitted.

### 3.4.5 Ending a job

1. Select the required job in the job overview.
2. Click on **End job** in the toolbar.

- or -

1. Right-click on the required job.
2. Select **End job** in the pop-up menu.

### 3.4.6 Enabling Auto jobs

1. Enable the checkbox in the **Activated** column in the overview of Auto jobs.

Auto jobs

Job number	Description	Machine	Activated
2323	842.715.777	Unit 2	<input checked="" type="checkbox"/>

### 3.4.7 Disabling Auto jobs

1. Disable the checkbox in the **Activated** column in the overview of Auto jobs.

Auto jobs

Job number	Description	Machine	Activated
2323	842.715.777	Unit 2	<input type="checkbox"/>

### 3.4.8 Editing a job

1. Select the required job in the job overview.


2. Click on **Edit job** in the toolbar.

- or -

1. Right-click on the required job.

2. Select **Edit job** in the pop-up menu.

→ The **Edit job** window appears.



3. Edit the job information as required.

Once all information has been entered:

1. Click on **Start** to start the job immediately.

- or -

1. Click on **OK** to save the job and set the status to **Waiting**.

### 3.4.9 Correction of a completed job

1. Select the job with the status **Completed** in the Job overview.

2. Click on **Edit job** in the toolbar.

- or -

1. Right-click on the required job.

2. Select **Edit job** in the pop-up menu.

→ The **Edit job** window appears.

The screenshot shows the 'Edit job' dialog box with the following details:

- Job information:** ID: 1, Job number: 4856, Description: 841.225.978, Machine: Unit 2.
- Start/End:** Set start time: 12:21, Calculated end time: 12:38, Set end time: 00:00, End with quantity: 1,000 pcs.
- Recurrence pattern:** Monday, Tuesday, Wednesday, Thursday, Friday, Saturday, Sunday (all unchecked).
- Plan values:** Quantity: 1,000 Piece(s), Cycle time: 1.0 sec, Set up time: 0:00 hr, Factor: 1.000 Piece(s)/cycle, Runtime: 0 hr 17 min.
- Set Actual value:** Amend actual quantity: 1,000 Piece(s), Actual set up time: 0:00 hr.
- Buttons:** Cancel (Close) and OK (Save).

3. Change the job information as required.

4. Click on **OK** to save the settings.

### 3.4.10 Deleting a job

1. Select the job in the job overview.


2. Click on **Delete job** in the toolbar.

- or -

1. Right-click on the job to be deleted.
2. Select **Delete job** in the pop-up menu.

### 3.4.11 Duplicating a job

1. Right-click on the required job.
2. Select **Duplicate job** in the pop-up menu.  
→ The **Duplicate job** window appears.




3. Modify the job information as required.
4. Click on **OK** to save the settings.

### 3.4.12 Report

A report can be generated for the filters currently selected and the current collation in the job overview. Only jobs on the machine are taken into account in the report as soon as a certain machine has been selected in the filter menu.

1. Adapting the required filters and collation.
2. Click on **Report / Export** in the toolbar.  
→ The **Generate report** window appears.




3. Select the required report in the **Data selection** area.



Selecting **Tabular display of data** allows the content of the report to be individually adapted.

4. Click on **OK**.

- Selecting **Tabular display of data** generates the report and the Print preview is displayed.
- Selecting **Tabular display of data** makes the window appear for further data selection.



5. Adapt the report by enabling or disabling the individual checkboxes.


6. Click on **OK**.

- The report is generated.
- The Print preview for the report appears.

## 3.5 Control

In the **Control** module, rules with different logic functions can be defined, with which WIN transmitter control can be switched or controlled. The WIN transmitter included in the WERMA-WIN network can be used as the input signals for the logic functions.






 No rules can be defined for WIN transmitter and WIN transmitter performance.

### 3.5.1 Overview of rules

The overview of rules shows a list of all switching rules that have been created and their current status.




Column	Description
Name	Name of switching rule
Result	Current result of switching rules (e.g. On, Off, Blinking)
Processed	✓ = Switching rule being processed
	✗ = No connection to WIN transmitter control
	🕒 = Switch being processed
Message	More information on the rule

## 3.5.2 Defining new rules

New rules can be defined either using an assistant, which takes you step by step through the settings, or in an Expert mode.

### 3.5.2.1 Creating a new rule with assistants

1. Click on **New rule (Assistant)** in the toolbar.  
→ The **Define new switching rule** window appears and shows an example of a switching rule.



2. Click on **Next**.  
→ The window to select the logic function appears.

## Selecting the logic function


Define new switching rule
✕

**Logic function**

Please select the logic function that the input signals should be assigned to.

Description	Logic function
Each tier must be in the selected status	AND
At least one tier must have the defined status	OR
No tier may be in the defined status	NOR
Enter custom logic function (expert mode)	

**AND-Logic example**



← Back  
Cancel
Next  
Next step →

3. Select the **Logic function** with which the input signals are to be linked.

Logic function	Description
AND	Each tier must be in the selected status.
OR	At least one tier must have the selected status.
NOR	No tier may be in the defined status.

i The graphic on the right in the window shows an example of the logic function selected. You may wish to create your own logic functions.

4. Click on **Next**.

→ The window to select the input signal appears.

## Selecting the input signal

Define new switching rule
✕


**Input signals for AND-Logic function**

Please select the input signals that are to be assigned to the switching rule AND.

WIN transmitter	Tier	Status

+ Add
✎ Edit
✖ Delete

**AND-Logic example**



**Switching delay**

If a switching delay is set up then the input signals must remain the same for the delay period.

Delay  sec.

← Back  
Cancel
Next  
Next step →

5. Click on **Add** to select the input signals for the selected logic function.

→ The **Select tier and status** window appears.

Name	MAC-Id
Unit 1	002705
Unit 2	0027C2
Unit 3	003983

Tier	Description	Blink recognition
1	Operational	-
2	Warning	-
3	Error	-

Description
On
Off
Connection error

Note: Only configured tiers are displayed. The tiers can be configured in the Control station module.  
The counter input of a WIN transmitter performance cannot be used as an input signal.

**i** The **Select tier and status** window shows all the WIN transmitters included in the WERMA-WIN network. The available tiers and statuses correspond to the tiers and statuses configured in the **Control station** module.

The blinking status is only displayed if blink recognition is enabled for the tier.

6. Select the WIN transmitter to be used as the input signal.

7. Select the tier of the WIN transmitter to be used as the input signal.

**i** The counter input of a WIN transmitter performance cannot be used as input signal for a logic function.

8. Select the status in which the selected tier is to be.

9. Click on **OK** to apply the settings.

→ The **Define new switching rule** window appears and shows the input signal defined in the list.

WIN transmitter	Tier	Status
Unit 1	1	On

**Add**  
**Edit**  
**Delete**

10. Click on **Add**, if necessary, to add an additional input signal.

11. Click on **Edit**, if necessary, to modify the selected input signal.


12. Click on **Delete**, if necessary, to delete the selected input signal.

13. Set the switching delay in the **Delay** field.


- i** The switching delay defines how long all input signals have to be in the same status for the output signal to be switched.

- 14.** Click on **Next**.  
→ The window for selection of the output signal appears.


### Selecting the output signal




- 15.** Click on **Add**.  
→ The **Select tier** window appears.




- 16.** Select the WIN transmitter control to be used as the output signal.  
**17.** Select the tier to be switched.  
**18.** Click on **OK** to apply the settings.  
→ The **Define new switching rule** window appears and shows the input signal defined in the list.



19. Click on **Add**, if necessary, to add an additional output signal.
20. Click on **Edit**, if necessary, to modify the selected output signal.
21. Click on **Delete**, if necessary, to delete the selected output signal.
22. Define whether the **output signal** should be switched as a **permanent light** or blinking.
23. Click on **Next**.




24. In the **Name** field, enter a name for the switching rule.
25. Enable **Show the advanced settings dialog** if more settings are to be entered for the switching rule.
26. Click on **OK** to save the switching rule.  
→ The switching rule appears in the rule overview and is enabled.



### 3.5.2.2 Defining new rules in Expert mode


1. Click on **New rule (Expert)** in the toolbar.  
→ The **Define new switching rule** window appears.




2. In the **Name** field, enter a name for the switching rule.

#### Selecting the output signal


1. Click on **Edit** beside the **Output signals** field.  
→ The **Define new switching rule** window appears and shows an example of a switching rule.



2. Click on **Add**.  
→ The **Select tier** window appears.



3. Select the WIN transmitter control to be used as the output signal.
4. Select the tier to be switched.
5. Click on **OK** to apply the settings.
  - The **Define new switching rule** window appears and shows the input signal defined in the list.




6. Click on **Add**, if necessary, to add an additional output signal.
7. Click on **Edit**, if necessary, to modify the selected output signal.
8. Click on **Delete**, if necessary, to deleted the selected output signal.
9. Define whether the **output signal** should be switched as a **permanent light** or blinking.
10. Click on **Next** to save the settings.
  - The **Define new switching rule** window appears.

### Selecting the logic function for permanent light


1. Click on **Edit** beside the **Logic function for permanent light** field.
  - The **Define new switching rule** window appears and shows an example of a switching rule.






2. Select the **Logic function** with which the input signals are to be linked.

Logic function	Description
AND	Each tier must be in the selected status.
OR	At least one tier must have the selected status.
NOR	No tier may be in the defined status.


 The graphic on the right in the window shows an example of the logic function selected. You may wish to create your own logic functions.

3. Click on **Next**.  
→ The window to select the input signal appears.

### Selecting the input signal



4. Click on **Add** to select the input signals for the selected logic function.  
→ The **Select tier and status** window appears.




**i** The **Select tier and status** window shows all the WIN transmitters included in the WERMA-WIN network. The available tiers and statuses correspond to the tiers and statuses configured in the **Control station** module.

The blinking status is only displayed if blink recognition is enabled for the tier.

5. Select the WIN transmitter to be used as the input signal.
6. Select the tier of the WIN transmitter to be used as the input signal.

**i** The counter input of a WIN transmitter performance cannot be used as the input signal for a logic function.

7. Select the status in which the selected tier is to be.
8. Click on **OK** to apply the settings.  
→ The **Define new switching rule** window appears and shows the input signal defined in the list.



9. Click on **Add**, if necessary, to add an additional input signal.


10. Click on **Edit**, if necessary, to modify the selected input signal.
11. Click on **Delete**, if necessary, to delete the selected input signal.
12. Set the switching delay in the **Delay** field.

**i** The switching delay defines how long all input signals have to be in the same status for the output signal to be switched.

13. Click on **Next** to save the settings.  
→ The **Define new switching rule** window appears.

### Selecting the logic function for blinking

1. Click on **Edit** beside the **Logic function for blinking light** field.  
→ The **Define new switching rule** window appears and shows an example of a switching rule.



2. Select the **Logic function** with which the input signals are to be linked.

Logic function	Description
AND	Each tier must be in the selected status.
OR	At least one tier must have the selected status.
NOR	No tier may be in the defined status.

**i** The graphic on the right in the window shows an example of the logic function selected. You may wish to create your own logic functions.

3. Click on **Next**.  
→ The window to select the input signal appears.

## Selecting the input signal

Define new switching rule
✕

**Input signals for AND-Logic function - Blinking**

Please select the input signals that are to be assigned to the switching rule AND.

WIN transmitter	Tier	Status

+ Add
✎ Edit
✖ Delete

**Switching delay**

If a switching delay is set up then the input signals must remain the same for the delay period.

Delay  sec.

← Back  
Cancel
→ Next  
Next step

**AND-Logic example**

4. Click on **Add** to select the input signals for the selected logic function.  
→ The **Select tier and status** window appears.

Select tier and status
✕

**1. WIN transmitter select**

Name	MAC-Id
Unit 1	002705
Unit 2	0027C2
Unit 3	003983

**2. Choose tier**

Tier	Description	Blink recognition
1	Operational	-
2	Warning	-
3	Error	-

**3. Select status**

Description
On
Off
Connection error

Note: Only configured tiers are displayed. The tiers can be configured in the Control station module.  
The counter input of a WIN transmitter performance cannot be used as an input signal.

↶ Cancel  
Close
↷ OK  
Apply

**i** The **Select tier and status** window shows all the WIN transmitters included in the WERMA-WIN network. The available tiers and statuses correspond to the tiers and statuses configured in the **Control station** module.


The blinking status is only displayed if blink recognition is enabled for the tier.

5. Select the WIN transmitter to be used as the input signal.
6. Select the tier of the WIN transmitter to be used as the input signal.

**i** The counter input of a WIN transmitter performance cannot be used as the input signal for a logic function.

7. Select the status in which the selected tier is to be.
8. Click on **OK** to apply the settings.


→ The **Define new switching rule** window appears and shows the input signal defined in the list.



9. Click on **Add**, if necessary, to add an additional input signal.
10. Click on **Edit**, if necessary, to modify the selected input signal.
11. Click on **Delete**, if necessary, to delete the selected input signal.
12. Set the switching delay in the **Delay** field.


 The switching delay defines how long all input signals have to be in the same status for the output signal to be switched.

13. Click on **Next** to save the settings.  
→ The **Define new switching rule** window appears.
14. Select whether the output signal is to be switched as a **Permanent light** or **Blinking**, if both logic functions apply.
15. Click on **OK** to save the switching rule.  
→ The switching rule appears in the rule overview and is enabled.



### 3.5.2.3 Entering custom logic function in expert mode

1. Select **Enter custom logic function (expert mode)** in the **Switching rule** window.
2. Click on **Next**.  
→ The **Logic function (expert mode)** window appears.



3. Enter a custom logic function in Visual Basic Syntax or create it using the buttons in the **Logic function** area.

Button	Function
WIN transmitter	Enter tier and status of a WIN transmitter.
AND	Enter logic function AND.
OR	Enter logic function OR.
NOT	Enter logic function NOT.
(...)	Insert brackets.

**i** The program code uses the MAC-IDs of the WIN transmitters, not the individual WIN transmitter names.

4. Click on **Check** to check the switching rule created.
  - WERMA-WIN checks the switching rule.
  - If the switching rule includes errors, a window appears with relevant information on resolving the errors.
5. Click on **Next**.
  - The switching rule is saved.

## Examples of custom logic functions

### Example 1: AND rule

Tiers 1 and 2 of an WIN transmitter must be **ON**.

```
Slave("0024B1").Tier1.On AND Slave("0024B1").Tier2.On
```

### Example 2: OR rule

Tier 1 of a WIN transmitter must be **Blinking** or Tier 2 of the same WIN transmitter must be **OFF**.

```
Slave("0024B1").Tier1.Blink OR Slave("0024B1").Tier2.Off
```

### Example 3: NOR rule

Neither of the two WIN transmitter may display a connection error.

```
NOT (Slave("0024B1").Tier1.Error OR Slave("0024B2").Tier1.Error)
```

### Example 4: Logic function using variables

```
' declare variables
Dim a As Boolean
Dim b As Boolean
Dim x As Boolean

' read out Slave status and store in variables
a = Slave("0024A1").Tier1.On
b = Slave("0024A2").Tier1.On

' Program code which processes variables.
x = a OR b

' Note: if multiple program lines are entered,
' the result of the logic function must be returned as Boolean data type with
' 'Return'.
Return x
```

## 3.5.3 Enabling a rule

1. Select the switching rule in the rule overview.
2. Click on **Enable rule** in the toolbar.
3. Confirm the prompt with **Yes** to enable the rule.

## 3.5.4 Disabling a rule



The WIN transmitter control remains in the last transmitted status as soon as a switching rule has been disabled.

---

1. Select the switching rule in the rule overview.
2. Click on **Disable rule** in the toolbar.
3. Confirm the prompt with **Yes** to disable the switching rule.

## 3.5.5 Editing a rule

1. Select the switching rule in the rule overview.
2. Click on **Edit rule** in the toolbar.

→ The **Edit switching rule** window appears.

Please determine the settings for the switch function.

Name:

Enable switching rule

Output signals:

Logic function for permanent light:

Logic function for blinking light:

If both logic functions are true activate the following output signal:

Permanent light

Blinking

3. Enable or disable **Enable switching rule** to immediately enable or disable the switching rule.
4. Adapt the **output signals** by clicking on **Edit**, if necessary.

---

**i** Only one switching rule can be enabled on an output signal.


---

5. Adapt the **Logic function for permanent light** and the **Logic function for blinking light:** by clicking on **Edit**, if necessary.
6. Remove the **Logic function for permanent light** and the **Logic function for blinking light:** by expanding the **Edit** button and clicking on **Delete**, if necessary.
7. Select whether the output signal is to be switched as a **Permanent light** or **Blinking**, if both logic functions apply.
8. Click on **OK** to apply the settings.

### 3.5.6 Duplicating a rule

1. Select the switching rule in the rule overview.
2. Click on **Duplicate rule** in the toolbar.
3. Confirm the prompt with **Yes**.  
→ The **Duplicate switching rule** window appears.






4. Enter the name of the switching rule in the **Name** field.
5. Enable or disable **Enable switching rule** to immediately enable or disable the switching rule.
6. Adapt the **output signals** by clicking on **Edit**, if necessary.

 Only one switching rule can be enabled on an output signal.

7. Adapt the **Logic function for permanent light** and the **Logic function for blinking light:** by clicking on **Edit**, if necessary.
8. Remove the **Logic function for permanent light** and the **Logic function for blinking light:** by expanding the **Edit** button and clicking on **Delete**, if necessary.
9. Select whether the output signal is to be switched as a **Permanent light** or **Blinking**, if both logic functions apply.
10. Click on **OK** to apply the settings.


### 3.5.7 Deleting a rule






 The WIN transmitter control remains in the last transmitted status once a switching rule has been deleted.


1. Select the switching rule in the rule overview.
2. Click on **Delete rule** in the toolbar.
3. Confirm the prompt with **Yes** to delete the rule.

## 3.6 Routing

The **Routing** module shows an overview of the WERMA-WIN network. A tree structure shows the structure and the quality of the radio connections between the individual devices.




Display	Description
	WIN receiver
	WIN ethernet receiver
	WIN transmitter, WIN transmitter control, WIN transmitter performance
	Good radio connection between the devices.
	Weak radio connection between the devices.


Display	Description
	Poor radio connection between the devices.

To ensure the best possible radio connection, every WIN transmitter automatically looks for the best transmission path to the WIN receiver. Other WIN transmitter can act as repeaters and forward the radio signal to improve the radio connection or increase the range.

Direct connection:




Connection via another WIN transmitter as a repeater:



**i** A WIN transmitter can set up a connection to the WIN receiver via at most two more WIN transmitters.


**i** Unconnected but configured WIN transmitters are displayed in the lower part of the window, if there are any.



### 3.6.1 Displaying connection status

The connection status and the connection type of all WIN receivers saved in the WERMA-WIN database can be displayed in the **Connection status** window.

1. Click on **Connection status** in the toolbar.  
→ The **Connection status** window appears.



### 3.6.2 Optimising radio communication

Radio communication can be improved by implementing the following measures:

- Position the WERMA-WIN devices within sight of each other.
- Remove as many metal surfaces as possible between the WERMA-WIN devices.
- Position WIN receiver as ideally as possible.
- Poor radio connections can be improved by the use of a repeater (WIN transmitter).
- Connect any parts of the system outside of radio range via a further WIN receiver.

## 3.7 Settings


The functions of WERMA-WIN can be modified under Settings.



Settings can be protected by a password to prevent unauthorised access.


To call up Settings:

1. Click on **Settings** in the toolbar.  
→ The **Settings** window appears.



### 3.7.1 General

Various settings can be adapted in the **General** tab.



The following settings can be adapted:

- Program interface language
- Search for updates
- Minimise program window in the system tray
- View at program start

#### 3.7.1.1 Selecting the language of the program interface

1. Select the language in the **Language** selection list.
2. Click on **OK** to save the settings.  
→ WERMA-WIN is restarted and appears in the selected language after the restart.

### 3.7.1.2 View at program start

It is possible to set which module is to be automatically displayed in which view when the program starts.


The following views are possible:

Module	Main view	More views	Time interval	Full screen mode
Control station	✓	✓		✓
Productivity	✓	✓	✓	✓
Runtime	✓	✓	✓	
Job	✓			
Control	✓			
Routing	✓			

1. Select the desired module in the **Module** selection list.
2. Select the required view in the **View** list.
3. If the **Runtime** or **Productivity** module has been selected, select the required time interval in the **Time interval** selection list.
4. Enable **Open in fullscreen mode** if WERMA-WIN is to be started in full-screen mode.
5. Click on **OK** to save the settings.

### 3.7.1.3 Minimising program window in the system tray

The minimised WERMA-WIN program window can be displayed in the taskbar (Windows standard) or in the system tray.



To display the minimised WERMA-WIN program window in the system tray.

1. Enable **Display minimised window only in the System tray**.
2. Click on **OK** to save the settings.

### 3.7.1.4 Updates

WERMA-WIN can search for updates after every program startup.


1. Enable **Search for product updates at Startup**.
2. Click on **OK** to save the settings.



The computer must be connected to the internet and must be able to access [www.werma.com](http://www.werma.com) to search for updates.

## 3.7.2 Views

The views of the **Control station**, **Productivity** and **Runtime** modules can be created and adapted in the **Views** tab.




The following functions are possible:

- Add view
- Copy view
- Rename view
- Sort views
- Delete view

### 3.7.2.1 Adding a view

1. Click on **Add**.  
→ The **Create view** window appears.



2. In the **Name** field, enter the name of the view.


**i** If the name of the view contains a **&** then it must be entered as **&&** The name **Bear ing 1 & Bear ing 2** for example, must be entered as **Bear ing 1 && Bear ing 2**

3. Click on **OK** to add the view.

### 3.7.2.2 Copying a view

1. In the list of views, select the view to be copied.
2. Click on **Copy**.


→ The **Copy view** window appears.



3. In the **Name** field, adapt the name of the view.
4. Click on **OK** to copy the view.

### 3.7.2.3 Renaming a view

1. In the list of views, select the desired view.
2. Click on **Edit**.  
→ The **Edit view** window appears.



3. In the **Name** field, adapt the name of the view.

---

**i** If the name of the view contains a & then it must be entered as && The name Bearing 1 & Bearing 2 for example, must be entered as Bearing 1 && Bearing 2

---

4. Click on **OK** to save the setting.

### 3.7.2.4 Sorting views

You can adapt the order of the views in the toolbar.

1. In the list of views, select the desired view.
2. Click on **Move up** or **Move down** to move the view.

---

**i** Views arranged at the top of the list of view appear first in the toolbar.

---


### 3.7.2.5 Deleting a view

1. In the list of views, select the view to be deleted .
2. Click on **Delete**.
3. Confirm the prompt with **Yes**.



### 3.7.3 Status transmission

A status transmission can be enabled by e-mail for individual WIN transmitters in the **Control station** module. The necessary settings can be modified in the **Status transmission** tab. The transfer of the status transmission to an external program using WINtoApplication can also be configured.




The following settings are possible:

- Disable e-mail transmission
- Modify settings of integrated e-mail transmission function
- Configure own SMTP server for the transmission of e-mails
- Modify message text
- Configure WINtoApplication

#### 3.7.3.1 Disabling e-mail transmission

1. Click on **Edit**.  
→ The **E-Mail settings** window appears.



2. Select **Disable mail transmission**.

3. Click on **OK** to save the setting.

### 3.7.3.2 Integrated transmission function

The e-mail transmission function integrated in WERMA-WIN is restricted as follows:

- Max. 10 recipients per e-mail
- Max. 100 different recipients in seven days
- Max. 240 e-mails in 4 hours




If more than 240 e-mails are sent in 4 hours, then message delivery is interrupted for one hour. The messages that accumulate during the interruption are not subsequently sent.

Transmission using your own SMTP server is recommended if the transmission function is to be used beyond these limits.

---

1. Click on **Edit**.

→ The **E-Mail settings** window appears.



2. Select **Send an E-Mail via built-in transmitting feature (recommended)**.

3. Enter e-mail recipients in the **Recipient** field.

---

**i** Multiple recipients are separated by a semicolon (;).

---

**i** If no e-mail recipient is specified, the recipient must be specified when enabling status transmission for the respective WIN transmitter.

---

4. Adapt the **web proxy** by clicking on **Configure** if necessary.


**i** Clicking on **Send test E-Mail** sends a test e-mail to test the settings entered.

---

5. Click on **OK** to save the settings.

### Configuring the web proxy

If a web proxy is used in the network, the access data can be entered in the **Configuration of web proxy** window.



1. Enter access data into the respective fields.
- 




Your network administrator will provide the requisite data.

---

2. Click on **Check**.  
→ WERMA-WIN checks the data entered.
3. Click on **OK** to save the settings.

### 3.7.3.3 Custom SMTP server

1. Click on **Edit**.  
→ The **E-Mail settings** window appears.



**E-Mail settings** [Close] [OK]

Server settings | Message

Disable mail transmission

Send an E-Mail via built-in transmitting feature (recommended)

Send an E-Mail with your own SMTP server

**E-Mail address(es) of recipients and sender**


Recipient:   
You may enter multiple E-Mail addresses by delimiting with a semicolon (;)

Sender:

Web proxy:

Please refer to the information in the manual regarding this function.

2. Select **Send an E-Mail with your own SMTP server**.  
→ The fields to adapt your custom SMTP server appear.



**E-Mail settings** [Close] [OK]

Server settings | Message

Disable mail transmission

Send an E-Mail via built-in transmitting feature (recommended)

Send an E-Mail with your own SMTP server

**E-Mail address(es) of recipients and sender**

Recipient:   
You may enter multiple E-Mail addresses by delimiting with a semicolon (;)

Sender:   
(your E-Mail address)

**Your E-Mail server data**

Server name:   
(alternative Server IP-Address)

Port:  Standard port 25

**Access data (if required)**

User name:

Password:

The configuration for the E-Mail server and account information will be provided by your network administrator or internet service provider.

Please note: All E-Mails are sent by the Server Service.

3. Enter e-mail recipients in the **Recipient** field.

---

 Multiple recipients are separated by a semicolon (;).

---


4. Enter the sender address in the **Sender** field.

5. Enter the details of your SMTP server in the respective fields in the **Your E-Mail server data** and **Access data (if required)** areas.

---

 Your network administrator or internet provider can provide the requisite data.

---

 Clicking on **Send test e-mail** sends a test e-mail to test the settings entered.


---

6. Click on **OK** to save the settings.

### 3.7.3.4 Modifying message text

The subject and the text of the e-mail can be modified by inserting individual texts and different placeholders.

1. Call up the **Message** tab.



2. Enter the text and desired placeholders in the Subject and Message fields.

---

 Clicking on **Reset** resets the subject and the message text to the default values.

---

3. Click on **OK** to save the setting.

### Example of a message text:

The WIN transmitter %name% changed its status at %time%.

Tier 4 (%statename4%): %state4%

Tier 3 (%statename3%): %state3%

Tier 2 (%statename2%): %state2%

Tier 1 (%statename1%): %state1%

### Placeholders/Parameters

The following placeholders/parameters are available:


Placeholders/Parameters	Description
%slaveid%	ID of the WIN transmitter
%name%	Name of the WIN transmitter
%time%	Date and time of status transmission
%reason%	Reason for status transmission
%state1%	Status of tier 1
%state2%	Status of tier 2
%state3%	Status of tier 3
%state4%	Status of tier 4
%statename1%	Name of tier 1
%statename2%	Name of tier 2
%statename3%	Name of tier 3
%statename4%	Name of tier 4
%counter%	Counter status of the job
%order-id%	Job ID
%order-number%	Job number
%order-description%	Name of job
%order-total%	Total amount of job
%order-progression%	Progression of job



All placeholders/parameters begin and end with the character %

## 3.7.4 Sound

Status change messages can be indicated by playing an individual signal tone.



---

**i** WERMA-WIN offers a pre-selection of signalling sounds. An overview of the pre-selection is displayed by clicking on **?**.

---

1. Select which sound is to be played when a status change message appears.
  2. Select **Selected sound** and click on **Browse** **...** to play an individual sound.
  3. Select the file in the appropriate format and click on **Open**.
- 

**i** Files in the popular audio formats ( .mp3 .wavetc.) can be used.

---

**i** The selected sound can be tested by clicking on **Play** and **Stop**.

---

4. Click on **OK** to save the settings.
- 

### 3.7.5 Reports

Individual headers and footers can be saved for reports.





1. In the **Company name** field, enter the text for the footer.
2. Click on **Select** to paste an individual company logo into the header.


**i** Graphics in the popular graphic formats ( . jpg . png etc.) can be used.  
The graphic file may not exceed 1 MB. The height and width are each restricted to 2,000 pixels.

**i** Clicking on **Reset** resets all settings to the default settings (WERMA logo and WERMA company name).

3. Click on **OK** to save the settings.

### 3.7.6 WIN devices

WERMA-WIN devices which are no longer in the WERMA-WIN network can be deleted. All the data recorded by these devices will be deleted from the WERMA-WIN database.



---

**i** WIN receivers can only be removed if the power supply to the WIN receiver is disconnected.

WIN transmitters can only be removed if the power supply to the WIN transmitter is disconnected.

---

1. Select the WERMA-WIN device to be deleted in the list of WERMA-WIN devices.

---

**i** Several WERMA-WIN devices can be selected by pressing CTRL.


---

2. Click on **Delete**.

3. Confirm the prompt with **Yes**.

### 3.7.7 Database

In the **Database** tab, various settings of the WERMA-WIN database can be adapted and the device data backed up or imported.



The following functions are available:

- Adapt connection settings in the Database assistant
- Export devices
- Import devices
- Clean old data


#### 3.7.7.1 Database assistant

The database assistant can be used to edit the connection settings for the database.

1. Click on **Database assistant**.

2. Confirm the prompt with **Yes**.

→ WERMA-WIN is ended and the assistant appears to set up the database.



The assistant to set up the database offers the following functions:

Function	Description
<b>Use local database server</b>	Reset existing connection settings.
<b>Connect database</b>	Connect to an existing WERMA-WIN database and thus enable multi-user access to the database.
<b>IT expert installation</b>	Enable Expert installation and adapt the saved connection settings.
<b>Save Link File to...</b>	Save the link file to connect other workplaces to the WERMA-WIN database.

### 3.7.7.2 Exporting devices

All device configurations and switching rules can be exported to apply all configured WERMA-WIN devices from an existing installation to a new installation or to another workplace.

1. Click on **Export devices**.
2. Select the filename and storage location for the export file.
3. Click on **Save**.

### 3.7.7.3 Importing devices

---

 During import, all existing device configurations and switching rules are overwritten.

---


1. Click on **Import devices**.
2. Select the saved export file.
3. Click on **Open**.

4. Confirm the prompt with **Yes**.

### 3.7.7.4 Cleaning data

Old data can be cleaned and deleted from the WERMA-WIN database. You can specify from what point in time the data is to be kept.


1. Click on **Clean data....**  
→ The **Data Removal** window appears.



2. Select the time interval from when the data is to be kept.
3. Click on **OK**.
4. Confirm the prompt with **Yes**.


### 3.7.8 Time period

Time periods (e.g. shift times) can be defined for the selection in the **Productivity** module.



#### 3.7.8.1 Adding time periods


1. Click on **Add**.  
→ The **Enter time period** window appears.



2. Enter the name of the time period entry in the **Name** field.
3. Enter the start of the time period in the **Start time** field.
4. Enter the end of the time period in the **End time** field.
5. Enable weekdays to which the time period applies.
6. Click on **OK** to save the settings.

### 3.7.8.2 Adapting time periods

1. Select the required time period entry in the list of time periods.
2. Click on **Edit**.  
→ The **Edit time period** window appears.



3. Adapt the time period entry as required.
4. Click on **OK** to save the settings.

### 3.7.8.3 Sorting time periods

1. Select the required time period entry in the list of time period entries.
2. Click on **Move up** or **Move down** to move the time period entry.



Time period entries arranged at the top of the list of view appear first in the selection list in the **Productivity** module.


### 3.7.8.4 Deleting a time period

1. Select the time period entry to be deleted in the list of time periods.


2. Click on **Delete**.
3. Confirm the prompt with **Yes**.

### 3.7.9 Fault conditions

Company-specific fault conditions (e.g. lack of material) can be defined for the creation of notes in the **Runtime** module. When a fault occurs, it is possible to select from the predefined fault conditions.



- i** **Use touch interface to assign fault conditions** must be enabled to show the display version for the **touch interface** instead of the **Edit note** window in the event of a fault. A defined fault condition can only be selected in this case.



#### 3.7.9.1 Adding fault conditions

1. Click on **Add**.

→ The **Enter fault condition** window appears.

2. Enter the fault condition in the **Description** field.
3. Select a **Colour** for the fault condition.
4. Enter additional information in the **Additional note** field if necessary.
5. Click on **OK** to save the settings.

### 3.7.9.2 Modifying fault conditions

1. Select the required fault condition in the list of fault conditions.
2. Click on **Edit**.  
→ The **Edit fault condition** window appears.

3. Modify the fault condition as required.
4. Click on **OK** to save the settings.

### 3.7.9.3 Collating fault conditions

1. Select the required fault condition in the list of fault conditions.
2. Click on **Move up** or **Move down** to move the fault conditions.




Fault conditions arranged at the top of the list of fault conditions appear first in the selection list in the **Runtime** module.

### 3.7.9.4 Deleting fault conditions

1. In the list of fault conditions, select the fault condition to be deleted.
2. Click on **Delete**.
3. Confirm the prompt with **Yes**.

### 3.7.10 Functions

The modules and functions that are to be available at a workplace can be enabled or disabled in the **Functions** tab. **Settings** can also be protected by a password to prevent unauthorised access.



#### 3.7.10.1 Enabling and disabling functions

To enable a module or a function:

1. Enable the checkbox in the **Enabled** column in the list of modules and functions.

Function	Enabled
Show 'Control station' module	<input checked="" type="checkbox"/>
-> Manual switching of WIN transmitter control	<input checked="" type="checkbox"/>
Show 'Productivity' module	<input checked="" type="checkbox"/>

2. Click on **OK** to save the settings.

To disable a module or a function:

1. Disable the checkbox in the **Enabled** column in the list of modules and functions.


Function	Enabled
Show 'Control station' module	<input checked="" type="checkbox"/>
-> Manual switching of WIN transmitter control	<input type="checkbox"/>
Show 'Productivity' module	<input checked="" type="checkbox"/>

2. Click on **OK** to save the settings.



### 3.7.10.2 Protecting settings with a password

1. Click on **Define**.  
→ The **Enter password** window appears.



Enter the existing password in the **Old password** field.

---

-  If no password has been assigned, leave the **Old password** field empty.
- 

2. Enter a new password in the **New password** field and in the **Repetition** field.
3. Click on **OK** to protect the settings with the password entered.

### 3.7.10.3 Deleting a password

1. Click on **Delete**.
2. Confirm the prompt with **Yes**.

## 3.8 Reports and exports


In the print preview, the export can be adapted or exported before printing.

---

-  Company name and logo can be modified under Settings.
-









Print preview 'Runtime - statuses'
















Page 1 of 9 | 100%

**Runtime - statuses** 

Time period from 06/08/2017 21:17:53 to 17/08/2017 21:47:53  
View 1

Machine	Start	End	Duration (Sec.)	Tier 1	Tier 2	Tier 3	Tier 4
Unit 1	06/08/2017 21:17:53	07/08/2017 16:43:24	69,932	No data received			
Unit 2	06/08/2017 21:17:53	07/08/2017 16:43:22	69,930	No data received			
Unit 3	06/08/2017 21:17:53	07/08/2017 16:43:30	69,937	No data received			
Unit 2	07/08/2017 16:43:22	07/08/2017 16:46:25	183				
Unit 1	07/08/2017 16:43:24	07/08/2017 16:46:25	180		Warning		
Unit 3	07/08/2017 16:43:30	07/08/2017 16:46:25	175				
Unit 1	07/08/2017 16:46:25	07/08/2017 16:46:29	4	No data received			
Unit 2	07/08/2017 16:46:25	07/08/2017 16:46:28	3	No data received			
Unit 3	07/08/2017 16:46:25	07/08/2017 16:46:36	11	No data received			
Unit 2	07/08/2017 16:46:28	07/08/2017 17:22:46	2,178				
Unit 1	07/08/2017 16:46:29	07/08/2017 17:22:46	2,177		Warning		
Unit 3	07/08/2017 16:46:36	07/08/2017 17:22:46	2,170				
Unit 3	07/08/2017 17:22:46	08/08/2017 09:01:58	56,352	No data received			
Unit 1	07/08/2017 17:22:46	08/08/2017 09:01:56	56,350	No data received			
Unit 2	07/08/2017 17:22:46	08/08/2017 09:02:07	56,361	No data received			
Unit 1	08/08/2017 09:01:56	08/08/2017 09:27:09	1,513		Warning		
Unit 2	08/08/2017 09:01:58	08/08/2017 09:27:09	1,511				


Function	Description
<b>Print</b>	
 Print	Print report. The print settings can be adapted.
 Quick Print	Print report on the default printer without adapting print settings.
<b>Page setup</b>	
 Scale	Enlarge or reduce report as a percentage or to page width.
 Margins	Adapt page margins.
 Orientation	Adapt page orientation (portrait or landscape).
 Size	Adapt paper size of the report. <b>Note:</b> All reports are optimised for <b>A4</b> .
<b>Navigation</b>	
 Find	Search for text in the report.
 Thumbnails	Show and hide miniature view of the report.

Function		Description
	 First Page	Move to first page.
	 Previous Page	Move to previous page.
	 Next Page	Move to next page.
	 Last Page	Move to last page.
<b>Zoom</b>		
		Enable default cursor.
		Enable the hand cursor to drag the print preview of the report with the cursor.
		Select the zoom cursor to zoom out of or zoom into the print preview.
	 Many Pages ▼	Display multiple pages in the print preview.
	 Zoom Out	Zoom out of print preview.
	 Zoom ▼	Set zoom to a fixed value.
	 Zoom In	Zoom into print preview.
<b>Background</b>		
	 Watermark	Insert a watermark into a report. Delete a watermark in a report.
<b>Export</b>		
	 Export To ▼	Export report. The export file format can be selected.
	 E-Mail As ▼	Send report as e-mail attachment. The e-mail attachment file format can be selected.
<b>Close</b>		
	 Close	Close print preview.

### 3.8.1 Pasting a watermark

An individual text, an image or a combination of text and image can be used as a watermark.

1. Click on **Watermark** in the toolbar.  
→ The **Watermark** window appears.



2. Enter the text in the **Text Watermark** tab and format it as required.
3. Upload a picture in the **Picture Watermark** tab and format it as required.
4. Select the position of the watermark in the **Position** area.
5. In the **Page range** area, select the pages on which the watermark is to be inserted.

---


**i** Multiple single pages are separated by a semicolon (;) (e.g. 3;5;7).  
Page ranges are specified by a hyphen (e.g. 3-5)

---

6. Click on **OK** to paste the watermark.

### 3.8.2 Deleting the watermark

1. Click on **Watermark** in the toolbar.  
→ The **Watermark** window appears.



2. Click on **Clear all** to delete the watermark.
3. Click on **OK** to apply the settings.

### 3.8.3 File formats

The following file formats are available for export and as e-mail attachment:

File format	Export	E-mail attachment
PDF file	✓	✓
HTML file	✓	
Excel file	✓	✓
Excel 2007 document	✓	✓
CSV file	✓	✓
Picture file	✓	✓

# 4 Automation interfaces

WERMA-WIN has 3 automation interfaces.

The XML interface makes it possible to make data available to third-party programs or to import data from a third-party program into WERMA-WIN.

The WINtoApplication makes it possible for the statuses of a signal tower to be transmitted to an external application.

The WERMA-WIN CLI Tool makes it possible for external applications to switch a WIN transmitter control controlled by the program.

## 4.1 XML interface

The XML interface consists of an export and an import module. It is possible to enable or disable both modules separately.

Information about imports and exports currently in progress as well as the status of the XML interface is displayed in the **Interface status** area.



The XML interface is set up on the (server) PC on which the WERMA-WIN server service is executed.

For optimum availability of the XML interface, WERMA recommends:


- Saving the export file or import file on a local data medium (not on a network drive).
  - Setting up an exception in the virus scanner for the export file and the import directory so that the export file is not completely scanned on every export.
  - Setting up write authorisation for the WERMA-WIN server service for the directory. The WERMA-WIN server service is executed under Windows user account `Network Service`
- WERMA-WIN does not archive the exported data. For error analysis purposes WERMA recommends archiving the XML export files in the external system.
- 

### 4.1.1 Export

During the export process changes to statuses, counter values and jobs are exported incrementally to an XML file. This sees a record written to the XML file for each change.


#### 4.1.1.1 Configuring the XML interface

1. **WERMA-WIN** Open the **Administration Console** on the server PC.



2. In the **Interfaces** area of the toolbar, click **XML interface**.  
→ The **XML interface** window appears.


3. Select the **Export** tab.



Export Import

**Configuration**


Filename  ...  
Specify the file to which to export the XML data.

 Note: Recommended file on local disk.


System ID  (optional)  
If you use multiple WERMA-WIN systems, you can later uniquely identify the various systems via the system ID in the processing of data.

Enable  Disable

**Export current conditions**  
When commissioning the XML export interface, you have the option of manually exporting the current state of all signals, counters and jobs. In regular operation of the interface, the changes are exported incrementally.


4. In the **Configuration** area click **Search**,  then select the storage location and also enter the name XML file.

5. If required, enter the system ID of the WERMA-WIN system in the field **System ID**.

 Entering the system ID makes it possible to unambiguously identify different WERMA-WIN systems while processing the data.

### 4.1.1.2 Enabling the XML interface

1. Click **Enable**.


 If the XML interface is enabled for the first time, WERMA recommends performing a one-off manual export of the data.

### 4.1.1.3 Disabling the XML interface

1. Click **Disable**.

 WERMA-WIN does not archive the exported data. For error analysis purposes WERMA recommends archiving the XML export files in the external system.

### 4.1.1.4 Element and attribute description

 WERMA recommends that you ignore unknown elements and attributes when processing the XML export file.

#### General attributes

Attributes	Data type	Description	Values
rowid	[bigint]	This is increased consecutively with each exported record; it is unique for each record.  To detect duplicates in the event an error occurs, the external system should import each rowid only once.	



Attributes	Data type	Description	Values
		<code>rowid</code> can be used as the primary key for the data records	
<code>timestamp</code>	[datetime]	Time stamp in ISO 8601 format	
<code>refid</code>	Different, see data type at respective element	When database objects are exported directly the <code>refid</code> specifies the internal ID in the WERMA-WIN database.	

### <data>

<data> contains all export data.

Attributes	Data type	Description	Values
<code>version</code>	[nvarchar] (20)	Version of the XML schema definition	
<code>systemid</code>	[nvarchar] (25)	System ID, which was configured in the WERMA-WIN Administration Console.	
<code>appname</code>	[nvarchar] (max)	Name of the exporting application	
<code>appversion</code>	[nvarchar] (20)	Version number of the exporting application	

### <slaveref>

Reference to a WIN transmitter. It is possible to use the `refid` or the `macid` to unequivocally identify a WIN transmitter.

Attributes	Data type	Description	Values
<code>refid</code>	[smallint]	When database objects are exported directly the <code>refid</code> specifies the internal ID in the WERMA-WIN database.	
<code>macid</code>	[nvarchar]	Assignment to a	

Attributes	Data type	Description	Values
	(6)	WIN transmitter via the wireless MAC address  Notation: Lower case letters without hyphens	

### <slavestate>

A new status was received for a WIN transmitter.

Attributes	Data type	Description	Values
tier1	[tinyint]	Status tier 1	0= Off= Off 1= On= On 2= Blinking= Blinking 3= [Error]= Connection error
tier2	[tinyint]	Status tier 2	
tier3	[tinyint]	Status tier 3	
tier4	[tinyint]	Status tier 4	

### <counterinfo>

A new counter value was received for a WIN transmitter performance, the counter manually reset, or a job started or completed.

Attributes	Data type	Description	Values
tier	[tinyint]	Configured counter tier	1= Tier 1 2= Tier 2 3= Tier 3 4= Tier 4
value	[int]	Counter status, display in control station	Value >= 0
orderrefid	[int]	Reference to an internal job ID	

### <order>

<order>contains data belonging to a job.

Attributes	Data type	Description	Values
orderid	[int]	Job ID generated by WERMA-WIN  The job ID is displayed in the job module.	

Attributes	Data type	Description	Values
ref id	[ int ]	When database objects are exported directly the ref id specifies the internal ID in the WERMA-WIN database.	
number	[ nvarchar ] ( 60 )	Selected job number	
description	[ nvarchar ] ( 250 )	Selected job name	
state	[ tinyint ]	Current job status	1= Waiting= Only created 2= Processing= In progress 3= Completed= Completed 4= WaitForStart(see waitmode)
waitmode	[ tinyint ]	If state= 4 the waitmode indicates when the job will be started.	0= Counter= Start with next piece 1= Signal= Start, as soon as tier job input is enabled
targetamount	[ decimal ] ( 18.3 )	Plan quantity	
piecesper signal	[ decimal ] ( 18.3 )	Factor (number of pieces per cycle)	
timeper signal	[ decimal ] ( 18.1 )	Plan cycle time in seconds	
targetsetuptime	[ int ]	Plan set up time in minutes	
amountcorrection	[ decimal ] ( 18.3 )	Actual correction (piece)	
realbegintime	[ datetime ]	Time when the job was started (or empty character string)	
realendtime	[ datetime ]	Time when the job was completed (or empty character string)	
realsetuptime	[ int ]	Actual set up time	
realamount	[ decimal ] ( 18.3 )	Actual quantity	

Attributes	Data type	Description	Values
		Is set when the job was completed. It is possible to determine the number of pieces until the job is completed using <code>&lt;counter info&gt;</code> in the XML interface.	
<code>autoStoptimeenabled</code>	[ bit ]	The job is completed automatically taking into consideration: <ul style="list-style-type: none"> <li>- <code>autoStopTime</code></li> <li>- <code>autoStoptimedays</code></li> </ul>	0= Job will not be completed 1= Job will be completed
<code>autoStoptime</code>	[ datet ime ]	Time at which the job is to be completed automatically	
<code>autoStoptimedays</code>	[ int ]	Specifies after how many days the job is to be completed.	
<code>autoStoptargetamount</code>	[ bit ]	Job is completed automatically as soon as the plan quantity is reached.	0= Job will not be completed 1= Job will be completed

### <deleteinfo>

<deleteinfo> flags a record as deleted.

Attributes	Data type	Description	Values
<code>type</code>		Record type	<code>order</code>
<code>ref id</code>	[ int ]	Internal record ID	

### <sync>

<sync> highlights the start and the end of the XML export.

Attributes	Description	Values
<code>state</code>	Specifies if the sync tag stands for the start ( <code>started</code> ) or the end ( <code>completed</code> ) of the synchronisation.	
<code>sync id</code>	Unambiguous GUID to assign the sync end to the start.	

## 4.1.1.5 Example XML export file

### Example of an XML export file

```
<?xml version="1.0" encoding="UTF-8"?>
<data appversion="4.5.0.1816" appname="WERMA-WIN-3.0" systemid="Wermac235" version="1.0">
  <slavestate tier4="0" tier3="0" tier2="0" tier1="0" timestamp="2018-02-14T15:03:35.5919399+01:00" rowid="551807">
    <slaveref macid="006C36" refid="1"/>
  </slavestate>
  <slavestate tier4="0" tier3="0" tier2="0" tier1="0" timestamp="2018-02-14T15:03:35.8260887+01:00" rowid="551808">
    <slaveref macid="006C79" refid="3"/>
  </slavestate>
  <slavestate tier4="0" tier3="0" tier2="0" tier1="1" timestamp="2018-02-14T15:03:41.7800895+01:00" rowid="551809">
    <slaveref macid="006C36" refid="1"/>
  </slavestate>
  <slavestate tier4="0" tier3="0" tier2="0" tier1="1" timestamp="2018-02-14T15:03:41.9988901+01:00" rowid="551810">
    <slaveref macid="006C79" refid="3"/>
  </slavestate>
  <slavestate tier4="0" tier3="0" tier2="0" tier1="2" timestamp="2018-02-14T15:03:42.0142973+01:00" rowid="551811">
    <slaveref macid="006C36" refid="1"/>
  </slavestate>
  <slavestate tier4="0" tier3="0" tier2="0" tier1="0" timestamp="2018-02-14T15:03:42.2332875+01:00" rowid="551812">
    <slaveref macid="006C79" refid="3"/>
  </slavestate>
  <slavestate tier4="0" tier3="0" tier2="0" tier1="0" timestamp="2018-02-14T15:03:58.5163838+01:00" rowid="551813">
    <slaveref macid="006C36" refid="1"/>
  </slavestate>
  <counterinfo timestamp="2018-02-14T15:12:13.9583469+01:00" rowid="551814" orderrefid="" value="0" tier="1">
    <slaveref macid="006BBD" refid="6"/>
  </counterinfo>
  <order timestamp="2018-02-14T15:13:08.2450790+01:00" rowid="551815" refid="180848" autostoptargetamount="1" autostoptimedays="1" autostoptime="00:00:00" autostoptimeenabled="0" realamount="0"
  realsetuptime="0" realendtime="" realbegintime="" amountcorrection="0" targetsetuptime="0" timepersignal="0.8" piecespersignal="10" targetamount="1000" waitmode="0" state="1" description="A00014" number="A00014"
  orderid="87677">
    <slaveref macid="006BBD" refid="6"/>
  </order>
  <order timestamp="2018-02-14T15:17:35.0651364+01:00" rowid="551816" refid="180848" autostoptargetamount="1" autostoptimedays="1" autostoptime="00:00:00" autostoptimeenabled="0" realamount="0"
  realsetuptime="0" realendtime="" realbegintime="2018-02-14T15:17:35.0494684+01:00" amountcorrection="0" targetsetuptime="0" timepersignal="0.8" piecespersignal="10" targetamount="1000" waitmode="0" state="2"
  description="A00014" number="A00014" orderid="87677">
    <slaveref macid="006BBD" refid="6"/>
  </order>
  <counterinfo timestamp="2018-02-14T15:17:35.0651364+01:00" rowid="551817" orderrefid="180848" value="0" tier="1">
    <slaveref macid="006BBD" refid="6"/>
  </counterinfo>
  <counterinfo timestamp="2018-02-14T15:17:35.0961291+01:00" rowid="551818" orderrefid="180848" value="0" tier="1">
    <slaveref macid="006BBD" refid="6"/>
  </counterinfo>
  <order timestamp="2018-02-14T15:30:47.7027443+01:00" rowid="551819" refid="180848" autostoptargetamount="1" autostoptimedays="1" autostoptime="00:00:00" autostoptimeenabled="0" realamount="0"
  realsetuptime="0" realendtime="" realbegintime="2018-02-14T15:30:47.7027443+01:00" amountcorrection="0" targetsetuptime="0" timepersignal="0.8" piecespersignal="10" targetamount="1000" waitmode="0" state="3" description="A00014" number="A00014" orderid="87677">
    <slaveref macid="006BBD" refid="6"/>
  </order>
  <counterinfo timestamp="2018-02-14T15:30:47.7495606+01:00" rowid="551820" orderrefid="" value="0" tier="1">
    <slaveref macid="006BBD" refid="6"/>
  </counterinfo>
  <deleteinfo timestamp="2018-02-14T15:30:50.1827293+01:00" rowid="551821" refid="180848" type="order"/>
</data>
```

## 4.1.1.6 Accessing the XML export


WERMA-WIN regularly opens the XML export file for write access purposes only and to check if the XML export file can be overwritten. Consequently, the XML export file must be renamed before the XML export file can be processed by an external system.

If the XML export file was renamed, WERMA-WIN creates a new file when the next export is run.



If WERMA-WIN has opened the XML export file, it cannot be renamed. In that case the external system must make several attempts to rename the XML export file.

Access can be granted to the XML export file according to the following schema:




---

**i** To prevent a new XML export file being created after it has been renamed, although no data needs to be processed, WERMA recommends only renaming and processing the XML export file as soon as its size exceeds 120 bytes. An empty XML export file without exported data is approx 120 bytes in size (depending on the stored system ID).

---

**i** WERMA-WIN exports new data within a few milliseconds. If the external system is to process the data very quickly, WERMA recommends using the Windows API to monitor the file system or rather the XML export file (for example with `.NET FileSystemWatcher`). In this case, WERMA recommends not checking the size of the file and to process the XML export file immediately after it is created.

---

#### 4.1.1.7 Exporting data manually

The manual export serves as the initial synchronisation after the XML interface is enabled for the first time. This exports all tier statuses, counter statuses and jobs. It is then subsequently possible to use the automated export interface.

1. Configuring the XML interface.
2. Click **Export** in the **Export current statuses** area.

---

**i** Depending on the number of jobs, manual export can take some time.

---

## 4.1.2 Import

During the import process WERMA-WIN reads in data from an XML file. The XML file can contain several data records. The data records to be imported can be different data record types, for example, `Set up job` `Start job` Each data record is processed individually.

An import report is created for each imported file in the form of an XML file and saved in a dedicated directory. The file name is suffixed with `-result`

### 4.1.2.1 Configuring the XML interface


---

**i** The file names of the XML files to be imported in the import directory must observe a specified schema.

An example shows the structure of the XML import file.

---

1. Open the **WERMA-WIN Administration Console** on the server PC.



2. In the **Interfaces** area of the toolbar, click **XML interface**.  
→ The **XML interface** window appears.
3. Select the **Import** tab.

Export Import

**Configuration**

Import directory  ...  
Specify the directory from which to read the XML files.

Results directory  ...  
A results file for each processed XML file is placed in this directory. The external system can process this as confirmation.

Archive directory  ...  
This directory contains the processed XML files

Number of days after which files will be from the archive  ↕

Enable  Disable

Note: Recommended directories to local disk.



4. In the **Configuration** area click **Search**  and select **Import directory**.
5. Select **Results directory**, in which a results file of every imported XML file is saved.

**i** The Results file can be processed by the external system as feedback.

6. Select **Archive directory**, into which the processed XML files are moved.
7. In the **Number of days after which archive files are deleted** field, specify how long archived files should be kept.

#### 4.1.2.2 Enabling the XML interface

1. Click **Enable**.

#### 4.1.2.3 Disabling the XML interface

1. Click **Disable**.

**i** WERMA-WIN does not archive the exported data. For error analysis purposes WERMA recommends archiving the XML export files in the external system.

#### 4.1.2.4 Element and attribute description

##### General attributes

Attributes	Data type	Description	Values
<code>rowid</code>	[ nvarchar ] ( 60 )	The <code>rowids</code> used for the record in the results file.  The external system is able to assign the <code>rowid</code> as required (max. 60 characters).  The <code>rowid</code> for each respective import file must be unambiguous.	
<code>timestamp</code>	[ datetime ]	Time stamp in ISO 8601 format  Date entries are evaluated as local time/time zone.	

Attributes	Data type	Description	Values
		Example: 31.12.2017 19:00:00 = 2017- 12-31T19:00:00	

### <data>

<data>contains all export data.

Attributes	Data type	Description	Values
version	[ nvarchar ] ( 20 )	Version of the XML schema definition	
appname	[ nvarchar ] ( max )	Name of the exporting application	
appversion	[ nvarchar ] ( 20 )	Version number of the exporting application	
cancelonerror	[ bit ]	Specifies if processing of the import file is to be continued if an import error occurs.	false= Continue processing with the next record true= Cancel processing the file

### <slaveref>

Reference to a WIN transmitter. It is possible to use the `refid` or the `macid` to unequivocally identify a WIN transmitter.

Attributes	Data type	Description	Values
refid	[ smallint ]	Assignment to a WIN transmitter via the database ID	
macid	[ nvarchar ] ( 6 )	Assignment to a WIN transmitter via the wireless MAC address  Notation: Lower case letters without hyphens	

### <orderref>

Assignment to a job. Can be selected using `orderid` or `refid`

Attributes	Data type	Description	Values
order id	[ int ]	The job ID shown in the user interface  The order ids generated continuously. If the job with the highest order id was deleted, the order id for the next job is used again.	
refid	[ int ]	Assignment to a job via the database ID	

### Setting up a job

Attributes	Data type	Description	Values
number	[ nvarchar ] ( 60 )	Job number	String with 60 characters, no line breaks
description	[ nvarchar ] ( 250 )	Job name	String with 250 characters, no line breaks
targetamount	[ decimal ] ( 18.3 )	Plan quantity	Integer
piecespersignal	[ decimal ] ( 18.3 )	Factor (number of pieces per cycle)	Integer
timepersignal	[ decimal ] ( 18.1 )	Plan cycle time in seconds	Decimal number max. one place after the decimal point
targetsetuptime	[ int ]	Plan set up time in minutes	Integer
autostoptargetamount	[ bit ]	Complete job automatically when the plan quantity is reached.	true = Complete job false = Do not complete job
autostoptimeenabled	[ bit ]	Complete job automatically when the autostop time is reached.	true = Complete job false = Do not complete job
autostoptime	[ datetime ]	Time at which the job is completed auto-	Date + time: 2017-12-31T19:00:00

Attributes	Data type	Description	Values
		<p>atically.</p> <p><code>autostoptime</code> evaluates the time only.</p>	
<code>autostoptimedays</code>	[ int ]	If the job is not to be completed on the start day, it is possible to specify a number of days after which the job will be completed automatically.	

---

**i** Do not use the attributes `refid` and `orderid` when setting up a new job.

---

**i** A point (.) is used as a decimal separator for decimal numbers.  
Thousands separators are not supported.  
Decimal places of quantities are ignored.

---

### Editing a job

Attributes	Data type	Description	Values
<code>amountcorrection</code>	[ int ]	<p>Actual correction</p> <p>Is added to the quantity determined per clock signal.</p> <p>If the actual correction is negative, it is subtracted from the determined quantity.</p>	
<code>realsetuptime</code>	[ int ]	Actual set up time in minutes	

---

**i** If an attribute is not specified, the value stored to date remains valid.

---

- i** When using the attributes `ref id` and `order id`
- Specify just one of the two attributes when editing a job. If there is an option in the external system to save the `ref id` generated when creating the job, the attribute `ref id` should always be specified for subsequent processing operations. In that case, the attribute `order id` need not be transferred.
  - If both attributes are specified, both IDs must reference the same job.

### Deleting the assignment of a WIN transmitter

Attributes	Description	Values
<code>slaveref refid</code>	Delete the assignment of a WIN transmitter to a job.	empty
<code>slaveref macid</code>	Delete the assignment of a WIN transmitter to a job.	empty

### Starting a job

Attributes	Description	Values
<code>action rowid="..." type="order-start"</code>	Start job.	
<code>action orderref refid="..." type="order-start"</code>	Start job.	
<code>action orderref oderid="..." type="order-start"</code>	Start job.	

### Changing job to active waiting

Attributes	Description	Values
<code>action rowid="..." type="order-wait-for-start" waitmode="..."</code>	Please wait for counter input or job input to start the job.	
<code>action orderref refid="..." type="order-wait-for-start" waitmode="..."</code>	Please wait for counter input or job input to start the job.	
<code>action orderref oderid="..." type="order-wait-for-start" waitmode="..."</code>	Please wait for counter input or job input to start the job.	
<code>waitmode</code>	Specification, if a counter input or job input triggers the change.	<code>signal=</code> Job input <code>counter=</code> Counter input

## Completing a job

Attributes	Description	Values
action rowid="..." type="order-stop"	Complete job.	
action orderref refid ="..." type-e="order-stop"	Complete job.	
action orderref oderid ="..." type-e="order-stop"	Complete job.	

## Deleting a job

Attributes	Description	Values
action rowid="..." type="order-delete"	Delete job.	
action orderref refid ="..." type-e="order-delete"	Delete job.	
action orderref oderid ="..." type-e="order-delete"	Delete job.	


### 4.1.2.5 Example of an XML import file

```
<?xml version="1.0" encoding="utf-8"?>
<data appname="test" appversion="1.0" cancelonerror="false" xmlns="http://www.werma-win.com/xml/1.0/import/data">
  <order rowid="1" numbez="AU-4711" description="alloy part 447-256" targetamount="1000" piecespersignal="1" timepersignal="2.5" />
</data>
```

 An example for an XML import file is available in the installation directory of WERMA-WIN in the subdirectory Docs

### 4.1.2.6 File name

The file name can be assigned as desired; however, it must end with a time stamp corresponding to the format -YYYYMMDDhhmss and the file extension .xml



## Examples:

```
order-20180301150000.xml
config-20180301150104.xml
start-order-20180301153041.xml
```

### 4.1.2.7 Results file

The results file is created during the import operation and saved to the results directory with the suffix `-result`. If the file already exists, the name is suffixed with `-0002` `-0003` and so forth.

#### Example of a results file

```
<?xml version="1.0" encoding="utf-8"?>
<results appname="..." appversion="..." cancelonerror="false" xmlns="http://www.werma-win.com/xml/1.0/import/results">
  <!-- XML format errors etc. -->
  <result timestamp="2018-01-17T11:08:31.2922173+01:00" type="file" success="false">
    <exception type="..." message="..." />
  </result>

  <result rowid="..." timestamp="2018-01-17T11:08:31.2922173+01:00" type="order" success="false">
    <!-- If available, all ID attributes are transferred in the results file -->
    <orderref refid="4711" orderid="2" />
    <exception type="..." message="..." />
  </result>

  <result rowid="..." timestamp="2018-01-17T11:08:31.2922173+01:00" type="order" success="true">
    <orderref refid="4711" orderid="2" />
  </result>


  <!-- Process (for example, Start job) was successfully executed -->
  <result rowid="..." timestamp="2018-01-17T11:08:31.2922173+01:00" type="action" success="true" />

  <!-- Process (for example, Start job) was not successfully executed -->
  <result rowid="..." timestamp="2018-01-17T11:08:31.2922173+01:00" type="action" success="false">
    <exception type="..." message="..." />
  </result>
</results>
```

### 4.1.3 Interface status

The **Interface status** area displays information about the current status of the XML interface as well as imports and exports currently in progress.

#### Interface status



Errors are also logged in the Windows Event Viewer and in the WERMA-WIN error log.

## 4.2 WINtoApplication

The WINtoApplication allows you to transmit the statuses of a signal tower to an external application and specifically further process them in this application. This application can be set up individually for each user.

---


**i** The application data is stored, user-related, locally and not in the WERMA-WIN database. The settings of the WINtoApplication can be exported and imported for use on another PC or with another user.

---

**i** The WINtoApplication only operates with an active user login. A user must be continuously logged in.

---

1. If the **Settings** window is not yet open, click on **Settings** in the toolbar.
2. Click on **Start WinToApplication** in the **Status transmission** tab.  
→ The **WINtoApplication task overview** window appears.



The **WINtoApplication task overview** shows an overview and the status of all available tasks.


Status	Description
✓	The task has been successfully performed.
✗	There was an error the last time the task was performed. The History shows error details.
⚙️	The task is running.

---

**i** Clicking on **Refresh** updates the task overview.


---



- 
-  The symbol in the system tray can be used to enable and disable tasks and end WINtoApplication.
- 


## 4.2.1 Adding a task

1. Click on **Add**.  
→ The **WINtoApplication task configuration** window appears.



The screenshot shows the 'WINtoApplication task configuration' window. The title bar reads 'WINtoApplication task configuration'. The window is divided into sections. At the top right, there is a diagram with three gears and arrows pointing to file extensions: \*.exe, \*.bat, and \*.cmd. Below this, the text '1/3 General settings' is displayed. The main area contains the following text: 'You can create new tasks or edit existing tasks with this assistant.' followed by 'Please specify the settings for the application'. There are three input fields: 'Description' (a single-line text box), 'Enabled' (a checkbox), and 'Comment' (a multi-line text area). At the bottom left, there are 'Close' and 'Cancel' buttons. At the bottom right, there is a 'Next' button with a blue arrow and the text 'Next step' below it.

2. Enter the name of the task in the **Description** field.
3. Enter an additional description of the task in the **Comment** field, if necessary.
4. Select **Enabled** if the task is to be immediately enabled once it has been created.
5. Click on **Next**.  
→ The window to input the application settings appears.




6. Click on ... in the **Application** field to select the external application.
7. In the **Parameter** field, enter the Parameters which are to be transmitted to the external application.
8. Enable **The application cannot be started multiple times simultaneously**, if required, to prevent the external application from being started several times simultaneously.

**i** By enabling **The application cannot be started multiple times simultaneously**, the program waits until the external application has ended. The external application is then called up again.

Disable **The application cannot be started multiple times simultaneously** if applications expect a multiple start.

9. Click on **Next**.  
→ The window to select the WIN transmitter appears.




10. From the list of WIN transmitters, select the WIN transmitters whose status changes are to be transmitted.
11. In the **Change of tier state** area, select for which tiers the status changes are to be transmitted.
12. Enter a **time delay** for each tier if necessary.

**i** The status change is only transmitted if the new status is unchanged during the defined **time delay**. No status change is transmitted if the status has changed again within the **time delay**.

13. In the **Change of job state** area, select at which job progression or at which quantity the status change is to be transmitted.
14. Enable **Transmit new counter values immediately** if every changed counter status is to be transmitted.

**i** The **Change of job state** area is only available if a WIN transmitter control is selected.

15. Click on **OK**.  
→ The window in which to create an Autostart shortcut appears.




16. Enable **Start WINtoApplication at windows startup** if WINtoApplication is to be automatically started when the PC is started or after user login.
17. Click on **OK** to save the task.

#### 4.2.1.1 Placeholders/Parameters

The following placeholders/parameters are available:


Placeholders/Parameters	Description
%s l a v e i d%	ID of the WIN transmitter
%n a m e%	Name of the WIN transmitter
%t i m e%	Date and time of status transmission
%r e a s o n%	Reason for status transmission
%s t a t e 1%	Status of tier 1
%s t a t e 2%	Status of tier 2
%s t a t e 3%	Status of tier 3
%s t a t e 4%	Status of tier 4
%s t a t e n a m e 1%	Name of tier 1
%s t a t e n a m e 2%	Name of tier 2
%s t a t e n a m e 3%	Name of tier 3
%s t a t e n a m e 4%	Name of tier 4
%c o u n t e r %	Counter status of the job

Placeholders/Parameters	Description
%order-id%	Job ID
%order-number%	Job number
%order-description%	Name of job
%order-total%	Total amount of job
%order-progression%	Progression of job

 All placeholders/parameters begin and end with the character %

## 4.2.2 Editing a task

1. Select the required task in the task overview.
2. Click on **Edit**.  
→ The **WINtoApplication task configuration** window appears.



WINtoApplication task configuration

1/3 General settings

You can create new tasks or edit existing tasks with this assistant.

Please specify the settings for the application

Description: Counter


Enabled

Comment: [Empty text area]

Close Cancel

Next Next step

3. Enter the name of the task in the **Description** field.
4. Enter an additional description of the task in the **Comment** field, if necessary.
5. Select **Enabled** if the task is to be immediately enabled once it has been created.
6. Click on **Next**.  
→ The window to input the application settings appears.




7. Click on ... in the **Application** field to select the external application.
8. In the **Parameter** field, enter the parameters which are to be transmitted to the external application.
9. Enable **The application cannot be started multiple times simultaneously**, if required, to prevent the external application from being started several times simultaneously.



By enabling **The application cannot be started multiple times simultaneously**, the program waits until the external application has ended. The external application is then called up again.

Disable **The application cannot be started multiple times simultaneously** if applications expect a multiple start.

10. Click on **Next**.  
→ The window to select the WIN transmitter appears.




11. From the list of WIN transmitters, select the WIN transmitters whose status changes are to be transmitted.
12. In the **Change of tier state** area, select for which tiers the status changes are to be transmitted.
13. Enter a **time delay** for each tier if necessary.

**i** The status change is only transmitted if the new status is unchanged during the defined **time delay**. No status change is transmitted if the status has changed again within the **time delay**.

14. In the **Change of job state** area, select at which job progression or at which quantity the status change is to be transmitted.
15. Enable **Transmit new counter values immediately** if every changed counter status is to be transmitted.

**i** The **Change of job state** area is only available if a WIN transmitter control is selected.

16. Click on **OK**.  
→ The window in which to create an Autostart shortcut appears.



17. Enable **Start WINtoApplication at windows startup** if WINtoApplication is to be automatically started when the PC is started or after user login.
18. Click on **OK** to save the task.


#### 4.2.2.1 Placeholders/Parameters

The following placeholders/parameters are available:

Placeholders/Parameters	Description
%s l a v e i d%	ID of the WIN transmitter
%n a m e%	Name of the WIN transmitter
%t i m e%	Date and time of status transmission
%r e a s o n%	Reason for status transmission
%s t a t e 1%	Status of tier 1
%s t a t e 2%	Status of tier 2
%s t a t e 3%	Status of tier 3
%s t a t e 4%	Status of tier 4
%s t a t e n a m e 1%	Name of tier 1
%s t a t e n a m e 2%	Name of tier 2
%s t a t e n a m e 3%	Name of tier 3
%s t a t e n a m e 4%	Name of tier 4
%c o u n t e r %	Counter status of the job




Placeholders/Parameters	Description
%order-id%	Job ID
%order-number%	Job number
%order-description%	Name of job
%order-total%	Total amount of job
%order-progression%	Progression of job

 All placeholders/parameters begin and end with the character %


### 4.2.3 Duplicating a task

1. Select the required task in the task overview.
2. Click on **Duplicate**.  
→ The **WINtoApplication task configuration** window appears.



The screenshot shows a software configuration window titled "WINtoApplication task configuration". The window is divided into sections. At the top right, there is a graphic of three interlocking gears and three vertical progress bars, with lines pointing to file extensions: \*.exe, \*.bat, \*.cmd, and an ellipsis. Below this, the text "1/3 General settings" is displayed. A message reads: "You can create new tasks or edit existing tasks with this assistant." Below this, it says "Please specify the settings for the application". There are three input fields: "Description" with the text "Counter", "Enabled" with a checked checkbox, and "Comment" with a large empty text area. At the bottom left, there is a "Close" button with a red 'X' icon. At the bottom right, there is a "Next" button with a blue arrow icon and the text "Next step".

3. Enter the name of the task in the **Description** field.
4. Enter an additional description of the task in the **Comment** field, if necessary.
5. Select **Enabled** if the task is to be immediately enabled once it has been created.
6. Click on **Next**.  
→ The window to input the application settings appears.




7. Click on ... in the **Application** field to select the external application.
8. In the **Parameter** field, enter the parameters which are to be transmitted to the external application.
9. Enable **The application cannot be started multiple times simultaneously**, if required, to prevent the external application from being started several times simultaneously.



By enabling **The application cannot be started multiple times simultaneously**, the program waits until the external application has ended. The external application is then called up again.

Disable **The application cannot be started multiple times simultaneously** if applications expect a multiple start.

10. Click on **Next**.  
→ The window to select the WIN transmitter appears.




11. WIN transmitter From the list of WIN transmitters, select the WIN transmitters whose status changes are to be transmitted.
12. In the **Change of tier state** area, select for which tiers the status changes are to be transmitted.
13. Enter a **time delay** for each tier if necessary.

**i** The status change is only transmitted if the new status is unchanged during the defined **time delay**. No status change is transmitted if the status has changed again within the **time delay**.

14. In the **Change of job state** area select at which job progression or at which quantity the status change is to be transmitted.
15. Enable **Transmit new counter values immediately** if every changed counter status is to be transmitted.

**i** The **Change of job state** area is only available if a WIN transmitter control is selected.

16. Click on **Next**.  
→ The window in which to create an Autostart shortcut appears.



17. Enable **Start WINtoApplication at windows startup** if WINtoApplication is to be automatically started when the PC is started or after user login.
18. Click on **OK** to save the task.

#### 4.2.3.1 Placeholders/Parameters

The following placeholders/parameters are available:


Placeholders/Parameters	Description
%s l a v e i d%	ID of the WIN transmitter
%n a m e%	Name of the WIN transmitter
%t i m e%	Date and time of status transmission
%r e a s o n%	Reason for status transmission
%s t a t e 1%	Status of tier 1
%s t a t e 2%	Status of tier 2
%s t a t e 3%	Status of tier 3
%s t a t e 4%	Status of tier 4
%s t a t e n a m e 1%	Name of tier 1
%s t a t e n a m e 2%	Name of tier 2
%s t a t e n a m e 3%	Name of tier 3
%s t a t e n a m e 4%	Name of tier 4
%c o u n t e r %	Counter status of the job


Placeholders/Parameters	Description
%order-id%	Job ID
%order-number%	Job number
%order-description%	Name of job
%order-total%	Total amount of job
%order-progression%	Progression of job

 All placeholders/parameters begin and end with the character %

## 4.2.4 Enabling or disabling an individual task


1. Select the required task in the task overview and enable or disable the checkbox in the **enabled** column.




 The statuses will continue to be monitored if a task is disabled. Status transmission to the external application is stopped.

## 4.2.5 Enabling or disabling all tasks

1. Right-click on the WINToApplication symbol in the information section.



2. Select **Enable** or **Disable** in the menu.

 The statuses will continue to be monitored if the tasks have been disabled but status transmission to the external application is terminated.

## 4.2.6 Deleting a task


1. Select the required task in the task overview.

2. Click on **Delete**.
3. Confirm the prompt with **Yes**.

## 4.2.7 Exporting tasks

An export can be created to use the created tasks on another PC or for another user.


1. Click on **Export** in the **Tools** menu.  
→ The **Export task configuration** window appears.



2. Click on ... in the **Export To** field.
3. Select the filename and storage location for the export file.
4. Click on **Save**.
5. Click on **OK**.

## 4.2.8 Importing tasks

1. Click on **Import** in the **Tools** menu.  
→ The **Import task configuration** window appears.



2. Enable **Delete all existing tasks before the import is activated** if all existing jobs are to be deleted before the import.
3. Click on ... in the **Import of** field and select the import file.
4. Confirm the prompt with **Yes**.

## 4.2.9 History

A history log is automatically created to understand previous processes better and identify errors. This indicates which parameters have been transmitted to which external application.


To display the history log of a task:

1. Hover your cursor over the **Status** column to select the required task in the task overview.

## 4.2.10 Settings

The processing of all jobs can be started and a startup shortcut created for the WINtoApplication in Settings.


1. Click on **Settings** in the **Tools** menu.  
→ The **Settings** window appears.



2. Enable **Task processing enabled** to start the processing of all jobs.
3. Enable **Start WINtoApplication at windows startup** if WINtoApplication is to be automatically started when the PC is started or after user login.
4. Click on **OK** to save the task.


## 4.2.11 Exiting WINtoApplication

To move WINtoApplication into the system tray:

1. Click on **Close overview** in the **File** menu or close the WINtoApplication task overview by clicking on .

To fully exit the WINtoApplication and the execution of all task:

1. Right-click on the WINtoApplication symbol in the system tray.




2. Select **Exit** in the pop-up menu.
3. Confirm the prompt with **Yes**.

### 4.3 WERMA-WIN CLI Tool

The WERMA-WIN CLI Tool (command-line interface tool) makes it possible to automate WIN transmitter control with different commands using an external application.

To call up the WERMA-WIN CLI tool:

1. Open the command line.






2. Enter the path for WERMA-WIN in the command line (e.g. `cd C:\Program Files (x86)\WERMA-WIN-4`).

The following functions are available:

Function	Description	Command line entry/example
<code>/help</code>	Shows all possible functions.	<code>WIN-CLI.exe /help</code>
<code>/server</code>	Adapts the WERMA-WIN server's port and server. The default setting is the server setting of WERMA-WIN.	<code>/server &lt;server&gt;[:&lt;port&gt;]</code> Example: <code>WIN-CLI.exe /server Winserver01:10710</code>





Function	Description	Command line entry/example															
<b>/switchcontrol</b>	Operates the WIN transmitter control.	<code>/switchcontrol &lt;slave&gt; &lt;tier&gt; &lt;state&gt;</code>															
		<table border="1"> <thead> <tr> <th>&lt;slave&gt;</th> <th>&lt;tier&gt;</th> <th>&lt;state&gt;</th> </tr> </thead> <tbody> <tr> <td>"id:&lt;slave-id&gt;"</td> <td>1: Tier1</td> <td>0: Off</td> </tr> <tr> <td>"macid:&lt;slave-macid&gt;"</td> <td>2: Tier2</td> <td>1: On</td> </tr> <tr> <td>"name:&lt;slave-name&gt;"</td> <td>3: Tier3</td> <td>2: Blinking</td> </tr> <tr> <td></td> <td>4: Tier4</td> <td></td> </tr> </tbody> </table>	<slave>	<tier>	<state>	"id:<slave-id>"	1: Tier1	0: Off	"macid:<slave-macid>"	2: Tier2	1: On	"name:<slave-name>"	3: Tier3	2: Blinking		4: Tier4	
		<slave>	<tier>	<state>													
		"id:<slave-id>"	1: Tier1	0: Off													
"macid:<slave-macid>"	2: Tier2	1: On															
"name:<slave-name>"	3: Tier3	2: Blinking															
	4: Tier4																
Example:  On <code>WIN-CLI.exe /switchcontrol "id:7" 2 1</code>																	
 Blinking <code>WIN-CLI.exe /switchcontrol "name:machine1" 2 2</code>																	
 Off <code>WIN-CLI.exe /switchcontrol "macid:03162D" 2 0</code>																	
<b>/export-slaves</b>	Create a CSV file with all WIN transmitter from the WERMA-WIN database in the selected location <file>.	<code>/export-slaves &lt;file&gt;</code> Example: <code>WIN-CLI.exe /export-slaves "C:\test.csv"</code>															

Exit Code	Description
0 .	command successfully executed
1 .	no command is executed, help message displayed
-1 .	an exception occurred, see command line output

# 5 Fault diagnostics


Possible errors and the current status of the WERMA-WIN devices are displayed by the respective LEDs.

## 5.1 WIN transmitter, WIN transmitter performance, WIN transmitter control


LED	Description
Green 	Radio connection established to the WIN receiver.
Red 	No radio connection possible to the WIN receiver.


## 5.2 WIN transmitter control

The blue status LEDs shows the status of the outputs.





Item	Description
1	Tier 4 output
2	Tier 3 output
3	Tier 2 output
4	Tier 1 output

LED	Description
 On	Output was switched manually or by a switching rule.
Off	Output was not switched.



 The blue LEDs only light up if **Activate additional pins 2 to 5** was selected during configuration of the switching behaviour of the WIN transmitter control.

### 5.3 WIN receiver

LED	Description
Green 	Radio connection established to the WIN transmitter.
Red 	No radio connection possible to the WIN transmitter.

### 5.4 WIN ethernet receiver

LED Ethernet connection	Description
Green	

LED Ethernet connection	Description	
	On	Connection established to the network.
	Off	No connection possible to the network.
	Blinking	Network activity
Yellow		
	On	Connection established to WERMA-WIN.
	Off	No connection established to WERMA-WIN.

## 6 Software update

As soon as a software update is available, it can be downloaded and installed from the WERMA homepage.

1. Click on **Software update** in the toolbar.  
→ The Download area on the WERMA homepage appears.
2. Download the update file and install on the PC.



If several workplaces are accessing a common WERMA-WIN database, you first need to install the software update on the PC with the WERMA-WIN database (server PC). An appropriate message appears if the installation is first started on a client PC.

The software update must be run on all PCs connected to the common WERMA-WIN database.


---

# 7 System requirements

The system requirements differ for the server PC and client PCs.

	Server PC	Client PC
Installed software components	Microsoft SQL server WERMA-WIN WERMA-WIN database Device driver for hardware	WERMA-WIN Network connection to Microsoft SQL server with the WERMA-WIN database Device driver for hardware
Processor	Pentium III compatible processor or higher Dual Core processor is recommended	
Minimum RAM	2 GB	1 GB
Free hard disk space (recommended)	8 GB	8 GB
USB port	Required for the hardware configuration. The configuration can also be used on the Client PC.	
Screen resolution	At least: 1280 x 1024 Recommended: 1920 x 1080 or higher Scaling of font size (DPI) 100% (96 DPI)	
Microsoft .NET Framework 4.5.2	Automatically installed when installing WERMA-WIN.	
Supported operating systems	Windows 7 SP1 Windows 8 Windows 8.1 Windows Server 2008 R2 SP1 Windows Server 2012 Windows Server 2012 R2 Windows 10 Windows Server 2016	
Supported SQL server	Microsoft SQL Server 2008 SP4 Microsoft SQL Server 2008 R2 SP3 Microsoft SQL Server 2012 SP4 Microsoft SQL Server 2014 SP2 (recommended) Microsoft SQL Server 2016 SP2 Microsoft SQL Server 2017	

---

 Unless otherwise specified, the 32 Bit (x86) and 64 Bit (x64) versions are supported.

---

- 
- ① Supported operating systems and SQL Server versions are only supported as long as Microsoft also supports them through the Microsoft Support **Lifecycle**.

The automatic installation of the database onto a domain controller is not supported. Manual installation is possible.

Installation of the Windows server core and nano server is not supported.

The Windows server role **Remote desktop services** is not supported on the server PC.

Only Microsoft SQL server editions Express, Workgroup, Standard, Enterprise and Data-center for Windows, as well as the supplied Microsoft SQL Server 2014 Express database, are supported.

In each case, only the latest Microsoft Windows and Microsoft SQL server service packs are supported.

---

## 7.1 Network stability and security

---

- ① WERMA recommends that you only operate WERMA-WIN in a reliable LAN environment (TCP/IP network). The function or performance of WERMA-WIN could be impaired in an unstable or insecure network.
-

## 8 Keyboard shortcuts

Keyboard shortcuts let you work more quickly with WERMA-WIN. You can select from general keyboard shortcuts and combinations that apply to the specific module.

### 8.1 Windows standard

Keyboard shortcut	Description
F1	Display Help.
F5	Refresh active window.
F10	Enable menu bar.
F11	Maximise active window.
CTRL + F1	Minimise menu bar.
CTRL + F4	Close active document.
CTRL + A	Select all items.
CTRL + C	Copy selected item.
CTRL + D	Delete selected item.
CTRL + N	Open new window.
CTRL + O	Open document / file.
CTRL + P	Print document.
CTRL + V	Paste selected item.
CTRL + W	Close current window.
CTRL + X	Cut selected item.
CTRL + Z	Undo action.
ALT + F4	Close active item or end active app.
ALT + P	Display preview window.
DELETE	Delete selected item.

### 8.2 General

Keyboard shortcut	Description
F1	Call up manual.
F2	Call up contact page.
F3	Call up Information window.
CTRL + F4	Close active document.
CTRL + F6	Call up <b>Control station</b> main view.
CTRL + F7	Call up <b>Productivity</b> main view.
CTRL + F8	Call up <b>Runtime</b> main view.
CTRL + F9	Call up <b>Job</b> main view.



Keyboard shortcut	Description
CTRL + F10	Call up <b>Control</b> main view.
CTRL + F11	Call up <b>Routing</b> main view.
CTRL + F12	Call up <b>Runtime</b> module with WIN transmitter selection.
ALT + F1	Call up <b>Job quick start</b> window.

## 8.3 Control station

Keyboard shortcut	Description
F1	Call up manual.
F2	Call up contact page.
F3	Call up Information window.
F8	Add WIN transmitter.
F9	Select background.
F11	Start full screen mode.
F12	Generate report.
CTRL + F4	Close active document.
ALT + F1	Call up <b>Job quick start</b> window.
ALT + F6	Call up <b>Activation</b> window.
ALT + F7	Call up <b>Settings</b> window.
ALT + F8	Search for software update.
ESC	Exit full screen mode.

## 8.4 Productivity

Keyboard shortcut	Description
F1	Call up manual.
F2	Call up contact page.
F3	Call up Information window.
F7	Show combined productivity.
F8	Add WIN transmitter.
F9	Select background.
F11	Start full screen mode.
F12	Generate report.
CTRL + F4	Close active document.
ALT + F1	Call up <b>Job quick start</b> window.
ALT + F6	Call up <b>Activation</b> window.
ALT + F7	Call up <b>Settings</b> window.
ALT + F8	Search for software update.
ESC	Exit full screen mode.

## 8.5 Runtime

Keyboard shortcut	Description
F1	Call up manual.
F2	Call up contact page.
F3	Call up Information window.
F7	Call up the <b>Status</b> view.
F8	Call up the <b>Quantity</b> view.
F9	Call up the <b>Combined</b> view.
F11	Start full screen mode.
F12	Generate report.
CTRL + F4	Close active document.
ALT + F1	Call up <b>Job quick start</b> window.
ALT + F6	Call up <b>Activation</b> window.
ALT + F7	Call up <b>Settings</b> window.
ALT + F8	Search for software update.
ESC	Exit full screen mode.

## 8.6 Job

Keyboard shortcut	Description
F1	Call up manual.
F2	Call up contact page.
F3	Call up Information window.
F9	Show Auto jobs.
F12	Generate report.
CTRL + E	Edit job.
CTRL + I	Import job list.
CTRL + N	Enter job.
CTRL + Q	End job.
CTRL + R	Start job.
CTRL + F4	Close active document.
ALT + F1	Call up <b>Job quick start</b> window.
ALT + F2	Start with 1st piece
ALT + F3	Start with job input
ALT + F6	Call up <b>Activation</b> window.
ALT + F7	Call up <b>Settings</b> window.
ALT + F8	Search for software update.
ESC	Exit full screen mode.
DELETE	Delete job.

## 8.7 Control

Keyboard shortcut	Description
F1	Call up manual.
F2	Call up contact page.
F3	Call up Information window.
CTRL + F4	Close active document.
CTRL + D	Duplicate rule.
CTRL + E	Edit rule.
CTRL + N	Create new rule (assistant).
CTRL + Q	Disable rule.
CTRL + R	Enable rule.
ALT + F1	Call up <b>Job quick start</b> window.
ALT + F6	Call up <b>Activation</b> window.
ALT + F7	Call up <b>Settings</b> window.
ALT + F8	Search for software update.
DELETE	Delete rule.
CTRL + Shift + NCTRL + N	Create new rule (Expert).

## 8.8 Routing

Keyboard shortcut	Description
F1	Call up manual.
F2	Call up contact page.
F3	Call up Information window.
F12	Call up the <b>Connection status</b> window.
CTRL + F4	Close active document.
ALT + F1	Call up <b>Job quick start</b> window.
ALT + F6	Call up <b>Activation</b> window.
ALT + F7	Call up <b>Settings</b> window.
ALT + F8	Search for software update.

## 9 FAQ – Frequently Asked Questions

### On which frequency band does the WIN system run?

WIN runs on the frequency band 912.997284 – 916.996307 MHz. This short-range radio system has no effect on existing Wi-Fi or Bluetooth networks.

### Can WIN be run on different radio channels?

Yes, you can choose from four radio channels. You should only run one WIN receiver per channel.

The channels have the following frequencies:

Channel	Frequency
1	912.997284 MHz
2	913.997040 MHz
3	916.996307 MHz
4	915.996552 MHz

### Why are different radio channels needed? When should the radio channel be changed?

If more than one WIN receiver is run on a channel, it can cause transmission problems between the systems. This can be seen by the frequency connection errors. In this case, the WIN receiver should be run on different radio channels.

### How can I increase the range?

Every WIN receiver possesses a repeater function, which can be used to increase the range between the WIN receiver and the WIN transmitter. Every WIN transmitter can thereby establish a connection to the WIN receiver using a maximum of 2 WIN transmitter (repeaters).

### Is the radio transmission encrypted?

The WIN system is equipped with several protection mechanisms, which prevent the radio transmission being intercepted. However, unrestricted security against interception cannot be guaranteed. In addition, no confidential data from the WIN system is transmitted wirelessly.

### How often does the WIN transmitter transmit the signal status to the WIN receiver?

If the status of the signal tower changes, the WIN transmitter sends this new signal status to the WIN receiver within a response time of up to 5 seconds. If the signal status does not change, the WIN transmitter transmits the signal status every 15 seconds to the WIN receiver.

### Why can the WIN transmitter not establish a connection to the WIN receiver?

Check the following points:

- The WIN receiver (USB) must be connected to the PC by USB. The red or green LED must light up.
- The WIN transmitter must be connected to a power supply. The red or green LED must light up.
- The WIN transmitter must be configured.

- The radio connection must not be disrupted.
- If the WIN receiver has been configured on another radio channel, the assigned WIN receivers have to be reconfigured on the WIN receiver.

#### **There are frequent connection errors to the WIN transmitters. What can be done?**

- Data will only be logged while WERMA-WIN is running. WERMA-WIN must be running in the monitoring period.
- The connection quality can be checked in the **Routing module**. The use of additional WIN transmitters as repeaters is recommended if connection lines appear red. A WIN transmitter must be positioned at the critical point for this purpose.
- There needs to be a permanent 24 V power supply connected to Pin 5 on every WIN transmitter.

#### **Why does the PC not recognise the WIN receiver?**

- WERMA-WIN must be installed and started on the PC.
- Disconnect the USB connection from the WIN receiver and reconnect it.
- Manually install the driver.
- The Windows Service **WERMA WIN 4 Connector Service** must have started.

#### **Why can WERMA-WIN not be installed?**

Administrator rights are needed to install WERMA-WIN.

#### **How many WIN transmitters can be monitored by one WIN receiver?**

Up to 50 WIN transmitters can be monitored.

#### **What happens if more than 50 WIN transmitters are connected?**

If more than 50 WIN transmitters are connected, this can lead to radio problems between the WIN transmitters.

#### **How many signal elements can be monitored per WIN transmitter?**

Up to 4 elements can be monitored per WIN transmitter. Up to 8 statuses can be monitored using blink recognition.

#### **How many signal elements can be monitored per WIN transmitter performance?**

Up to 3 elements can be monitored per WIN transmitter performance. Up to 6 statuses can be monitored using blink recognition.

A tier is essential for the counter input.

You can monitor up to 2 elements or a maximum of 4 statuses if a tier is also fitted with the job input.

#### **How many strokes per minute (e.g with punching) can WERMA-WIN count or record?**

WERMA-WIN can count up to a maximum of 600 strokes per minute. The timer of the machine or control must be increased (> 100 ms) to detect the correct quantity of the machine.

#### **Why does the WIN receiver light up red?**

The WIN receiver is ready for operation but is not connected to a WIN transmitter.

**Why is the red status LED on the WIN transmitter lit?**

The WIN transmitter is ready for operation but is not connected to a WIN receiver.

**What is the maximum permissible USB cable length between the WIN receiver and PC?**

The cable length should not exceed 3 metres. The maximum cable length can be increased using a USB hub.

**Can the collected data be further processed?**

Yes, all data is stored in a Microsoft SQL server database. The data can be read (Microsoft Excel, Microsoft Access ...). Avoid changing the database to avoid loss of data.

**What steps need to be taken with time changes?**

A time change can lead to a data loss. If the system time is synchronised several times (e.g. automatically with a server), then we would recommend doing so outside the monitoring period.

**Can a WIN transmitter performance be configured to have the same configuration as a WIN transmitter?**

No, a WIN transmitter performance always needs one tier allocated to the counter input.

**What must be considered when installing WERMA-WIN?**

The system requirements need to be observed. Administrator rights are needed to install WERMA-WIN.

**How fast can a WIN transmitter performance count on the tier with counter input?**

The counter impulse can be up to 10 Hz.

**Can blink recognition be set up for all tiers of the WIN transmitter performance?**

No, blink recognition cannot be selected for the tier with counter input or for the tier with job input.

**Is it possible to read data from an ERP system into WERMA-WIN?**

Yes, you need to create a CSV file with the correct format for this. This can then be imported into WERMA-WIN.

**Are there any keyboard shortcut functions in the software?**

Yes, WERMA-WIN can be quickly operated using the keyboard with a number of different keyboard shortcuts.

**What must be observed when saving data to the WERMA-WIN database?**

The PC to which the WIN receiver is connected by a USB cable must be continuously in operation.

The PC on which the WERMA-WIN database is installed must be in operation around the clock

The **WERMA WIN 4 Server Service** and the **WERMA WIN 4 Connector Service** must have been started.

#### **Why is the WERMA WIN 4 Server Service needed?**

The service runs in the background when the PC (client and server) is running. The collected WERMA-WIN data from the WIN receiver is transmitted to the **WERMA WIN 4 Server Service** without WERMA-WIN being started and a user being logged in.

#### **What is the WERMA WIN 4 Server Service needed for?**

The service runs in the background when the PC (client and server) is running. The collected WERMA-WIN data from the WIN receiver is transmitted to the **WERMA WIN 4 Server Service** without WERMA-WIN being started and a user being logged in.

#### **Can energy-saving mode or hibernation mode be enabled on a PC with WERMA-WIN?**

We recommend disabling energy-saving mode and hibernation state for the following uses:

- PC with the WERMA-WIN database
- PC with the **WERMA WIN 4 Server Service**
- PC with a connected WIN receiver (USB)

#### **Can the WIN ethernet receiver be operated over the internet?**

From a technical perspective, the WIN ethernet receiver can be operated over the internet.

In spite of basic security measures, we would nevertheless strongly recommend in this case providing additional security for the connection to the WIN ethernet receiver, for example via an encrypted VPN connection.