

Accessories

5. Terminal Cover, AP

It is an attachment for prevention of electrical shock and foreign substances entering the terminal part

It is an option for those who ordered terminal cover for magnetic contactors or thermal overload relays. (Protection class : IP20)

1. Basic Features

Functions of terminal cover are as below.

- Prevention for front side of arc
- Protection from pollutants like dust
- Prevention from malfunction and safety failures due to any mistake

2. Model Name and Description

| Dividing | Type | Applied MC | Quantity | Remark |
|--------------------|---------|---------------------|----------|--------|
| Magnetic Contactor | AP-9 | Metasol | 1 | |
| | AP-220 | MC-185a, 225a | 2 | |
| | AP-400 | MC-265a, 330a, 400a | 2 | |
| | AP-800 | MC-500a, 630a, 800a | 2 | |
| Thermal Relay | APT-225 | MT-225 | 1 | |
| | APT-400 | MT-400 | 1 | |
| | APT-800 | MT-800 | 1 | |

3. Installation Method

- AP-9 is installed at front side of Metasol series MC.
- AP-220~800 are installed at terminal side of power and load side of large capacity Metasol series MC.
- APT-225~800 are installed load terminal side of large capacity thermal overload relays.

