

Pole Bracket TYPE SZP-004 Instruction Manual

Notice to Customer

Thank for your purchasing our PATLITE products.

- This product is a pole bracket for attaching a USB Signal Tower (LR6-3USB□-RYG / body unit LR6-USB□) to a pole.
- This pole bracket is an exclusive product for the USB Signal Tower (LR6-3USB□-RYG / body unit LR6-USB□).
- Read this manual thoroughly before using this product to ensure correct use.
- Request the installation and wiring be performed by a professional contractor if construction work is involved.
- Re-read this manual before conducting maintenance, inspections, repairs, and so on. If you have any questions about this product, please contact your PATLITE sales representative listed on the back of this manual.
- For details on using the USB Signal Tower/body unit, download the instruction manual [WEB version] for the USB Signal Tower/body unit from our website.

Home Page Address	http://www.patlite.com
-------------------	---

To the Contractor

- Prior to installation, read this manual thoroughly to ensure correct use.
- Return this manual to the customer.

1. Before you begin

1.1 About Safety Symbols

To prevent injuries to the user and other personnel, as well as to prevent damage to assets, note the following:

- ◆ The following symbols classify warnings and cautions, and describe the level of harm and damage that will occur when the corresponding instructions are ignored.

	WARNING	This symbol indicates, "Failure to follow the instructions may lead to death or serious injury."
	CAUTION	This symbol indicates, "Failure to follow the instructions may lead to injury or property damage."

- ◆ The following symbols classify and describe the content of associated messages.

	This symbol identifies "Mandatory" instructions that should always be carried out.
--	--

1.2 Safety Precautions

- Carefully read the following contents as well as Safety Precautions stated on each model's Instruction Manuals included in the package and on our website.

WARNING

	◆ Request the installation and wiring be performed by a professional contractor if construction work is involved.
--	---

CAUTION

	◆ A good mounting location should include the following requirements: <ul style="list-style-type: none"> • Low vibration. • Sufficient strength. • Flat location. 	◆ Install so that the signal tower is always upright.	◆ Do not use this product in a watery environment.
--	--	---	--

2. Models

- SZP-004W : φ 60, Color : Off-white
- SZP-004K : φ 60, Color : Black

3. Supported Pole Models

Name	Model
Aluminum Pole (Silver)	POLE-100A21, POLE-300A21, POLE-800A21
Aluminum Pole (Black)	POLE-100A21K, POLE-300A21K, POLE-800A21K

4. Contents

Product: 1 unit	This manual : 1	Tapping screws (M3x14) : 2	Pole ring : 1
<ul style="list-style-type: none"> • Pole Bracket 			

5. Wiring and Product Installation

① Insert the pole ring to the pole bracket.

⑥ Connect the USB cable to the body unit.

⑦ Bundle and secure the USB cable with the cable ties, included.

⑧ Use nippers to cut any excess from the cable tie.

② Pass the USB cable from the bottom of the pole.

③ Next, pass the USB cable from the bottom of the pole bracket.

④ Insert the pole into the pole bracket, lining up the indentations.

⑤ In two positions, with the screws included with the pole bracket, secure the pole bracket to the pole. (Recommended torque:1.4N·m)

⑨ Affix the pole bracket and the body unit in 3 positions (with nuts available as a body unit accessory). (Recommended torque:0.6N·m)

PATLITE Corporation

G2G

PATLITE Corporation ※Head office ■ <http://www.patlite.com/>
 4-1-3, Kyutaromachi, Chuo-ku, Osaka 541-0056 Japan

PATLITE (U.S.A.) Corporation ■ <http://www.patlite.com/>
PATLITE Europe GmbH ※Germany ■ <http://www.patlite.eu/>
PATLITE (SINGAPORE) PTE LTD ■ <http://www.patlite.com/>
PATLITE (CHINA) Corporation ■ <http://www.patlite.cn/>
PATLITE KOREA CO., LTD. ■ <http://www.patlite.co.kr/>
PATLITE TAIWAN CO., LTD. ■ <http://www.patlite.tw/>
PATLITE (THAILAND) CO., LTD. ■ <http://www.patlite.co.th/>